# Panasonic®

# Servo System MINAS A7B Series **Operating Instructions (Tuning)**

# **EtherCAT Rotary Motor**

- Thank you for purchasing a Panasonic product.
- Please use it correctly and safely after reading this document and Operating Instructions (Overall) carefully.
- Read <u>"1.1.1 Safety Precautions"</u> before use.
- Keep these Operating Instructions safe.
- This product is for industrial use. It cannot be used for any other purpose (e.g., household use).

# **Table of Contents**

1	Before Use	8
	1.1 Precautions	9
	1.1.1 Safety Precautions	9
	1.1.2 Precautions for Proper Use	12
	1.1.3 Network Security	13
	1.2 Related Documents	14
	1.3 Software Version	15
	1.3.1 Notes Regarding Software	15
	1.3.2 Applicable Software Version	15
	1.3.3 Software Version Confirmation Method	15
	1.3.4 Functions Not Currently Supported	15 16
	1.3.6 Functional Differences from Previous Series	16
	14 Tradomarka	17
		17
	1.5 EtherCAT Communication Overview	17
2	Overview of Tuning Functions	18
	2.1 Types of Tuning and Control Functions	19
	2.1.1 Auto Tuning (TUNE COMPASS) and Manual Tuning	19
	2.1.2 Control Functions to Improve Tracking With Respect to Control Commands	21
	2.1.3 Control Functions for Suppressing Abnormal Noise and Vibration	23
	2.1.4 List of Control Functions (By Driver Type)	25
		20
	2.2 Safety Function Setup Before Tuning	27
	2.3 Adjustment Workflow	28
	2.3.1 Adjustments at Device Startup	28
		29
3	Details of Tuning Functions	30
	3.1 Auto Tuning (TUNE COMPASS)	31
	3.1.1 TUNINGLESS	31
	3.1.1.1 Function Overview	31
	3.1.1.3 Parameters That Are Automatically Set and Automatically Tuned	31
	3.1.1.4 Usage	31
	3.1.2 One Minute TUNING	32
	3.1.2.1 Function Overview	32
	3.1.2.3 Parameters That Are Automatically Set and Automatically Tuned	32
	3.1.2.4 Usage	32
	3.1.2.5 Use Cases in Re-adjustment	50
	3.1.3 precAlse TUNING	52
	3.1.3.2 Operational Conditions	52
	3.1.3.3 Parameters That Are Automatically Set and Automatically Tuned	52
	3.1.3.4 Usage	53
	3.2 Manual Tuning	65
	3.2.1 Manual TUNING	65
	3.2.1.1 Function Overview	00 65
	3.2.1.3 Tuning Method	65
	3.2.1.4 Manual TUNING Using Set-up Support Software (PANATERM ver.7)	69

	3.2.2 Load	I Fluctuation Suppression Tuning (Stabilizing Load Fluctuation Applications)	.92
	3.2.2.1	Function Overview	.92
	3.2.2.2	Operational Conditions	.92
	3.2.2.3	Tuning Procedure	.92
4	Control Function	ons to Improve Tracking With Respect to Control Commands	. 93
	11 Real-time	Auto Tuning Function	95
		time Auto Tuning (Two degree of freedom Control Mode for Standard Type)	05
	4.1.1 100	-une Auto Turning (Two-degree-of-freedom Control Mode for Standard Type).	.95
	4.1.1.1	Operation Mode	.95
	4.1.1.2	Operational Conditiona	.90
	4.1.1.3	Polatod Parametere	.90
	4.1.1.4	How to Use	.90 105
	4.1.1.3	Pagia Cain Deremotor Setup Table	105
	4.1.1.0	time Auto Turing (Ture de mas of franciero Control Mode for Currenciantica)	. 107
	4.1.2 Real	-ume Auto Tuning (Two-degree-oi-freedom Control Mode for Synchronization	100
	Type	J	109
	4.1.2.1	Function Overview	. 109
	4.1.2.2	Operation Mode	109
	4.1.2.3	Operational Conditions	. 109
	4.1.2.4		. 110
	4.1.2.3	How to Use	110
	4.1.2.6	Basic Gain Parameter Setup Table	.118
	4.1.3 Real	-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)	.120
	4.1.3.1	Function Overview	.120
	4.1.3.2	Operation Mode	.120
	4.1.3.3	Operational Conditions	.120
	4.1.3.4	Related Parameters	.121
	4.1.3.5	How to Use	.129
	4.1.3.6	Basic Gain Parameter Setup Table	.131
	4.2 Gain Swi	tching Function	.133
	4 2 1 Func	tion Overview	133
	4.2.1 Tune	rational Conditions	122
	4.2.2 Oper		400
	4.2.3 Rela	ted Parameters	.133
	4.2.4 How		.138
	4.2.4.1	For Manual Setting	.138
	4.2.4.2	When Set-up Support Software (PANATERM ver.7) is Used	.142
	4.3 3rd Gain	Switching Function	. 145
	4.3.1 Fund	tion Overview	145
	132 Oper	rational Conditions	1/5
	4.3.2 Oper	ted Deremetere	145
	4.3.3 Rela		. 140
	4.3.4 How		.146
	4.3.4.1	For Manual Setting	.146
	4.3.4.2	When Set-up Support Software (PANATERM ver.7) is Used	.147
	4.4 Feedforw	ard Function	. 148
	441 Fund	tion Overview	148
	112 Oner	rational Conditions	1/18
		tad Deremetere	110
	4.4.3 Rela		. 140
	4.4.4 HOW		.149
	4.4.4.1	For Manual Setting	.149
	4.4.4.2	when Set-up Support Software (PANATERM ver.7) is Used	.150
	4.5 Friction T	orgue Compensation Function	. 154
	451 Euno	tion Overview	154
	152 Oper	rational Conditions	15/
		tod Daramators	151
	4.3.3 Rela	เธน r ลเลเปียเรียง	. 104
	4.5.4 HOW		.155
	4.5.4.1	vvnen Set-up Support Software (PANATERM ver./) is Used	.156
	4.6 Load Flue	ctuation Control Function (Disturbance Suppression Applications)	. 160
	4.6.1 Fund	tion Overview	.160
	462 Oner	rational Conditions	160
		tod Daramators	160
	4.0.3 Kela	itu raiaiiititis	. 100

4.6.4.1 For Manual Setting 4.6.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	161 161 162
<ul> <li>4.7 Load Fluctuation Control Function (Load Fluctuation Stabilization Applicati 4.7.1 Function Overview</li></ul>	ions)167 167 167
<ul> <li>4.7.3 Related Parameters</li></ul>	
4.8 High Response Current Control Function	
4.8.2 Operational Conditions	
4.8.3 Related Parameters	
4.8.4 How to Use 4.8.4.1 For Manual Setting	1/5
4.8.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	
4.9 Quadrant Glitch Suppression Function	
4.9.1 Function Overview	
4.9.2 Operational Conditions	178
4.9.3 Related Parameters	178
4.9.4 How to Use	
4.9.4.1 For Maridal Setting	
4.10. Backlash Compensation Function	183
4.10.1 Function Overview	
4.10.2 Operational Conditions	
4.10.3 Related Parameters	183
4.10.4 How to Use	185
5 Details of Control Function to Suppress Abnormal Noise and Vibration	
5.1. Torque Eilter Eulerien	
5.1.1 Function Overview	
5.1.1 Function Overview	
5.1.1 Function Overview	
5.1.1 Function Overview 5.1.2 Operational Conditions 5.1.3 Related Parameters 5.1.4 How to Use 5.1.4.1 For Manual Setting	
<ul> <li>5.11 Function Overview</li></ul>	
<ul> <li>5.1 Forque Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> </ul>	
<ul> <li>5.1 Forque Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> </ul>	
<ul> <li>5.1 Forque Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> </ul>	
<ul> <li>5.1 Forque Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> </ul>	
<ul> <li>5.1 Forque Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4 How to Use</li> <li>5.2.4 For Manual Setting</li> </ul>	
<ul> <li>5.1 Forque Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4 How to Use</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> </ul>	
<ul> <li>5.1 Forque Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4 How to Use</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> </ul>	
<ul> <li>5.1 Forque Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4 How to Use</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.3 Notch Filter Function</li> <li>5.3 Notch Filter Function</li> </ul>	
<ul> <li>5.1 Torque Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4 How to Use</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.3 Notch Filter Function</li> <li>5.3.1 Function Overview</li> <li>5.3.2 Operational Conditions</li> </ul>	
<ul> <li>5.1 Forque Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4 How to Use</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.3 Notch Filter Function</li> <li>5.3 Notch Filter Function</li> <li>5.3.1 Function Overview</li> <li>5.3.2 Operational Conditions</li> <li>5.3.3 Related Parameters</li> <li>5.3.3 Related Parameters</li> </ul>	
<ul> <li>5.11 Function Overview</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4 How to Use</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.3 Notch Filter Function</li> <li>5.3.1 Function Overview</li> <li>5.3.2 Operational Conditions</li> <li>5.3.3 Related Parameters</li> <li>5.3.4 How to Use</li> <li>5.3.4 How to Use</li> </ul>	
<ul> <li>5.11 Forque Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4 How to Use</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.3 Notch Filter Function</li> <li>5.3.1 Function Overview</li> <li>5.3.2 Operational Conditions</li> <li>5.3.3 Related Parameters</li> <li>5.3.4 How to Use</li> <li>5.3.4 When Set-up Support Software (PANATERM ver.7) Is Used</li> </ul>	
<ul> <li>5.1 Forque Pulter Pultition</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4 How to Use</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.3 Notch Filter Function</li> <li>5.3.1 Function Overview</li> <li>5.3.2 Operational Conditions</li> <li>5.3.3 Related Parameters</li> <li>5.3.4 How to Use</li> <li>5.3.4 How to Use</li> <li>5.3.4.1 For Manual Setting</li> <li>5.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> </ul>	
<ul> <li>5.1 Forque Friter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.3 Notch Filter Function</li> <li>5.3.1 Function Overview</li> <li>5.3.2 Operational Conditions</li> <li>5.3.3 Related Parameters</li> <li>5.3.4 How to Use</li> <li>5.3.3 Related Parameters</li> <li>5.3.4 How to Use</li> <li>5.3.4.1 For Manual Setting</li> <li>5.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> </ul>	
<ul> <li>5.1 forde Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4 How to Use</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.3 Notch Filter Function</li> <li>5.3.1 Function Overview</li> <li>5.3.2 Operational Conditions</li> <li>5.3.3 Related Parameters</li> <li>5.3.4 How to Use</li> <li>5.3.4.1 For Manual Setting</li> <li>5.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.4 Adaptive Filter Function</li> <li>5.4.1 Function Overview</li> <li>5.4.1 For Manual Setting</li> <li>5.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> </ul>	
<ul> <li>5.1 forde Pinel Punction</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4 How to Use</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.3 Notch Filter Function</li> <li>5.3.1 Function Overview</li> <li>5.3.2 Operational Conditions</li> <li>5.3.3 Related Parameters</li> <li>5.3.4 How to Use</li> <li>5.3.4.1 For Manual Setting</li> <li>5.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.4.1 For Manual Setting</li> <li>5.3.4.1 For Manual Setting</li> <li>5.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.4.2 Operational Conditions</li> <li>5.4.3 Related Parameters</li> <li>5.4.3 Related Parameters</li> <li>5.4.4 Represent Software (PANATERM ver.7) Is Used</li> </ul>	
<ul> <li>5.1 Forque Filter Function</li> <li>5.1.1 Function Overview</li> <li>5.1.2 Operational Conditions</li> <li>5.1.3 Related Parameters</li> <li>5.1.4 How to Use</li> <li>5.1.4.1 For Manual Setting</li> <li>5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.2 2-stage Torque Filter Function</li> <li>5.2.1 Function Overview</li> <li>5.2.2 Operational Conditions</li> <li>5.2.3 Related Parameters</li> <li>5.2.4 How to Use</li> <li>5.2.4.1 For Manual Setting</li> <li>5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.3 Notch Filter Function</li> <li>5.3.1 Function Overview</li> <li>5.3.2 Operational Conditions</li> <li>5.3.3 Related Parameters</li> <li>5.3.4 How to Use</li> <li>5.3.4.1 For Manual Setting</li> <li>5.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used</li> <li>5.4.4 How to Use</li> <li>5.4.3 Related Parameters</li> <li>5.4.4 How to Use</li> </ul>	

5.4.4.1 For Manual Setting 5.4.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	
5.5 Damping Control Function	211
5.5.1 Function Overview	
5.5.2 Operational Conditions	211
5.5.3 Related Parameters	211
5.5.4 How to Use	215
5.5.4.1 For Manual Setting	
5.5.4.2 When Set-up Support Software (PANATERM ver./) is Used	
5.6 Model-type Damping Filter Function	
5.6.1 Function Overview	
5.6.2 Operational Conditions	220
5.6.4 How to Use	221 223
5.6.4.1 When Set-up Support Software (PANATERM ver.7) Is Used	
5.6.4.2 Error Troubleshooting	228
5.7 Position Command Filter Function	
5.7.1 Function Overview	
5.7.2 Operational Conditions	229
5.7.3 Related Parameters	229
5.7.4 How to Use	230
5.7.4.1 For Manual Setting	
5.7.4.2 When Set-up Support Software (PANATERIN Ver.7) is Used	233 235
E 9 Speed Command Appelaration/Decolaration Setting Function	
5.8.1 Eunction Overview	230 236
5.8.2 Operational Conditions	236
5.8.3 Related Parameters	236
5.8.4 How to Use	
5.9 Hybrid Vibration Suppression Function	
5.9.1 Function Overview	
5.9.2 Operational Conditions	238
5.9.3 Related Parameters	238
5.9.4 How to Use	238
5.9.4.1 For Manual Setting	
5.9.4.2 When Set-up Support Software (PANATERIN Ver.7) is Used	239
6 Functions to Assist Tuning	
6.1 Waveform Measurement	243
6.1.1 Function Overview	
6.1.2 Purpose of Use	243
6.1.3 Measurement Procedure	243
6.1.4 Method of Use	245
6.2 Frequency Response Measurement	
6.2.1 Function Overview	246
6.2.2 Types of Measurement Modes	246
6.2.3 Changes from measurements using A6 Series drivers	
6.2.4 Restrictions	
b.∠.5 Measurement Procedure	
	254
7 References	
7.1 Object Dictionary List	258
7.1.1 CoE Communication Area (1000h to 1FFFh)	258
7.1.2 Servo Parameter Area (3000h to 3FFFh)	
7.1.2.1 Class 0: Basic Settings	

7.1.2.2 Class 1: Gain Adjustment	266
7.1.2.3 Class 2: Vibration Suppression	268
7.1.2.4 Class 3: Velocity/Torque Control/Full-closed Control	272
7.1.2.5 Class 4: I/O Monitor Settings	273
7.1.2.6 Class 5: Enhancing Settings	275
7.1.2.7 Class 6: Special Settings	278
7.1.2.8 Class 7: Special Settings 2	283
7.1.2.9 Class 8: Special Settings 3	285
7.1.2.10 Class 9: Linear Relationship	280
7.1.2.11 Class 10: Special Settings 4	207
7.1.2.12 Class 11. Manufacturer Ose	200
7.1.5 User-specific Area (4000110 4FFF1)	209
7.1.4 Drive Prome Area (0000110 0FFFI)	297
7.2 Control Mode Block Diagram	303
7.2.1 Position Control Mode Block Diagram	303
7.2.2 Speed Control Mode Block Diagram	306
7.2.3 Torque Control Mode Block Diagram	308
7.2.4 Full-closed Control Mode Block Diagram	309
7.3 Parameters Related To TUNINGLESS	313
7.4 Parameters Related To One Minute TUNING	315
7.5 Other Parameters Related To Tuning	319
7.6 List of Errors Related to One Minute TUNING	323
7.7 Glossary	326

# Introduction

Servo drivers have many parameters for realizing various control functions and control performance. To obtain the desired control performance, functions appropriate for the characteristics of the target device must be selected, and parameters set while considering balance. Performing these tasks requires knowledge of controls and tuning experience, which is generally complex.

To facilitate setting parameters, this product is equipped with the following automatic tuning functions which automatically perform parameter setting tasks with no initial setting of control gain, or by simply configuring initial settings such as target control performance.

- TUNINGLESS: The driver automatically tunes the inertia ratio, enabling equipment to be operated immediately
- One Minute TUNING: Measuring the characteristics of equipment enables adjustments with control stability to be made in a short time
- precAIse TUNING: AI automatically optimizes even complex adjustments, enabling expert-level tuning

### Notes

• Set-up Support Software (PANATERM ver.7) is equipped with AI.

This manual describes these automatic tuning functions and conventional manual tuning, as well as control functions for resolving various control challenges.

### – Precautions –

- Unauthorized reproduction or duplication of the contents of the present text, either in whole or in part, is strictly prohibited.
- The contents of the present text (specifications, software versions, etc.) are subject to change without notice.
- Read <u>"1.1 Precautions"</u> before using this product.
- Before using the tuning and control functions, properly configure the settings described in <u>"2.2 Safety</u> <u>Function Setup Before Tuning"</u>.
- If communication with a host device is required, properly configure communication-related settings to prevent any obstruction to motor rotation.

# **1** Before Use

<ul> <li>1.1 Precautions</li> <li>1.1.1 Safety Precautions</li> <li>1.1.2 Precautions for Proper Use</li></ul>	.9 .9 .12 13
1.2 Related Documents	. 14
1.3 Software Version	. 15
1.3.1 Notes Regarding Software         1.3.2 Applicable Software Version	.15
1.3.3 Software Version Confirmation Method	.15
1.3.4 Functions Not Currently Supported	.15
1.3.6 Functional Differences from Previous Series	.16
1.4 Trademarks	. 17
1.5 EtherCAT Communication Overview	. 17

# 1.1 Precautions

# 1.1.1 Safety Precautions

#### Must be adhered to

This section explains precautions that must be taken to prevent harm to people and damage to property.

# The following symbols represent the extent of the harm or damage that may occur through improper use.

Danger	This indicates "a significant risk of death or serious injury".
Caution	This indicates "a risk of injury or property damage".

#### The matters to be observed are explained using the following symbols.

$\bigcirc$	Must not be done.
	Must be done.

<u> </u>				
Do not use in wet places, corrosive atmospheres, inflammable gas atmospheres, atmospheres in which gases of low molecular weight such as helium gas are generated, or near combustible materials.	May cause fire.			
Do not place combustible materials near the motor, driver, regener- ative resistor, or dynamic brake resistor.				
Do not use in places subject to strong vibration or impact.	May cause electric shock, injury, and fire.			
Do not use with the cable immersed in oil or water.	May cause electric shock, malfunction, and damage.			
Do not install next to a heating element, such as a heater or large coil resistor.	May cause fire and malfunction.			
Never connect a commercial power supply directly to the motor.				
Do not perform wiring or operate with wet hands.	May cause electric shock, injury, and fire.			
Never put your hand inside the driver.	May cause burns and electric shock.			
In the case of a motor with axis end keyway, do not touch the key- way with bare hands.	May cause injury.			
Never touch the rotating portion of the motor while it is running.				
Do not touch the motor, driver heat sink, regenerative resistor, or dynamic brake resistor, since they become very hot.	May cause burns and parts damage.			
Do not drive the motor with external power.	May cause fire.			
Do not damage the cables, subject them to excessive force, place heavy objects on them, or pinch them.	May cause electric shock, malfunction, and damage.			
Install in an area free from excessive dust, water, oil, etc.	Improper installation site conditions may cause electric shock, fire, malfunction or damage.			
Install the motor, driver, and peripheral devices to nonflammable materials such as metal.	Mounting on a flammable material may cause fire.			
Wiring must be carried out by an expert in electrical work.	Wiring by a person with no expertise may cause electrical shock.			
Carry out wiring in accordance with the Operating Instructions.	Incorrect wiring may cause electrical shock, injury, malfunction, or damage.			
After correctly connecting cables, insulate the live parts with insulating material.	Incorrect wiring and short circuits may cause electrical shock, fire, or malfunction.			
Connect to the earth terminals of the motor and driver without fail.	Not grounding may cause electrical shock.			
Install and mount securely to prevent any possible fire or personal injury during an earthquake.	Failure to install properly may cause electric shock, fire, malfunction, or damage.			
Install an emergency stop circuit externally so that operation can be stopped and power turned off immediately in the event of an emergency.				
Install an overcurrent protection device, residual current device, overheating prevention device, and emergency stop device without fail.	Failure to install and check these may cause electric shock, injury, or fire.			
After an earthquake, always confirm safety.				
Before moving, wiring, or inspecting the driver, turn off power, wait at least as long as specified on the main unit side panel nameplate, and ensure that there is no risk of electrical shock.	Not turning off the power before these oper- ations may cause electric shock.			

	When transporting the product, do not hold it by the cable or motor axis.	May cause injury.			
	Do not drop or tip over the product during transportation or installa- tion.	May cause injury or malfunction.			
	Do not stand on or place heavy objects on the product.	May cause electric shock, injury, malfunc- tion, or damage.			
	Do not place any objects that would block air passage around the motor, driver, and peripheral devices.	May cause burns or fires.			
	Do not use in direct sunlight.	May cause injury or fire.			
	Do not block or insert foreign matter into the heat dissipation holes.	May cause electric shock or fire.			
$(\mathbf{N})$	There should be no strong impact on the product.	May cause malfunction.			
	There should be no strong impact on the motor axis.	May cause detectors, etc., to malfunction.			
	Do not turn the driver main power on and off frequently.	May cause malfunction.			
	Never run or stop the motor with the electromagnetic contactor in- stalled on the main power supply side.				
	Do not make extreme gain adjustments or changes in the driver, or destabilize the driving or operation of the machine.	May cause injury.			
	Do not use the motor's built-in brakes to stop a moving load.	May cause injury or malfunction.			
	Never modify, dismantle, or repair.	May cause fire, electric shock, injury, or malfunction.			
	Mount in a manner appropriately matched to the base machine mass and product rated output.	Improper attachment or installation may			
	Observe the specified mounting method and orientation.	cause injury or manunction.			
	Only use the eye bolt of the motor for transportation of the motor.	Use for transportation of the machine may cause injury or malfunction.			
	Set the motor and driver ambient temperature within the tempera- ture and humidity ranges for use.	Improper attachment or installation may cause injury or malfunction.			
	Create the specified clearance in separating the driver from the control panel inner surface and from other devices when installing.	-			
	Maintain the specified voltage.	Operation at a voltage outside the rated voltage range may cause electric shock, in- jury, or fire.			
	Connect a relay that disconnects in the event of an emergency stop in series with the brake control relay.	Not connecting it may cause injury or mal- function.			
	Install safety devices for built-in brake or gear head idling or lock- ing, or grease leakage from gear head.	Non-installation may cause injury, damage, or pollution.			
	The servo drive may start up with no warning when power is re- stored after a blackout, so the machine must be set to ensure the safety of the operator at all times.	May cause injury.			
	Use the specified combination of motor and driver.	May cause malfunction or fire if not used in the correct combination.			
	To perform a trial run, secure the motor, and install it in the me- chanical system after checking its operation while disconnected from the mechanical system.	Use of the wrong model or incorrect wiring may cause injury.			
	When an error occurs, clear the error and only restart after elimi- nating the cause and ensuring safety.	Not eliminating the cause of the error might cause injury.			
	If the driver malfunctions, shut off the power on the power supply side of the driver.	Continued passage of a large current may lead to fire.			
	Always disconnect the power when not in use for a long time.	Improper operation may cause injury.			
	Use a stabilized power supply with double insulation or reinforced insulation for the DC power supply.	May cause electric shock , fire or malfunc- tion.			

#### Other precautions

- When disposing of batteries, insulate them with tape and dispose of them in accordance with local regulations.
- When disposing of the Servo driver and motor, they are treated as industrial waste.
- Wrinkling of the label affixed to the motor will not present a problem in use of the motor.

#### 1.1.2 Precautions for Proper Use

• Observe the following precautions when exporting the product or equipment incorporating the product.

If the end user or end use of this product is related to the military or weaponry, etc., it may be subject to export restrictions as set forth in the Foreign Exchange and Foreign Trade Act or by the regional authority. When exporting, please review and follow the necessary export procedures.

- This product is intended for use with general industrial products. It is not designed or manufactured for use in machines or systems that may cause death on failure. This product is not for use in devices critical to human wellbeing or in specialized environments, such as nuclear power control, aerospace equipment, transportation systems, medical equipment or various safety devices.
- Installation, wiring, operation and maintenance of the equipment should be carried out by qualified and experienced personnel.
- Apply adequate tightening torque to the product mounting screws by taking into consideration the strength of the screws and the characteristics of the material to which the product is installed.
- Install safety equipment when applying this product to systems that could cause serious accidents or damage in the event of product failure.
- Because noise resistance may be affected by wiring conditions (e.g., earthing methods, cable length, signal wire shielding), please confirm the noise resistance of your equipment.
- Ensure that the motor axis is not operated without being electrically grounded, as this may lead to electrolytic corrosion of the motor bearing and increased bearing noise, depending on the machine and the installation environment.
- Some faults may cause the emission of roughly one cigarette's worth of smoke. Please consider these possibilities when using the device in cleanrooms and similar facilities.
- Make sure to follow indications as overloading products can cause loads to collapse.
- Do not use detergents containing benzine, thinner, alcohol, acid, or alkaline, since this may cause discoloration or damage the exterior of the product. When using a neutral detergent, please use a solution diluted to the concentration specified for the neutral detergent you are using.
- Treat as industrial waste on disposal.
- Please ensure that finished equipment complies with standards, laws and regulations, and confirm that the structure, dimensions, lifetime and characteristics of the product are suitable for your installed equipment and components.
- Note that use of this product outside the scope of specifications is not covered under warranty.
- Reverse engineering, decompiling and disassembling of this product is strictly prohibited.

# 1.1.3 Network Security

As you will use this product connected to a network, your attention is called to the following security risks.

- 1 Leakage or theft of information through this product
- 2 Use of this product for fraudulent operation by persons with malicious intent
- 3 Interference with or stoppage of this product by persons with malicious intent

It is the customer's responsibility to ensure that sufficient network security measures are taken, including the following.

We will not be liable for any damage caused by insufficient network security.

#### – Precautions –

- This product is to be used in an environment where only a limited number of parties are permitted access to the product.
- This product is not to be installed in locations where the product and its accessories, such as cables, can be easily destroyed.
- This product is to be used on a network that is not connected to the Internet.
- If an external device, such as a computer or tablet, is connected to this product, there are concerns about the effects of computer viruses and unauthorized programs.

Take appropriate security measures with external devices, such as ensuring that they are checked for computer viruses and that regular cleaning of such viruses is performed before connecting them.

• If this product is turned over to a third party for transfer, disposal, repair, etc., important information may be left recorded in the device.

Make deletions, etc.. at your own risk, and handle such matters with sufficient care.

# 1.2 Related Documents

The following are documents related to this product (including this manual). See each document as necessary for safe use of this product.

The documents can be downloaded from the following site.

https://industry.panasonic.com/global/en/

Document name	Abbreviations in this manual	Document No.	Description		
Servo System Operating Instructions					
MINAS A7B Series Operating In- structions (Overall) EtherCAT Rotary Motor	01_0	IMG07	This manual describes the selection, connection, us- age, and error handling of servo drivers and servo motors to ensure correct and safe use of this prod- uct.		
MINAS A7B Series Operating In- structions (Tuning) EtherCAT Rotary Motor	OI_A	IMG20	This document describes the adjustment function of the servo driver.		
For MINAS Set-up Support Soft- ware (PANATERM ver.7) Operat- ing Manual	PT_OM	IMG15	This document describes how to use PANATERM ver. 7, the setup support software for this product.		
Servo Driver Standard Specification	Servo Driver Standard Specification				
MINAS A7BSeries Standard Specifications Rotary Motor (Standard / Multi- function / Application specialized)	SS	SX-DSV03714	This document describes the hardware specifica- tions of the servo driver.		
Servo Driver Technical Reference					
MINAS A7B Series Technical Ref- erence Functional Specification Rotary Motor (Standard / Multi- function / Application specialized)	TR_FS	SX-DSV03752	This document describes how to use the various functions of the servo driver.		
MINAS A7B Series Technical Ref- erence Communication Specifica- tion Rotary Motor (Standard / Multi- function / Application specialized)	TR_CS	SX-DSV03755	This document describes the interface that connects the servo driver to the host device.		
Motion Controller User's Manual					
GM1 Controller User's Manual (Operation)	GM1_UM	WUME-GM1OP	This document describes how to use the motion controller GM1.		

# 1.3 Software Version

#### 1.3.1 Notes Regarding Software

This product incorporates open source software (OSS), and usage is pursuant to the terms of the license (see Technical Reference Functional Specification "10 License Terms for Open Source Software (OSS)"). Your company may also have an obligation to use OSS, so please take appropriate measures at your company.

### 1.3.2 Applicable Software Version

The present manual applies to the following servo driver software versions.

CPU 1 (Software version 1)	Ver.1.05
CPU 2 (Software version 2)	Ver.1.02
Manufacture Software (Software version 3)	Ver.1.01

### 1.3.3 Software Version Confirmation Method

The above software versions can be confirmed using the following methods.

- Software version 1, Software version 2
  - EtherCAT communication command Obj.3744h:00h "Software version" (See Operating Instructions (Overall) "6.3.1 Device Information" )
  - Set-up Support Software (PANATERM ver.7)
- Software version 3
  - EtherCAT communication command Obj.100Ah:00h "Manufacturer software version" (See Operating Instructions (Overall) "6.3.1 Device Information")
  - Set-up Support Software (PANATERM ver.7)

### 1.3.4 Functions Not Currently Supported

The functions listed in the table below are not currently supported in this software version.

Please note that although the following functions are described in some parts of the text, they are not supported in this software version.

Function name
Batteryless encoder
Full-closed control function (rotary scale)
Virtual full-closed control function
Deterioration diagnosis warning function
Retracting operation function
EoE (Ethernet over EtherCAT)
Touch probe function
• External scale z-phase latch function for semi-closed control
Backlash compensation function

# 1.3.5 Software Version History

• New software versions are upward compatible with old software versions.

The parameters used in the old software version can be used as they are in the new software version.

Parameter factory default values for features added in the new software version are set to values that disable the added features. For this reason, immediately after upgrading, the servo driver will operate in a manner compatible with an older software versions.

• When using the added functions, set parameters in accordance with the explanations of functions in this manual.

Soft ver CPU1	ware sion CPU2	Class	Changed Function Details	Relevant Section	Supported Set- up Support Software (PAN- ATERM ver.7)
1.04	1.02	First version	Newly created	-	7.0.0.0 and later
1.05	1.02	Extended Ver- sion 1	Monitor Signal Output	OI_O "3.2.8.1"	7.0.3.0 and later
			Position Comparison Output Function	OI_O "8.3"	
			EtherCAT communication Enhancements	OI_O "4.2.2", "10.2.3" TR_CS "1.2.7"	

# 1.3.6 Functional Differences from Previous Series

- For differences from the MINAS A6B Series, see Technical Reference Functional Specification "1.2.6 Functional Differences from Previous Series" and Technical Reference Communication Specification "1.2.7 Functional Differences from Previous Series".
- The MINAS A7B Series may not operate in complete compatibility with previous series (the A6B Series, etc.). Be sure to carry out an evaluation before changing from a previous series to the MINAS A7B Series, as parameter retuning may be required.

The initial values for the MINAS A7B Series are listed in Operating Instructions (Overall) "6.2 Object Dictionary List".

# 1.4 Trademarks

- MINAS, TUNE COMPASS and PANATERM are registered trademarks or trademarks of Panasonic Holdings Corporation in Japan and other countries.
- EtherCAT is a registered trademark and patented technology licensed by Beckhoff Automation GmbH, Germany.

# 1.5 EtherCAT Communication Overview

EtherCAT is short for "Ethernet for Control Automation Technology", and is an open network communication between main devices and sub devices using real-time Ethernet developed by Beckhoff Automation GmbH.

EtherCAT is managed by ETG (EtherCAT Technology Group).

EtherCAT<sup>®</sup> is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.



# **2** Overview of Tuning Functions

2.1 Types of Tuning and Control Functions	19
2.1.1 Auto Tuning (TUNE COMPASS) and Manual Tuning	19
2.1.2 Control Functions to Improve Tracking With Respect to Control Commands	21
2.1.3 Control Functions for Suppressing Abnormal Noise and Vibration	23
2.1.4 List of Control Functions (By Driver Type)	25
2.1.5 List of Control Functions (By Control Mode)	26
2.2 Safety Function Setup Before Tuning	27
2.3 Adjustment Workflow	28
2.3.1 Adjustments at Device Startup	
2.3.2 Re-adjustment After Device Startup	29

# 2.1 Types of Tuning and Control Functions

# 2.1.1 Auto Tuning (TUNE COMPASS) and Manual Tuning

In order to get the best performance out of the device, parameters must be set to optimal values using appropriate control functions, which is generally complex. This product provides the three automatic tuning functions shown in the table below, which automatically tune parameters with no initial setting of control gain, or by simply configuring initial settings such as target control performance. TUNE COMPASS is the collective name for these automatic tuning functions. The functions selected can be tailored to meet customer requirements.

Manual tuning is also possible to ensure the best responsiveness and stability for individual loads.

For specific instructions on selecting tuning means, see <u>"2.3 Adjustment Workflow"</u>.



○: Supported ×: Not supported

Function name	Function overview	Operation	command	Set-up Sup-	Reference
		Internal com- mand	Upper com- mand	port Soft- ware (PANA- TERM ver.7) needed	
	Auto tuning (TUNE	COMPASS)			
TUNINGLESS	This function automatically tunes inertia based on the actual operation of the mo- tor, using the initial values as parame- ters. This function is enabled at the time of shipment. This function is useful when you want to move the motor immediately.	O (*1)	0	×	<u>"3.1.1 TU-</u> <u>NINGLESS"</u>
One Minute TUNING	A function that automatically tunes vari- ous parameters to satisfy target perform- ance by measuring device characteristics and ensuring the control tolerance from the actual operation of the device. This is effective for obtaining a higher control performance in a relatively short time. If there is a change in the device work- piece or position, only specific items can be auto tuned again.	0	×	0	<u>"3.1.2 One</u> <u>Minute TUN-</u> <u>ING</u> "

Function name	Function overview	Operation	command	Set-up Sup-	Reference	
		Internal com- mand	Upper com- mand	port Soft- ware (PANA- TERM ver.7) needed		
precAlse TUNING	This function automatically tunes various parameters while the motor is running, with AI determining the response. It is effective for tuning devices that are difficult to tune and require tuning by skil- led operators. The tuning results are ex- pected to exceed those of skilled opera- tors. This is also effective for reducing opera- tor labor hours, because it performs au- tomatic operation using Set-up Support Software (PANATERM ver.7) after initial setting of target performance and multi- ple operation patterns, etc.	0	×	0	<u>"3.1.3 pre-</u> <u>cAIse TUN-</u> <u>ING"</u>	
	Manual Tu	ning				
Manual TUNING	Re-adjustment may be necessary to fur- ther improve responsiveness and stabili- ty, for example, after auto tuning. In such cases, this function manually sets indi- vidual parameters to their optimal values. The dedicated user interface for Set-up Support Software (PANATERM ver.7), groups the related parameters by control function. Gain adjustment and tuning of vibration suppression filters, etc., can easily be performed manually.	O (*1)	0	O (*2)	<u>"3.2.1 Man-</u> <u>ual TUN-</u> <u>ING"</u>	
Load fluctuation sup- pression tuning (stabilizing load fluc- tuation applications)	In devices where load inertia fluctuates, vibration may occur due to the effect of load inertia fluctuations. This function re- duces this vibration and improves stabili- ty.	O (*1)	0	O (*2)	<u>"3.2.2 Load</u> <u>Fluctuation</u> <u>Suppression</u> <u>Tuning (Sta- bilizing Load</u> <u>Fluctuation</u> <u>Applica-</u> <u>tions)</u> "	

\*1 Use the Set-up Support Software (PANATERM ver.7) trial run function.

\*2 Can be implemented without Set-up Support Software (PANATERM ver.7).

# 2.1.2 Control Functions to Improve Tracking With Respect to Control Commands

These functions are expected to improve tracking with respect to control commands.

A list of functions is shown below.

The "Auto tuning (TUNE COMPASS) supported" column indicates whether or not the parameters can be tuned by each automatic tuning function.

The functions listed in gray in the table below are not currently supported in this software version.

$\sim$					
()	Supported	$\sim$ .	Nlot	CUD	nortod
U.	Supported	$\sim$ .	INOL	Sup	porteu

Function name	Function overview	Auto tuning (TUNE COMPASS) support- ed			Refer- ence
		TUNING- LESS	One Minute TUNING	precAlse TUNING	
Real-time auto tuning func- tion	This function estimates machine load characteristics in real time and uses those results to automatically perform basic gain setting and load characteris- tic compensation. The tuning of stiffness parameters should yield a reduction in settling time.	O (*1)	0	0	<u>"4.1 Re-</u> al-time <u>Auto Tun-</u> ing Func- tion"
Gain switching function	This function optimizes control based on the operating state of the servo driv- er by changing settings such as gain types and setting conditions based on command inputs such as torque com- mands or control data such as position deviation. This is expected to shorten the settling time and suppress fine vibration while stopped.	×	×	0	<u>"4.2 Gai</u> <u>n Switch-</u> <u>ing Func-</u> <u>tion</u> "
3rd gain switching function	In addition to the normal gain switching function (two-stage gain switching function), this function sets a 3rd gain between both gains. This is expected to shorten the settling time. Overshoot suppression is expect- ed from the gain switching function.	×	×	0	<u>"4.3 3rd</u> <u>Gain</u> <u>Switching</u> <u>Func-</u> <u>tion"</u>
Feedforward function	This function performs compensation to minimize the effect of delay caused by feedback control on the command value before the effect is apparent. This is expected to improve tracking of position control and speed control.	0	0	0	<u>"4.4 Fee</u> dforward <u>Func-</u> tion"
Friction torque compensation function	This function reduces the effect of me- chanical system friction and improves responsiveness. This is expected to compensate the ef- fect of friction and improve command tracking.	×	0	0	<u>"4.5 Fric-</u> <u>tion Tor-</u> <u>que</u> <u>Compen-</u> <u>sation</u> <u>Func-</u> <u>tion</u> "

Function name	Function overview	Auto tuning (TUNE COMPASS) support- ed			Refer- ence
		TUNING- LESS	One Minute TUNING	precAlse TUNING	
Load fluctuation control func- tion	In devices with which disturbance tor- que is applied, velocity change may oc- cur due to the disturbance torque. This function reduces this velocity change and improves stability. In devices where load inertia fluctu- ates, vibration may occur due to the ef- fect of load inertia fluctuations. This function reduces this vibration and im- proves stability. This is expected to compensate the ef- fect of disturbance torque and inertia change and improve operation stability.	×	0	0	"4.6 Loa d Fluctu- ation Control Function (Disturb- ance Suppres- sion Ap- plica- tions)" "4.7 Loa d Fluctu- ation Control Function (Load Fluctua- tion Sta- bilization Applica- tions)"
High response current con- trol function	This function improves the responsive- ness of the current controller by chang- ing the current response setting to a value greater than the initial value in order to improve the current control re- sponsiveness when operating at low current, such as with a processing ma- chine. This is expected to improve the re- sponsiveness of position control and speed control by enhancing current control performance in locus control.	×	×	0	<u>"4.8 High</u> <u>Re-</u> <u>sponse</u> <u>Current</u> <u>Control</u> <u>Func-</u> <u>tion</u> "
Quadrant glitch suppression function	This function suppresses quadrant glitches that occur when drawing an arc with two or more axes. This is expected to suppress quadrants glitches during a change of direction in locus control.	×	×	0	<u>"4.9 Qua</u> <u>drant</u> <u>Glitch</u> <u>Suppres-</u> <u>sion</u> <u>Func-</u> <u>tion</u> "
Backlash compensation function	When driving a device with backlash (mechanical gap in the drive system), the amount of movement commanded by the host device will differ from the actual amount of movement of the me- chanical axis. The backlash compensa- tion function adds a backlash compen- sation value to the host device position command and drives the motor axis by the command to which the compensa- tion value has been added, thereby matching the amount of movement commanded by the host device with the actual amount of movement of the mechanical axis. In devices with backlash, this is expect- ed to reduce the deviation between the actual amount of movement of the me- chanical axis and the amount of move- ment commanded by the host device.	×	×	×	<u>"4.10 Ba</u> <u>cklash</u> <u>Compen-</u> <u>sation</u> <u>Func-</u> <u>tion</u> "

\*1 Pr0.04 "Inertia ratio" is estimated automatically.

# 2.1.3 Control Functions for Suppressing Abnormal Noise and Vibration

These functions are expected to suppress abnormal noise and vibration, such as abnormal noise caused by oscillation and residual vibration during positioning.

A list of functions is shown below.

The "Auto tuning (TUNE COMPASS) supported" column indicates whether or not the parameters can be tuned by each automatic tuning function.

 $\bigcirc$ : Supported X: Not supported

Function name	Function overview	Auto tuning (TUNE COMPASS) support- ed			Refer- ence
		TUNING- LESS	One Minute TUNING	precAlse TUNING	
Torque filter function	Sounds and vibrations in the high fre- quency range may occur when the gain is increased. By setting a torque filter, this function is expected to suppress this sound and vibration. This function is expected to suppress sound and vibration in the high fre- quency range $(^{*1})$ .	0	0	0	<u>"5.1 Tor-</u> <u>que Filter</u> <u>Func-</u> <u>tion"</u>
2-stage torque filter function	This function sets a 2-stage torque fil- ter to suppress high-frequency vibra- tion components that cannot be re- moved by the <u>"5.1 Torque Filter Func- tion"</u> torque filter alone. This function is expected to suppress sound and vibration in the high fre- quency range <sup>(*1)</sup> . The suppression ef- fect is stronger than that of a torque fil- ter.	×	×	0	<u>"5.2 2-</u> <u>stage</u> <u>Torque</u> <u>Filter</u> <u>Func-</u> <u>tion</u> "
Notch filter function	When the gain is increased, sounds and vibrations of specific frequencies in the high frequency range may occur. This function suppresses sound and vi- bration at specific frequencies in the high frequency range by setting a notch filter. This function is expected to suppress noise and vibration caused by mechan- ical resonance of the device <sup>(*2)</sup> .	×	0	0	<u>"5.3 Notc</u> <u>h Filter</u> <u>Func-</u> <u>tion</u> "
Adaptive filter function	This function auto tunes parameters re- lated to notch filters.	×	0	×	<u>"5.4 Ada</u> <u>ptive Fil-</u> <u>ter Func-</u> <u>tion"</u>
Damping control function	This function reduces residual vibration of approximately 100 Hz or less that occurs at the moving part tip or the overall device during positioning opera- tion by setting a damping filter. This is expected to suppress residual vibration of the at the moving part tip or the overall device during positioning.	×	0	0	<u>"5.5 Da</u> mping Control <u>Func-</u> tion"

Function name	Function overview	Auto tuning (TUNE COMPASS) support- ed			Refer- ence
		TUNING- LESS	One Minute TUNING	precAlse TUNING	
Model-type damping filter function	This function reduces residual vibration of approximately 100 Hz or less that occurs at the moving part tip or the overall device during positioning opera- tion by setting a model-type damping filter. This is expected to suppress residual vibration of the at the moving part tip or the overall device during positioning. A shorter settling time is expected than with damping control.	×	×	0	<u>"5.6 Mod</u> <u>el-type</u> <u>Damping</u> <u>Filter</u> <u>Func-</u> <u>tion</u> "
Position command filter func- tion	A function that applies a positional command smoothing filter to a position command to gently accelerate or de- celerate the motor. This is expected to suppress vibration and velocity change caused by the command resolution and command up- dating cycle roughness.	×	0	0	<u>"5.7 Po-</u> <u>sition</u> <u>Com-</u> <u>mand Fil-</u> <u>ter Func-</u> <u>tion</u> "
Speed command accelera- tion/deceleration setting function	This function performs speed control by applying a speed command for which acceleration and deceleration have been tuned inside the servo driv- er with respect to the speed command input from the host device. In speed control mode, it is expected that there will be a reduction in shocks caused by acceleration changes and that vibration will be suppressed.	×	×	×	<u>"5.8 Spe</u> ed Com- mand Ac- celera- tion/ Deceler- ation Set- ting Func- tion"
Hybrid vibration suppression function	This function suppresses vibration caused by the amount of torsion be- tween the motor and the load in full- closed control mode. This is expected to shorten the settling time.	×	×	×	<u>"5.9 Hy-</u> <u>brid Vi-</u> <u>bration</u> <u>Suppres-</u> <u>sion</u> <u>Func-</u> <u>tion</u> "

\*1 This product assumes frequencies of 1.5 kHz or more as the high frequency range.

\*2 This product assumes frequencies of 600 Hz to 1.5 kHz to be mechanical resonance.

# 2.1.4 List of Control Functions (By Driver Type)

The table below shows the functions supported by this product by driver type.

The functions listed in gray in the table below are not currently supported in this software version.

	$\bigcirc$ : Supported $ imes$ : Not supported			
Function name		Driver type		
	A7BE	A7BF	A7BR	
	Standard type	Multi-function type	Application spe- cialized type	
Control functions for contr	ol performance			
Real-time auto tuning function	0	0	0	
Gain switching function	0	0	0	
3rd gain switching function	0	0	0	
Feedforward function	0	0	0	
Friction torque compensation function	0	0	0	
Load fluctuation control function	0	0	0	
High response current control function	0	0	0	
Quadrant glitch suppression function	0	0	0	
Backlash compensation function	0	0	0	
Control functions to suppress abno	rmal noise and vibra	ation		
Torque filter function	0	0	0	
2-stage torque filter function	0	0	0	
Notch filter function	0	0	0	
Adaptive filter function	0	0	0	
Damping control function	0	0	0	
Model-type damping filter function	0	0	0	
Position command filter function	0	0	0	
Speed command acceleration/deceleration setting function	0	0	0	
Hybrid vibration suppression function	×	0	0	

# 2.1.5 List of Control Functions (By Control Mode)

The table below shows the functions supported by this product by control mode.

The functions listed in gray in the table below are not currently supported in this software version.

$\bigcirc$ : Supported X: Not supported							
Function name		Contro	l mode				
	Position control	Speed control	Torque control	Full-closed con- trol			
Contr	Control functions for control performance						
Real-time auto tuning function	0	0	0	0			
Gain switching function	0	0	0	0			
3rd gain switching function	0	×	×	0			
Feedforward function	0	0	×	0			
Friction torque compensation function	0	0	0	0			
Load fluctuation control function	0	0	×	0			
High response current control function	0	0	0	0			
Quadrant glitch suppression function	0	×	×	0			
Backlash compensation function	0	×	×	0			
Control functio	ns to suppress abno	ormal noise and vibr	ration				
Torque filter function	0	0	0	0			
2-stage torque filter function	0	0	0	0			
Notch filter function	0	0	0	0			
Adaptive filter function	0	0	×	0			
Damping control function	0	×	×	0			
Model-type damping filter function	0	×	×	×			
Position command filter function	0	0	×	0			
Speed command acceleration/deceleration setting function	×	0	×	×			
Hybrid vibration suppression function	×	×	×	0			

# 2.2 Safety Function Setup Before Tuning

Before tuning any parameters, make sure the following settings are properly configured.

This reduces the impact of unforeseen movements and ensures safer tuning.

Over-travel inhibit input setup	This setting prevents moving parts from colliding with the mechanical end.
<ul> <li>Pr5.04 "Over-travel inhibit input set- up"</li> </ul>	
<ul> <li>Pr5.05 "Sequence at over-travel in- hibit"</li> </ul>	
Torque limit setup	This setting limits the maximum torque to prevent damage to moving parts.
Pr0.13 "1st torque limit"	
• Pr5.11 "Torque setup for emergency stop"	
Pr5.21 "Selection of torque limit"	
Pr5.22 "2nd torque limit"	
Overspeed protection setup	This setting stops the alarm in the event of abnormally high speed.
Pr5.13 "Over-speed level setup"	
Position deviation excess protection set- up	This setting stops the alarm when abnormal position deviation from a command occurs in the position control mode.
<ul> <li>Pr0.14 "Position deviation excess setup"</li> </ul>	
<ul> <li>Pr5.20 "Position setup unit select"</li> </ul>	
Motor working range setup	This setting stops the alarm when the motor position exceeds the allowable width
<ul> <li>Pr5.14 "Motor working range setup"</li> </ul>	from the command range in the position control mode.
• Pr6.97 "Function expansion setup 3" :bit 2 "Motor movable range error protection expansion"	
Hybrid deviation excess protection set- up	This setting prevents abnormal operation due to incorrect external scale settings, etc., in full-closed control mode.
<ul> <li>Pr3.28 "Hybrid deviation excess set- up"</li> </ul>	
• Pr3.29 "Hybrid deviation clear setup"	
Speed limit setting	This setting prevents the speed exceeding the speed limit value in torque control
Pr3.17 "Selection of speed limit"	mode.
• Pr6.97 "Function expansion setup 3" :bit 12 "Speed limit priority function during torque control"	

For details, see Operating Instructions (Overall) "7.2.9 Before Gain Tuning Protection Function Setup" and "7.5.2 Velocity Limit Function".

# 2.3 Adjustment Workflow

# 2.3.1 Adjustments at Device Startup

Select the tuning function and adjust the parameters with reference to the following workflow.

#### Adjustment Workflow at Device Startup



# 2.3.2 Re-adjustment After Device Startup

- When Set-up Support Software (PANATERM ver.7) is used
  - Tuning is made using one of the following.
  - Tuning function One Minute TUNING: See <u>"3.1.2.5 Use Cases in Re-adjustment"</u> for details.
  - Tuning function Manual TUNING: See <u>"3.2.1.4.4 Tuning Procedure When Control Challenges Are Identified</u>" for details.
- When Set-up Support Software (PANATERM ver.7) is not used

The control functions that address the main issues when re-adjusting are listed in the table below.

Perform tuning by referring to the reference tuning procedures.

Issues during re-adjustment	Corresponding control function references
Shortening the settling time.	"4.1 Real-time Auto Tuning Function"
	"5.7 Position Command Filter Function"
Reducing overshoot/undershoot.	"4.1 Real-time Auto Tuning Function"
	"4.3 3rd Gain Switching Function"
	<u>"4.4 Feedforward Function"</u>
	<u>"4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)"</u>
	"4.8 High Response Current Control Function"
Reducing abnormal noise and oscillation.	"5.3 Notch Filter Function"
	"5.7 Position Command Filter Function"
Reducing vibration just before stopping.	"5.5 Damping Control Function"
	"5.6 Model-type Damping Filter Function"
Suppressing velocity changes during constant speed control.	"4.1 Real-time Auto Tuning Function"
	"4.6 Load Fluctuation Control Function (Disturbance Sup-
	pression Applications)"
	<u>"4.8 High Response Current Control Function"</u>
Preventing falling on the vertical axis after servo-on.	"4.5 Friction Torque Compensation Function"
Suppressing quadrant glitches when velocity is inverted for processing machines, etc.	"4.9 Quadrant Glitch Suppression Function"
Ensuring own axis is not moved when other axes are moved.	"4.1 Real-time Auto Tuning Function"
	"4.6 Load Fluctuation Control Function (Disturbance Sup-
	pression Applications)"
	<u>"4.8 High Response Current Control Function"</u>
Reducing vibration when gain is increased in full-closed con- trol.	<u>"5.9 Hybrid Vibration Suppression Function"</u>

# **3 Details of Tuning Functions**

3.1 Auto Tuning (TUNE COMPASS)	31
3.1.1 TUNINGLESS	31
3.1.1.1 Function Overview	31
3.1.1.2 Operational Conditions	31
3.1.1.3 Parameters That Are Automatically Set and Automatically Tuned	31
3.1.1.4 Usage	31
3.1.2 One Minute TUNING	
3.1.2.1 Function Overview	32
3.1.2.2 Operational Conditions	32
3.1.2.3 Parameters That Are Automatically Set and Automatically Tuned	32
3.1.2.4 Usage	32
3.1.2.5 Use Cases in Re-adjustment	50
3.1.3 precAlse TUNING	52
3.1.3.1 Function Overview	52
3.1.3.2 Operational Conditions	52
3.1.3.3 Parameters That Are Automatically Set and Automatically Tuned	52
3.1.3.4 Usage	53
3.2 Manual Tuning	65
3.2.1 Manual TUNING	65
3.2.1.1 Function Overview	65
3.2.1.2 Operational Conditions	65
3.2.1.3 Tuning Method	65
3.2.1.4 Manual TUNING Using Set-up Support Software (PANATERM ver.7)	69
3.2.2 Load Fluctuation Suppression Tuning (Stabilizing Load Fluctuation Applications)	92
3.2.2.1 Function Overview	92
3.2.2.2 Operational Conditions	92
3.2.2.3 Tuning Procedure	92

# 3.1 Auto Tuning (TUNE COMPASS)

# 3.1.1 TUNINGLESS

#### 3.1.1.1 Function Overview

This function automatically tunes inertia based on the actual operation of the motor, using the initial values as parameters. This function is enabled in the settings at the time of shipment.

This function is useful when you want to move the motor immediately.

## 3.1.1.2 Operational Conditions

Item	Operational Conditions
Control mode	All control modes
Other	The related parameters ( <u>"7.3 Parameters Related To TUNINGLESS"</u> ) are not changed from the initial values.

#### – Precautions –

- Since the real-time auto tuning function is enabled while this function is in use, the automatically set parameters cannot be manually changed to any desired value. For details, see <u>"4.1 Real-time Auto Tuning Function"</u>.
- While this function is operating, notch filters, damping control, the gain switching function, the load fluctuation control function, the friction compensation function, and the inertia ratio switching function are disabled.
- Under the following conditions, TUNINGLESS inertia estimating may not be performed correctly.

Item	Conditions that obstruct the TUNINGLESS inertia estimation					
Load inertia	<ul> <li>When small or large compared to the rotor inertia of the servo motor (less than 3× or 20× or more)</li> <li>When load inertia fluctuates</li> </ul>					
Load	<ul> <li>When machine stiffness is extremely low</li> <li>When non-linear characteristics exist, such as backlash</li> </ul>					
Operation pat- terns	<ul> <li>When used continuously at low speeds of less than 100 r/min</li> <li>When acceleration and deceleration are gentle, less than 2000 r/min in 1 s</li> <li>When the acceleration and deceleration torque is small compared to the unbalanced load and viscous friction torque</li> <li>When the speed is more than 100 r/min and the acceleration and deceleration condition of more than 2000 r/min in 1 s does not continue for more than 50 ms</li> </ul>					

# 3.1.1.3 Parameters That Are Automatically Set and Automatically Tuned

• Pr0.04 "Inertia ratio"

# 3.1.1.4 Usage

If "3.1.1.2 Operational Conditions" is met, setting tasks are not required.

Tuning is performed automatically by operating the motor.

# 3.1.2 One Minute TUNING

#### 3.1.2.1 Function Overview

A function that automatically tunes various parameters to satisfy target performance by measuring device characteristics and ensuring control tolerance.

This is effective for obtaining a higher control performance in a relatively short time.

If there is a change in the device workpiece or position, only specific items will be auto tuned again.

### 3.1.2.2 Operational Conditions

Item	Operational Conditions					
Control mode	Position control mode, speed control mode					
Other	Set-up Support Software (PANATERM ver.7) is required.					

#### – Precautions –

- Tuning results that satisfy the required performance may not be obtained. In such cases, the tuning results judged to be the best are displayed.
- This tuning is performed in position control mode.

When One Minute TUNING is started in speed control mode, the driver temporarily changes to position control mode internally to execute tuning.

The tuning results obtained are tuning results from position control mode and may differ from tuning results obtained in speed control mode (Manual TUNING, etc.).

After tuning is completed, check the operation in speed control mode.

- The motor rotates during execution of this function. Be careful not to contact moving parts.
- This tuning changes the values of many parameters. If you need the values before tuning, save the data beforehand.
- Under the following conditions, One Minute TUNING inertia estimating may not be performed correctly.

Item	Conditions that obstruct the One Minute TUNING inertia estimation						
Load	When load inertia fluctuates						
	When machine stiffness is extremely low						
	When non-linear characteristics exist, such as looseness due to backlash						

 Do not use this function in a mechanism that causes the moving part to deviate from the operating range when the servo is OFF.

#### 3.1.2.3 Parameters That Are Automatically Set and Automatically Tuned

See <u>"7.4 Parameters Related To One Minute TUNING</u>".

#### 3.1.2.4 Usage

Instructions for use are described according to the following steps.

- 1 <u>"Starting the Tuning Function"</u>
- 2 <u>"Initial Settings</u>"
- 3 <u>"Adjustment Operation"</u>
- 4 <u>"Confirming Tuning Results, Ending One Minute TUNING"</u>

#### 3.1.2.4.1 Starting the Tuning Function

# << Procedure >>

- Check that Pr0.01 "Control mode setup" is set to the target mode for the operational conditions. In position control mode, set parameters related to command division/multiplication (electronic gear ratio) correctly to set the operating range in command units in the initial settings.
- 2. Activate Set-up Support Software (PANATERM ver.7).
- 3. Select one device that you want to tune in the device tree and click the "Tuning" tab.

9						PANATERM ver.7				- 0	×
File(F)	Troubleshootir	ng(T)	Help(H)							_	
			E Device tree			{ĝ} Setting	嬰 Monitor	比 Logging	프운 Tuning	Device Info	IJ
	-		MINAS A7BR		]		EtherCAT object	IO Setting	Alarm	Analog input	Trial r
@Υ		Online	Axis0_No name set	SRV-OFF		Onen file	Cause file	Conv	Luslues Lead	Mile	un/Z-
	-	USB	MADN085BRU 23080001				Jave me	copy Load Initia	Tvalues Load		phase
	M.			Encoder Info				Config Reset			e sear
	0		MINAS A7BR MHMG022U1A2 24020001	39405786 pulse	•	Search	Compa	rison None	✓ Add/delete c	olumn	ch▼
						Switch to HEX input	Display A6-compati	ble control parameters	Allow out-of-range settin	igs	

4. In the "Tuning" tab screen, select "One Minute TUNING", and click the [Go to the Tuning screen] button.



The "One Minute TUNING" settings screen is displayed.

One Minute TUNING				_
		0	2	
		Setting	Execute tuning	Tuning results
Recall conditions			Advanced setting	s
Applications			To perform tuning u	sing operation command settings and operation commands from the host device, or to change the
Positioning/general-purpose			required performan	e, perform setup using "Advanced settings".
Do not use this function in a mechanism to deviate from the operating range whe	that causes the moving portion n the servo is off.			
* Two-degree-of-freedom control is enabled. To disable, it is necessary to change Pr6.47:bit and write to the driver.	0 from the setting screen			
Operating range setting				
Protection Functions				
Pr5.12 Overload level[%]	0			
Pr5.13 Overspeed level[r/min]				
	Automatic setting (overspeed			
Pr5.14 Motor mova[0.1 rotation]	10			
Operation limit				
Pr5.04 Over-travel inhibit input s	1: CoE-side (CiA402) deceler 💙			
Operating range				
Use JOG to move to the Max./Mir	n. positions or input a numeric value			
JOG speed[r/min]	60			
JOG acceleratio[ms/JOG speed]	50			
Servo-on Operates o	nly while the button is pressed.			
- direction	to 0 + direction			
Current position	(command unit)			
Minimum position	Maximum position			
[command unit]	[command unit]			
0	0			
				Next

If the set values of the parameters set before tuning are required, save the data before tuning at this point. For details, see Set-up Support Software (PANATERM ver.7) Operating Manual "8.3 Save File".

#### 3.1.2.4.2 Initial Settings

# << Procedure >>

- 1. Starts configuration of initial settings.
  - To set new initial settings

Go to "Step 2".

• To use the contents of a previously saved configuration file

Click on the [Recall conditions] button at the top of the screen to load.

To modify the settings, go to <u>"Step 2"</u>.

If you do not wish to modify the settings, go to <u>"3.1.2.4.3 Adjustment Operation"</u>.

# **One Minute TUNING Settings Screen**

One Minute TUNING				_ 🗆 ×
		1 Settina	2 Execute tuning	Tuning results
			,	
Recall conditions			Advanced setting	IS .
Applications			To perform tuning u	sing operation command settings and operation commands from the host device, or to change the
Positioning/general-purpose			required performan	ce, perform setup using "Advanced settings".
Do not use this function in a mechanism to deviate from the operating range whe	that causes the moving portion n the servo is off.			
* Two-degree-of-freedom control is enabled. To disable, it is necessary to change Pr6.47:bit and write to the driver.	0 from the setting screen			
Operating range setting				
Protection Functions				
Pr5.12 Overload level[%]	0			
Pr5.13 Overspeed level[r/min]				
	Automatic setting (overspeed			
Pr5.14 Motor movaI0.1 rotation	10			
Operation limit				
Pr5.04 Over-travel inhibit input s	1: CoE-side (CiA402) deceler V			
Operating range				
Use JOG to move to the Max/Mir	. positions or input a numeric value			
JOG speed[r/min]	60			
JOG acceleratio[ms/JOG speed]	50			
Servo-on O Aperates o	nly while the button is pressed.			
- direction 🕨 Go	to 0 + direction			
Current position	(command unit)			
C				
Minimum position	Maximum position			
0	0			
				Next

#### **2.** Select the application.

One Minute TUNING			_ 🗆 ×
	1- Setting	2 Execute tuning	Tuning results
Recall conditions <b>Applications</b> O Positioning/general purpose             On out use this function in a mechanism that causes the result of the operating range when the serve is of the observed of the drive.             Operating range setting         Protection functions         Pro5.12 Overload well(b)              Protection functions         Pro5.12 Overload well(b)              Protection functions              Pro5.12 Overload well(b)              Pro5.12 Overload well(b)                    Protection functions               Pro5.12 Overload well(b)              Protection functions              Protection functions	moving partion f, arg screen etting (overspeed this (overspeed but a numeric value ton is pressed. direction Maximum position (command unit)	Execute tuning	Ining rears
			Next

#### **3.** Set the protection functions.

One Minute TUNING	_ 🗆 ×
	Image: Setting         Execute tuning           Tuning results
Recall conditions         Applications         Image: Conditions of the operating range when the save to a diff.         Image: Condition of the operating range when the save to a diff.         Image: Condition of the operating range when the save to a diff.         Image: Condition of the operating range when the save to a diff.         Image: Condition of the operating range when the save to a diff.         Image: Condition of the operating range when the save to a diff.         Image: Condition of the operating range when the save to a diff.         Image: Condition of the operating range when the save to a diff.         Image: Condition of the operating range when the save to a diff.         Image: Condition of the operating range.         Image: Condition of the operating range.         Image: Condition of the operating range.         Use JOG to more to the Max./Min. positions or input a numeric value.         Image: Condition of the operation of the operating range.         Umark: Condition of the operation of the operating range.         M	Advanced settings To perform funing using operation command settings and operation commands from the host device, or to change the required performance, perform setup using "Advanced settings".
	Next

• Pr5.12 "Motor overload level setup" [%]

Sets the motor overload level of effective torque. If this setup value is 0, the motor overload level setup is 115%.

• Pr5.13 "Over-speed level setup" [r/min]

Sets the judgment level for overspeed. Checking the "Automatic setting (overspeed level)" check box sets the automatically set value. Uncheck the box to allow input of setup values. If this setup value is 0, the over-speed level setup is the internal value of the applicable motor.

• Pr5.14 "Motor working range setup" [0.1 rotation]

Sets the amount by which the motor is allowed to move outside the input position command range.

**4.** Sets the operation limit.

One Minute TUNING	×
	Execute tuning Tuning results
Recall conditions         Applications         Image: Conditions         Image: Conditions         Image: Conditions         Image: Conditions         Image: Conditions         Image: Conditions         Posterion Functions         Ph: 12 Overload level[%]         Image: Conditions         Ph: 12 Overload level[%]         Image: Conditions         Ph: 14 Matter move, [0:1 totalion]         Image: Conditions         Ph: 15:0 Over travel inhibit Input s         Ph: 15:0 Over travel inhibit Input s         Ph: 15:0 Over travel inhibit Input s         Image: Conditions         <	Setting     Execute tuning Tuning results
[command unit] [command unit] 0 0	Next

• Pr5.04 "Over-travel inhibit input setup"

Sets the input operations for the over-travel inhibit inputs (POT, NOT).
#### **5.** Sets the operating range.

One Minute TUNING	_ 🗆 ×
	Image: Constraint of the second constraints
Recall conditions         Applications	Setting       Execute tuning Tuning results         Advanced setting:       To perform tuning unicoperation commands strings and operation commands from the host device, or to change the required performance, perform setup using "Advanced settings".
JOG speedly/min) 60 JOG acceleratiomrs/JOG speed[ 50 Servo on A for a constraint of the speed of the spee	Net

The operating range can be set using JOG operation or by entering a numerical value.

- JOG operation method
  - 1 Sets the JOG speed and JOG acceleration and deceleration time.

#### JOG speed

Sets the JOG operation speed.

#### JOG acceleration and deceleration time

Sets the time it takes for the speed of JOG operation to reach the set JOG speed from 0.

- 2 Sets servo-on.
- 3 Press the [+ direction] or [- direction] button to move the motor to both ends of the movable range. The motor runs only as long as the button is pressed, and the values in the "minimum position" and "maximum position" text boxes are updated.
- 4 When the motor has finished moving to both ends of the movable range, click the [Go to 0] button to return the motor to its initial position.

#### – Precautions –

- If oscillation occurs during JOG operation, the value of Advanced settings>Tuning conditions>Tuning start RTAT machine stiffness setting should be lowered before performing the JOG operation.
- Numerical value input method
  - 1 With the current position as 0, enter the positions at both ends of the operable range in the "Minimum position" and "Maximum position" text boxes in command units.

Check that the set values are appropriate beforehand to prevent the moving part from colliding at both ends.

#### – Precautions –

- Set the minimum and maximum positions to provide a sufficiently large operable range. Errors occur when the operable range is small. A setting of 0.5 rotations or more is recommended for the motor rotational amount.
- An error may occur if the set value converted to the motor rotational amount is excessive.

- **6.** Each item in "Advanced settings" has a pre-set recommended value. Normally, the settings can be used as they are.
  - To change the setting, such as to change the required performance, Go to <u>"Step 7"</u>.
  - To proceed with the settings as they are, Go to "3.1.2.4.3 Adjustment Operation".
- 7. Check the "Advanced settings" check box. The advanced settings items are displayed. Change the settings according to your requirements. See <u>"Advanced settings items</u>" below for details of advanced settings items. After completing the settings, go to <u>"3.1.2.4.3 Adjustment Operation"</u>.

When changing the settings of the tuning target during re-adjustment, also refer to <u>"3.1.2.5 Use Cases in Re-adjustment"</u> to change the settings.

One Minute TUNING		- 0
		Image: Setting     Execute tuning     Tuning results
Recall conditions		Advanced settings
Applications		To perform tuning using operation command settings and operation commands from the host device, or to change th
<ul> <li>Positioning/general-purpose</li> </ul>		required performance, perform setup using "Advanced settings".
Do not use this function in a mechanism that of	auses the moving portion	> Detailed protection function
to deviate from the operating range when the	servo is off.	> Required performance
* Two-degree-of-freedom control is enabled.		> Tuning conditions
To disable, it is necessary to change Pr6.47:bit 0 from and write to the driver.	n the setting screen	> Command condition
Operating range setting		
Protection Functions		
Pr5.12 Overload level[%] 0		
Pr5 13 Overspeed level[r/min]		
	1 1 1 1 1 1 1	
<b>∀</b> A	utomatic setting (overspeed	
Pr5.14 Motor mova[0.1 rotation] 10		
Operation limit		
Pr5.04 Over-travel inhibit input s 1: Co	E-side (CiA402) deceler 💙	
Operating range		
Use JOG to move to the Max./Min. posi	tions or input a numeric value	
JOG speed[r/min] 60		
JOG acceleratio[ms/JOG speed] 50		
Servo-on Operates only wh	ile the button is pressed.	
- direction Go to U	+ direction	
Current position [comr	nand unit]	
· · · · · · · · · · · · · · · · · · ·		
[command unit]	[command unit]	
-40000000	40000000	
		Next

# **Advanced Settings Items**

Advanced settings for "Step 7". Configure items as required.

After configuring the settings, go to <u>"3.1.2.4.3 Adjustment Operation"</u>.

Period   Seture   Contract this function as mechanism that causes the moving portion command settings and operation command settings and operation command settings.   Contract this function is a mechanism that causes the moving portion commands.   Contract this function is a mechanism that causes the moving portion commands.   Contract this function is a mechanism that causes the moving portion commands.   Contract this function is mechanism that causes the moving portion commands.   Contract this function is mechanism that causes the moving portion commands.   Contract this function is mechanism that causes the moving portion commands.   Contract this function is mechanism.   Contract this function is mechanism.   Position function:   Position function:<	Dne Minute TUNING	_ 0
Recall conditions     Applications   Postioning/general-purpose To draw this function in a mechanism that causes the moving portion to be drawed from the perpending manage when the serve is off. To draw this function in a mechanism that causes the moving portion to be drawed from the perpending manage when the serve is off. To draw this function in a mechanism that causes the moving portion to be drawed from the perpending manage when the serve is off. To draw the to the drawed manage when the serve is off. To draw the to the drawed manage when the serve is off. To drawe the drawed from the perpending manage when the serve is off. To drawed the drawed from the perpending manage when the serve is off. Perpending range setting Protection functions Prof.14 Motor move0.1 rotation [		Setting Execute tuning Tuning results
Applications	Recall conditions	Advanced settings
We broke this function in a mechanism that causes the moving portion to devide from the operating range when the serve is off.       > Detailed protection function         * Two-dignee-of-freedom control is enabled. To disable, if is necessary to charge Pr6.47.bit 0 from the setting screen and write to the driver.       > Detailed protection function         Operating range setting Pr5.12 Overload level[//min]       0       > Tuning conditions         Protection function Operating range       @ Automatic setting (overspeed       > Tuning condition         Pr5.14 Motor mova[0.1 rotation]       10       Operating range       @ Operates only while the button is pressed.         JOG speed[//min]       £0	Applications	To perform tuning using operation command settings and operation commands from the host device, or to change required performance, perform setup using "Advanced settings".
Concerning the function is a mechanism that causes the moving portion to devide the normatic grange wheth is even is oft. * Two-diagne-of-freedom control is enabled. to disable, if is notecosary to change Pr6A7bit 0 from the setting screen and write to the driver. Operating range setting Pr5.13 Overspeed level(r/min] Pr5.13 Overspeed level(r/min] Pr5.14 Motor mova[0.1 rotation] Operating range Use DG to move to the Max/Min. positions or input a numeric value JOG speed[r/min] JOG acceleratio[ms/JOG speed] JoG acceleratio[ms/JOG speed] JoG acceleration.[ms/JOG speed] Maximum position Kommand unit] Maximum position Kommand unit] Maximum position Kommand unit] Monococo	Positioning/general-purpose	Detailed protection function
<ul> <li>* Nov-degree-of-freedom control is enabled. To diable, it is necessary to change P647/bit 0 from the setting screen and write to the drive.</li> <li>Operating range setting <ul> <li>Protection Functions</li> <li>P65.12 Overload level[0/min]</li> <li>@ Automatic setting (overspeed</li> <li>P5.14 Motor mova[0.1 rotation]</li> <li>@ Automatic setting (overspeed</li></ul></li></ul>	Do not use this function in a mechanism that causes the moving portion to deviate from the operating range when the servo is off.	Required performance
To diable, it is necessary to change Pr647-bit 0 from the setting screen and write to the drive: Operating range setting Protection Functions Pr5.12 Overload level[7ki] Pr5.13 Overspeed level[7kii] Pr5.14 Motor mova[0.1 rotation] Operating range Use DG to move to the Max/Min. positions or input a numeric value JOG speed[7kiii] JOG sceleratio[ms/JOG speed] So Servo of Operation limit Pr5.04 Over-travel inhibit the button is pressed. Current position [command unit] Operation and unit] Mainium position [command unit] Mainium position [command unit] Mainium position [command unit] Mainium position	* Two-degree-of-freedom control is enabled.	> Tuning conditions
Operating range setting         Protection Functions         P5.12 Overload level(/fii)         0         P5.13 Overspeed level(//min)         120         Operating range         Use VoG to mova(D.1 rotation)         10         Operating range         Use VoG to mova(ms/)OG speed]         50         Servor of         Image of the detection         Current position [command unit]         Image of the detection         Current position [command unit]         Image of the detection	To disable, it is necessary to change Pr6.47:bit 0 from the setting screen and write to the driver.	Command condition
Protection functions Pr5.12 Overload level[%] 0 Pr5.13 Overspeed level[%] Pr5.13 Overspeed level[/min] 2 Automatic setting (overspeed Pr5.14 Motor mova[0.1 rotation] 0 Operation limit Pr5.04 Over-travel inhibit input s 1: CoE-side (CIA402) deceler V Operating range Use J/OG speed[//min] 60 J/OG seceleratio[ms/J/OG speed] 50 Servo-on Current position [command unit]	Operating range setting	
Pr5.12 Overload level[%]   0   Pr5.13 Overspeed level[/min]   120   ✓ Automatic setting (overspeed   Pr5.14 Motor mova[0.1 rotation]   10   Operation limit   Pr5.04 Over-travel hibit input s   1: CeE-side (CIA402) deceler ∨   Operation limit   Pr5.04 Over-travel hibit input s   1: CeE-side (CIA402) deceler ∨   Operation limit   Pr5.04 Over-travel hibit input s   1: CeE-side (CIA402) deceler ∨   Obsecoleratio[ms/JOG speed]   50   Servo- on   Current position [command unit]   V   Minimum position [command unit]   400000000	Protection Functions	
Pr5.13 Overspeed level//minj 120	Pr5.12 Overload level[%] 0	
Automatic setting (overspeed P5.14 Motor mova(D.1 rotation) 10 Operation limit P5.04 Over-travel inhibit input s 1:CoE-side (CIA402) deceler Operation grange Use DG5 to move to the Max/Min. positions or input a numeric value JOG speed[r/min] 60 JOG acceleratio[ms/JOG speed] 50 Servor on on on one of the direction Current position [command unit] 4 direction Kasimum position Koommand unit] 400000000	Pr5.13 Overspeed level[r/min] 120	
P/5.14 Motor mova(b).1 rotation[10] Operation limit P/5.04 Over-travel hhibit input s 1: CoE-side (CIA402) deceler v Operating range Use Do to move to the Max/Min. positions or input a numeric value JOG speed[j/min] IOG acceleratio[ms/IOG speed] Servor on O O Operation or post on the the button is pressed. - direction Current position [command unit] Operation of the direction command unit]	Automatic setting (overspec	ed
Operation limit Pf:5.04 Over-travel inhibit input s 1: CoE-side (CDA402) deceler ♥ Operating range Use JOG to move to the Max/Min. positions or input a numeric value JOG speed[/min] 60 JOG acceleratio[ms/JOG speed] 50 Servo-on O O O enters only while the button is pressed. - direction	Pr5.14 Motor movaI0.1 rotation1 10	
Pr5.04 Over-travel inhibit input s 1: CoE-side (CIA402) deceler Operating range Use JOG to move to the Max/Min. positions or input a numeric value JOG speed[//min] 60 JOG acceleratio[ms/JOG speed] 50 Servo-on	Operation limit	
Operating range Use JOG to move to the Max/Min. positions or input a numeric value JOG speed[/r/min] 60 JOG acceleratio[ms/JOG speed] 50 Serve-on C G Operates only while the button is pressed.	Pr5.04 Over-travel inhibit input s 1: CoE-side (CiA402) deceler	v
Use JOG to move to the Max/Min. positions or input a numeric value JOG speed[/r/min] 60 JOG acceleratio[ms/JOG speed] 50 Servo-on O O O erates only while the button is pressed. - direction O o difference of the direction Current position [command unit] - 400000000 Maximum position [command unit] - 400000000	Operating range	
JOG speed[r/min]       60         JOG acceleratio[ms/JOG speed]       50         Servo- on	Use JOG to move to the Max./Min. positions or input a numeric v	alue
JOG acceleratio[ms/JOG speed] 50 Servo- on O O O OPerates only while the button is pressed.      - direction Current position [command unit]      O Minimum position [command unit] 400000000	JOG speed[r/min] 60	
Servo-on Operates only while the button is pressed.	JOG acceleratio[ms/JOG speed] 50	
• direction     • Go to 0     • direction       Current position [command unit]     •       •     •	Servo-on Operates only while the button is pressed.	
Current position [command unit]  Minimum position [command unit]  -400000000	- direction F Go to 0 + direction	
Minimum position [command unit] -400000000 400000000	Current position [command unit]	
Minimum position [command unit] [-400000000 40000000		
Minimum position Maximum position [command unit] [command unit] -400000000 40000000		
-400000000	Minimum position Maximum pos [command unit] [command unit]	ition iti
	-400000000 400000000	

# Detailed Protection Function

This setup value is enabled only during One Minute TUNING execution.

<ul> <li>Detailed protection function</li> </ul>	
	?
Tuning vibration automatic suppression effective level[%]	
Tuning over-speed level setup[r/min] 0	
Tuning torque limit[%] 0	
Tuning JOG test run command speed[r/min] 60	
Tuning JOG test run acceleration and decel[ms/Max speed] 50	

Item	Description
Tuning vibration auto- matic suppression effec- tive level	If oscillation does not subside when auto tuning is in progress, the gain is automatically lowered to stabilize.
	Set the vibration level of the torque to be considered as oscillation by half amplitude value (half of the peak-to-peak value) with the rated torque as 100%.
Tuning overspeed level setting	<ul> <li>Stops the motor if the motor speed becomes excessive when auto tuning is in progress.</li> <li>Sets the speed in units of [r/min] at which the speed is judged to be excessive.</li> <li>If 0, Pr5.13 "Over-speed level setup" set values are used.</li> <li>— Precautions —</li> <li>If the set value is less than 1.11 times the rated speed, the device characteristics measuring accuracy may drop and it may not be possible to perform tuning correctly. If the value has not been changed from the initial value, there is no problem.</li> </ul>

Item	Description
Tuning torque limit	Sets the value for determining torque saturation when auto tuning is in progress. Sets the ratio when the rated torque is 100% in units of [%].
	If 0, setup values enabled by Pr5.21 "Selection of torque limit" are used. For details, see Operating Instructions (Overall) "8.1 Torque Limit Switching Function" .
	<ul> <li>Precautions –</li> <li>If the set value is less than 111% the rated speed, the device characteristics measuring accuracy may drop and it may not be possible to perform tuning correctly. If the value has not been changed from the initial value, there is no problem.</li> </ul>
Tuning JOG test run command speed	Sets the motor speed in [r/min] units when checking the movable range.
Tuning JOG test run ac- celeration and decelera- tion time	Sets the time for acceleration and deceleration of the motor speed when checking the movable range (time from 0 to JOG speed or from JOG speed to 0).

## Required performance

✓ Required performance	
	?
Positioning complete (In-position) range[Command unit]	8400
Target settling time[ms]	0
Settling time count condition	<ul> <li>After completion of command transfer judgment</li> </ul>
	O At start of command transfer judgment
	100
Allowable overshoot amount[%]	

# Example of positioning waveform



Item	Description
Positioning complete (In- position) range	Sets the position deviation (difference between command position and actual position) that determines that positioning is complete.
Target settling time	Sets the target time in [ms] units from the timing of the following settling time count condition until convergence to the positioning complete (in-position) range. If the setup value is 0, the settling time is tuned to be the shortest it can be.
Settling time count con- dition	Selects the timing to be time 0 when calculating the settling time.

Item	Description
Allowable overshoot amount	Sets the maximum allowable position deviation after position deviation reaches 0. Sets this as a percentage of the positioning complete (in-position) range in [%] units.
	<ul> <li>Precautions –</li> <li>The deviation of the command position deviation relative to the command input before position command filter is calculated.</li> </ul>
	For details, see Operating Instructions (Overall) "3.2.8 Wiring to Connector X7 (Connecting to External Monitor)" .

# Tuning conditions

<ul> <li>Tuning conditions</li> </ul>	?	7
RTAT machine stiffness setting at the start of the tuning	Set automatically	
Stability margin[%]	12     Emphasis on balance     80	
Tuning step		
	Advance operation OFF	
	Homing operation	
Tuning target		
	Inertia ratio	
	Unbalanced load compensation	
	Dynamic friction compensation	
	Viscous friction compensation	
	RTAT machine stiffness setting	
	RTAT FF stiffness setting	
	Load fluctuation suppression (disturban ON 🔵	
	Notch filter	
	1st damping filter	
	2nd damping filter	

Item	Description
RTAT machine stiffness setting at the start of the tuning	Configures the real-time auto-tuning machine stiffness setup for auto tuning startup. When tuning for the first time, do not change the setting and use by checking the "Set automatical- ly" check box.
Stability margin	Sets the control tolerance for the tuning results.
	Control tolerance
	Tolerance for changes to the characteristics of machine axes that can be driven stably
	You can choose from the following four items.
	Emphasis on responsiveness: 60%
	Emphasis on balance: 80%
	Emphasis on stability: 100%
	<ul> <li>Manual: The lower slide bar can be used to set any value.</li> </ul>
	The higher the value, the higher the control stability against changes in characteristics, but the lower the suppression against disturbance. When the two-degree-of-freedom control mode is disabled, not only is the suppression of disturbance reduced, but also the command responsiveness. If the set value is 0, the setting is the same as for "Emphasis on balance".

Item	Description
Tuning step	Select whether to perform advance operation and homing operation. If performing these opera- tions, set to "ON".
	Advance operation: Operation to check the operating range
	Homing operation: Operation for moving to the initial position after completion of auto tuning
Tuning target	<ul> <li>The tuning target can be selected arbitrarily. When switched to "ON", the item is subject to tuning. When tuning for the first time, do not change the setting before use.</li> <li>— Precautions —</li> <li>When setting the "Inertia ratio" to "OFF", make sure the appropriate inertia ratio for the device being tuned is set in Pr0.04 "Inertia ratio". If the appropriate inertia ratio is not set in Pr0.04 "Inertia ratio" with inertia ratio excluded from tuning, the correct tuning results may not be obtained.</li> <li>When two-degree-of-freedom control mode is disabled, "Viscous friction compensation" is set to "OFF".</li> </ul>

# Command conditions

<ul> <li>Command condition</li> </ul>	?
Is there an upper command?	• No Yes
Tuning amount of movement[Command unit]	0
Tuning max speed[r/min]	0
Tuning acceleration and deceleration time[ms/Max speed]	0
Tuning wait time[ms]	2000

# Image of the motor operation pattern



Item	Description
Is there an upper com- mand?	Select whether to use an upper command as an operation command during command response measurement.
	The current version of Set-up Support Software (PANATERM ver.7) does not support the "Yes" for upper commands. Only "No" can be selected.
Tuning amount of move- ment	Sets the amount of movement when the motor operation pattern for command response measure- ment in the automatic adjustment process is generated inside the driver.
	If the set value is 0, the servo driver automatically sets the value within the operating range set by <u>"Step 5"</u> .
	- Precautions -
	• Set a value larger than the positioning complete (In-position) range. If it is smaller, an error occurs. The upper-limit value that can be set is 1073741823.

Item	Description
Tuning max speed	Sets the maximum speed when the motor operation pattern for command response measurement in the automatic adjustment process is generated inside the driver.
	If the set value is 0, the servo driver automatically sets the value within the tuning overspeed level setting set in detailed protection function.
	<ul> <li>Precautions –</li> <li>Set a value smaller than the over-speed level setup. If it is larger, an error occurs.</li> </ul>
Tuning acceleration and deceleration time	Sets the acceleration and deceleration time (from 0 to maximum speed or from maximum speed to 0) when the motor operation pattern for command response measurement in the automatic adjustment process is generated inside the driver.
	If the set value is 0, the servo driver automatically sets the value within the range below the tuning torque limit set in detailed protection function.
Tuning wait time	Sets the waiting time between operations when the motor operation pattern for command re- sponse measurement in the automatic adjustment process is generated inside the driver. — Precautions —
	• Set a sufficiently large value for the waiting time so that the previous positioning operation does not affect measurement, and so that measurement can be performed correctly even if settling time during tuning is long. The time that can be set is limited to between 501 and 9000 ms.

After configuring the settings, go to <u>"3.1.2.4.3 Adjustment Operation"</u>.

# 3.1.2.4.3 Adjustment Operation

# << Procedure >>

1. After finishing configuring the <u>"initial settings"</u>, click the [Next] button. This displays the Execute Tuning screen.

## – Precautions –

• If <u>"Step 5</u>" of <u>"3.1.2.4.2 Initial Settings</u>" is not set for the operating range, the [Next] button cannot be clicked.

<complex-block>  Section     Vertice controls     Control freedom control is enabled.        Point control freedom control is enabled.   Sol user freedom control is enabled.   <th>One Minute TUNING</th><th></th><th>_ 🗆 ×</th></complex-block>	One Minute TUNING		_ 🗆 ×
Recall conditions     Applications   Positoning/general-purpose To rot use the function in a machanism that causes the moving portion To degree of freedom control is malded. To degree of freedom control is malded. Detailed porticina functions Positoning general-purpose Positon functions Positoning general-purpose Positoning general-purpose Positoning general-purpose Positon motion position (Contantion general-purpose) Positon functions Positoning general-purpose Positon functions <			1 2 3 Setting Execute tuning Tuning results
<ul> <li>Protection framework in the cause the moving portion to be serve is off.</li> <li>&gt; Non-degree-of-freedom control is enabled.</li> <li>&gt; Non-degree-of-freedom control is enabled.</li> <li>&gt; Non-degree-of-freedom control is enabled.</li> <li>&gt; Operating range setups</li> <li>Protection functions</li> <li>Protection functions&lt;</li></ul>	Recall conditions		Advanced settings To perform tuning using operation command settings and operation commands from the host device, or to change the
<ul> <li>Detailed protection function</li> <li>Detailed protection function</li> <li>Required performance</li> <li>Required performance</li> <li>Turing conditions</li> <li>Command condition</li> </ul>	Positioning/general-purpose		required performance, perform setup using "Advanced settings".
<ul> <li>To detect nom the operating range when the serve sol.</li> <li>Two-degree of-freedom controls is enabled.</li> <li>Tuning conditions</li> <li>Tuning conditions</li> <li>Command condition</li> <li>Comma</li></ul>	Do not use this function in a mechanism	that causes the moving portion	Detailed protection function
To diable, if necessary to change h647bit form the setting screen and write to the driver.         Operating range setting         Protection functions         P5.12 Overload level[th]         0         P5.13 Overspeed level[thin]         100         P5.14 Motor mova[0.1 rotation]         10         Operation finit         P5.04 Over-trade inhibit input s         1: CoE-side (CiA402) deceler ▼         Operation finit         P5.04 Over-trade inhibit input s         1: CoE-side (CiA402) deceler ▼         Operation finit         P6.04 Over-trade inhibit input s         1: Of acceleratio[ms//OG speed]         3: O speed[lymin]         1: O for acceleration[ms//OG speed]         3: O speed[lymin]         1: O for acceleration[ms//OG speed]         1: O for acceleration[ms//OG speed]         1: O for acceleration [command unit]         1: O dococool	* Two degrees of freedom control is probled	en the servo is on.	> Kequired performance
and write to the driver. Operating range setting Protection functions Pr5.12 Oversad level[95] 0 Pr5.13 Overspeed level[97min] 120 Pr5.14 Motor mova[0.1 rotation] 10 Operation limit Pr5.04 Over-travel inhibit input s 1: CoE-side (CIA402) deceler v Operating range Use JOG to move to the Max./Min. positions or input a numeric value JOG speed[//min] 60 JOG sceleratio[mx/JOG speed] 50 Servo-on for for 0 + direction Current position forommad unit] Minimum position [command unit] 400000000	To disable, it is necessary to change Pr6.47:bit	0 from the setting screen	> Tuning conditions
Operating range setting         Protection Functions         Pr5.12 Overload level[%]         0         Pf5.13 Overspeed level[/min]         120         Image: Pf5.14 Motor mova[0.1 notation]         10         Operation limit         Pf5.14 Motor mova[0.1 notation]         10         Operation limit         Pf5.04 Over-travel inhibit input s         12: CoE-side (CiA402) deceler v         Operating range         Use V05 to move to the Max/Min. positions or input a numeric value         JOG speed[/min]         60         JOG acceleratio[ms/JOG speed]         50         Servo-on         Current position [command unit]         Minimum position [command unit]         Minimum position [command unit]         400000000	and write to the driver.		> Command condition
Protection Functions Ph:12 Overload leve[[%] 0 Ph:13 Overspeed level[/min] 120 Ph:14 Motor mova[0.1 rotation] 10 Operation limit Ph:0.4 Over-travel inhibit input s 1: CoE-side (CIA402) deceler V Operating range Use JOG to move to the Max/Min. positions or input a numeric value JOG speed[/min] 60 JOG acceleratio[ms/JOG speed] 50 Servo-on O O O Operates only while the button is pressed. direction e direction of the directio	Operating range setting		
Pr5.12 Overload level[%]       0         Pr5.13 Overspeed level[/min]       120         Image: Contract Setting (overspeed       Pr5.14 Motor mova[0.1 rotation]         Pr5.14 Motor mova[0.1 rotation]       10         Operation limit       Pr5.04 Over-travel inhibit input s         Pr5.04 Over-travel inhibit input s       1: CoE-side (CIA402) deceler           Operation gange       Use JOG to move to the Max/Min, positions or input a numeric value         JOG speed[//min]       60         JOG acceleratio[ms/JOG speed]       50         Servo-on       Correct position [command unit]         Operation limit       + direction         Current position [command unit]       Maximum position [command unit]         Imposition       Command unit]         Imposition       400000000	Protection Functions		
Pr5.13 Overspeed level[r/min] Automatic setting (overspeed Pr5.14 Motor mova[0.1 rotation] 10 Operation limit Pr5.04 Over-travel inhibit input s 1: CoE-side (CIA402) deceler V Operating range Use JOG to move to the Max/Min. positions or input a numeric value JOG speed[r/min] 60 JOG acceleratio[ms/JOG speed] 50 Servo- on	Pr5.12 Overload level[%]	0	
Automatic setting (overspeed Pr5.14 Motor mova[0.1 rotation] Operation limit Pr5.40 Aver-travel inhibit input s Pr5.40 Aver-travel inhibit input s Coperating range Use DG to move to the Max/Min. positions or input a numeric value DG speed[r/min] 60 DG acceleratio[ms/DG speed] 50 Servo-on Current position [command unit] 6 Minimum position [command unit] 400000000 Next	Pr5.13 Overspeed level[r/min]		
Pr5.14 Motor mova[0.1 rotation] 10 Operation limit Pr5.04 Over-travel inhibit input s 1: CcE-side (CA402) deceler V Operating range Use JOG to move to the Max/Min. positions or input a numeric value JOG speed[//min] 60 Servo-on C C operation(ms/JOG speed] 50 Servo-on		Automatic setting (overspeed	
Operation limit Pr5.04 Over-travel inhibit input s 1: CoE-side (CiA402) deceler  Operating range Use JOG to move to the Max/Min. positions or input a numeric value JOG speed[r/min] 60 JOG acceleratio[ms//OG speed] 50 Servo- on  O O O O O O O O O O O O O O O O O O O	Pr5.14 Motor mova[0.1 rotation]	10	
Pr5.04 Over-travel inhibit input s 1: CoE-side (CIA402) deceler  Operating range Use JOG to move to the Max/Min. positions or input a numeric value JOG speed[/min] GO JOG acceleratio[ms/JOG speed] Operates only while the button is pressed.  direction Go to 0 + direction Current position [command unit]  Maximum position [command unit] 400000000 Next	Operation limit		
Operating range Use JOG to move to the Max/Min. positions or input a numeric value JOG speed[//min] 60 JOG acceleratio[ms/JOG speed] 50 Servo-on  Current position [command unit] Current position [command unit] Minimum position [command unit] 400000000 Movet	Pr5.04 Over-travel inhibit input s	1: CoE-side (CiA402) deceler 🗸	
Use JOG to move to the Max/Min. positions or input a numeric value JOG speed[/min] 60 JOG acceleratio[ms/JOG speed] 50 Servo-on C Current position [command unit] Current position [command unit] Current position [command unit] 400000000 Maximum position [command unit] 400000000	Operating range		
JOG speed[//min]       60         JOG acceleratio[ms/JOG speed]       50         Servo-on	Use JOG to move to the Max./Mir	n. positions or input a numeric value	
JOG acceleratio[ms/JOG speed]       50         Servo-on <ul> <li>Go to 0</li> <li>+ direction</li> <li>Current position (command unit)</li> <li> <ul> <li>Maximum position</li> <li>(command unit)</li> <li>400000000</li> <li>400000000</li> </ul> </li> </ul>	JOG speed[r/min]	60	
Servo-on Correctes only while the button is pressed.	JOG acceleratio[ms/JOG speed]	50	
direction     Goto0     + direction      Current position [command unit]     0      Maximum position     [command unit]     [command unit]     400000000     Move  Nevet	Servo-on Operates o	nly while the button is pressed.	
Current position (command unit)	- direction F Go to 0 + direction		
Minimum position [command unit] -40000000 40000000	Current position [command unit]		
Minimum position [command unit] -400000000 400000000			
Minimum position Maximum position [command unit] [command unit] -400000000 40000000			
Loommano uniti         Loommano uniti           -400000000         400000000	Minimum position	Maximum position	
-40000000 40000000	[command unit]	[command unit]	
Next	-4000000	40000000	
			Next

2. Click the [Start] button to start auto tuning and the motor starts moving.

Click the [Back] button to return to the settings screen.

linute TUNING		-		
	1     2       Setting     Execute tuning   Tuning results			
Start     Back       Adjustment start       Step 2 Advance operation       Step 3 Load characteristic measurement       Step 4 Stiffness measurement       Step 5 Command response measurement       Step 6 Homing operation       Adjustment complete	Setting Execute tuning Tuning results			
		N	ext	

# One Minute TUNING Execute Tuning Screen

 Once auto tuning is started, the parameters are tuned based on the <u>"Step 2</u>" to <u>"Step 6</u>" settings of <u>"3.1.2.4.2 Initial Settings</u>" while the motor is running.

If you wish to stop the auto tuning process midway, click the [Stop] button. Clicking the [Stop] button discards all values of parameters being tuned and returns them to the values before tuning started.

One Minute TUNING		_	⊐ ×
	3 Setting Execute tuning Tuning results		
Stop Back			
Adjustment start			
Step 2 Advance operation			
✓ Step 4 Stiffness measurement			
✓ Step 5 Command response measurement			
Step 6 Homing operation			
<ul> <li>Adjustment complete</li> </ul>			
		Nex	t

## One Minute TUNING In Progress Screen

## – Precautions –

- If an error occurs during operation, resolve according to the message. For details on error content, see <u>"7.6 List of Errors Related to One Minute TUNING"</u>.
- Error no. 1537 "Device characteristics measuring error 1" may occur, and the error may not be resolved even after action is taken. In such cases, perform manual tuning. For details on manual tuning, See <u>"3.2 Manual Tuning"</u>.
- If an error occurs during tuning and the machine stops, there is no homing operation for the initial position.
- If power is interrupted when tuning is in progress, the servo driver parameters must be initialized manually.

**4.** Tuning is complete when all steps are checked with a check mark. Click the [Next] button.

		-
	1 2 3 Setting Execute tuning Tuning results	
Start Back		
Adjustment start		
✓ Step 2 Advance operation		
✓ Step 3 Load characteristic measurement		
✓ Step 4 Stiffness measurement		
✓ Step 5 Command response measurement		
✓ Step 6 Homing operation		
<ul> <li>Adjustment complete</li> </ul>		

# One Minute TUNING Completion Screen

The tuning results screen is displayed.

	Name	Unit	Before tuni	After tuning	L	Load characteristic Inertia ratio: 0 [%]     Operation command during training. Amount of mourment 32 554 422 (Command unit). Maximum credit: 1959 (com)
Pr0.02	Real-time auto-gain tunin		1	0	L	Coleration command during tuning Amount of movement: 55,534,452 [Command unit] Maximum speed: 1,535 [[pm]] Acceleration and deceleration time 122 [ms]
Pr0.04	Inertia ratio	%	250	0		■ Tuning performance Positioning complete (In-position) range: 8400 [Command unit] Settling time: 0 [ms] Overshoot amount: 724 [Command unit]
Pr0.27	Selection of machine stiffn		16	29		> Detailed measurement results
Pr0.28	Selection of feed forward		16	31		
Pr1.00	1st gain of position loop	0.1/s	480	1850		
Pr1.01	1st velocity loop gain	0.1Hz	270	1025		
Pr1.02	1st velocity loop integrati	0.1ms	210	70		
Pr1.03	1st filter of velocity detect		0	0		
Pr1.04	1st torque filter time cons	0.01ms	10	10		
Pr1.05	2nd gain of position loop	0.1/s	480	1850		
Pr1.06	2nd velocity loop gain	0.1Hz	270	1025		
Pr1.07	2nd velocity loop integrati	0.1ms	210	70		
Pr1.08	2nd filter of velocity detec		0	0		
Pr1.09	2nd torque filter time con	0.01ms	10	10		
Pr1.10	Velocity feed forward gain	0.1%	1000	1000		
Pr1.11	Velocity feed forward filter	0.01ms	0	0		
Pr1.12	Torque feed forward gain	0.1%	1000	1000		

## 3.1.2.4.4 Confirming Tuning Results, Ending One Minute TUNING

The left side of the tuning results screen displays the parameters before and after tuning. A summary is displayed in the upper right-hand corner of the tuning results screen.

					1 3 Setting Execute tuning Tuning results
	Name	Unit	Before tuni	After tuning	Load characteristic Inertia ratio: 0 [%]
Pr0.02	Real-time auto-gain tunin		1	0	<ul> <li>Operation command during tuning Amount of movement: 33,554,432 [Command unit] Maximum speed: 1,959 [rpm] Acceleration and deceleration time 122 [ms]</li> </ul>
Pr0.04	Inertia ratio	%	250	0	<ul> <li>Tuning performance Positioning complete (In-position) range: 8400 [Command unit] Settling time: 0 [ms]</li> <li>Overshoot amount: 724 [Command unit]</li> </ul>
Pr0.27	Selection of machine stiffn		16	29	> Detailed measurement results
r0.28	Selection of feed forward		16	31	> Graph
Pr1.00	1st gain of position loop	0.1/s	480	1850	
Pr1.01	1st velocity loop gain	0.1Hz	270	1025	
Pr1.02	1st velocity loop integrati	0.1ms	210	70	
Pr1.03	1st filter of velocity detect		0	0	
Pr1.04	1st torque filter time cons	0.01ms	10	10	
Pr1.05	2nd gain of position loop	0.1/s	480	1850	
Pr1.06	2nd velocity loop gain	0.1Hz	270	1025	
Pr1.07	2nd velocity loop integrati	0.1ms	210	70	
Pr1.08	2nd filter of velocity detec		0	0	
Pr1.09	2nd torque filter time con	0.01ms	10	10	
Pr1.10	Velocity feed forward gain	0.1%	1000	1000	
Pr1.11	Velocity feed forward filter	0.01ms	0	0	
Pr1.12	Torque feed forward gain	0.1%	1000	1000	

#### **One Minute TUNING Results Screen**

# << Procedure >>

**1.** To see details of the tuning results, click ">" in "> Detailed measurement results" to expand details of the measurement results.

One Minut	e TUNING				_   ×
					Setting     Execute tuning Tuning results
	Name	Unit	Before tuni	After tuning	■ Load characteristic Inertia ratio: 0 [%]
Pr0.02	Real-time auto-gain tunin		1	0	<ul> <li>Operation command during tuning Amount of movement: 33,554,432 [Command unit] Maximum speed: 1,959 [rpm]</li> <li>Acceleration and deceleration time 122 [ms]</li> </ul>
Pr0.04	Inertia ratio	%	250	0	Tuning performance Positioning complete (In-position) range: 8400 [Command unit] Settling time: 0 [ms] Overshoot amount: 724 [Command unit]
Pr0.27	Selection of machine stiffn		16	29	Detailed measurement results
Pr0.28	Selection of feed forward		16	31	Justic mornauon     Tuning conditions
Pr1.00	1st gain of position loop	0.1/s	480	1850	Load characteristic
Pr1.01	1st velocity loop gain	0.1Hz	270	1025	Operation command     Tuning performance
Pr1.02	1st velocity loop integrati	0.1ms	210	70	> Protection Functions
Pr1.03	1st filter of velocity detect		0	0	
Pr1.04	1st torque filter time cons	0.01ms	10	10	
Pr1.05	2nd gain of position loop	0.1/s	480	1850	
Pr1.06	2nd velocity loop gain	0.1Hz	270	1025	
Pr1.07	2nd velocity loop integrati	0.1ms	210	70	
Pr1.08	2nd filter of velocity detec		0	0	
Pr1.09	2nd torque filter time con	0.01ms	10	10	
Pr1.10	Velocity feed forward gain	0.1%	1000	1000	
Pr1.11	Velocity feed forward filter	0.01ms	0	0	
Pr1.12	Torque feed forward gain	0.1%	1000	1000	> Graph
	i	1	1	1	Save results Complete

Click ">" by each item displayed to expand it, allowing you to check detailed information on tuning conditions and tuning performance.

Item	Check item
Basic information	Date and time of measurement
	Driver information (Model No., Serial No.)
	Motor information (Model No., Serial No.)
Tuning conditions	Set in initial setting.
	Application
	Positioning complete (In-position) range
	Target settling time
	Settling time count condition
	Allowable overshoot amount     Stability margin
	RTAT machine stiffness setting at the start of the tuning
	Tuning step (advance operation, homing operation)
	Tuning target (inertia ratio, etc.)
Load characteristics	Calculated during the adjustment process.
	Inertia ratio
	Unbalanced load
	Dynamic friction torque
	Viscous friction torque
	Resonance frequency
	Vibration frequency
Operation command	Set in initial setting.
	Tuning Amount of movement
	• Tuning Max speed
	Iuning Acceleration and deceleration time     Tuning Weit time
	Command time
	Command speed (maximum)
	Command speed (maximum)     Command speed (minimum)
	Command amount of movement
Tuning performance	Measured during the adjustment process.
	Settling time
	Overshoot amount
	INP change count
	Vibration level
	Effective load factor
	• Takt
	Velocity zero cross count
	Motor speed (maximum)     Motor speed (minimum)
	Torque command (maximum)
	Torque command (minimum)
	Position deviation (maximum)
	Position deviation (minimum)
	Fine vibration count
	INP change count at settling time
	Regenerative load factor

Item	Check item
Protection functions	Set in initial setting.
	Tuning vibration automatic suppression effective level
	Tuning operating range upper limit
	Tuning operating range lower limit
	Tuning over-speed level setup
	Tuning torque limit

 To save the settings and information on the adjustment process (<u>"3.1.2.4.2 Initial Settings"</u> to <u>"3.1.2.4.3 Adjustment Operation"</u>) to a file, click the [Save results] button. A save file dialog box opens. Set the folder to save to and the file name, and save the file.

To end One Minute TUNING, click the [Complete] button.

One Minut	e TUNING					_ 🗆 ×
						1     2     3       Setting     Execute tuning     Tuning results
	Name	Unit	Before tuni	After tuning		Load characteristic Inertia ratio: 0 [%]     Operation command during tuning Amount of movement: 33,554,432 [Command unit] Maximum speed: 1,959 [rpm]
Pr0.02	Real-time auto-gain tunin		1	0	L	Acceleration and deceleration time 122 [ms] Tuning performance Positioning complete (In-position) range: 8400 [Command unit] Settling time: 0 [ms]
Pr0.04	Inertia ratio	%	250	0	L	Overshoot amount: 724 [Command unit]
Pr0.27	Selection of machine stiffn		16	29		Detailed measurement results     Graph
Pr0.28	Selection of feed forward		16	31		
Pr1.00	1st gain of position loop	0.1/s	480	1850		
Pr1.01	1st velocity loop gain	0.1Hz	270	1025		
Pr1.02	1st velocity loop integrati	0.1ms	210	70		
Pr1.03	1st filter of velocity detect		0	0		
Pr1.04	1st torque filter time cons	0.01ms	10	10		
Pr1.05	2nd gain of position loop	0.1/s	480	1850		
Pr1.06	2nd velocity loop gain	0.1Hz	270	1025		
Pr1.07	2nd velocity loop integrati	0.1ms	210	70		
Pr1.08	2nd filter of velocity detec		0	0		
Pr1.09	2nd torque filter time con	0.01ms	10	10		
Pr1.10	Velocity feed forward gain	0.1%	1000	1000		
Pr1.11	Velocity feed forward filter	0.01ms	0	0		
Pr1.12	Torque feed forward gain	0.1%	1000	1000		
						Save results Complete

A confirmation dialog box is displayed asking if you want to write the parameters from the tuning results to EEPROM.

- Click the [Yes] button to end One Minute TUNING with parameters written to EEPROM.
- Click the [No] button to end One Minute TUNING without parameters written to EEPROM.
- Click the [Cancel] button to close the confirmation dialog box and return to the tuning results screen.

			$\times$
Tuning will be finished. Are you sure you want to stop real-time	auto-tuning and wr	rite the adjusted para	meters to EEPROM?
	Yes	No	Cancel

# 3.1.2.5 Use Cases in Re-adjustment

With One Minute TUNING, if there is a change in the device workpiece or position, only specific items can be auto tuned again.

Read out a previously saved configuration file, configure the appropriate settings for the tuning target in <u>"Advanced</u>" (<u>"3.1.2.4.2 Initial Settings"</u> (<u>"Step 6"</u> onward), and execute One Minute TUNING.

The table below shows reasons for re-adjustment and examples of setting items to be turned ON for tuning at that time.

Reason for re-adjustment	Re-adjustment method	ON setting items to be tuned
A component of the device mov- ing part was changed.	Settings such as inertia ratio and machine stiffness require re-adjusting due to inertia fluctuations.	<ul> <li>Inertia ratio</li> <li>RTAT machine stiffness setting</li> <li>RTAT FF stiffness setting</li> <li>Load fluctuation suppression</li> <li>Notch filter</li> </ul>
Vibration as a result of a change in position.	Re-adjust damping control (damping filter) to suppress vibration.	<ul> <li>RTAT FF stiffness setting</li> <li>Load fluctuation suppression</li> <li>1st damping filter</li> <li>2nd damping filter</li> </ul>
Abnormal noise occurred due to aging.	Re-adjust the notch filter to suppress me- chanical resonance.	<ul><li>Load fluctuation suppression</li><li>Notch filter</li></ul>

# 3.1.3 precAlse TUNING

## 3.1.3.1 Function Overview

This function automatically tunes various parameters while the motor is running, with AI determining the motor response.

It is effective for tuning devices that are difficult to tune and require tuning by skilled operators. The tuning results are expected to exceed those of skilled operators.

This is also effective for reducing operator labor hours, because it performs automatic operation using Set-up Support Software (PANATERM ver.7) after initial setting of target performance and multiple operation patterns, etc.

## 3.1.3.2 Operational Conditions

Item	Operational Conditions
Control mode	Position control and two-degree-of-freedom control mode enabled
Real-time auto tuning control type	Two-degree-of-freedom Control Mode for Standard Type
Load fluctua- tion control function	<ul> <li>The load fluctuation control function is enabled and load fluctuation compensation gain is 90 % or more</li> <li>Load fluctuation control function disabled</li> </ul>
Other	Set-up Support Software (PANATERM ver.7) is required.

### – Precautions -

- The motor rotates during execution of this function. Be careful not to contact moving parts.
- Tuning results that satisfy the required performance may not be obtained. In such cases the tuning results judged to be the best are displayed.
- This tuning changes the values of many parameters. If you need the values before tuning, save the data beforehand.
- Depending on the initial parameter settings, the following may occur when tuning is in progress. Initial settings must be configured to ensure the motor operates properly.
  - The motor operates in an unintended position, direction, or amount of movement (for example, when the rotational direction setup is incorrect)
  - he motor oscillates (for example, when the maximum value of the tuning range for the parameter to be tuned is too large)
  - Al set values are not reflected (for example, when the mode is one in which the parameter to be tuned is automatically set)
  - An alarm is triggered and tuning is aborted (For example, when the detection level of the protection function is set too low. If an alarm is triggered and the response in the initial settings is unclear, please contact us.)
- Depending on what the parameters are when the tuning is initiated, oscillation may occur while the tuning is in progress. Please use OneMinuteTUNING or similar software to perform tuning beforehand to ensure that no oscillation occurs with all the operation patterns that will be set and that they all operate normally.

# 3.1.3.3 Parameters That Are Automatically Set and Automatically Tuned

Parameters selected in *<u>"Initial settings"</u> ("Step 2")* in the usage instructions

## 3.1.3.4 Usage

Instructions for use are described according to the following steps.

- 1 <u>"Starting the Tuning Function"</u>
- 2 <u>"Initial Settings</u>"
- 3 <u>"Adjustment Operation"</u>
- 4 <u>"Confirming Tuning Results, Ending precAlse TUNING"</u>

## 3.1.3.4.1 Starting the Tuning Function

# << Procedure >>

- **1.** Check that Pr0.01 "Control mode setup" is set to position control mode for operational conditions.
- 2. Activate Set-up Support Software (PANATERM ver.7).
- 3. Select one device that you want to tune in the device tree and click the "Tuning" tab.

8	<i>w</i>									
	File(F)	Troubleshooting(T)	Help(H)							_
			E Device tree			ôð Setting	嬰 Monitor	比 Logging	🕞 Tuning	🚺 Device Info
		-	MINAS A7BR				EtherCAT object	IO Setting	Alarm	Analog input
C	<b>9</b> ~	Online	Axis0_No name set	SRV-OFF						
		USB	MADN085BRU 23080001			Open file	Save file	Copy Load initia	values Load	Write
		NL.		Encoder Info				Config Reset		se searc
			MINAS A78K MHMG022U1A2 24020001	33403700 pulse	•	Search	Compa	rison None	✓ Add/delete d	column
						Switch to HEX input	Display A6-compati	ible control parameters	Allow out-of-range setting	ngs

4. In the "Tuning" tab screen, select "precAIse TUNING", and click the [Go to the Tuning screen] button.



The "precAIse TUNING" settings screen is displayed.

ecAlse TUNING												
				1		2	3					
				Setting	Execut	e tuning	Tuning results					
Load tuning conditions	Check past results	Tuning based or	past history Save	tuning condi	tions							
<ul> <li>Evaluation method setti</li> </ul>	ing					✓ Conc	lition setting					
Evaluation target	Servo data	~	Advanced sensor se	tting:		Comma	nd input mode	Он	ost device			
Evaluation data compensation	tion Offset amount			[96]				P#	NATERM trial run	Trial	run pattern settings	]
	Average number	of points moved										
Evaluation metric	Settling width		8400	Com	mand unit							
	Settling time		0.000	[ms]								
Evaluation time/operation	count O Evaluation ti	me		[min]								
	Operation of the ope	ount	1000	[time	s]							
Measurement item Position command speed	Evaluation target [r/min]	Edit	Sampling cycle [ms] [ [	0.7500			Measurement tin	ne [ms] 7	67.25			
Torque command[%]			Trigger condition 1 o	or 2 🗸 🗸	Trigger p	oosition 1,	8 ~					
Analog input[V]	tion[Command unit]	- T	The second Development	Target		Level		Slope		lter		
Encoder position deviatio	n[Encoder unit]	_	Trigger 1 Position command speed[r/min]  Trigger 2 Position command speed[r/min]			-50 Falling down		~	No use	~		
<ul> <li>Parameter setup</li> <li>Parameter class</li> </ul>	All parameters	✓ () Depe	ending on parameter s	ettings, AI set	values may r	not be refle	cted or the motor n	nay oscill	ate. See the Techn	ical Reference to ensu	ire that each control	function operates
funing target Class No.	Name			Unit	Initial Valu	16	Tuning range			Tuning step width		
✓ 0 27	Selection of machine st	iffness at real-time	auto-gain tuning 2		29		0	~ 4	4	1		
Pr0.27 Selection of ma nput range: 0 - 44 When Pr2.45 "Function exp	achine stiffness at r	eal-time auto- = 1,	gain tuning 2									
												Go to tuning

#### 3.1.3.4.2 Initial Settings

#### << Procedure >>

- **1.** Starts configuration of initial settings.
  - To set new initial settings

Go to <u>"Step 2"</u>.

• To use the contents of a previously saved configuration file

Perform one of the following operations before proceeding to <u>"Step 3"</u>.

• To use the contents of a previously saved tuning condition setup file Click on the [Load tuning conditions] button to load that file.

To check previously saved tuning results

Click on the [Check past results] button to load that file.

• To start tuning based on previously saved tuning results

Click on the [Tuning based on past history] button to load that file. If tuning is aborted due to a problem, tuning can be resumed using past history files saved up to that point.

### precAlse TUNING Settings Screen

precAlse TUNING								×
Image: Setting     Execute tuning     Tuning results								
Load tuning conditions Check past results Tuning	based on past history Save	tuning conditions						
<ul> <li>Evaluation method setting</li> </ul>			✓ Condition setting					
Evaluation target Servo data	Advanced sensor set	ting:	Command input mode	Оно	ost device			
Evaluation data compensation Offset amount		[%]		💿 PA	ANATERM trial run	Trial	run pattern settings	
Average number of poin	ts moved 1							
Evaluation metric Settling width	8400	Command unit						
Settling time	0.000	[ms]						
Evaluation time/operation count O Evaluation time		[min]						
Operation count	1000	[times]						
Waveform measurement conditions Measurement item     Studiation target Position command speed[r/min] Torque command[%]	Edit Sampling cycle [ms]	0.7500 	Measurement f	time [ms] 7	67.25			
Command position deviation[Command unit]	•	Target	Level			Slope	Filter	
Encoder position deviation[Encoder unit]	Trigger 1 Position con	nmand speed[r/min] ~	✓ 50		Rising up 🗸		No use	~
	Trigger 2 Position con	nmand speed[r/min] ~	-50		Falling down	~	No use	<u> </u>
Parameter setup Parameter class All parameters	Parameter setup Parameter class     All parameters     O     Depending on parameter settings. All set values may not be reflected or the motor may oscillate. See the Technical Reference to ensure that each control function operates     correctly.							
Tuning target Class No. Name		Unit Initial Va	lue Tuning range			Tuning step width		
✓ 0 27 Selection of machine stiffness a	t real-time auto-gain tuning 2	29	0	4	4	1		
Pr0.27 Selection of machine stiffness at real-tim Input range: 0 - 44 When Pr2.45 "Function expansion setup 10" bit 5 = 1,	ne auto-gain tuning 2							
							Go to tur	aing

2. To set new tuning conditions, set the following. After completing the settings, go to "Step 3".

# Evaluation method setting

<ul> <li>Evaluation method setting</li> </ul>			
Evaluation target	Servo data 🗸 🗸	Advanced sensor setting:	
Evaluation data compensation	Offset amount	0	[%]
	Average number of points moved	1	
Evaluation metric	Settling width	8400	Command unit
	Settling time	0.000	[ms]
Evaluation time/operation count	O Evaluation time	10	[min]
	Operation count	1000	[times]

n target Se • is [Ma Wr Wr Wr is s var	elect data to be used is automatically assig leasurement items]. hen "Servo data" is so hen "Analog sensor" selected, click the [Ad	for performance evalua ned to the evaluation ta elected, the target data	tion (servo data, a arget in [Waveform	nalog sensors).								
● is [Me Wh Wh is s var	s automatically assig easurement items]. hen "Servo data" is s hen "Analog sensor" i selected, click the [Ad	ned to the evaluation ta	arget in [Waveform	Select data to be used for performance evaluation (servo data, analog sensors).								
Wh Wh is s var	hen "Servo data" is so hen "Analog sensor" i selected, click the [Ao	elected, the target data	• is automatically assigned to the evaluation target in [Waveform measurement conditions] - [Measurement items].									
Wh is s var	hen "Analog sensor" i selected, click the [Ac		When "Servo data" is selected, the target data is command position deviation.									
	When "Analog sensor" is selected, the target data is the analog input. When "Analog sensor" is selected, click the [Advanced sensor settings] button and enter specifications from the "Advanced sensor settings" screen.											
~	<ul> <li>Evaluation method setting</li> </ul>											
E	Evaluation target	Analogue sensor 🗸	Advanced sensor setting:									
E	valuation data compensation	Offset amount	10	[%]								
		Average number of points moved	9	]								
E	Evaluation metric	Settling width	0.000	[V]								
		Settling time	0.000	[ms]								
E	Evaluation time/operation count	O Evaluation time	10	[min]								
		<ul> <li>Operation count</li> </ul>	1000	[times]								
	,	j bullon to apply the se	ttling width on the	settings screen.								
Ad It a	dvanced sensor settings t register the correspondence and calculate the tuning range	between the analog output volta for the analog input value [V] co	tuing wigth on the sensor and the r	settings screen. × measured value,								
Ad It au	dvanced sensor settings t register the correspondence and calculate the tuning range Sensor specifications	between the analog output volta for the analog input value [V] co	tuing width on the sensor and the normal sensor and the sensor and the normal sensor.	settings screen.								
Ad It au	dvanced sensor settings t register the correspondence and calculate the tuning range Sensor specifications	between the analog output volta for the analog input value [V] co Measured value [mm]	uing wigth on the rige of the sensor and the rige of the sensor and the right of the	settings screen.								
Ad It a	dvanced sensor settings t register the correspondence and calculate the tuning range Sensor specifications Maximum value	between the analog output volta for the analog input value [V] co Measured value [mm] 1.0000	ige of the sensor and the inversion. Analog output vo 10.500	settings screen.								
Ad It au	dvanced sensor settings t register the correspondence and calculate the tuning range Sensor specifications Maximum value Minimum value	between the analog output volta for the analog input value [V] co Measured value [mm] 1.0000 -1.0000	tuing width on the response of the sensor and the response of the respo	settings screen.								
Ad It au	dvanced sensor settings t register the correspondence and calculate the tuning range Sensor specifications Maximum value Minimum value Evaluation metric	between the analog output volta for the analog input value [V] co Measured value [mm] 1.0000 -1.0000	ige of the sensor and the inversion. Analog output vo 10.500 0.000	settings screen.								
Ad It au	dvanced sensor settings t register the correspondence and calculate the tuning range Sensor specifications Maximum value Minimum value Evaluation metric Settling width[µm]	between the analog output volta for the analog input value [V] co Measured value [mm] 1.0000 -1.0000 50.0	tuing width on the response of the sensor and the response of the res	settings screen.								
Ad It a	dvanced sensor settings t register the correspondence and calculate the tuning range Sensor specifications Maximum value Minimum value Evaluation metric Settling width[µm] Settling width[V]	between the analog output volta for the analog input value [V] co Measured value [mm] 1.0000 -1.0000 50.0 0.262	tuing width on the analog output vo	settings screen.								

Item	Description
Evaluation data com- pensation	This item can be set when "Analog sensor" is selected, and it sets the measurement data compensation value.
	Offset amount [%]
	Sets the percentage of data used for offset calculation relative to the entire measured set- ting time waveform data (for automatic calibration of analog sensor data).
	Average number of points moved
	Sets the number of movement averaging data points for measured waveform data.
Evaluation metric	Sets the target values for settling width and settling time.
Evaluation time/opera-	Sets the upper limit for the operation count or evaluation time.
tion count	- Precautions -
	<ul> <li>In the current version of Set-up Support Software (PANATERM ver.7), only "operation count" can be selected.</li> </ul>
	<ul> <li>The actual operation count will be less than the set operation count due to the adjust- ment algorithm.</li> </ul>
	The set upper limit value is displayed in the operation count [times] denominator on the Execute Tuning screen.
tion count	<ul> <li>Precautions –</li> <li>In the current version of Set-up Support Software (PANATERM ver.7), only "operation count" can be selected.</li> <li>The actual operation count will be less than the set operation count due to the adjument algorithm.</li> <li>The set upper limit value is displayed in the operation count [times] denominator or Execute Tuning screen.</li> </ul>

## Waveform measurement conditions

<ul> <li>Waveform measurement conditions</li> </ul>								
Measurement item	Edit Sampling cycle [ms] 0.25	Measurement time [ms] 25	55.75					
Position command speed[r/min] Torque command[%]	Trigger condition 1 or 2 V Trig	Trigger condition 1 or 2 V Trigger position 1/8 V						
Analog input[V]	Target Trigger 1 Position command speed[r/min]	V 50	Slope Rising up	Filter				
	Trigger 2 Position command speed[r/min]	-50	Falling down 🗸	No use 🗸				
Item		Description						

Item	Description
Measurement item	This displays the measurement items. Measurement items can be added or deleted in the "Edit measurement items" dialog box that is displayed when the [Edit] button is clicked. For the editing method, see Set-up Support Software (PANATERM ver.7) Operating Manual. Default items cannot be deleted.
Sampling cycle, trigger- related setting items	<ul> <li>See Set-up Support Software (PANATERM ver.7) Operating Manual.</li> <li>Precautions — <ul> <li>Set the sampling cycle so that the evaluation metric (settling time) can be determined within the measurement time.</li> </ul> </li> </ul>

# Parameter setup

✓ Parameter setup									
Paramete	Parameter dass All parameters 🗸 Depending on parameter settings, Al set values may not be reflected or the motor may oscillate. See the Technical Reference to ensure that each control function operates correctly.								
Tuning ta	rget	Class	No.	Name	Unit	Initial Value	Tuning range	Tuning step width	
✓	0 28 Selection of feed forward stiffness at real-time auto-gain tuning		31	0 ~ 44	1				
	1         00         1st gain of position loop         0.1/s         1850         0         ~ 30000         1								
Pr0.28 Selection of feed forward stiffness at real-time auto-gain tuning									
Input range: 0 - 44									
When Pr	2.45 "F	Functio	n exp	pansion setup 10":bits 5 and 4 = 11b, the feedforward stiffness is	set when real-t	time auto tuning is e	ecuted.		

Item	Description
Parameter setup	Select the parameters to be tuned.
	The "Parameter class" drop-down list allows only "All parameters" to be selected.
	A list of parameters is displayed at the bottom of the screen.
	Select the parameter to be tuned by checking the "Tuning target" check box, and enter the "Initial value", "Tuning range" and "Tuning step width" in the text boxes.
	- Precautions -
	<ul> <li>At least one parameter should be set as a tuning target.</li> </ul>
	<ul> <li>Tuning can be performed without changing the setting values. Changing the tuning range, tuning target, or initial value may cause the motor to oscillate.</li> </ul>

# Condition setting

<ul> <li>Condition setting</li> </ul>						
Command input mode	O Host device					
	PANATERM trial run     Trial run pattern settings					
Item	Description					
Command input mode	Set the command generation means.					
	<ul> <li>Precautions –</li> <li>In the current version of Set-up Support Software (PANATERM ver.7), only "PANA- TERM trial run" can be selected.</li> </ul>					

# Configure the advanced settings from the [Trial run pattern settings] button.

# Condition setting - Trial run pattern settings screen

Trial run pattern settings								×
		6		2				
		Tuning s	ettings Op	eration settings				
Protection Functions					1		1	_
Pr5.12 Overload level[%]	0	Operation No.	Start position	End position	Amount of movement	Target speed	Acceleration and deceleration time Operation	atin (i
Pr5.13 Overspeed level[r/min]	120	1	0	0	0	1	1	
	Automatic setting (overspeed lev							
Pr5.14 Motor movable[0.1 rotation]	10				( <b>2</b> )			
Operation limit					(2)			
Pr5.04 Over-travel inhibit input setup	1: CoE-side (CiA402) deceleratio 🗸							
Operating range Use JOG to move to the Max./Min. p	ositions or input a numeric value							
JOG speed[r/min]	60							
JOG acceleration a[ms/JOG speed]	50							
Servo-on Operates only  - direction Generation  Minimum position [command unit] 0 Trouble								
							To trial run pattern setting	js
(1) Set the prote	ctive function and ope	rable rang	e for trial i	run.				
(2) The paramet	ers of the operation co	mmand fo	r which th	e respon	se is to be ev	aluated	are displayed.	
To edit, click the [To trial run pattern settings] button at the bottom, which becomes active when the operating range is set in (1), and then click the button to display the screen (next figure).								

Trial run pattern settings									×
• •									
Tuning settings Operation settings									
Protection Functions         Pr512 Overfoad level(%)         0         Add						Add Delete			
Pr5.13 Overspeed level[r/min]         0           Pr5.14 Motor movable. (0.1 rotation)         10	Operation No.	Start position [Command unit]	End position [Command unit]	Amount of movement [Command unit]	Target speed [r/min]	Acceleration and deceleration time [ms]	Operating wait time [ms]	Preliminary speed [r/min]	Preliminary acceleration and deceleration time [ms]
· · · · · · · · · · · · · · · · · · ·	1	0	1000	1000	3000	100	2000	200	100
	2	0	2000	2000	3000	100	2000	200	100
	3	0	5000	5000	3000	100	2000	200	100
	4	0	10000	10000	3000	100	2000	200	100
	5	0	20000	20000	3000	100	2000	200	100
	6	0	50000	50000	3000	100	2000	200	100
Servo-on Correction Contraction Contractio									
Back									End

Different trial run patterns can be added or deleted by clicking the [Add] and [Delete] buttons. Please refer to the following example of a trial run pattern when setting.

The maximum number of trial run patterns that can be set is 100. The amount of movement can be automatically calculated by entering the start and end positions. When finishing configuring the settings, click the [End] button.

#### – Precautions –

• In all trial run patterns, the amount of movement must be greater than or equal to 1.

### Example trial run pattern



Once finished configuring the settings for tuning conditions, go to "Step 3".

**3.** To save the settings configured in <u>"Step 1"</u> or <u>"Step 2"</u>, click the [Save tuning conditions] button. A save file dialog box opens. Set the folder to save to and the file name, and save the file.

After finishing the tuning condition setup, click the [Go to tuning] button in the lower right-hand corner of the screen.

precAlse TUNING											×
Setting Execute Luning Tuning results											
Load tuning conditions Che	ck past results Tuning based or	past history Save tu	ning condition	ns							
<ul> <li>Evaluation method setting</li> </ul>	v Evaluation method setting										
Evaluation target	Servo data 🗸	Advanced sensor setti	ng:		Com	imand inp	ut mode (	Host device			
Evaluation data compensation	Offset amount		1961				6	PANATERM trial run	Trial nun patte	m settings	
	Average number of points moved		(*)						martaripatte	in actinga	
Evaluation metric	Settling width	8400	Commo	nd unit							
Evaluation metric	Setting wider	0.000									
	Settling time	0.000	[ms]								
Evaluation time/operation count	O Evaluation time		(min)								
	<ul> <li>Operation count</li> </ul>	1000	[times]								
Measurement item • E Position command speed[r/min Torque command[%]	ivaluation target Edit	Sampling cycle [ms] 0.7	*500 ! ~	Trigger position 1	Measuremen	t time (m:	s] 767.25				
Command position deviation[Co	ommand unit]		Target			Leve	ы		Slope		Filter
Encoder position deviation/Enco	oder unit]	Trigger 1 Position com	mand speed[r/	'min] ~	50			Rising up	~	No use	~
		Trigger 2 Position com	mand speed[r/	'min] ~	-50			Falling down	~	No use	~
Parameter setup Parameter setup Parameter setup All parameters     V Depending on parameter settings, Al set values may not be reflected or the motor may oscillate. See the Technical Reference to ensure that each control function operates correctly.											
Tuning target Class No. Name	e	u	nit	Initial Value	Tuning range			Tuning step width			
✓ 0 28 Select	tion of feed forward stiffness at real-	time auto-gain tuning		16	0	~	44	1			
Pr0.28 Selection of feed for	rward stiffness at real-time a	uto-gain tuning									
Input range: 0 - 44											
											Go to tuning

The screen switches to the Execute Tuning screen.

precAlse TUNING			×
	1 2 3 Setting Execute tuning Tuning results		
Settling time measurement data	Parameters		Waveform graph
Execute tuning Progress	Current operating conditions	100	100
Start Stop Status Elapsed time Operation count	Operation No.	0	
Refore tuning 0:00 0	Operation direction		
Verbre torining 0.00 /0	Amount of movement [Command unit]	0 90 -	90 -
Attempts [times] Select to check the settling time.	Max speed [r/min]	0	
Settling time(ms) Attempts (times)	Acceleration and deceleration time [ms/Max speed]	0 80 -	80 -
- Current evaluation value -	Display only parameters with differences		
- 🔶 Best evaluation value -	Name Unit Current	◆ Best 70 -	70 -
Percet direlay range	Number of trials Times 0	0	
Neset usping range		60 -	E 60 -
		Ę	
		veform	d sbee
0.8	4	50 - 5	50 -
		aluati	5
· · · · · · · · · · · · · · · · · · ·		<sup>40</sup> –	
<u><u><u></u><u></u><u></u><u></u><u></u><u></u><u></u><u></u><u></u><u></u><u></u><u></u><u></u><u></u><u></u><u></u><u></u><u></u></u></u>			
ي بو بو		30 -	30 -
B 0.4			
· · · · · · · · · · · · · · · · · · ·			
		20 -	20 -
0.2			
		10 -	10 -
0 0.2 0.4 0.6 0.8 1		0	0
Number of trials [times]			0 20 40 60 80 100 Elapsed time[ms]
Bark			Go to result
			Gotoresur

Go to <u>"3.1.3.4.3 Adjustment Operation"</u>.

### 3.1.3.4.3 Adjustment Operation

### << Procedure >>

1. Click the [Start] button on the Execute Tuning screen.



The "Tuning start preparation dialog" dialog box is displayed.

2. Perform servo-on, set the operating range of the device, and click the [Start] button.

Once clicked, the "Tuning start preparation dialog" dialog box automatically closes and AI evaluates the motor command response and starts tuning the parameters.

• If you are tuning repeatedly under the same conditions, please use PANATERM to align the motor position as much as possible when setting the servo to servo-on status.

The precAIse TUNING function uses PANATERM and operates with the reference position (zero position) set as the motor position when the servo is set to servo-on status.

If the reference position (zero position) deviates significantly in comparison to past tunings, an error may occur when tuning is in progress or the expected performance may not be achieved.

Protection Eunctions					
Pr5.12 Overload level[%]	0				
Pr5.13 Overspeed level[r/min]	120				
	Automatic setting (overspeed level)				
Pr5.14 Motor movable range[0.1 rotation]	10				
Operation limit					
Pr5.04 Over-travel inhibit input setup	1: CoE-side (CiA402) deceleration to stop 🗸				
JOG speed[r/min] JOG acceleration and dece[ms/JOG speed	60 1] 50				
Servo-on Operates only while	the button is pressed.				
- direction	So to 0 + direction				
Current positio	n [command unit]				
current positio	0				
Current positio					
Minimum position [command unit]	Maximum positior [command unit]				
Minimum position [command unit] -400000	Maximum position [command unit] 400000				

**3.** If you wish to end parameter tuning, for example in an emergency, click the [Stop] button.



You can check progress with "Progress status" and "Current operating conditions". In addition, detailed data is displayed on three central images on the screen.

(1)	Settling time meas- urement data	The settling time transition in the adjustment process is displayed.
(2)	Parameters	The current parameters in the adjustment process and the parameters with the best re- sults at that time are displayed.
(3)	Waveform graph	The current measurement data (time-series data) is displayed.

4. When the progress status displays "Complete", click the [Go to result] button in the lower right-hand corner.



The tuning results screen is displayed.

# 3.1.3.4.4 Confirming Tuning Results, Ending precAlse TUNING

To check the tuning results and end precAlse TUNING, use the respective buttons listed in the table below.



## precAlse TUNING Results Screen

(1)	Settling time meas-	The settling time transition in the adjustment process is displayed.
	urement data	Each dot represents an evaluation value (data result) measured after changing the parameter setup values.
		Red dot: Best evaluation value
		Blue dots: Other evaluation values
		Green dot: Selected evaluation value (displayed in [Current evaluation value] at the top of the screen)
(2)	Parameters	The parameters from the settling time measurement data determined to be the best in the ad- justment process and the parameters for the selected settling time measurement data are dis- played.
(3)	Waveform graph of	The measurement data (time-series data) for the selected trial is displayed.
	selected data	When multiple operation commands are set in the operational conditions settings, measure- ment data (time-series data) for each operation command can be selected and superimposed on top of each other.
(4)	[Send parameters] button	Sets the parameters for the selected trial to the servo driver.
(5)	[Additional tuning] button	Click this button to continue tuning. Click the button to go to the settings screen.
(6)	[End] button	Save all results of the adjustment process and end precAlse TUNING.

# 3.2 Manual Tuning

Manual tuning is possible if gain adjustment has not be adequately performed using an automatic tuning function such as One Minute TUNING, or to ensure the best responsiveness and stability for individual loads. The user determines the response results when the parameters are changed, and performs tuning.

## 3.2.1 Manual TUNING

#### 3.2.1.1 Function Overview

Use to further improve responsiveness and stability after auto tuning, for example. Make sure you have a thorough understanding of the characteristics of each control function before use.

Set-up Support Software (PANATERM ver.7) has a user interface that groups related parameters by control function for easy tuning.

#### 3.2.1.2 Operational Conditions

Set-up Support Software (PANATERM ver.7) is used.

Depending on the parameters to be changed, power may need to be restored. If the power needs to be restored, a message is displayed. Follow the instructions in the message to restore the power.

#### 3.2.1.3 Tuning Method

The tuning method with Manual TUNING for each control mode is described in this section.

- <u>"3.2.1.3.1 Tuning in Position Control Mode"</u>
- <u>"3.2.1.3.2 Tuning in Speed Control Mode"</u>
- <u>"3.2.1.3.3 Tuning in Torque Control Mode"</u>
- <u>"3.2.1.3.4 Tuning in Full-closed Control Mode"</u>

#### 3.2.1.3.1 Tuning in Position Control Mode

This section describes the basic gain adjustment procedure when the gain switching function is not used in position control mode.

This section describes the adjustment procedure aimed at position control with high responsiveness and that uses the basic parameters of position loop gain, speed loop gain, speed integral time constant, and torque filter and notch filter parameters to suppress vibration.

For a block diagram on position control, see <u>"7.2.1 Position Control Mode Block Diagram"</u>.

Refer to the following procedure for reference when tuning.

#### << Procedure >>

1. After tuning using an automatic tuning function, go to <u>"Step 3"</u>. When starting new tuning, configure initial settings for the parameters.

Reset the following parameters to the initial values. For initial values, see "7.1 Object Dictionary List".

- Pr0.02 "Real-time auto-gain tuning setup"
- Pr0.04 "Inertia ratio"
- Pr1.00 "1st gain of position loop"
- Pr1.01 "1st velocity loop gain"
- Pr1.02 "1st velocity loop integration time constant"
- Pr1.03 "1st filter of velocity detection"

- Pr1.04 "1st torque filter time constant"
- Pr1.14 "2nd gain setup"
- Pr2.00 "Adaptive filter mode setup"
- Pr2.01 "1st notch frequency"
- Pr2.02 "1st notch width selection"
- Pr2.03 "1st notch depth selection"
- Pr2.04 "2nd notch frequency"
- Pr2.05 "2nd notch width selection"
- Pr2.06 "2nd notch depth selection"
- Pr2.07 "3rd notch frequency"
- Pr2.08 "3rd notch width selection"
- Pr2.09 "3rd notch depth selection"
- Pr2.10 "4th notch frequency"
- Pr2.11 "4th notch width selection"
- Pr2.12 "4th notch depth selection"

### **2.** Set the inertia ratio.

Set Pr0.04 "Inertia ratio".

If the Pr0.04 "Inertia ratio" value is found with the real-time auto tuning function, use the Pr0.04 "Inertia ratio" set value as it is.

If the inertia ratio is found by load calculation or other means, enter the calculated value.

**3.** Check the motor operation.

Run the motor with Set-up Support Software (PANATERM ver.7), etc., and check for any abnormalities in operation.

If no vibration or oscillation occurs at stop (servo lock) or during operation, go to "Step 4".

If vibration or oscillation occurs, lower Pr1.01 "1st velocity loop gain" and Pr1.00 "1st gain of position loop" by about 50 [0.1 Hz] until vibration or oscillation no longer occurs.

**4.** Adjust the speed loop gain.

Raise Pr1.01 "1st velocity loop gain" by about 100 [0.1 Hz], and then raise Pr1.00 "1st gain of position loop" by the same amount.

Run the motor to check for vibration or oscillation, and if vibration or oscillation does not occur, proceed to <u>"Step 5"</u>.

If vibration or oscillation occurs, lower Pr1.01 "1st velocity loop gain" to about 80% of the current value and then lower Pr1.00 "1st gain of position loop" to the same value and proceed to <u>"Step 5"</u>.

### – Precautions –

- Parameters should be changed when the motor is stopped.
- **5.** Set the time constant of the torque filter.
  - Refer to the following formula when setting Pr1.04 "1st torque filter time constant".
    - Torque filter cut-off frequency  $[Hz] \times 4 \ge$  speed loop gain [Hz]
  - The torque filter cut-off frequency can be obtained using the following formula.

Cut-off frequency [Hz] =  $1/(2 \pi \times Pr1.04$  "1st torque filter time constant" [0.01 ms]  $\times$  0.00001)

If the operation sound is noticeable, increase Pr1.04 "1st torque filter time constant" by about 10 [0.01 ms].

To speed up the response, decrease Pr1.04 "1st torque filter time constant" by about 10 [0.01 ms] and increase Pr1.01 "1st velocity loop gain".

If Pr0.04 "Inertia ratio" is set correctly, the value of Pr1.01 "1st velocity loop gain" is the speed loop gain [Hz].

**6.** Set 1st filter of velocity detection.

To speed up the response, decrease Pr1.03 "1st filter of velocity detection" and increase Pr1.01 "1st velocity loop gain".

Normally use with Pr1.03 "1st filter of velocity detection" set to 0.

**7.** Set 1st gain of position loop.

Set Pr1.00 "1st gain of position loop" to a value of about Pr1.01 "1st velocity loop gain" ×1.5.

Run the motor and fine tune while checking the positioning settling time by Set-up Support Software (PANATERM ver.7) waveform measurement or other means.

To shorten the positioning settling time, go to "Step 8", and if not, go to "Step 9".

#### – Precautions –

• Increasing the value shortens the positioning settling time, but too large a value may cause vibration or oscillation. Take due care.

If vibration or oscillation occurs, lower Pr1.00 "1st gain of position loop" to about 80% of the current level.

• Parameters should be changed when the motor is stopped.

8. Set the 1st velocity loop integration time constant.

Lower Pr1.02 "1st velocity loop integration time constant" from the initial value below according to the conditions.

The extent of lowering depends on the value of Pr1.02 "1st velocity loop integration time constant" [0.1 ms]. Refer to the conditions in the table below when lowering the value.

#### Initial value

 $1,500,000 / (2 \pi \times Pr1.01 \text{ "1st velocity loop gain" [0.1 Hz]})$ 

#### **Extent of lowering**

Pr1.02 "1st velocity loop integration time constant" [0.1 ms] value	Extent of lowering
300 or more	100 at a time
150 to 299	50 at a time
Less than 150	10 at a time

To further shorten the positioning settling time, go back to "Step 4" and tune Pr1.01 "1st velocity loop gain" .

If vibration or oscillation occurs when Pr1.01 "1st velocity loop gain" is raised, configure the notch filter settings in <u>"Step 9</u>", and then go back to <u>"Step 4</u>" and tune Pr1.01 "1st velocity loop gain".

A smaller Pr1.02 "1st velocity loop integration time constant" value will bring the deviation during positioning settling time closer to 0 sooner, but may delay the time to first reach the settling width. In this case, the settling time may be improved by setting Pr1.07 "2nd velocity loop integration time constant" to 10,000 (disabled) during operation using the gain switching function.

**9.** Set the notch filter settings.

Measure the vibration frequency of the torque command using Set-up Support Software (PANATERM ver.7) waveform measurement, frequency response measurement, etc.

Take the following measures according to the measured vibration frequency.

Compare before and after the measures and continue to tune settings to raise Pr1.01 "1st velocity loop gain" more.

After the measures, vibration and oscillation, etc. may subside even if Pr1.01 "1st velocity loop gain" is raised. Go back to <u>"Step 4"</u> again to check.

Vibration frequency	Details of measures
1.5 kHz or more	Increase the set value for Pr1.04 "1st torque filter time constant" until the vibration is within the allowable range. The set value should be changed by increasing by 10% at a time.
	If Pr1.04 "1st torque filter time constant" is set too large, vibration at low frequencies may increase. In this case, lower Pr1.01 "1st velocity loop gain".
600 Hz to 1.5 kHz	Set the vibration frequency to Pr2.01 "1st notch frequency". Set a notch filter to suppress resonance peaks.
	If vibration is not reduced, fine tune the Pr2.01 "1st notch frequency" value.
	Resonance peaks can be measured using Set-up Support Software (PANATERM ver.7) fre- quency response measurement.
	If there are multiple resonance peaks, set the vibration frequency to Pr2.04 "2nd notch fre- quency" to Pr2.10 "4th notch frequency" .
	If the vibration is still 600 Hz or more, increase the set value for Pr1.04 "1st torque filter time constant" . The set value should be changed by increasing by 10% at a time.
400 to 600 Hz	Measure the resonance frequency using the frequency response measurement in Set-up Support Software (PANATERM ver.7) and set the resonance frequency in Pr2.01 "1st notch frequency".
	After setting Pr2.01 "1st notch frequency", measure the frequency response again and con- firm that the resonance peak is reduced.
	If the resonance peak is not reduced, tune Pr2.01 "1st notch frequency", Pr2.02 "1st notch width selection", and Pr2.03 "1st notch depth selection" to lower the resonance peak.
	For vibrations with resonance peaks at low frequencies and frequencies lower than the anti- resonance frequency, make Pr1.01 "1st velocity loop gain" smaller.
	When the resonance frequency is within the range of about 350 to 450 Hz, raise Pr1.01 "1st velocity loop gain" and set a notch filter when vibration occurs. Vibration may be reduced.

If the vibration is not reduced by the measures taken, no further tuning is available. Disable the notch filter used for the measures taken and end tuning.

### 3.2.1.3.2 Tuning in Speed Control Mode

Tuning in speed control is almost the same as in <u>"3.2.1.3.1 Tuning in Position Control Mode"</u>. Tune parameters excluding the Pr1.00 "1st gain of position loop" setting in accordance with the <u>"3.2.1.3.1 Tuning in Position Control Mode"</u> procedure.

For speed control mode block diagram, see <u>"7.2.2 Speed Control Mode Block Diagram"</u>.

#### 3.2.1.3.3 Tuning in Torque Control Mode

In torque control mode, the Obj.6080h:00h "Max motor speed" speed limit controls the rotational velocity of the motor so that it does not exceed the speed limit value.

For a block diagram on torque control, see <u>"7.2.3 Torque Control Mode Block Diagram"</u>.

Details on setting speed limit values are provided below.

• Setting speed limit values

Set the speed limit value selection method in Pr3.17 "Selection of speed limit" .

For this driver, set Pr3.17 "Selection of speed limit" = 2 (fixed) and set the speed limit value in Obj.6080h:00h "Max motor speed".

When Pr6.97 "Function expansion setup 3" :bit 12 "Speed limit priority function during torque control" =1, if Obj.6080h:00h "Max motor speed" is exceeded, the torque limit is disabled by Obj.60E0h:00h "Positive torque limit value" and Obj.60E1h:00h "Negative torque limit value" and the required torque is generated and controlled to stay below the speed limit value.

To ensure stable operation even when there are speed limits, it is necessary to set parameters according to <u>"3.2.1.3.2 Tuning in Speed Control Mode"</u>. If the speed limit value is too low, the speed loop gain is too low, or the speed loop integral time constant is set to 10,000 (disabled), the input to the torque limit part will be small and torque may not be produced as per the torque command.

### 3.2.1.3.4 Tuning in Full-closed Control Mode

In full-closed control, the same procedure as for <u>"3.2.1.3.1 Tuning in Position Control Mode"</u> can be used for tuning, except for the notes in Operating Instructions (Overall) "7.6.1 Full-closed Control Overview" (difference in command units, difference in command division/multiplication, etc.).

For a block diagram on full-closed control, see <u>"7.2.4 Full-closed Control Mode Block Diagram"</u>.

External scale ratio setup and hybrid deviation excess setup in the initial settings for full-closed control are detailed below.

• External scale ratio setup

Use Pr3.24 "Numerator of external scale division" and Pr3.25 "Denominator of external scale division" to set the external scale ratio.

Check the encoder pulse count per motor revolution and the external scale pulse count per motor revolution, and set Pr3.24 "Numerator of external scale division" and Pr3.25 "Denominator of external scale division" so that the following formula holds.

External scale ratio =	Pr3.24	134217728	Encoder pulse count per motor revolution [pulse]		
	Pr3.25 100000	External scale pulse count per motor revolution [pulse]			

If this ratio is wrong, the difference between the position calculated based on the encoder pulse and the position calculated based on the external scale pulse becomes large over a long travel distance and Err25.0.0 "Hybrid deviation excess protection" is triggered.

Setting Pr3.24 "Numerator of external scale division" to 0 automatically sets the encoder pulse count as the numerator.

• Hybrid deviation excess setup

Set Pr3.28 "Hybrid deviation excess setup" to the minimum allowable difference between the motor (encoder) position and the load (external scale) position.

In addition to the primary causes above, Err25.0.0 "Hybrid deviation excess protection" can also be caused by reverse connection of the external scale or loose connection between the motor and the load. Also check for these primary causes.

### – Precautions –

- Input a command pulse value based on the feedback scale resolution.
- Set Pr3.28 "Hybrid deviation excess setup" to the appropriate value in command units to prevent damage to the machine due to an out-of-control motor caused by improper setting of parameters related to the external scale.
- An external scale ratio of  $1/40 \leq$  External scale ratio  $\leq 20480$  is recommended.

Setting the external scale ratio to a smaller value than 50/position loop gain (Pr1.00, Pr1.05) even if the value is within the aforementioned range, may prevent control in single pulse units.

Also, increasing the external scale ratio may increase operation sound.

• For a list scale manufacturers and product numbers that can be used for full-closed control, see the "AC Servo Partner Products" catalog.

### 3.2.1.4 Manual TUNING Using Set-up Support Software (PANATERM ver.7)

#### 3.2.1.4.1 How to Use

<< Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7).
- 2. Select one device that you want to tune in the device tree and click the "Tuning" tab.

2				PANATERM ver.7				
File(F)	Troubleshooting(T)	Help(H)						_
		E Device tree		ô Setting	嬰 Monitor	ピ Logging	프운 Tuning	👖 Device Info 🔌
	-	MINAS A7BR		All parameters	EtherCAT object	IO Setting	Alarm	Analog input
₫⋎	Online	Axis0_No name set	SRV-OFF					
	USB	MADN085BRU 23080001		Open file	Save file	Copy Load initia	values Load	Write
	1		Encoder Info			Config Reset		je sez
		MINAS A7BR MHMG022U1A2 24020001	39405786 pulse	Search	Compa	rison None	✓ Add/delete d	column
				Switch to HEX input	Display A6-compati	ble control parameters	Allow out-of-range settin	ngs

3. In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

6									
	File(F) Tro	ubleshooting(T) Help(H)							
Devic	ŝ	Setting 🛛 🛱 Monitor	ŀά ιο	ogging	프 <mark>은</mark> Tuning	Device Info	1	Trial run	Z-phase search
e tree	<	Manual TUNING		✓ Graph Wave graphic	c Frequency response		rial run/Z-		2
	Ba Damping Mode sett (i) Wher <u>A7 recon</u> (i) Wher	sic Load characteri Notch settings (settin Application Manual ng () (CJ)sabled ( Customize settings) launching for the first time umended settings recommended upgrading from A6A6 compatibility setting		Stop ♥ Single trigger Acquire Messurement data management Edit display range Fixed display range Reset zoom Align with center of Y-axis Display as elapsed time Display as time standard Load file Save file				Protection Functions Pr5.12 Overload level(%) Pr5.13 Overspeed level(r/min) Pr5.14 Motor mova(0.1 rotation) Operation limit Pr5.04 Over-travel inhibit input s	0 120 2 Automatic setting (overspee 10 1: CoE-side (CIA402) deceler ¥
•	is recomi Load chara Inertia ra For more Gain settin Feedback Speed re Automa	teristic settingoFF io 0 advanced settings Load characteristic settings g gain setting - 29 + sponse frequenc 102.5 tic oscillation su OFF	•	Graph disp     Measureme     Acquire fr     Monitor     Simple meni	play settings ent Condition Edit display rom driver Acquire fro	ed data Cursor	- ►	Operating range Use JOG to move to the Max./M JOG speed[//min] JOG acceleratio[ms/JOG speed]	n positions or input a numeric value 60 50
	FF gain s Positiona Overshoe Notch filte 3rd notcl 4th potch	Safety function           etting         -         3.1         +           I command smo         0.8           t suppression (%)         -         100.0         +           r settings         Automatic setting:OFF         -         100.0           frequency (Hz)         5000         -         5000		Start measu Trial No. Se [times] [n	urem Measurement mod ettling time INP change co ns] [times]	le With Position C V Measurement count Vibration level Effective load factor Tal [%] [%]	2 ct s]	( Servo-on Operates of - direction • G	3) http://while the button is pressed. to 0 + direction frommand unit
	For more Damping 1 1st damp For more a What if I h Refer to vibration	advanced settings <u>Notch settings</u> advanced settings <u>Notch settings</u> lifer setup Automatic setting:ON ing frequency [Hz] 0 dvanced settings <u>Damping settings</u> (1) ave a problem? (1) (1) (1) (1) (1) (1) (1) (1)				(2)		Minimum position (command unit) 0 Trouble	Maximum position [command unit] 0 schooting To trial run
_									
	(1) This is the main screen. This displays the parameter tuning screen.								
	(2)	This displays the wavefor	mι	measur	rement and fre	equency response mea	sure	ement screens.	
	(3)	(3) This displays the trial run operation screen.							

Each item on the main screen (left side of the screen) is described below.

Selected driver:Axis0_No nam	Manual TUNING (E ne set	3)(9
Basic	Load characteristic set	tings Notch settings
Damping settings	Application	Manual
Mode setting ()	7:Custom	nize2
	Customi	ize settings
i When launching for the fill i When upgrading from A6	rst time <u>A7 recommende</u> A6 compatibility setting	<u>ed setting</u> is recommended gis recommended
Tuning conditions	O Position	oning/general-purpose
	O Proce	ssing machine
	O Custo	omize
> Parameters for tuning	conditions	
Load characteristic settings	Automati	ic settingOFF
Inertia ratio	250	
For more advanced settings L	oad characteristic settin	ngs
Gain setting		
Feedback gain setting	- 16	5
Speed response frequency [H	z]	2
Automatic oscillation suppre	ession OFF	
	Safety fu	unction
FF gain setting	- 16	5
Positional command smoothi	ing filter [ms]	,
Overshoot suppression [%]	- 10	00.0
Notch filter settings	Automati	ic setting:OFF
3rd notch frequency [Hz]		50
4th notch frequency [Hz]		50
For more advanced settings N	Notch settings	
Damping filter setup	Automati	ic setting:ON
1st damping frequency [Hz]		

For details on each item, see <u>"3.2.1.4.2 Main Screen Details"</u>.

	Reference	Description
(1)	"Category Selection"	Clicking the button toggles the content displayed on the main screen.
(2)	"Mode Setting"	Set Pr0.02 "Real-time auto-gain tuning setup" .
(3)	<u>"Load characteristic set- tings"</u>	Tune the parameters related to setting and estimating load characteristics.
(4)	"Gain setting"	Tune the parameters related to feedback and feedforward collectively or when over- shoot occurs.
(5)	"Notch settings"	Tune the parameters related to the notch filter and torque filter.
(6)	"Damping settings"	Tune the parameters related to damping control, the model-type damping filter and position command filter function.
(7)	"What if I have a prob- lem?"	A PDF file detailing the basics of tuning parameters and typical control challenges is displayed.
		Ose this when issues are known, but corresponding tuning procedures are unknown.
(8)	<u>"Application"</u>	This section summarizes features not listed above.
(9)	<u>"Manual"</u>	Displays the parameters shown in "Basic", "Load characteristic settings", "Notch set- tings", "Damping settings", and "Apply" in list format.
4. To end the Manual TUNING function, click the [<] button in the upper left corner.

5				PANATE	ERM ver.7			– 🗆 X	
Fi	ile(F) Troubleshooting(T) Help(H)								
Devic	袋 Setting - 問 Monitor	Ŀб	Logging	ତ. Tuning	Device Info	2	Trial run	Z-phase search	
e tree	K Manual TUNING		🗸 Graph			rial run/	•	2	
	Selected driver:Axis0_No name set		Wave grap	hic Frequency response		2-ph	Limit setting	Trial run	
	Basic Load characteri Notch settings		Start n	neasurement Stop	Single trigger Acquire	ase sear	Protection Functions Pr5.12 Overload level[%]	0	
	Damping settin Application Manual		Measurem	ent data management Edit	display range Fixed display range	9	Pr5 13 Oversneed level(r/min)	120	
	Mode setting () 0:Disabled ~		Reset zoon	Align with center of Y-axi	is	ш	TIS TO OVERSPEED REVERTING	Automatic setting (overspee	
	Customize settings		Display as	elapsed time Display as tim	ne standard Load file	ш	Pr5.14 Motor mova[0.1 rotation	ı] 10	
	A7 recommended settingis recommended		Save fil	e			Operation limit		
	() When upgrading from A6A6 compatibility setting is recommended					81	Pr5.04 Over-travel inhibit input s.	1: CoE-side (CiA402) deceler 🗸	
	Load characteristic settings Automatic settingOFF		✓ Graph display settings			-	Operating range		
	Inertia ratio 0		Measurer	nent Condition Edit displaye	ed data Cursor		Use JOG to move to the Max./N	in. positions or input a numeric value	
	For more advanced settings Load characteristic settings						JOG speed(r/minj	60	
►	Gain setting		Acquire	from driver Acquire from	n file Load condition presets		JOG acceleratio[ms/JOG speed	I] 50	
	Feedback gain setting - 29 +	•				- 1			
	Speed response frequenc 102.5		<ul> <li>Monitor</li> </ul>						
	Safety function		Simple mo	nitor IO monitor					
	FF gain setting - 31 +		Start mea	surem Measurement mod	e With Position C 🗸 Measurement count	2			
	Positional command smo 0.8		Trial No.	Settling time INP change cou	unt Vibration level Effective load factor Tak	t			
	Overshoot suppression [%] - 100.0 +		[times]	[ms] [times]	[%] [%] [ms	]	Servo-on O A Operates	only while the button is pressed.	
	Notch filter settings Automatic setting:OFF						- direction	50 to 0 + direction	
	3rd notch frequency [Hz] 5000 4th patch frequency [Hz] 5000						Current positio	n (command unit)	
	For more advanced settings Notch settings						current positio	0	
	Damping filter setup Automatic setting:ON								
	1st damping frequency [Hz] 0						Minimum position	Maximum position	
	For more advanced settings Damping settings						[command unit]	[command unit]	
	What if I have a problem?						0	0	
	Reter to luning Help when problems occur such as vibration or abnormal noise						Troub	leshooting To trial run	

The "Finish Manual TUNING" dialog box is displayed.

- **5.** Check the tuning results, select "Retained" or "Disabled", and then click the [End] button.
  - To retain parameters related to inertia ratio and friction compensation
    - "Disabled" automatic inertia ratio setup
  - To retain parameters related to notch filter
    - "Disabled" automatic notch setting

Selecting "Disabled" for both is recommended as this allows parameters to be fixed after tuning.

Enable the "Automatic inertia ratio setup" and "Automatic notch setting" automatic setting functions, and select "Retained" to keep the automatic setting functions enabled after tuning. (If "Retained" is selected after tuning with the automatic setting functions disabled, the parameters are the same as when "Disabled" is selected.)

Finish Manual TUNING	×
It will disable the automatic configuration feature below. Is it okay to proceed and exit?	
Automatic inertia ratio setup O Retained O Disabled	
Automatic notch setting O Retained O Disabled	
Back End	

If there is a change to a parameter, the "Write to EEPROM" dialog box is displayed.

## **6.** Click the [Confirm] button.

Write to EEPROM			×
Target device: Axis0_N	lo name set		
Parameters to be writte	en: User parameters		
Target parameter			
Parameter number	Parameter name	RAM value	EEPROM value
Pr0.02	Real-time auto-gain tuning setup	0: Conventional co	1: Conventional co
Pr6.10	Function expansion setup	16914	528
Pr6.32	Real time auto tuning custom setup	2181	0
		Confirm	Cancel

A confirmation dialog box is displayed asking if you want to write the parameters to EEPROM.

- To write the parameters to EEPROM, click the [Yes] button.
- To end tuning without writing the parameters to EEPROM, click the [No] button.

	$\times$
Parameters will be written to EEPROM	I. Is it OK?
Yes	No

Clicking the [Cancel] button ends tuning without writing the parameters to EEPROM.

## 3.2.1.4.2 Main Screen Details

This section describes each item on the main screen of the Manual TUNING screen.

<	Manua	al TUNII	NG			
elected driver:Axis0_No nar	ne set					
Basic	Load charac	teristic	settings		Notch settin	igs
Damping settings	App	lication			Manual	
1ode setting 🕕		0:Disa	bled			~
		Custo	omize setti	ings	]	
<ol> <li>When launching for the 1</li> <li>When upgrading from A</li> </ol>	first time <u>A7 re</u> .6 <u>A6 compatib</u>	comme vility set	nded setti tingis reco	ingis re	) commended nded	
oad characteristic settings		Auton	natic settir	ngOFF		
Inertia ratio		250				
For more advanced settings	Load characte	ristic se	ttings			
ain setting						
Feedback gain setting		-	16			+
Speed response frequency [I	Hz]					27.0
Automatic oscillation suppression OFF						
		Safet	y function			
FF gain setting		-	16			+
Positional command smootl	hing filter [ms]					9.2
Overshoot suppression [%]		-	100.0			+
lotch filter settings		Auton	natic settir	ng:OFF		
3rd notch frequency [Hz]						5000
4th notch frequency [Hz]						5000
For more advanced settings	Notch setting:	5		0.11		
amping filter setup 1st damping frequency [Hz]		Auton	natic settir	ig:ON		0
or more advanced settings	amping settin	qs				0
/hat if I have a problem?						
	roblems occu	such a	s vibration	h or ab	normal noise	

# **Category Selection**

• Clicking the category selection button toggles the display content on the main screen.

Basic	Load characteristic settings	Notch settings	
Damping settings	Application	Manual	

Item	Description
Basic	The first screen displayed is for tuning basic settings.
Load characteristic settings	Fine tune parameter details related to the inertia ratio and friction.
Notch settings	Fine tune the notch filter and torque filter parameters.
Damping settings	Fine tune the damping control, the model-type damping filter and position command filter function parameters.
Application	Tune parameters for functions other than those listed above, such as the gain switching function.
Manual	Tune parameters related to control in list format.

# Mode Setting

- Set Pr0.02 "Real-time auto-gain tuning setup".
- When "A7 recommended setting" is selected, "7 (Customize 2)" is automatically set in "Mode setting". When "A6 compatibility setting" is selected, the current "Mode setting" set value is retained.

• When "A7 recommended setting" or "A6 compatibility setting" is selected, parameters other than Pr0.02 "Realtime auto-gain tuning setup" are also set. For details, see the table below.

<	Manua	al TUNING			
Selected driver:Axis0_No nam	ie set				
Basic	Load charac	teristic settings		Notch setting	gs
Damping settings	Арр	lication		Manual	
Mode setting (j)		0:Disabled			~
		Customize sett	ings		
(i) When launching for the fi (i) When upgrading from A6	rst time <u>A7 rec</u> A6 compatibi	commended setti ility settingis reco	ngis rec mmeno	commended ded	
oad characteristic settings		Automatic settir	ngOFF		
Inertia ratio		250			
For more advanced settings	oad character	istic settings			
Gain setting					
Feedback gain setting		- 16			+
Speed response frequency [H	z]				27.0
Automatic oscillation suppr	ession	OFF			
		Safety function			
FF gain setting		- 16			+
Positional command smooth	ing filter [ms]				3.7
Overshoot suppression [%]		- 100.0			+
Notch filter settings		Automatic settir	na:OFF		
3rd notch frequency [Hz]					5000
4th notch frequency [Hz]					5000
For more advanced settings	Notch settings				
Damping filter setup		Automatic settir	ng:ON		
1st damping frequency [Hz]					0
or more advanced settings Da	amping setting	<u>15</u>			
What if I have a problem? Refer to Tuning Help <u>when pr</u>	oblems occur	such as vibratior	n or abr	ormal noise	

Item	Description
A7 recommended setting (blue text)	Sets Pr0.02 "Real-time auto-gain tuning setup" to setup value 7 (Customize 2). Sets Pr6.10 "Function expansion setup" and Pr2.45 "Function expansion setup 10", etc. to A7
	series recommended values.
	Allows finer tuning, such as 45-stage tables for real-time auto-tuning machine stiffness setup.
	Normally, this item should be selected when launching for the first time, for example.
	Click the [Yes] button when the dialog box for confirming the parameter change is displayed.
	×
	Parameters will be changed to A7 recommended settings. Is it OK?
	Yes No
A6 compatibility setting	The current settings for Pr0.02 "Real-time auto-gain tuning setup" are retained.
	Sets Pr6.10 "Function expansion setup" and Pr2.45 "Function expansion setup 10", etc. to settings used for the A6 series.
	Select this item if you need compatibility with the A6 series.
	Click the [Yes] button when the dialog box for confirming the parameter change is displayed.

• When "A7 recommended setting" is selected, "7: Customize2 " is automatically input in "Mode setting" (set Pr0.02 = 7 (Customize2)).

Clicking the [Customize settings...] button allows you to customize settings according to the application.

Mode setting (j)	7:Customize2	~	
	Customize settings		
<ul> <li>When launching for the first time<u>A7 recommended setting</u> is recommended</li> <li>When upgrading from A6<u>A6 compatibility setting</u> is recommended</li> </ul>			
Tuning conditions	Positioning/general-purpose		
	O Processing machine		
	O Customize		
> Parameters for tuning conditions			

# **Customize Settings Screen**

Customize settings	×
In the auto tuning function customization setting Manual setting/automatic setting of each control Load characteristics estimation	s, parameter can be selected.
Inertia Ratio Update	ON
Stiffness Setup	
Fixed Parameter Setup	OFF
Gain Switching Setup	0:Use current settings 🗸
Torque compensation setting switching	
Tuning torque command additional value	OFF
Tuning positive direction torque compensation	OFF
Tuning negative direction torque compensation	OFF
Tuning viscous friction compensating gain	OFF
OK	Cancel

Item	Description
Load characteristics esti- mation	Set to enable or disable the load characteristics estimation function. ON: Enabled OFF: Disabled
Inertia ratio update	Set updates in load characteristic estimation results for Pr0.04 "Inertia ratio" . ON: Update with estimated value OFF: Current settings retained
Stiffness setup	Set to enable or disable the basic gain setting using Pr0.03 "Real-time auto-tuning machine stiff- ness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2" . ON: Enabled OFF: Disabled
Fixed parameter setup	Set whether or not to change the parameters that become prescribed fixed values when Pr0.02 "Real-time auto-gain tuning setup" is enabled. ON: Change to fixed value OFF: Current settings retained
Gain switching setup	Select the method for setting parameters related to gain switching when Pr0.02 "Real-time auto- gain tuning setup" is enabled.

Item	Description				
Torque compensation set-	Select settings for parameters related to friction torque compensation.				
ting switching	ON: MINAS A7 Series recommended setting				
	OFF: MINAS A6 Series compatibility setting				
	ON is selected when "A7 recommended setting" is selected in mode setting, and OFF is selected when "A6 compatibility setting" is selected in mode setting.				
Torque command addi- tional value tuning	Select the method for setting the torque command additional value (Pr2.52 "Torque command additional value 2" or Pr6.07 "Torque command additional value" ).				
	ON: Automatic setting				
	OFF: Manual setting				
Positive direction torque compensation tuning	Select the method for settings the positive direction torque compensation value (Pr2.53 "Positive direction torque compensation value 2" or Pr6.08 "Positive direction torque compensation value").				
	ON: Automatic setting				
	OFF: Manual setting				
Negative direction torque compensation tuning	Select the method for setting the negative direction torque compensation value (Pr2.54 "Negative direction torque compensation value 2" or Pr6.09 "Negative direction torque compensation value").				
	ON: Automatic setting				
	OFF: Manual setting				
Viscous friction compen-	Select the method for setting Pr6.50 "Viscous friction compensating gain" .				
sating gain adjustment	ON: Automatic setting				
	OFF: Manual setting				

For details, see Pr6.32 "Real time auto tuning custom setup" below.

- <u>"4.1.1.4 Related Parameters"</u> of <u>"4.1.1 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Standard Type)</u>"
- <u>"4.1.3.4 Related Parameters"</u> of <u>"4.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled</u> <u>Type)</u>"

## Tuning conditions

1 When "7: Customize 2" is selected, "Tuning conditions" are displayed. Normally, select "Positioning/generalpurpose".

When "Positioning/general-purpose" is selected, the basic gain parameter setting is used when Pr0.02 "Real-time auto-gain tuning setup" is enabled.

Mode setting ()	7:Customize2		
	Customize settings		
<ul> <li>When launching for the first time<u>A7 recommended setting</u> is recommended</li> <li>When upgrading from A6<u>A6 compatibility setting</u> is recommended</li> </ul>			
Tuning conditions	• Positioning/general-purpose		
	O Processing machine		
	O Customize		
> Parameters for tuning conditions			

- 2 When "Customize" is selected for "Tuning conditions", "Parameters for tuning conditions" is expanded. In "Parameters for tuning conditions" individual change ratios can be set for each basic gain parameter.
  - For basic gain parameter settings, refer to the following.
    - <u>"4.1.1.4 Related Parameters"</u> of <u>"4.1.1 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for</u> <u>Standard Type)</u>"
    - <u>"4.1.3.4 Related Parameters"</u> of <u>"4.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode</u> <u>Disabled Type)</u>"

Mode setting (i)	7:Customize2
	Customize settings
When launching for the first time <u>A7 re</u> When upgrading from A6 <u>A6 compatil</u>	commended settingis recommended <u>pility setting</u> is recommended
Tuning conditions	Positioning/general-purpose
	O Processing machine
	O Customize
> Parameters for tuning conditions	

## **Customize Settings Screen**

Tuning conditions	Positioning/general-purpose
	O Processing machine
	O Customize
<ul> <li>Parameters for tuning conditions</li> </ul>	
1st position loop gain change ratio [%]	100
1st velocity integration change ratio [%]	100
1st torque filter change ratio [%]	100
2nd position loop gain change ratio [%]	100
2nd velocity loop gain change ratio [%]	100
2nd velocity integration change ratio [%]	100
2nd torque filter change ratio [%]	100
Load fluctuation compensation filter change ratio [%]	100
Smoothing filter change ratio [%]	100
Tuning filter change ratio [%]	100

### Load characteristic settings

- Parameter values related to setting and estimating load characteristics can be tuned manually.
- When "A7 recommended setting" is selected in <u>"Mode Setting"</u>, the inertia ratio is estimated and set automatically (Automatic setting: ON) in this mode.

The current set value is displayed in "Inertia ratio".

• To fine tune parameters related to load characteristics such as "Inertia ratio", click "Load characteristics" in blue text, or click the [Load characteristic settings] button at the top. The main screen changes to the "Load characteristic settings" screen. To return to the "Basic" screen, click on the [Basic] button at the top.

K Manual TUNING						
Selected driver:Axis0_No name set						
Basic	Load charact	teristic settings	Notch settings			
Damping settings	Appl	lication	Manual			
Load characteristics estimation						
Tuning conditions						
Estimated speed (i)		1: almost no change	· · · ·			
(i) Automatic oscillation suppression						
Related Parameters 🕕						
Inertia ratio[%]						
Estimated value [%]:0		Reflect the estimate	ed value			
. Torque command additional value[0.	1%]	0				
Estimated value [%]:0.0		Reflect the estimate	ed value			
Positive direction torque compensation	on value[0.1%]	0				
Negative direction torque compensat	tion value[0.1%]	0				
Estimated value (positive) [%]:0.0		Deflect the extinent	- develop			
Estimated value (negative) [%]:0.0	Estimated value (negative) [%]:0.0					
Viscous friction compensating gain[0	.1%/(10000r/min)]	0				
Estimated value [%]:0.0	Estimated value [%]:0.0 Reflect the estimated value					
$\bigcirc$ Set values may be automatically updated depending on real-time auto tuning mode settings. Basic Check the mode settings.						

## "Load Characteristic Settings" Advanced Settings Screen

Item	Description
Estimation speed	Set the speed for load characteristics estimation.
	Normally, set the value to 3.
	Higher set values result in faster responses to changes in load characteristics, but they also increase variations in disturbance estimation.
Related parameters	Displays the setup values for each parameter currently set in the driver.
	Parameters with automatic setting selected are grayed out.
	Numerical values can be entered directly for parameters that do not have automatic settings selected.
	The estimated value under the parameter name indicates the load characteristic estimation re- sult. When the estimated value is updated, the value displayed is also updated. When Pr0.02 "Real-time auto-gain tuning setup" is 0 (disabled), no value is displayed.
	Click the [Reflect the estimated value] button to reflect the estimated value of the target parameter in the set value.

# Gain setting

• Tune the parameters related to feedback and feedforward collectively and tune the suppression level for when overshoot occurs.

Item	Description						
FB gain setting	Used when tuning feedback-related parameters collectively.						
	• This setting is linked to Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Se- lection of machine stiffness at real-time auto-gain tuning 2".						
	• To change the set value, click the [+] or [-] buttons, or enter the value directly.						
	• The larger the set value, the higher the command responsiveness and servo stiffness also in creases, but vibration is more likely to occur.						
	While checking the operation, increase the set value by increments of 1.						
	– Precautions –						
	<ul> <li>Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.</li> </ul>						
	<ul> <li>Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03</li> </ul>						
	• Pr2.45: bits 5 to 4 = 10b : Pr0.27						
	• Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28						
	• Even if the same value is set for both Pr0.03 "Real-time auto-tuning machine stiffness setup" and Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2" parameters, the values of the respective related parameters may be different. Refer to the basic gain parameter settings in <u>"4.1 Real-time Auto Tuning Function"</u> for the relation-ship between the set values and the corresponding related parameters.						
	<ul> <li>To set the safety function (for automatically lowering the set value to eliminate oscilla- tion when tuning is in progress), click the [Safety function] button.</li> </ul>						
	"Enable (Yes)" or "Disable (No)" can be selected for the safety function. When enabled, the "Oscillation detection level" can be set.						
	"Eachback Gain Sotting" "Safety Function" Advanced Settings						
	Screen						
	Safety function						
	Safety functions can be set during gain adjustment. When this function is enabled, the Feedback gain setting is automatically lowered to immediately suppress vibration if any vibrations occur that exceed the detection level set by the torque command.						
	Safety function (Automatic oscillation suppression function) Ves  No						
	Oscillation detection level 15 %						
FF gain setting	Used when tuning feedforward-related parameters collectively.						
	<ul> <li>This setting is linked to Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tun- ing". For details on set values and corresponding parameters, see <u>"4.1 Real-time Auto Tun-</u> ing Function" "4.1.1.6 Basic Gain Parameter Setup Table".</li> </ul>						
	To change the set value, click the [+] or [-] buttons, or enter the value directly.						
	<ul> <li>Although speed responsiveness is higher the larger the set value, overshoot is more likely to</li> </ul>						
	occur.						
Our makes at a surgery in							
Overshoot suppression	Used when overshoot occurs.     To change the set value, disk the fuller [] buttons, or enter the value directly.						
	<ul> <li>To change the set value, click the (+) or (-) buttons, or enter the value directly.</li> <li>To suppress overshoot, adjust the value by decreasing it by about 5% from 100%.</li> </ul>						
	<ul> <li>To suppress overshoot, adjust the value by decreasing it by about 5% from 100%.</li> <li>A smaller value suppresses overshoot, but delays reasonses</li> </ul>						
	This setting is linked to Pr1 10 "Velocity feed forward gain"						

# Notch settings

- Tune the parameters related to the notch filter and torque filter.
- When "A7 recommended setting" is selected in <u>"Mode Setting"</u>, the notch filters are set automatically in adaptive filter when the operation command is input in this mode (Pr2.00 = 5) (Automatic setting: ON). In this case, the notch frequencies set automatically are displayed in 3rd notch frequency and 4th notch frequency.

• To fine tune related parameters, click "Notch settings" in blue text, or click the [Notch settings] button at the top. The main screen changes to the "Notch Settings" screen.

To return to the "Basic" screen, click on the [Basic] button at the top.

# "Notch Settings" Advanced Settings Screen

<		Manua	al TUNING			
Selected driver:Axis0_N	lo name set					
Basic		Load charac	teristic setti	ngs	Notch se	ettings
Damping set	ttings	Арр	lication		Manual	
Resonance monitor					Not detected	
Resonance frequency	[Hz] (i)					5000
(i) "5000" is displayed	l until resonance	is detected.				
Tuning based on positio	ning operation based on the po	sitioning operatior	n, use the fo	llowing se	ttings 1 to 5.	¥
Pr2.00 Adaptive filter r	node			5: High-p	brecision adaptive filte	er 🔹
Tuning based on freque	ncy characteristic	S		] Display r	notch filter characteris	tics in a graph
					Offset [dB]	0.0
	Fre	equency [Hz]		Width	D	epth
1th notch	5000		2		0	
2th notch	5000		2		0	
3th notch (i)	5000		2		0	
4th notch (i)	5000		2		0	
5th notch	5000		2		0	
Costom notch	5000		2		0	
(i) The 3rd and 4th no	otches are autom	atically set depend	ing on the s	setting for	Pr2.00 Adaptive filter	mode.
Torque filter						
1st torque filter [0.01 ms]				10		
2-stage torgue filter time constant [0.01 ms]						
2-stage torque filter ti	me constant [0.0]	1 ms]		0		

Item	Description
Resonance monitor	When Pr2.00 "Adaptive filter mode setup" is enabled, the resonance frequency is displayed if resonance is detected.
Pr2.00 Adaptive filter mode	When "A7 recommended setting" is selected in <u>"Mode Setting"</u> , "5: High-precision adaptive fil- ter" settings are set, and the 3rd notch filter and 4th notch filter are automatically set. Use this setting if you are unfamiliar with notch filter tuning.
	To manually tune the 3rd notch filter and 4th notch filter, set "0: Disable adaptive filter". For de- tails on Pr2.00 "Adaptive filter mode setup", see <u><i>"5.4 Adaptive Filter Function"</i></u> .
Display notch filter char- acteristics in a graph	When the check box is checked, the combined filter characteristics of the notch filter and torque filter are displayed when the frequency response graph is displayed on the center screen.
	Tuning can be performed while comparing with the frequency response measurement results. If the box is not checked, the filter characteristics are not displayed.
Offset	Entering a numerical value in Offset changes the display position of the filter characteristics.

Item	Description
1st notch	Allows advanced settings to be set for notch filter and torque filter parameters. Notch filter pa-
2nd notch	rameters set automatically in Pr2.00 "Adaptive filter mode setup" cannot be changed. When real-
3rd notch	time auto-gain tuning setup is enabled, the torque filter parameters cannot be changed because the torque filter is set automatically.
4th notch	Custom notch functions the same as other notch filters. It can be used as a 6th notch filter
5th notch	
Custom notch	
1st torque filter	
2-stage torque filter time constant	
2-stage torque filter at- tenuation term	

For details on functions, see <u>"5.3 Notch Filter Function</u>", <u>"5.1 Torque Filter Function</u>" and <u>"5.2 2-stage Torque Filter Function</u>".

## **Damping settings**

- Parameters related to damping control, the model-type damping filter and position command filter function can be tuned.
- When "A7 recommended setting" is selected in <u>"Mode Setting</u>", the damping control vibration frequency is estimated and set in damping frequency in this mode. The automatically set damping frequency is displayed.
- To manually tune related parameters, click "Damping settings" in blue text, or click the [Damping settings] button at the top. The main screen changes to the "Damping settings" screen. The screen displays the parameters of the filter used based on the Pr2.13 "Selection of damping filter switching" set value. To return to the "Basic" screen, click on the [Basic] button at the top.

# "Damping Settings" Advanced Settings Screen

# When Pr2.13 = 0

<	Manual TUNING				<
Selected driver:Axis0_No name set					Selected driver:Axis0_No nar
Basic	Load characteristic settings		Notch setting	s	Basic
Damping settings	Application		Manual		Damping settings
Vibration monitor		Not	detected		Vibration monitor
Vibration frequency [Hz] ()				0.0	Vibration frequency [Hz] ()
(i) "0.0" is displayed until vibration is d	etected				(i) "0.0" is displayed until vi
Damping filter setup					Damping filter setup
Pr2.13 Damping filter switching	0: U	lse up to two sin	ultaneously	~	Pr2.13 Damping filter switchi
Automatic frequency setting ()	1st	damping freque	ncy	~	Automatic frequency setting
$\bigoplus$ When vibrations are detected, the v the target filter.	ibration frequency value is automa	ically applied to	the damping fr	equency of	() When vibrations are determined the target filter.
IN I					IN I
➡ FIR filter	Au	tomatic setting			
Pr2.23 Positional command FIR fil	ter [0.1 ms] 10				Pr2.23 Positional comm
Smoothing filter					Smoothing filter
Pr2.22 Positional command smoo	thing filter [0.1 ms] 8				Pr2.22 Positional comm
Pr6.49 Command response filter a	ttenuation term setup 5: 1			~	Pr6.49 Command respo
Damping filter 1					Damping filter 1
Pr2.14 1st damping frequency [0.1	Hz] 0				[Enabled during positiv
Pr2.15 1st damping filter setup [0.	1 Hz] 0				Pr2.14 1st damping fi
Pr2.27 1st damping width setting	0				Pr2.15 1st damping fi
Pr6.41 1st damping depth	0				Pr2.27 1st damping w
Damping filter 2					Pr6.41 1st damping d
Pr2.16 2nd damping frequency [0.	1 Hz] 0				[Enabled during negativ
Pr2.17 2nd damping filter setup [0	0.1 Hz] 0				Pr2.16 2nd damping
Pr2.28 2nd damping width setting	0				Pr2.17 2nd damping
Pr6.60 2nd damping depth	0				Pr2.28 2nd damping
OUT					Pr6.60 2nd damping
Tuning filter					Damping filter 2
Filter function switching	A7	mode		~	[Enabled during positiv
Tuning filter time constant0.01ms]	4				Pr2.18 3rd damping f
Pr6.49 Tuning filter attenuation ter	m setup	lo attenuation te	rm	~	Pr2.19 3rd damping f
					Pr2.29 3rd damping v
					Def 71 2nd domains d

## When Pr2.13 = 3

K Manual TUNING						
Selected driver:Axis0_No name set						
Basic	Loa	ad characteristic settin	gs	Notch settings		
Damping settings		Application		Manual		
Vibration monitor				Not detected		
Vibration frequency [Hz] ()				C	0.0	
(i) "0.0" is displayed until v	ibration is detected					
Damping filter setup						
Pr2.13 Damping filter switchi	ng	[	3: Switch	ing by command direction	·	
Automatic frequency setting	(i)		1st damp	bing frequency	~	
(i) When vibrations are determined the target filter.	ected, the vibration f	requency value is auto	matically	applied to the damping frequency	of	
IN 						
♥ FIR filter			Automa	tic setting		
Pr2.23 Positional com	nand FIR filter (0.1 m	ISI (	10			
<ul> <li>Smoothing filter</li> </ul>						
Pr2.22 Positional comm	nand smoothing filte	er [0.1 ms]				
Pr6.49 Command resp	onse filter attenuatio	n term setup	5: 1	· · · · · · · · · · · · · · · · · · ·	~	
<ul> <li>Damping filter 1</li> </ul>						
[Enabled during positiv	e direction operation	n]				
Pr2.14 1st damping f	requency [0.1 Hz]		0			
Pr2.15 1st damping f	ilter setup [0.1 Hz]		0			
Pr2.27 1st damping v	Pr2.27 1st damping width setting					
Pr6.41 1st damping depth			0			
[Enabled during negati	ve direction operatio	n]			_	
Pr2.16 2nd damping	frequency [0.1 Hz]		0			
Pr2.17 2nd damping	filter setup [0.1 Hz]		0			
Pr2.28 2nd damping width setting			0			
Pr6.60 2nd damping	depth	-	0		1	
Damping filter 2						
[Enabled during positiv	ve direction operation	n]				
Pr2.18 3rd damping	frequency [0.1 Hz]		0			
Pr2.19 3rd damping	filter setup [0.1 Hz]		0			
Pr2.29 3rd damping	width setting		0			
Pr6.71 3rd damping	depth		0			
[Enabled during negati	ve direction operatio	n]				
Pr2.20 4th damping f	requency [0.1 Hz]		0			
Pr2.21 4th damping filter setup [0.1 Hz]			0			
Pr2.30 4th damping width setting			0			
Pr6.72 4th damping	depth		0			
OUT						
<ul> <li>Tuning filter</li> </ul>					_	
Filter function switching	9		A7 mode	,	·	
Tuning filter time const	ant0.01ms]		4			
Pr6.49 Tuning filter atte	enuation term setup		1: No atte	enuation term	~	

## When Pr2.13 = 4

<		Manual TUNING			
Selec	ted driver:Axis0_No name set				
	Basic	Load characteristic setti	ngs	Notch se	ttings
	Damping settings	Application		Manu	al
Vibra	tion monitor			Not detected	
Vibr	ation frequency [Hz] ()				0.0
í	"0.0" is displayed until vibration is o	letected			
Dam	ping filter setup				
Pr2.	13 Damping filter switching		4: No sw	itching (model type)	~
Auto	omatic frequency setting (i)		Disabled		~
i	When vibrations are detected, the v the target filter.	ibration frequency value is aut	omatically	applied to the dampir	ng frequency of
IN					
↓					
	FIR filter		Automa	tic setting	
↓	Pr2.23 Positional command FIR fi	lter [0.1 ms]	10		
	Smoothing filter				
	Pr2.22 Positional command smoo	othing filter [0.1 ms]			
	Pr6.49 Command response filter a	attenuation term setup	5: 1		~
	Model-type damping filter 1				
	Pr6.61 1st resonance frequency [0	.1 Hz]	0		
	Pr6.62 1st resonance attenuation	ratio	0		
	Pr6.63 1st anti-resonance frequen	cy [0.1 Hz]	0		
	Pr6.64 1st anti-resonance attenua	tion ratio	0		
Ļ	Pr6.65 1st response frequency [0.	1 Hz]	0		
	Model-type damping filter 2				
	Pr6.66 2nd resonance frequency [	0.1 Hz]	0		
	Pr6.67 2nd resonance attenuation	ratio	0		
	Pr6.68 2nd anti-resonance freque	ncy [0.1 Hz]	0		
	Pr6.69 2nd anti-resonance attenua	ation ratio	0		
Ļ	Pr6.70 2nd response frequency [0	.1 Hz]	0		
OUT					
		🗌 Display mod	el-type da	mping filter characteri	stics in a graph
				Offset [dB]	0.0
	Tuning filter				
	Filter function switching		A7 mode		~
	Tuning filter time constant0.01ms	1	4		
	Pr6.49 Tuning filter attenuation ter	rm setup	1: No att	enuation term	~

### When Pr2.13 = 5

<		Manual TUNING				
Selec	ted driver:Axis0_No name set					
	Basic	Load characteristic setti	ngs	Notch	settings	
	Damping settings	Application		M	anual	
/ibra	tion monitor			Not detecte	d	
Vibr	ation frequency [Hz] ()					0.0
(j)	"0.0" is displayed until vibration is c	letected				
am	ping filter setup					
Pr2.1	13 Damping filter switching		5: Switch	by external input (	model type)	~
Auto	omatic frequency setting ()		Disabled			~
<b>(</b> )	When vibrations are detected, the v the target filter.	ibration frequency value is aut	omatically	applied to the dam	iping frequer	ncy of
IN						
¥						
-	FIR filter		Automa	tic setting		
¥	Pr2.23 Positional command FIR fil	ter [0.1 ms]	10			
	Smoothing filter					
	Pr2.22 Positional command smoo	thing filter [0.1 ms]	8			
	Pr6.49 Command response filter a	attenuation term setup	5: 1			~
	Model-type damping filter 1					
	[Enabled when VS-SEL1 = OFF]					
	Pr6.61 1st resonance frequency	[0.1 Hz]	0			
	Pr6.62 1st resonance attenuation	n ratio	0			
	Pr6.63 1st anti-resonance freque	ncy [0.1 Hz]	0			
	Pr6.64 1st anti-resonance attenu	ation ratio	0			
	Pr6.65 1st response frequency [0	).1 Hz]	0			
	[Enabled when VS-SEL1 = ON]					
	Pr6.66 2nd resonance frequency	[0.1 Hz]	0			
	Pr6.67 2nd resonance attenuatio	n ratio	0			
	Pr6.68 2nd anti-resonance frequ	ency [0.1 Hz]	0			
	Pr6.69 2nd anti-resonance atten	uation ratio	0			
Ļ	filtercombination7TextBlock_13Te	ext	0			
тис						
		Display mod	el-type da	mping filter charact	eristics in a g	raph
				Offset [d	B] 0.0	
	Tuning filter					
	Filter function switching		A7 mode	,		~
	Tuning filter time constant0.01ms		4			
	Pr6.49 Tuning filter attenuation ter	m setup	1: No att	enuation term		~

### When Pr2.13 = 6

when $Pr2.13 = 1$	When	ו Pr2	.13	= 7
-------------------	------	-------	-----	-----

<	Manual TUNING		<		Manual TUNING			
Selected driver:Axis0 No name set			Select	ed driver:Axis0 No name set				
Basic Load	d characteristic settings	Notch settings		Basic	Load characteristic setti	ings	Notch settings	
Damping settings	Application	Manual		Damping settings	Application	-	Manual	
Vibration monitor		Not detected	Vibrati	on monitor			Not detected	
Vibration frequency [Hz] (i)	_	0.0	Vibrat	ion frequency [Hz] (i)				0.0
() "0.0" is displayed until vibration is detected			<u>()</u> .	0.0" is displayed until vibration is	detected			
Damping filter setup			Damp	ng filter setup				
Pr2.13 Damping filter switching	6: Switch	by command direction (model 💙	Pr2.13	Damping filter switching		7: Damping	3 stages	~
Automatic frequency setting ()	Disabled	×	Autor	natic frequency setting ()		Disabled		~
() When vibrations are detected, the vibration free the target filter.	equency value is automatically	applied to the damping frequency of	(i) t	/hen vibrations are detected, the ne target filter.	vibration frequency value is aut	tomatically ap	oplied to the damping frequ	iency of
IN			IN					
↓			↓					
FIR filter	Automa	tic setting	-	FIR filter		Automatic	setting	
Pr2.23 Positional command FIR filter [0.1 ms	] 10		↓	Pr2.23 Positional command FIR f	ilter [0.1 ms]	10		
Smoothing filter				Smoothing filter				
Pr2.22 Positional command smoothing filter	[0.1 ms] 8			Pr2.22 Positional command smo	othing filter [0.1 ms]	8		
Pr6.49 Command response filter attenuation	term setup 5: 1	~		Pr6.49 Command response filter	attenuation term setup	5: 1		~
Model-type damping filter 1				Damping filter 1				
[Enabled during positive direction operation]				Pr2.14 1st damping frequency [0	.1 Hz]	0		
Pr6.61 1st resonance frequency [0.1 Hz]	0			Pr2.15 1st damping filter setup [(	0.1 Hz]	0		
Pr6.62 1st resonance attenuation ratio	0			Pr2.27 1st damping width setting	I	0		
Pr6.63 1st anti-resonance frequency [0.1 Hz	:] 0			Pr6.41 1st damping depth		0		
Pr6.64 1st anti-resonance attenuation ratio	0		<b></b>	Damping filter 2				
Pr6.65 1st response frequency [0.1 Hz]	0			Pr2.16 2nd damping frequency [(	0.1 Hz]	0		
[Enabled during negative direction operation	1			Pr2.17 2nd damping filter setup	[0.1 Hz]	0		
Pr6.66 2nd resonance frequency [0.1 Hz]	0			Pr2.28 2nd damping width settin	g	0		
Pr6.67 2nd resonance attenuation ratio	0			Pr6.60 2nd damping depth		0		
Pr6.68 2nd anti-resonance frequency [0.1 H	z] 0			Damping filter 3				
Pr6.69 2nd anti-resonance attenuation ratio	0			Pr2.18 3rd damping frequency [0	.1 Hz]	0		
Pr6.70 2nd response frequency [0.1 Hz]	0			Pr2.19 3rd damping filter setup (	0.1 Hz]	0		
OUT				Pr2.29 3rd damping width setting	1	0		
	Display model-type da	mping filter characteristics in a graph		Pr6 71 3rd damping depth	, ,	0		
	_ sopiaj measi tipe de	Offset (dB) 0.0	OUT			-		
<ul> <li>Tuning filter</li> </ul>		onser [db]		Tuning filter				
Filter function switching	A7 mode	• •		- Filter function switching		A7 mode		~
Tuning filter time constant0.01ms]	4			Tuning filter time constant0.01ms	;]	4		
Pr6.49 Tuning filter attenuation term setup	1: No att	renuation term ~		Pr6.49 Tuning filter attenuation te	erm setup	1: No atten	uation term	~

For details on functions, see <u>"5.5 Damping Control Function</u>" and <u>"5.6 Model-type Damping Filter Function</u>".

Item	Description
Vibration monitor	When automatic frequency setting of the damping filter is enabled, the vibration frequency is displayed if vibration is detected.
Pr2.13 Damping filter switching	Set Pr2.13 "Selection of damping filter switching" . The parameters of the filter used based on the set value are displayed.
	When automatic setting is enabled, the parameters for the damping filter selected for setup are set automatically.
Automatic frequency set- ting	Select the damping filter for which the damping frequency is automatically set. Each time vibration is detected, the frequency displayed on the vibration monitor is set to the damping frequency.
FIR filter	Sets the value for Pr2.23 "Positional command FIR filter". Clicking the [Automatic setting] but- ton calculates and automatically sets the appropriate parameters.
	For details on functions, see <u>"5.7 Position Command Fliter Function</u> .
Smoothing filter	When the two-degree-of-freedom control mode for standard type is set and real-time auto tun- ing is enabled, the parameters are automatically set to the command response filter settings. Otherwise, parameters can be set manually.
	If synchronization of multiple axes is required, such as for a processing machine, set Pr2.22 "Positional command smoothing filter" to the same value for all axes.
	For details on functions, see <u>"5.7 Position Command Filter Function"</u> .

Item	Description
Damping filter 1	Parameters for damping filters that are not identified for automatic setting can be set manually.
Damping filter 2	For details on functions, see <u>"5.5 Damping Control Function"</u> and <u>"5.6 Model-type Damping</u>
Damping filter 3	Filter Function".
Damping filter 4	
Model type damping filter 1	
Model type damping filter 2	
Tuning filter	In the case of filter function switching, when "A7 recommended setting" is selected in <u>"Mode</u> <u>Setting"</u> , "A7 mode" is automatically set, and when "A6 compatibility setting" is selected, "Backward compatible" is automatically set. Changes are not required.
	When the two-degree-of-freedom control mode is enabled and real-time auto tuning is enabled, the tuning filter time constant is automatically set. Otherwise, parameters can be set manually.
Display model-type damping filter character-	This is displayed when Pr2.13 "Selection of damping filter switching" is between 4 and 6, using a model-type damping filter. Use to support tuning of model-type damping filters.
istics in a graph	When the check box is checked, the model-type damping filter characteristics are displayed on the frequency characteristic screen in the center of the "Manual TUNING" screen. Use with torque speed characteristics displayed.
	For details of the model-type damping filter function, see <u>"5.6 Model-type Damping Filter</u> <u>Function"</u> .
Offset	Entering a numerical value in Offset changes the display position of the filter characteristics.

# What if I have a problem?

• Clicking on "When problems occur" in blue text displays a PDF file detailing the basics of tuning parameters and typical control challenges.

Use this when issues are known, but corresponding tuning procedures are unknown.

The PDF file is displayed in a separate window. Manual TUNING is possible while viewing the displayed contents.

# Application

• This section summarizes functions not described previously.

• The main screen changes to the "Application" screen where the names of various functions are displayed. To return to the "Basic" screen, click on the [Basic] button at the top.

<	Manual TUNING	
Selected driver:Axis0_No name set		
Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual
> Feedforward function		
> Load fluctuation control function		
> High response current control fu	nction	
> Gain switching function		
> Quadrant glitch suppression fund	tion	
> Hybrid vibration suppression fun	tion	

Click ">" to the left of each function name to display the related parameters and enable setup.

For details on each function and related parameters, please refer to the relevant items.

- <u>"4.4 Feedforward Function"</u>
- <u>"4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)"</u>
- <u>"4.8 High Response Current Control Function"</u>
- <u>"4.2 Gain Switching Function"</u>
- <u>"4.3 3rd Gain Switching Function"</u>
- <u>"4.9 Quadrant Glitch Suppression Function"</u>
- <u>"5.9 Hybrid Vibration Suppression Function</u>"

### Manual

• Displays the parameters shown in "Basic", "Load characteristic settings", "Notch settings", "Damping settings", and "Apply" in list format.

<	Ma	anual TUNING		
Selected driver:Axis0_No name set				
Basic	Load ch	aracteristic set	tings	Notch settings
Damping settings		Application		Manual
Write to EEPROM Config	Reset			
Recall presets Load presets Sele	cted preset:All	parameters		
Name		Unit	Value	
Pr0.00 manufacturer use			1	
Pr0.01 Control mode setup			0: Semi-cl	osed control 🗸
Pr0.02 Real-time auto-gain tuning setup	)		7: Conven	tional control: Customization 🗸
Pr0.03 Real-time auto-tuning machine s	tiffness setup		13	
Pr0.04 Inertia ratio		%	0	
Pr0.08 manufacturer use			0	
Pr0.09 manufacturer use			1	
Pr0.10 manufacturer use			1	
Pr0.11 Number of output pulses per mo	otor revolution	pulse/r	2500	
Pr0.12 Reversal of pulse output logic			0: Encode	r, positive = B-phase progress 🗸
Pr0.13 1st torque limit		%	350	
Pr0.14 Position deviation excess setup		Command	83886080	
Pr0.15 Absolute encoder setup			1: Used in	incremental 🗸
D=0.16 External regenerative resistor est			Di Nia ragi	anaration process

# 3.2.1.4.3 Tuning Procedure When Starting a New Tuning Session

The basic tuning procedure is described when "A7 recommended setting" is selected in the mode setting as an example.

### << Procedure >>

1. Run the motor and check the position deviation response.



2. To reduce overshoot, increase the "Feedback gain setting" by increments of 1.



**3.** If the "Feedback gain setting" is set too high, oscillation may occur. In this case, set the filter properly in "Notch filter settings". For the tuning procedure, see <u>"5.3 Notch Filter Function"</u>.



4. Once the overshoot is reduced to a satisfactory level, increase the "FF gain setting" by increments of 1.



**5.** If the position deviation residual vibration is large, set the filter properly in "Damping filter settings". For the tuning procedure, see <u>"5.5 Damping Control Function"</u>.



6. If you experience any trouble during the process, click "When problems occur" in blue text and refer to the tuning advice that is displayed. Check the <u>"3.2.1.4.4 Tuning Procedure When Control Challenges Are Identified</u>" table for the main contents.

### 3.2.1.4.4 Tuning Procedure When Control Challenges Are Identified

### << Procedure >>

1. Click on "When problems occur" in blue text on the "Basic" screen under "What if I have a problem?".

**2.** A PDF file detailing the basics of tuning parameters and typical control challenges is displayed. Use this when issues are known, but corresponding tuning procedures are unknown.

Issues during re-adjustment	Corresponding control function references
Shortening the settling time.	"4.1 Real-time Auto Tuning Function"
	<u>"5.7 Position Command Filter Function"</u>
Reducing overshoot/undershoot.	"4.1 Real-time Auto Tuning Function"
	"4.3 3rd Gain Switching Function"
	<u>"4.4 Feedforward Function"</u>
	<u>"4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)</u> "
	"4.8 High Response Current Control Function"
Reducing abnormal noise and oscillation.	"5.3 Notch Filter Function"
	<u>"5.7 Position Command Filter Function"</u>
Reducing vibration just before stopping.	"5.5 Damping Control Function"
	"5.6 Model-type Damping Filter Function"
I want to reduce uneven operation and deviation during operation.	<u>"4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)</u> "
	"4.8 High Response Current Control Function"
Preventing falling on the vertical axis after servo-on.	"4.5 Friction Torque Compensation Function"
Suppressing quadrant glitches when velocity is inverted for processing machines, etc.	"4.9 Quadrant Glitch Suppression Function"
Ensuring own axis is not moved when other axes are	"4.1 Real-time Auto Tuning Function"
moved.	<u>"4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)"</u>
	"4.8 High Response Current Control Function"
Reducing vibration when gain is increased in full-closed control.	"5.9 Hybrid Vibration Suppression Function"

For details on each control function, refer to the relevant sections in this document.

# 3.2.2 Load Fluctuation Suppression Tuning (Stabilizing Load Fluctuation Applications)

### 3.2.2.1 Function Overview

In devices where load inertia fluctuates, vibration may occur due to the effect of load inertia fluctuations. This function reduces this vibration and improves stability. Set-up Support Software (PANATERM ver.7) has a dedicated screen for tuning the parameters of this function.

## 3.2.2.2 Operational Conditions

Item	Operational Conditions
Control mode	Position control, speed control, and full-closed control

Under the following conditions, the effect of the load fluctuation control function may not be seen.

Item	Conditions that obstruct the effectiveness of the load fluctuation control function
Load	• Low stiffness (antiresonance points exists in the low frequency range of 10 Hz or less)
	<ul> <li>Looseness, backlash, etc. are present and the load non-linearity is strong</li> </ul>

### 3.2.2.3 Tuning Procedure

For the tuning procedure using Set-up Support Software (PANATERM ver.7), see <u>"4.7.4.2 When Set-up Support</u> Software (PANATERM ver.7) Is Used" in <u>"4.7 Load Fluctuation Control Function (Load Fluctuation Stabilization</u> <u>Applications)</u>".

# 4 Control Functions to Improve Tracking With Respect to Control Commands

4.1.1 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Standard Type)       95         4.1.1.1 Function Overview       95         4.1.1.2 Operation Mode       95         4.1.1.3 Operational Conditions       96         4.1.1.4 Related Parameters       96         4.1.1.5 How to Use       105         4.1.6 Basic Gain Parameter Setup Table       107         4.1.2 Operation Mode       109         4.1.2.1 Function Overview       109         4.1.2.2 Operation Mode       109         4.1.2.3 Operational Conditions       109         4.1.2.4 Related Parameters       109         4.1.2.5 How to Use       110         4.1.2.6 Basic Gain Parameter Setup Table       110         4.1.2.5 How to Use       111         4.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)       120         4.1.3.1 Function Overview       120         4.1.3.3 Operational Conditions       120         4.1.3.4 Related Parameters       120         4.1.3.5 How to Use       120         4.1.3.4 Related Parameters       120         4.1.3.5 How to Use       120         4.1.3.4 Related Parameters       120         4.1.3.5 How to Use       120
4.1.1.1 Function Overview
4.1.1.2 Operation Overview
4.1.1.3 Operational Conditions964.1.1.4 Related Parameters964.1.1.5 How to Use1054.1.1.6 Basic Gain Parameter Setup Table1074.1.2 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Synchronization Type)1094.1.2.1 Function Overview1094.1.2.2 Operation Mode1094.1.2.3 Operational Conditions1094.1.2.4 Related Parameters1104.1.2.5 How to Use1154.1.2.6 Basic Gain Parameter Setup Table1154.1.2.6 Department of Use1154.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)1204.1.3.1 Function Overview1204.1.3.2 Operational Conditions1204.1.3.3 Operational Conditions1204.1.3.4 Related Parameters1204.1.3.5 How to Use1204.1.3.5 How to Use120
4.1.1.4Related Parameters
4.1.1.5 How to Use1054.1.1.6 Basic Gain Parameter Setup Table1074.1.2 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Synchronization Type)1094.1.2.1 Function Overview1094.1.2.2 Operation Mode1094.1.2.3 Operational Conditions1094.1.2.4 Related Parameters1104.1.2.5 How to Use1154.1.2.6 Basic Gain Parameter Setup Table1184.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)1204.1.3.1 Function Overview1204.1.3.2 Operation Mode1204.1.3.4 Related Parameters1204.1.3.4 Related Parameters1214.1.3.5 How to Use121
4.1.1.6 Basic Gain Parameter Setup Table1074.1.2 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Synchronization Type)1094.1.2.1 Function Overview1094.1.2.2 Operation Mode1094.1.2.3 Operational Conditions1094.1.2.4 Related Parameters1104.1.2.5 How to Use1154.1.2.6 Basic Gain Parameter Setup Table1184.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)1204.1.3.1 Function Overview1204.1.3.2 Operational Conditions1204.1.3.3 Operational Conditions1204.1.3.4 Related Parameters1214.1.3.5 How to Use121
4.1.2 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Synchronization Type)109         4.1.2.1 Function Overview       109         4.1.2.2 Operation Mode       109         4.1.2.3 Operational Conditions       109         4.1.2.4 Related Parameters       110         4.1.2.5 How to Use       115         4.1.2.6 Basic Gain Parameter Setup Table       118         4.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)       120         4.1.3.2 Operation Mode       120         4.1.3.3 Operational Conditions       120         4.1.3.4 Related Parameters       120         4.1.3.5 How to Use       120
4.1.2.1 Function Overview1094.1.2.2 Operation Mode1094.1.2.3 Operational Conditions1094.1.2.4 Related Parameters1104.1.2.5 How to Use1154.1.2.6 Basic Gain Parameter Setup Table1184.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)1204.1.3.1 Function Overview1204.1.3.2 Operation Mode1204.1.3.3 Operational Conditions1204.1.3.4 Related Parameters1214.1.3.5 How to Use121
4.1.2.2 Operation Mode1094.1.2.3 Operational Conditions1094.1.2.4 Related Parameters1104.1.2.5 How to Use1154.1.2.6 Basic Gain Parameter Setup Table1184.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)1204.1.3.1 Function Overview1204.1.3.2 Operation Mode1204.1.3.3 Operational Conditions1204.1.3.4 Related Parameters1214.1.3.5 How to Use121
4.1.2.3 Operational Conditions1094.1.2.3 Related Parameters1104.1.2.4 Related Parameters1104.1.2.5 How to Use1154.1.2.6 Basic Gain Parameter Setup Table1184.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)1204.1.3.1 Function Overview1204.1.3.2 Operation Mode1204.1.3.3 Operational Conditions1204.1.3.4 Related Parameters1214.1.3.5 How to Use129
4.1.2.4 Related Parameters1104.1.2.5 How to Use1154.1.2.6 Basic Gain Parameter Setup Table1184.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)1204.1.3.1 Function Overview1204.1.3.2 Operation Mode1204.1.3.3 Operational Conditions1204.1.3.4 Related Parameters1214.1.3.5 How to Use129
4.1.2.5 How to Use.       115         4.1.2.6 Basic Gain Parameter Setup Table       118         4.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)       120         4.1.3.1 Function Overview       120         4.1.3.2 Operation Mode       120         4.1.3.3 Operational Conditions       120         4.1.3.4 Related Parameters       121         4.1.3.5 How to Use       129
4.1.2.6 Basic Gain Parameter Setup Table       118         4.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)       120         4.1.3.1 Function Overview       120         4.1.3.2 Operation Mode       120         4.1.3.3 Operational Conditions       120         4.1.3.4 Related Parameters       121         4.1.3.5 How to Use       129
4.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)       120         4.1.3.1 Function Overview       120         4.1.3.2 Operation Mode       120         4.1.3.3 Operational Conditions       120         4.1.3.4 Related Parameters       121         4.1.3.5 How to Use       129
4.1.3.1 Function Overview1204.1.3.2 Operation Mode1204.1.3.3 Operational Conditions1204.1.3.4 Related Parameters1214.1.3.5 How to Use129
4.1.3.2       Operation Mode       120         4.1.3.3       Operational Conditions       120         4.1.3.4       Related Parameters       121         4.1.3.5       How to Use       129
4.1.3.3 Operational Conditions
4.1.3.4 Related Parameters
4.1.3.5 How to Use
4.1.3.6 Basic Gain Parameter Setup Table
4.0. Opin Switching Exaction (20)
4.2 Gain Switching Function
4.2.1 Function Overview
4.2.2 Operational Conditions
4.2.3 Related Parameters
4.2.4 How to Use
4.2.4.1 For Manual Setting
4.2.4.2 When Set-up Support Software (PANATERM Ver.7) is Used
4.3 3rd Gain Switching Function
4.3.1 Function Overview
4.3.2 Operational Conditions
4.3.3 Related Parameters
4.3.4 How to Use
4.3.4.1 For Manual Setting
4.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used
4.4 Feedforward Function
4.4.1 Function Overview
4.4.2 Operational Conditions
4.4.3 Related Parameters
4.4.4 How to Use
4.4.4.1 For Manual Setting
4.4.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

4.5 Friction Torque Compensation Function	154
4.5.1 Function Overview	154
4.5.2 Operational Conditions	154
4.5.3 Related Parameters	154
4.5.4 How to Use	155
4.5.4.1 When Set-up Support Software (PANATERM ver.7) Is Used	156
4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)	160
4.6.1 Function Overview	160
4.6.2 Operational Conditions	160
4.6.3 Related Parameters	160
4.6.4 How to Use	161
4.6.4.1 For Manual Setting	161
4.6.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	162
4.7 Load Fluctuation Control Function (Load Fluctuation Stabilization Applications)	167
4.7.1 Function Overview	167
4.7.2 Operational Conditions	167
4.7.3 Related Parameters	168
4.7.4 How to Use	169
4.7.4.1 For Manual Setting	169
4.7.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	169
4.8 High Response Current Control Function	
4.8.1 Function Overview	174
4.8.2 Operational Conditions	174
4.8.3 Related Parameters	174
4.8.4 How to Use	175
4.8.4.1 For Manual Setting	175
4.8.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	175
4.9 Quadrant Glitch Suppression Function	
4.9.1 Function Overview	178
4.9.2 Operational Conditions	178
4.9.3 Related Parameters	178
4.9.4 How to Use	179
4.9.4.1 For Manual Setting	179
4.9.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	180
4.10 Backlash Compensation Function	
4.10.1 Function Overview	183
4.10.2 Operational Conditions	
4.10.3 Related Parameters	
4.10.4 How to Use	185

# 4.1 Real-time Auto Tuning Function

This function estimates machine load characteristics in real time and uses those results to automatically perform basic gain setting and load characteristic compensation.

There are the following three types of real-time auto tuning, which can be switched by setting parameters.

Control type	Description
Two-degree-of-freedom control mode for standard type	This mode is suitable for positioning control. Load characteristic measurement, 3rd gain switching and viscous friction compensation can be enabled.
Two-degree-of-freedom control mode for synchronization type	This mode is suitable for controlling multiple loci such as with multijoint robots, etc. This type differs from the two-degree-of-freedom control mode for standard type in that the command response can be set individually and unbalanced load (gravity) compensation can be disabled.
Two-degree-of-freedom control mode disabled type	Two-degree-of-freedom control mode is disabled.

# 4.1.1 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Standard Type)

## 4.1.1.1 Function Overview

This control mode is suitable for positioning control where the moving locus is not important. It is effective for individually tuning operation acceleration and disturbance suppression. This is a standard control mode, and normally the two-degree-of-freedom control mode for standard type should be used.

Set Pr6.47 "Function expansion setup 2" :bit 0 "Two-degree-of-freedom control mode" = 1 (enabled) and bit 3 "Two-degree-of-freedom control real-time auto tuning selection" = 0 (standard type) to set this type.

## 4.1.1.2 Operation Mode

In real-time auto tuning (two-degree-of-freedom control mode for standard type), the operation mode can be changed according to Pr0.02 "Real-time auto-gain tuning setup". In each operation mode, automatic inertia ratio updates, basic gain setting, unbalanced load compensation, and friction compensation can be enabled or disabled.

In all modes of operation, operation acceleration and disturbance suppression can be tuned individually.

When Pr0.02 = 7, automatic inertia ratio updates, basic gain setting, unbalanced load compensation, and friction compensation can be enabled or disabled individually. Select Pr0.02 = 7 (set value 7) to optimize each function according to device characteristics.

Setup value	Operation mode	Description
0	Disabled	The real-time auto tuning function is disabled.
1	Standard response mode	This is an operation mode with an emphasis on stability. Unbalanced load compensation and friction compensation are not performed, and gain switching is not used.
2	High response mode 1	This is a positioning-focused operation mode. Use for devices such as low-friction ball screw driven devices that do not have unbalanced load on the horizontal axis.
3	High response mode 2	In addition to high response mode 1, this mode suppresses variation in positioning set- tling times using unbalanced load compensation, such as for a vertical axis, as well as via application of 3rd gain.
4	High response mode 3	In addition to high response mode 2, this mode shortens the positioning settling time with a belt mechanical shaft with high friction, etc.
		In terms of speed control, this mode is the same as high response mode 2.
		The Pr2.53 "Positive direction torque compensation value 2", Pr2.54 "Negative direction torque compensation value 2", and Pr6.50 "Viscous friction compensating gain" parameter values are updated, but are not reflected in the operation.

Details on Pr0.02 "Real-time auto-gain tuning setup"

Setup value	Operation mode	Description
5	Load characteristic measurement	The basic gain setting and friction compensation setting are not changed, only load char- acteristic estimation is performed. Used in combination with Set-up Support Software (PANATERM ver.7).
6	Customize 1	The real-time auto tuning function is disabled in two-degree-of-freedom control mode for standard type.
7	Customize 2	The combination of real-time auto tuning functions can be customized for each applica- tion by configuring advanced settings in Pr6.32 "Real time auto tuning custom setup".
		A change ratio can be set for the basic gain setting. Therefore, this mode should normally be selected.
		Some functions are not available depending on the control mode. For details, see <u>"De-tails on Pr6.32</u> "Real time auto tuning custom setup" ".

# 4.1.1.3 Operational Conditions

Item	Operational Conditions		
Control mode	Position control, speed control, and full-closed control		
	<ul> <li>Pr6.47:bit 0 = 1 and bit 3 = 0 (standard type)</li> </ul>		

Real-time auto tuning may not work normally under the following conditions. In such cases, change the load conditions, operation pattern, or manually set the related parameters.

Item	Conditions that obstruct the operation of real-time auto tuning					
Load	<ul> <li>When load inertia is small or large compared to the rotor inertia of the servo motor (less than 3× or 20× or more)</li> </ul>					
	When load inertia fluctuates					
	When machine stiffness is extremely low					
	<ul> <li>When non-linear characteristics exist, such as looseness due to backlash</li> </ul>					
Operation pat-	<ul> <li>When used continuously at low speeds of less than 100 r/min</li> </ul>					
terns	<ul> <li>When acceleration and deceleration are gentle, less than 2000 r/min in 1 s</li> </ul>					
	• When the speed is more than 100 r/min and the acceleration and deceleration condition of more than 2000 r/min in 1 s does not continue for more than 50 ms					
	Example of an operation pattern that obstructs function operation					
	Command Command Command					
	<ul> <li>Gradient 2000 (r/min)/s or less</li> <li>100 r/min</li> <li>Time</li> <li>Tim</li></ul>					

### 4.1.1.4 Related Parameters

# 4.1.1.4.1 Parameters That Control the Operation of This Function

		-				—: N/A
Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
0	02	В	Real-time auto- gain tuning setup	0 to 7	-	Sets the real-time auto tuning operation mode. Normally, select setting value 7.
0	03	В	Real-time auto- tuning machine stiffness setup	0 to 31	_	Sets responsiveness when real-time auto tuning is ena- bled. Higher settings result in higher speed responsive- ness and servo stiffness, but make it more likely that vi- bration will occur. Values should be changed from low to high with a close eye on operation. Enabled with Pr2.45 "Function expansion setup 10" : bit 5 = 0 (32 stiffness settings).
0	27	В	Selection of ma- chine stiffness at real-time auto- gain tuning 2	0 to 44		Sets responsiveness when real-time auto tuning is ena- bled. Higher settings result in higher speed responsive- ness and servo stiffness, but make it more likely that vi- bration will occur. Values should be changed from low to high with a close eye on operation. Allows finer gain adjustment than Pr0.03. Enabled with Pr2.45 "Function expansion setup 10" : bit 5 = 1 (45 stiffness settings).
0	28	В	Selection of feed forward stiffness at real-time auto- gain tuning	0 to 44	_	Sets responsiveness when real-time auto tuning is ena- bled. Higher settings result in higher speed responsive- ness, but make it more likely that overshoot will occur. Val- ues should be changed from low to high with a close eye on operation. Enabled with Pr2.45 "Function expansion setup 10" : bits 5 to 4 = 11b.
2	74	A	Tuning auto tun- ing application se- lection	-32768 to 32767	_	For Pr0.02 = 7 (Customize 2), any change ratio can be set for the basic gain setting to fit the application when the set value = 3. 0: Positioning 3: Customize
6	10	В	Function expan- sion setup	-32768 to 32767	_	bit 14: Load fluctuation suppression function automatic tuning 0: Disabled 1: Enabled
6	31	В	Real time auto tuning estimation speed	0 to 3	_	Sets load characteristics estimated speed when real-time auto-tuning is enabled. Higher settings result in faster re- sponses to changes in load characteristics, but they also increase variations in disturbance estimation. Estimation results are saved in EEPROM every 30 mi- nutes regardless of the load characteristic estimated speed setting. When automatic vibration detection is enabled from Set- up Support Software (PANATERM ver.7), this setting will be ignored and the setting value will be set to 3.
	Set	up	Mode			Description
	0 Does not change		Stops load cha	racteri	stics estimation.	
	1 Changes very little		Estimates char	nges in	load characteristics in minutes.	
	2 Changes slowly		Estimates char	nges in	load characteristics in seconds.	
	3 Changes precipitously		/ Fastest estima	st estimation of changes in load characteristics.		

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	32	В	Real time auto tuning custom setup	-32768 to 32767	_	Makes advanced settings for the automatic adjustment function when the Pr0.02 = 7 (Customize 2) is selected as an operation mode for real-time auto tuning.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# Details on Pr6.32 "Real time auto tuning custom setup"

bit	Name	Description				
1 to 0	Load characteristics estimation	<ul> <li>Set to enable or disable the load characteristics estimation function.</li> <li>0: Disabled</li> <li>1: Enabled</li> <li>— Precautions —</li> <li>• When this setting is disabled, the target parameters are not updated from the current settings even if bit 3 to 2 "Inertia Ratio Update", bit 6 to 4 "Torque compensation", and bit 15 to 12 "Individual torque compensation settings" are set to enable updates.</li> <li>• To enable load characteristic estimation, set Pr6.31 "Real time auto tuning estimation speed" to a value other than 0 (no change).</li> </ul>				
3 to 2	Inertia Ratio Update	<ul> <li>Set updates in load characteristic estimation results for Pr0.04 "Inertia ratio" .</li> <li>0: Disabled</li> <li>1: Enabled</li> <li>Precautions –</li> <li>To enable inertia ratio updates, set bit 1 to 0 "Load characteristics estimation" to 1 (enabled). If both are not enabled, the inertia ratio will not be updated.</li> </ul>				
6 to 4	Torque compensa- tion (*1)	Set updat value 2", tion torqu 0 1 2 3 4 5 - Preca • Char expa initial • Pr	es in load characteristic es Pr2.53 "Positive direction is e compensation value 2" a Mode Use current settings Disable torque compen- sation Vertical axis mode Friction compensation (weak) Friction compensation (medium) Friction compensation (strong) utions — nge the parameters to be u nsion setup 10" :bit 2 "Frict value is Pr2.45: bit 2 = 1. :2.45: bit 2=0 : Pr6.07, Pr6. :2.45: bit 2=1 : Pr2.52, Pr2.	timation results for Pr2.52 "Torque command additional torque compensation value 2", Pr2.54 "Negative direc- nd Pr6.50 "Viscous friction compensating gain". Description Uses current settings. Clear Pr2.52, Pr2.53, Pr2.54, and Pr6.50 to 0. Update Pr2.52 and clear Pr2.53, Pr2.54 and Pr6.50 to 0. Update Pr2.52 and set weak compensation for Pr2.53, Pr2.54, and Pr6.50. Update Pr2.52 and set medium compensation for Pr2.53, Pr2.54, and Pr6.50. Update Pr2.52 and set strong compensation for Pr2.53, Pr2.54 and Pr6.50. Sed depending on the values set in Pr2.45 "Function tion torque compensation parameter selection" . The 08, Pr6.09 53, Pr2.54		

bit	Name	Description							
7	Stiffness Setup (*2)	Set to enable or disable the basic gain setting using Pr0.03 "Real-time auto-tuning machine stiffness setup", Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2" or Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning".							
		0: Disabled							
		1: Enabled							
		- Precautions -							
		• Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.							
		• Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03							
		• Pr2.45: bits 5 to 4 = 10b : Pr0.27							
		• Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28							
8	Fixed Parameter Setup <sup>(*2)</sup>	Set whether or not to change parameters that become fixed values when real-time auto tun- ing is enabled.							
		For details, see the table <u>"Values Set When Real-Time Auto Tuning is Enabled (Pr0.02 = 1</u> to 4, 7)" in <u>"4.1.1.4.3 Parameters Changed By This Function"</u> .							
		0: Use current settings							
		1: Set to fixed values							
10 to 9	Gain Switching Set- up <sup>(*2)</sup>	Select the method for setting parameters related to gain switching when real-time auto tun- ing is enabled.							
		0: Use current settings							
		1: Gain switching disabled							
		2: Gain switching enabled							
11	Torque compensa-	Select whether to enable bits 6 to 4 or bits 15 to 12 for torque compensation.							
	tion setting switch-	0: Enable bits 6 to 4							
	ing	1: Enable bits 15 to 12							
15 to 12	Individual torque compensation set-	Select whether to use or update the current setting for the corresponding parameters when bit 11 "Torque compensation setting switching" = 1.							
	tings <sup>(*1)</sup>	0: Use current settings							
		1: Update							
		bit 15 bit 14 bit 13 bit 12							
		When Pr2.45:bit 2 = 1 Pr6.50 Pr2.54 Pr2.53 Pr2.52							
		When Pr2.45:bit 2 = 0 Pr6.50 Pr6.09 Pr6.08 Pr6.07							

\*1 To set to enable updates to torque compensation, set bit 1 to 0 "Load characteristics estimation" and bit 3 to 2 "Inertia Ratio Update" to 1 (enabled). Updates are not applied with update settings for torque compensation only.

\*2 To set this set value to a value other than 0, set bit 3 to 2 "Inertia Ratio Update" to 1 (enabled). Whether or not inertia ratio update is enabled at this time can be set with bit 1 to 0 "Load characteristics estimation".

# - Precautions -

- These parameters must be set in bit units. Operation cannot be guaranteed with incorrect settings. Using Set-up Support Software (PANATERM ver.7) is recommended for changing parameter setup values.
- Do not change these parameters during motor operation. Actually updating of parameters takes place when the motor stops after the load characteristic measurement results are confirmed.

## Notes

• Calculating Pr6.32 set value from values in bit units

When configuring each setting to a value other than 0, use the following procedure to calculate the set value for Pr6.32.

1 Confirm the least significant bit for each setting.

(Example) The least significant bit of the torque compensation function is 4

2 Multiply 2 to the power of (LSB) by the set value.

(Example) If bit 6 to 4 "Torque compensation" = 3 (friction compensation (weak)), then  $2^4 \times 3$ .

3 For each setting, calculate <u>"1"</u> and <u>"2"</u> and then add them all together to obtain the set value for Pr6.32.

(Example) When load characteristic measurement = enabled, inertia ratio update = enabled, torque compensation = friction compensation (weak), stiffness setting = enabled, fixed parameters = set to fixed values, gain switching setup = enabled

 $2^0 \times 1 + 2^2 \times 1 + 2^4 \times 3 + 2^7 \times 1 + 2^8 \times 1 + 2^9 \times 2 = 1461$ 

# 4.1.1.4.2 Parameters to Switch the Parameters Used by This Function to Minas A6 Series-Compatible Specification

In real-time auto tuning, the parameters used in real-time auto tuning can be switched to MINAS A6 Seriescompatible specification parameters by setting Pr2.45 "Function expansion setup 10".

- Parameters related to stiffness, unbalanced load and friction compensation and tuning filters
- Calculation method when updating torque filter time constant and some parameters for load fluctuation compensation (Pr6.73 "Load estimation filter" and Pr6.76 "Load estimation count" )

Item	Parameters for switching to MINAS A6 Series-compatible specification	Initial value (*1)
Stiffness	Can be changed with Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness set- ting resolution, individual FB/FF setting switching" .	bits 5 to 4 = 11b
Unbalanced load/ friction compensa- tion	Can be changed with Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection" .	bit 2 = 1
Torque filter time constant	Determined by the value of Pr2.45 "Function expansion setup 10" :bit 1 to 0 "Two-de- gree-of-freedom control function setting" .	bits 1 to 0 = 01b
Load fluctuation compensation	Determined by the value of Pr2.45 "Function expansion setup 10" :bit 3 "Load fluctua- tion suppression function automatic calculation" .	bit 3 = 1

\*1 Normally used with initial values.

	_	_				—: N/A
Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	38	В	Filter function switching	-32768 to 32767	_	Select a tuning filter. Normally, set to bit 1 = 1. bit 1: Tuning filter 2 0: Use Pr6.48 "Tuning filter" (MINAS A6 Series-compati- ble specification) 1: Use Pr2.46 "Tuning filter 2" (MINAS A7 Series specifi- cation)
2	45	В	Function expan- sion setup 10	-2147483648 to 2147483647	_	Sets various functions. bit 1 to 0: Two-degree-of-freedom control function setting bit 2: Friction torque compensation parameter selection bit 3: Load fluctuation suppression function automatic cal- culation bit 5 to 4: Stiffness setting resolution, individual FB/FF set- ting switching bit 31 to 6: Unused

· NI/A

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

### Details on Pr2.45 "Function expansion setup 10"

bit	Name	Description	Initial value
1 to 0	Two-degree-of-freedom control function setting	00b: Two-degree-of-freedom control (MINAS A6 Series-compatible specification)	01b
		01b: Two-degree-of-freedom control (MINAS A7 Series specifica- tion)	
		10b: Manufacturer use	
		11b: Manufacturer use	
2	Friction torque compen-	0: MINAS A6 Series-compatible specification settings	1
	sation parameter selec-	Unbalanced load compensation value: Use Pr6.07	
	tion	Dynamic friction compensation value: Use Pr6.08, Pr6.09	
		1: MINAS A7 Series specification settings	
		Unbalanced load compensation value: Use Pr2.52	
		Dynamic friction compensation value: Use Pr2.53, Pr2.54	
3	Load fluctuation sup- pression function auto-	0: Conventional setting (MINAS A6 Series specification)	1
		1: The following parameters are automatically calculated.	
	matic calculation	Pr6.73 "Load estimation filter"	
		Pr6.76 "Load estimation count"	
5 to 4	Stiffness setting resolu- tion, individual FB/FF	00b: 32 stiffness settings, FB/FF common setting (MINAS A6 Ser- ies-compatible specification)	11b
	setting switching	Use Pr0.03	
		01b: Same as 00b	
		10b: 45 stiffness settings, FB/FF common setting (MINAS A7 Series specification)	
		Use Pr0.27	
		11b: 45 stiffness settings, individual FB/FF settings (MINAS A7 Series specification)	
		Use Pr0.27 and Pr0.28	
31 to 6	Not used	-	_

### 4.1.1.4.3 Parameters Changed By This Function

### Parameters updated using estimated values for load characteristics

When Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4, real-time auto tuning updates the parameters in the table below using the estimated value for load characteristics.

When Pr0.02 "Real-time auto-gain tuning setup" is 7, the parameters in the table below are updated using the estimated value for load characteristics estimates based on the contents of Pr6.32 "Real time auto tuning custom setup".

Target para	Conditions for update (*2)	
Pr2.45:bit 2 = 1	Pr2.45:bit 2 = 0	
Pr0.04 "Inertia ratio"		When inertia ratio update is enabled (Pr0.02 = 1 to 4, 7)
Pr2.52 "Torque command additional value 2"	Pr6.07 "Torque command additional value"	When vertical axis mode or friction compensa- tion mode is enabled (Pr0.02 = 3, 4, 7)
Pr2.53 "Positive direction torque compensation value 2"	Pr6.08 "Positive direction torque compensation value"	When friction compensation mode is enabled $(Pr0.02 = 4, 7)$
Pr2.54 "Negative direction torque compensation value 2"	Pr6.09 "Negative direction torque compensation value"	When friction compensation mode is enabled $(Pr0.02 = 4, 7)$

Target para	Conditions for update <sup>(*2)</sup>
Pr2.45:bit 2 = 1	
Pr6.50 "Viscous friction compensating	When viscous friction compensation mode is enabled ( $Pr0.02 = 4, 7$ )

- \*1 Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection". The initial value is Pr2.45: bit 2 = 1.
- \*2 When Pr0.02 = 7, each parameter update can be set with Pr6.32 "Real time auto tuning custom setup" .

## Basic gain setting parameters updated according to machine stiffness settings

Real-time auto tuning updates the basic gain setting parameters according to the parameter settings below when Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4 or 7. For details, see <u>"4.1.1.6 Basic Gain Parameter Setup Table"</u>.

- Pr0.03 "Real-time auto-tuning machine stiffness setup"
- Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
- Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning"

# Notes

- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.
  - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
  - Pr2.45: bits 5 to 4 = 10b : Pr0.27
  - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

### Basic gain setting

Target parameter	Conditions for update according to stiffness (*1)
Pr1.00 "1st gain of position loop" Pr1.01 "1st velocity loop gain" Pr1.02 "1st velocity loop integration time con- stant" Pr1.04 "1st torque filter time constant" Pr1.05 "2nd gain of position loop" Pr1.06 "2nd velocity loop gain" Pr1.07 "2nd velocity loop integration time con- stant" Pr1.09 "2nd torque filter time constant"	• When stiffness setup is enabled (Pr0.02 = 1 to 4, 7)
Pr2.22 "Positional command smoothing filter"	<ul> <li>When stiffness setup is enabled (Pr0.02 = 1 to 4, 7)</li> <li>In speed control, the first order lag filter is fixed.</li> </ul>
Pr2.46 "Tuning filter 2"	<ul> <li>Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2" = 1 (enabled)</li> <li>When stiffness setup is enabled (Pr0.02 = 1 to 4, 7)</li> </ul>
Pr6.48 "Tuning filter"	<ul> <li>Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2" = 0 (disabled) When stiffness setup is enabled (Pr0.02 = 1 to 4, 7)</li> <li>In speed control, the first order lag filter is fixed.</li> </ul>
Pr6.49 "Command response/tuning filter at- tenuation term"	• Set to (Pr0.02 = 1 to 4, 7) or 15 when real-time auto tuning is enabled.

\*1 When Pr0.02 = 7, each parameter update can be set with Pr6.32 "Real time auto tuning custom setup" .

When Pr0.02 = 7 (Customize 2) and Pr2.74 "Tuning auto tuning application selection" = 3, any change ratio can be set for the values in the Basic Gain Parameter Settings Table.

Target parameter	Basic gain parameter setting in stiffness setup values when gain change ra- tio is enabled
Pr1.106 "1st position loop gain change ratio"	<ul><li>Sets the change ratio for Pr1.00 "1st gain of position loop"</li><li>When this setup value is 0, this is set to 100%.</li></ul>
Pr1.107 "1st velocity integration change ratio"	<ul> <li>Sets the change ratio for Pr1.02 "1st velocity loop integration time constant"</li> <li>When this setup value is 0, this is set to 100%.</li> </ul>
Pr1.108 "1st torque filter change ratio"	• Sets the change ratio for Pr1.04 "1st torque filter time constant"
Pr1.109 "2nd position loop gain change ratio"	<ul> <li>Sets the change ratio for Pr1.05 "2nd gain of position loop"</li> <li>When this setup value is 0, this is set to 100%.</li> </ul>
Pr1.110 "2nd velocity loop gain change ratio"	<ul><li>Sets the change ratio for Pr1.06 "2nd velocity loop gain"</li><li>When this setup value is 0, this is set to 100%.</li></ul>
Pr1.111 "2nd velocity integration change ratio"	<ul> <li>Sets the change ratio for Pr1.07 "2nd velocity loop integration time constant"</li> <li>When this setup value is 0, this is set to 100%.</li> </ul>
Pr1.112 "2nd torque filter change ratio"	Sets the change ratio for Pr1.09 "2nd torque filter time constant"
Pr1.113 "Load fluctuation compensation filter change ratio"	<ul> <li>Sets the change ratio for Pr6.24 "Load change compensation filter"</li> <li>When this setup value is 0, this is set to 100%.</li> </ul>
Pr1.114 "Smoothing filter change ratio"	• Sets the change ratio for Pr2.22 "Positional command smoothing filter" (*1)
Pr1.115 "Tuning filter change ratio"	Sets the change ratio for Pr6.48 "Tuning filter"

\*1 The "High response modes 1 to 3" column in the Basic Gain Parameter Settings Table is used for Pr2.22 values. For details, see <u>"4.1.1.6 Basic Gain Parameter Setup Table"</u>.

### Parameters set based on Fixed Parameter Setup

For real-time auto tuning, set the parameters in the table below in any of the following cases.

- When Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4
- When Pr0.02 "Real-time auto-gain tuning setup" is 7 and Pr6.32 "Real time auto tuning custom setup" :bit 8 "Fixed Parameter Setup" is 1

Target parameter	Value to set (Pr0.02 = 1 to 4, 7) when real-time auto tuning is enabled
Pr1.03 "1st filter of velocity detection"	Set to 0
Pr1.08 "2nd filter of velocity detection"	Set to 0
Pr1.10 "Velocity feed forward gain"	Set to 1000
Pr1.11 "Velocity feed forward filter"	Set to 0
Pr1.12 "Torque feed forward gain"	Set to 1000
Pr1.13 "Torque feed forward filter"	Set to 0
Pr6.10 "Function expansion setup"	Set bit 4 "Current response improvement" to 1 (enabled)

### Parameters set based on Gain Switching Setup

For real-time auto tuning, set the parameters in the table below in any of the following cases.

- When Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4
- When Pr0.02 "Real-time auto-gain tuning setup" is 7 and Pr6.32 "Real time auto tuning custom setup" :bit 10 to 9 "Gain Switching Setup" is 1

Target parameter	Value to be set					
	Pr0.02 = 1	Pr0.02 = 2	Pr0.02 = 3	Pr0.02 = 4	Pr0.02 = 7	
Pr1.14 "2nd gain setup"	Set to 1	•				
Pr1.15 "Mode of position control switching"	Set to 0	Set to 7				

Target parameter	Value to be set						
	Pr0.02 = 1	Pr0.02 = 2	Pr0.02 = 3	Pr0.02 = 4	Pr0.02 = 7		
Pr1.16 "Delay time of position control switch- ing"	Set to 10						
Pr1.17 "Level of position control switching"	Set to 0						
Pr1.18 "Hysteresis at position control switch- ing"	Set to 0						
Pr1.19 "Position gain switching time"	Set to 10						
Pr1.20 "Mode of velocity control switching"	Set to 0						
Pr1.21 "Delay time of velocity control switch- ing"	Set to 0						
Pr1.22 "Level of velocity control switching"	Set to 0						
Pr1.23 "Hysteresis at velocity control switch- ing"	Set to 0						
Pr1.24 "Mode of torque control switching"	Set to 0						
Pr1.25 "Delay time of torque control switching"	Set to 0						
Pr1.26 "Level of torque control switching"	Set to 0						
Pr1.27 "Hysteresis at torque control switching"	Set to 0						
Pr6.05 "Position 3rd gain valid time"	Set to 0 (disab	led)	Set to "Pr2.22 >	< 20"			
			(However, the r 10000.)	naximum value	is limited to		
Pr6.06 "Position 3rd gain scale factor"	Set to 100 (100	0%)	Set to 200 (200	%)			

# Parameters set based on Load fluctuation suppression function automatic tuning

When Pr0.02 "Real-time auto-gain tuning setup" is between 1 to 4 or 7, set the following parameters according to Pr6.10 "Function expansion setup" :bit 14 "Load fluctuation suppression function automatic tuning".

Target parameter	Condition	Value to be set		
		Pr6.10:bit 14 = 1	Pr6.10:bit 14 = 0	
Pr6.10 "Function expan- sion setup"	When stiffness setup is enabled	bit 1 "Load fluctuation con- trol function" = 1 (enabled)	bit 1 "Load fluctuation con- trol function" = 0 (disabled)	
Pr6.23 "Load change com- pensation gain"	When stiffness setup is enabled	Set to 90 (90%)	Set to 0	
Pr6.24 "Load change com- pensation filter"	When stiffness setup is enabled	Updates to set value ac- cording to stiffness	Retain value	
Pr6.73 "Load estimation fil- ter"	When stiffness setup is enabled and Pr2.45 "Function expansion setup 10" :bit 3 = 0	Set to 13	Set to 0	
When stiffness setup is enabled a Pr2.45 "Function expansion setup 10" :bit 3 = 1		Set automatically		
Pr6.74 "Torque compensa- tion frequency 1"	Set to 0 regardless of the value of Pre	5.10:bit 14.		
Pr6.75 "Torque compensa- tion frequency 2"	Set to 0 regardless of the value of Pre	6.10:bit 14.		
Pr6.76 "Load estimation count"	When stiffness setup is enabled and Pr2.45 "Function expansion setup 10" :bit 3 = 0	Set to 4	Set to 0	
When stiffness setup is enabl Pr2.45 "Function expansion s 10" :bit 3 = 1		Automatically set according to stiffness		

## 4.1.1.5 How to Use

- When Pr0.02 "Real-time auto-gain tuning setup" is set to 1 to 4 or 7, real-time auto tuning is enabled. The parameter values used for tuning are automatically set according to the parameter settings below.
  - Pr0.03 "Real-time auto-tuning machine stiffness setup"
  - Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
  - Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning"
  - Pr6.10 "Function expansion setup" :bit 14 "Load fluctuation suppression function automatic tuning"
- Input the operation command after approximately 100 ms have elapsed since servo-on.
- Pr0.04 "Inertia ratio" changes when load characteristics estimation is complete. Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" also change depending on the mode setting (see <u>"Supplement"</u>).
- Increasing the setup values of the following parameters will increase the responsiveness of the motor. While checking the positioning settling time and vibration state, increase the setup values by increments of 1 and tune to the optimal values.
  - Pr0.03 "Real-time auto-tuning machine stiffness setup"
  - Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
  - Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning"
- Setting Pr0.02 "Real-time auto-gain tuning setup" to 0 disables real-time auto tuning. Automatic estimation of Pr0.04 "Inertia ratio" stops, but the inertia ratio value at the time of estimation stopping is retained. If the value of the inertia ratio is clearly abnormal, set a reasonable value manually.

### Notes

• Pr2.52, Pr2.53 and Pr2.54

Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection". The initial value is Pr2.45: bit 2 = 1.

- Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
- Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.
  - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
  - Pr2.45: bits 5 to 4 = 10b : Pr0.27
  - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

## – Precautions –

- When real-time auto tuning is enabled, the response to estimated values after power-up to completion
  of load characteristic estimation may be faster regardless of the set value for Pr6.31 "Real time auto
  tuning estimation speed".
- Immediately after power-up, there is not enough operation data effective for load characteristic estimation, meaning estimated values may be abnormal and operation instable due to disturbance, etc. Once tuning is finished, we recommended that real-time auto tuning is set to disabled (Pr0.02 "Real-time auto-gain tuning setup" = 0).
- Until load characteristic estimation results stabilize, abnormal noise or oscillation may occur.
   For example, if abnormal noise or oscillation occurs immediately after the first servo-on after activation or when the Pr0.03 "Real-time auto-tuning machine stiffness setup" set value is increased, it is not abnormal for the operation to stabilize immediately. After abnormal noise or oscillation occurs ,Pr0.04

"Inertia ratio", Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", or Pr2.54 "Negative direction torque compensation value 2" may change to extreme values. Take the following measures. The following measures should also be taken if abnormal noise or oscillation occurs frequently.

- 1 Lower the set value for Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2".
- 2 Set Pr0.02 "Real-time auto-gain tuning setup" to 0 to disable real-time auto tuning.
- 3 Set Pr0.04 "Inertia ratio" to the value calculated on the device and set Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" to 0 (see <u>"Supplement"</u>).
- 4 After setting Pr6.10 "Function expansion setup" :bit 14 = 0, set bit 1 = 0 to disable the load fluctuation control function.
- The Pr0.04 "Inertia ratio", Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" (see <u>"Supplement"</u>) values, which are the results of real-time auto gain tuning, are automatically written to and saved in EEPROM every 30 minutes. When power is restored, auto tuning is performed using the saved EEPROM values as the initial values. If turning OFF the power without 30 minutes having elapsed since values were automatically saved in EEPROM, manually write the latest real-time auto gain tuning results to EEPROM before turning OFF the power.
- Since control gain is updated when the motor stops, changes to Pr0.03 "Real-time auto-tuning machine stiffness setup", Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2", and Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning" settings are not reflected if the motor does not stop (if the gain is extremely low or if a command is continuously given in one direction).

Before changing any of the above three parameters related to stiffness setup, stop the motor once to make sure that the stiffness setup has been reflected. Depending on the stiffness setup reflected after the motor is stopped, abnormal noise or oscillation may occur.

- In torque control of two-degree-of-freedom control mode, when real-time auto tuning is enabled, torque feedforward is disabled (equivalent to Pr1.12 = 0) regardless of the Pr1.12 "Torque feed forward gain" set value. Operation continues with torque feedforward disabled until the next operation is performed.
  - Set Pr1.12 "Torque feed forward gain" to a value other than the current parameter (1000) after switching real-time auto tuning from enabled to disabled.
- The following are linked in the Set-up Support Software (PANATERM ver.7) Manual TUNING screen.
  - Feedback gain setting: Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
  - FF gain setting: Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning"

### Notes

• Pr2.52, Pr2.53 and Pr2.54

Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection". The initial value is Pr2.45: bit 2 = 1.

- Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
- Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.
  - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03

- Pr2.45: bits 5 to 4 = 10b : Pr0.27
- Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

# 4.1.1.6 Basic Gain Parameter Setup Table

-: None									
Stiffness <sup>(*1)</sup>			1st gain/	2nd gain		Command	Load fluctuation suppression		
Pr0 0.3 (*1)	Pr0.27	Pr1.00	Pr1.01	Pr1.02	Pr1.04	Pr2.22		Pr6 48 <sup>(*3)</sup>	Pr6.24
110.00	Pr0.28 <sup>(*1)</sup>	Pr1.05	Pr1.06	Pr1.07	Pr1.09 <sup>(*2)</sup>			110.40	
		Position	Speed	Speed in-	Torque	Time constant		Time con-	Load change
		[0.1 s <sup>-1</sup> ]	[0.1 Hz]	tegration	[0.01 ms]	[0.1	ms]	stant	compensation
				[0.1 110]		Standard response mode	High re- sponse modes 1 to 3	[0.1 110]	
0	0	20	15	3700	1500	1919	764	155	2500
1	1	25	20	2800	1100	1487	595	115	2500
2	2	30	25	2200	900	1214	486	94	2500
3	3	40	30	1900	800	960	384	84	2500
4	4	45	35	1600	600	838	335	64	2500
5	5	55	45	1200	500	668	267	54	2500
6	6	75	60	900	400	496	198	44	2500
7	7	95	75	700	300	394	158	34	2120
8	8	115	90	600	300	327	131	34	1770
9	9	140	110	500	200	268	107	24	1450
10	10	175	140	400	200	212	85	23	1140
_	11	250	160	350	163	170	68	19	1000
11	12	320	180	310	126	139	55	16	880
_	13	355	200	280	114	125	49	14	795
12	14	390	220	250	103	113	45	13	720
_	15	435	245	225	93	101	40	12	650
13	16	480	270	210	84	92	37	11	590
_	17	535	300	190	74	82	33	10	535
14	18	630	350	160	65	71	28	9	450
15	19	720	400	140	57	62	25	8	400
_	20	810	450	125	51	55	22	7	355
16	21	900	500	120	45	50	20	7	320
_	22	990	550	110	41	45	18	6	290
17	23	1080	600	110	38	41	17	6	270
_	24	1170	650	105	35	37	15	5	250
	25	1260	700	100	32	35	14	5	235
18	26	1350	750	90	30	33	13	5	210
	27	1490	825	85	27	30	12	5	190
19	28	1620	900	80	25	28	11	5	180
_	29	1850	1025	70	22	24	10	4	160

Stiffness <sup>(*1)</sup>		1st gain/2nd gain				Command response		Tuning fil- ter	Load fluctuation suppression
Pr0.03 <sup>(*1)</sup>	Pr0.27 Pr0.28 <sup>(*1)</sup>	Pr1.00 Pr1.05	Pr1.01 Pr1.06	Pr1.02 Pr1.07	Pr1.04 Pr1.09 <sup>(*2)</sup>	Pr2.22		Pr6.48 <sup>(*3)</sup>	Pr6.24
		Position [0.1 s <sup>-1</sup> ]	Speed [0.1 Hz]	SpeedSpeed in- tegrationTorque [0.01 ms]Time constant [0.1 ms]		Time constant [0.1 ms]		Load change compensation	
				[0.11115]		Standard response mode	High re- sponse modes 1 to 3	[0.1 ms]	
20	30	2060	1150	70	20	22	9	4	140
_	31	2260	1260	65	18	20	8	4	130
21	32	2510	1400	60	16	18	7	4	110
_	33	2780	1550	55	14	16	6	3	100
22	34	3050	1700	50	13	15	6	3	90
_	35	3410	1900	45	12	13	5	3	80
23	36	3770	2100	40	11	12	5	3	80
24	37	4490	2500	40	9	10	4	3	60
25	38	5000	2800	35	8	9	4	2	60
26	39	5600	3100	30	7	8	3	2	50
27	40	6100	3400	30	7	7	3	2	50
28	41	6600	3700	25	6	7	3	2	40
29	42	7200	4000	25	6	6	2	2	40
30	43	8100	4500	20	5	6	2	2	40
31	44	9000	5000	20	5	5	2	2	40

\*1 Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.

- Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
- Pr2.45: bits 5 to 4 = 10b : Pr0.27
- Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

In the initial settings, only Pr2.22 is set according to Pr0.28 in the basic gain parameter setup table.

- \*2 The values in the table are used only when Pr2.45 "Function expansion setup 10" :bit 1 to 0 = 0.
- \*3 Pr6.48 "Tuning filter" may be +1 depending on the combination of servo driver and motor. Also, Pr6.48 is not used because Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2" =1 (enabled) in the initial settings. The Pr2.46 "Tuning filter 2" value is set automatically when real-time auto tuning is enabled.
# 4.1.2 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Synchronization Type)

# 4.1.2.1 Function Overview

The two-degree-of-freedom control mode for synchronization type is suitable for controlling multiple loci such as with multijoint robots, because the command response setting for each axis can be set to the same value.

Set Pr6.47 "Function expansion setup 2" :bit 0 "Two-degree-of-freedom control mode" = 1 (enabled) and bit 3 "Two-degree-of-freedom control real-time auto tuning selection" = 1 (synchronization type) to set this type.

# 4.1.2.2 Operation Mode

In real-time auto tuning (two-degree-of-freedom control mode for synchronization type), the operation mode can be changed according to Pr0.02 "Real-time auto-gain tuning setup". In each operation mode, automatic inertia ratio updates, basic gain setting, dynamic friction compensation, and viscous friction compensation can be enabled or disabled. An operation mode (Pr0.02 = 6) is also available for applications where load inertia fluctuates, such as multijoint robots.

Setup value	Operation mode	Description
0	Disabled	The real-time auto tuning function is disabled.
1	Synchronization	This mode is for synchronous control. The settings for unbalanced load compensation and friction compensation are not changed. The command response filter is retained. Use this mode first. If you have any issues, try a different mode.
2	Synchronous friction compensation	In addition to synchronous mode, dynamic friction compensation and viscous friction compensation are applied. Use this mode for loads with high friction.
3	Stiffness setup	Only the gain and filter settings corresponding to the stiffness table are updated without changing the settings for inertia ratio estimation, unbalanced load compensation or friction compensation. For loads with significant inertia change, use this mode after inertia ratio estimation in the
		synchronous mode, etc.
4	Load characteristics up- date	Of the load characteristics, only the inertia ratio, dynamic friction compensation and vis- cous friction compensation are updated. Gain and filter settings retain their current val- ues.
5	Load characteristic measurement	The basic gain setting and friction compensation setting are not changed, only load char- acteristic estimation is performed. Used in combination with Set-up Support Software (PANATERM ver.7).
6	Load fluctuation support mode	Use this mode for robust tuning against load fluctuations.
7	Disabled	The real-time auto tuning function is disabled for the two-degree-of-freedom control mode for synchronization type.

#### Details on Pr0.02 "Real-time auto-gain tuning setup"

# 4.1.2.3 Operational Conditions

Item	Operational Conditions	
Control mode	Position control	
	• Pr6.47:bit 0 = 1 and bit 3 = 1 (synchronization type)	

Real-time auto tuning may not work normally under the following conditions. In such cases, change the load conditions, operation pattern, or refer to the manual TUNING function description and manually set the related parameters.



### 4.1.2.4 Related Parameters

4.1.2.4.1	Parameters	<b>That Control</b>	the Operation	of This Function
-----------	------------	---------------------	---------------	------------------

						—: None
Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
0	02	В	Real-time auto- gain tuning setup	0 to 7	-	Sets the real-time auto tuning operation mode.
0	03	В	Real-time auto- tuning machine stiffness setup	0 to 31	_	Sets responsiveness when real-time auto tuning is ena- bled. Higher settings result in higher speed responsive- ness and servo stiffness, but make it more likely that vi- bration will occur. Values should be changed from low to high with a close eye on operation. Enabled with Pr2.45 "Function expansion setup 10" : bit 5 = 0 (32 stiffness settings).
0	27	В	Selection of ma- chine stiffness at real-time auto- gain tuning 2	0 to 44	_	Sets responsiveness when real-time auto tuning is ena- bled. Higher settings result in higher speed responsive- ness and servo stiffness, but make it more likely that vi- bration will occur. Values should be changed from low to high with a close eye on operation. Allows finer gain adjustment than Pr0.03. Enabled with Pr2.45 "Function expansion setup 10" : bit 5 = 1 (45 stiffness settings).
0	28	В	Selection of feed forward stiffness at real-time auto- gain tuning	0 to 44	-	Cannot be used with two-degree-of-freedom control mode for synchronization type.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function	
2	74	A	Tuning auto tun- ing application selection	-32768 to 32767	_	Cannot be used with two-degree-of-freedom control mode for synchronization type.	
6	10	В	Function expan- sion setup	-32768 to 32767	_	bit 14: Load fluctuation suppression function automatic tuning 0: Disabled 1: Enabled	
6	31	В	Real time auto tuning estimation speed	0 to 3	_	Sets load characteristics estimated speed when real-time auto-tuning is enabled. Higher settings result in faster re- sponses to changes in load characteristics, but they also increase variations in disturbance estimation.	
						Estimation results are saved in EEPROM every 30 mi- nutes regardless of the load characteristic estimated speed setting.	
						When automatic vibration detection is enabled from Set- up Support Software (PANATERM ver.7), this setting will be ignored and the setting value will be set to 3.	
	Set val	Setup Mode value				Description	
	C	)	Does not change	Stops load cha	racteri	teristics estimation.	
	1		Changes very little	Estimates char	Estimates changes in load characteristics in minutes.		
	2		Changes slowly	Estimates char	Estimates changes in load characteristics in seconds.		
	3	3	Changes precipitously	y Fastest estima	tion of	changes in load characteristics.	
6	32	В	Real time auto tuning custom setup	-32768 to 32767	_	Cannot be used with two-degree-of-freedom control mode for synchronization type. Use with the setup value at 0.	

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# 4.1.2.4.2 Parameters to Switch the Parameters Used by This Function to Minas A6 Series-Compatible Specification

In real-time auto tuning, the parameters used in real-time auto tuning can be switched to MINAS A6 Seriescompatible specification parameters by setting Pr2.45 "Function expansion setup 10".

- Parameters related to stiffness, unbalanced load and friction compensation and tuning filters
- Calculation method when updating torque filter time constant and some parameters for load fluctuation compensation (Pr6.73 "Load estimation filter" and Pr6.76 "Load estimation count" )

Item	Parameters for switching to MINAS A6 Series-compatible specification	Initial value (*1)
Stiffness	Can be changed with Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching" .	bits 5 to 4 = 11b
Unbalanced load/fric- tion compensation	Can be changed with Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection" .	bit 2 = 1
Tuning filter	Can be changed with Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2".	bit 1 = 1
Torque filter time constant	Determined by the value of Pr2.45 "Function expansion setup 10" :bit 1 to 0 "Two-degree-of-freedom control function setting" .	bits 1 to 0 = 01b
Load fluctuation compensation	Determined by the value of Pr2.45 "Function expansion setup 10" :bit 3 "Load fluctua- tion suppression function automatic calculation".	bit 3 = 1

#### \*1 Normally used with initial values.

	_	_				—: None
Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	38	В	Filter function switching	-32768 to 32767	_	Select a tuning filter. Normally, set to bit 1 = 1. bit 1: Tuning filter 2 0: Use Pr6.48 "Tuning filter" (MINAS A6 Series-compati- ble specification) 1: Use Pr2.46 "Tuning filter 2" (MINAS A7 Series specifi- cation)
2	45	В	Function expan- sion setup 10	-2147483648 to 2147483647		Sets various functions. bit 1 to 0: Two-degree-of-freedom control function setting bit 2: Friction torque compensation parameter selection bit 3: Load fluctuation suppression function automatic cal- culation bit 5 to 4: Stiffness setting resolution, individual FB/FF set- ting switching bit 31 to 6: Unused

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# Details on Pr2.45 "Function expansion setup 10"

			—: N/A
bit	Name	Description	Initial value
1 to 0	Two-degree-of-freedom control function setting	00b: Two-degree-of-freedom control (MINAS A6 Series-compatible specification)	01b
		01b: Two-degree-of-freedom control (MINAS A7 Series specifica- tion)	
		10b: Manufacturer use	
		11b: Manufacturer use	
2	Friction torque compen-	0: MINAS A6 Series-compatible specification settings	1
	sation parameter selec-	Unbalanced load compensation value: Use Pr6.07	
	uon	Dynamic friction compensation value: Use Pr6.08, Pr6.09	
		1: MINAS A7 Series specification settings	
		Unbalanced load compensation value: Use Pr2.52	
		Dynamic friction compensation value: Use Pr2.53, Pr2.54	
3	Load fluctuation sup- pression function auto- matic calculation	0: Conventional setting (MINAS A6 Series specification)	1
		1: The following parameters are automatically calculated.	
		Pr6.73 "Load estimation filter"	
		Pr6.76 "Load estimation count"	
5 to 4	Stiffness setting resolu- tion, individual FB/FF	00b: 32 stiffness settings, FB/FF common setting (MINAS A6 Ser- ies-compatible specification)	11b
	setting switching	Use Pr0.03	
		01b: Same as 00b	
		10b: 45 stiffness settings, FB/FF common setting (MINAS A7 Series specification)	
		Use Pr0.27	
		11b: 45 stiffness settings, individual FB/FF settings (MINAS A7 Series specification)	
		Use Pr0.27 and Pr0.28	
31 to 6	Not used	-	_

# 4.1.2.4.3 Parameters Changed By This Function

#### Parameters updated using estimated values for load characteristics

Real-time auto tuning updates the parameters in the table below using the estimated value for load characteristics based on the Pr0.02 "Real-time auto-gain tuning setup" setting.

Target para	ameter <sup>(*1)</sup>	Conditions for update
Pr2.45:bit 2 = 1	Pr2.45:bit 2 = 0	
Pr0.04 "Inertia ratio"		When in synchronous mode ( $Pr0.02 = 1$ ), synchronous friction compensation mode ( $Pr0.02 = 2$ ), or load characteristics update mode ( $Pr0.02 = 4$ ).
		However, in load fluctuation support mode (Pr0.02 = 6), the value is fixed at 100.
Pr2.52 "Torque command addi- tional value 2"	Pr6.07 "Torque command ad- ditional value"	When in synchronous friction compensation mode (Pr0.02 = 2) or load characteristics update mode (Pr0.02 = 4)
Pr2.53 "Positive direction tor- que compensation value 2" Pr6.08 "Positive direction tor- que compensation value"		
Pr2.54 "Negative direction tor- que compensation value 2" Pr6.09 "Negative direction tor- que compensation value"		
Pr6.50 "Viscous friction compen	sating gain"	

\*1 Change the parameters to be used depending on Pr2.45 "Function expansion setup 10" and bit 2 "Friction torque compensation parameter selection" set values. The initial setting is Pr2.45:bit 2 = 1.

#### Basic gain setting parameters updated according to machine stiffness settings

Real-time auto tuning updates the basic gain setting parameters according to the parameter settings below. For details, see <u>"4.1.2.6 Basic Gain Parameter Setup Table"</u>.

- Pr0.03 "Real-time auto-tuning machine stiffness setup"
- Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"

#### Notes

- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.
  - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
  - Pr2.45: bits 5 to 4 = 10b : Pr0.27
  - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

Pr0.28 is disabled.

#### Basic gain setting

Target parameter	Conditions for update according to stiffness
Pr1.00 "1st gain of position loop"	• When in synchronous mode, synchronous friction compensation mode, stiffness setting mode, or load fluctuation support mode (Pr0.02 = 1 to 3
Pr1.01 "1st velocity loop gain"	or 6)
Pr1.02 "1st velocity loop integration time con- stant"	
Pr1.04 "1st torque filter time constant"	
Pr1.05 "2nd gain of position loop"	
Pr1.06 "2nd velocity loop gain"	
Pr1.07 "2nd velocity loop integration time con-	
stant"	
Pr1.09 "2nd torque filter time constant"	

Target parameter	Conditions for update according to stiffness
Pr2.46 "Tuning filter 2"	<ul> <li>Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2" = 1 (enabled)</li> </ul>
	When in synchronous mode, synchronous friction compensation mode, stiffness setting mode, or load fluctuation support mode (Pr0.02 = 1 to 3, or 6)
Pr6.48 "Tuning filter"	<ul> <li>Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2" = 0 (disabled)</li> </ul>
	When in synchronous mode, synchronous friction compensation mode, stiffness setting mode, or load fluctuation support mode (Pr0.02 = 1 to 3, or 6)
Pr6.49 "Command response/tuning filter at- tenuation term"	• Set the tens place to 1 and keep the ones place unchanged when in syn- chronous mode, synchronous friction compensation mode, stiffness set- ting mode, or load fluctuation support mode (Pr0.02 = 1 to 3, or 6).

## ■ Parameters set according to Pr0.02 "Real-time auto-gain tuning setup" settings

Real-time auto tuning sets the following parameters according to the Pr0.02 "Real-time auto-gain tuning setup" settings.

Target parameter	Values to set when in synchronous mode, synchronous friction compensa- tion mode, stiffness setting mode, or load fluctuation support mode (Pr0.02 = 1 to 3, or 6)
Pr1.03 "1st filter of velocity detection"	Set to 0
Pr1.08 "2nd filter of velocity detection"	Set to 0
Pr1.10 "Velocity feed forward gain"	Set to 1000 (100%)
Pr1.11 "Velocity feed forward filter"	Set to 0 (disabled)
Pr1.12 "Torque feed forward gain"	Set to 1000 (100%)
Pr1.13 "Torque feed forward filter"	Set to 0 (disabled)
Pr1.14 "2nd gain setup"	Set to 1
Pr1.15 "Mode of position control switching"	Set to 0
Pr1.16 "Delay time of position control switch- ing"	Set to 10 (1.0 ms).
Pr1.17 "Level of position control switching"	Set to 0
Pr1.18 "Hysteresis at position control switch- ing"	Set to 0
Pr1.19 "Position gain switching time"	Set to 10 (1.0 ms).
Pr1.20 "Mode of velocity control switching"	Set to 0
Pr1.21 "Delay time of velocity control switch- ing"	Set to 0
Pr1.22 "Level of velocity control switching"	Set to 0
Pr1.23 "Hysteresis at velocity control switch- ing"	Set to 0
Pr1.24 "Mode of torque control switching"	Set to 0
Pr1.25 "Delay time of torque control switching"	Set to 0
Pr1.26 "Level of torque control switching"	Set to 0
Pr1.27 "Hysteresis at torque control switching"	Set to 0
Pr6.10 "Function expansion setup"	Set bit 4 "Current response improvement" to 1 (enabled)

## Parameters set based on Load fluctuation suppression function automatic tuning

When Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4, set the following parameters according to Pr6.10 "Function expansion setup" :bit 14 "Load fluctuation suppression function automatic tuning".

Target parameter	Target parameter Condition		Value to be set				
		Pr6.10:bit 14 = 1	Pr6.10:bit 14 = 0				
Pr6.10 "Function expan- sion setup"	When stiffness setup is enabled	bit 1 "Load fluctuation con- trol function" = 1 (enabled)	bit 1 "Load fluctuation con- trol function" = 0 (disabled)				
Pr6.23 "Load change com- pensation gain"	When stiffness setup is enabled	Set to 90 (90%)	Set to 0				
Pr6.24 "Load change com- pensation filter"	When stiffness setup is enabled	Updates to set value ac- cording to stiffness	Retain value				
Pr6.73 "Load estimation fil- ter" When stiffness setup is enal Pr2.45 "Function expansion 10" :bit 3 = 0		Set to 13	Set to 0				
	When stiffness setup is enabled and Pr2.45 "Function expansion setup 10" :bit 3 = 1	Set automatically					
Pr6.74 "Torque compensa- tion frequency 1"	sa- Set to 0 regardless of the value of Pr6.10:bit 14.						
Pr6.75 "Torque compensa- tion frequency 2"	Set to 0 regardless of the value of Pre	5.10:bit 14.					
Pr6.76 "Load estimation count"	When stiffness setup is enabled and Pr2.45 "Function expansion setup 10" :bit 3 = 0	Set to 4	Set to 0				
	When stiffness setup is enabled and Pr2.45 "Function expansion setup 10" :bit 3 = 1	Automatically set according	to stiffness				

When Pr0.02 "Real-time auto-gain tuning setup" is set to 6 (load fluctuation support mode), the settings change to those shown in the table below.

Target parameter	Value to be set
Pr6.10 "Function expansion setup"	The load fluctuation control function is always enabled (bit 1 = 1, bit 2 = 1)
Pr6.23 "Load change compensation gain"	Set to 100%
Pr6.24 "Load change compensation filter"	Updates to set value according to stiffness
Pr6.73 "Load estimation filter"	Set to 13 (0.13 ms).
Pr6.74 "Torque compensation frequency 1"	Updates to set value according to stiffness
Pr6.75 "Torque compensation frequency 2"	Updates to set value according to stiffness
Pr6.76 "Load estimation count"	Set to 4

#### 4.1.2.5 How to Use

- When Pr0.02 "Real-time auto-gain tuning setup" is set to 1 to 3 or 6, real-time auto tuning is enabled. The parameter values used for tuning are automatically set according to the parameter settings below.
  - Pr0.03 "Real-time auto-tuning machine stiffness setup"
  - Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
  - Pr6.10 "Function expansion setup" :bit 14 "Load fluctuation suppression function automatic tuning"
- Input the operation command after approximately 100 ms have elapsed since servo-on.
- Pr0.04 "Inertia ratio" changes when load characteristics estimation is complete. Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" also change depending on the mode setting (see <u>"Supplement"</u>).
- Increasing the set value of either of the following parameters will increase motor responsiveness. While checking the positioning settling time and vibration state, increase the setup values by increments of 1 and tune to the optimal values.
  - Pr0.03 "Real-time auto-tuning machine stiffness setup"

- Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
- Setting Pr0.02 "Real-time auto-gain tuning setup" to 0 disables real-time auto tuning. Automatic estimation of Pr0.04 "Inertia ratio" stops, but the inertia ratio value at the time of estimation stopping is retained. If the value of the inertia ratio is clearly abnormal, set a reasonable value manually.

#### Notes

• Pr2.52, Pr2.53 and Pr2.54

Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection". The initial value is Pr2.45: bit 2 = 1.

- Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
- Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.
  - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
  - Pr2.45: bits 5 to 4 = 10b : Pr0.27
  - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

Pr0.28 is disabled.

#### – Precautions –

- When real-time auto tuning is enabled, the response to estimated values after power-up to completion of load characteristic estimation may be faster regardless of the set value for Pr6.31 "Real time auto tuning estimation speed".
- Immediately after power-up, there is not enough operation data effective for load characteristic estimation, meaning estimated values may be abnormal and operation instable due to disturbance, etc. Once tuning is finished, we recommended that real-time auto tuning is set to disabled (Pr0.02 "Real-time auto-gain tuning setup" = 0).
- Until load characteristic estimation results stabilize, abnormal noise or oscillation may occur.

For example, if abnormal noise or oscillation occurs immediately after the first servo-on after activation or when the Pr0.03 "Real-time auto-tuning machine stiffness setup" set value is increased, it is not abnormal for the operation to stabilize immediately. After abnormal noise or oscillation occurs ,Pr0.04 "Inertia ratio" , Pr2.52 "Torque command additional value 2" , Pr2.53 "Positive direction torque compensation value 2" , or Pr2.54 "Negative direction torque compensation value 2" may change to extreme values. Take the following measures. The following measures should also be taken if abnormal noise or oscillation occurs frequently.

- 1 Lower the set value for Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2".
- 2 Set Pr0.02 "Real-time auto-gain tuning setup" to 0 to disable real-time auto tuning.
- Set Pr0.04 "Inertia ratio" to the value calculated on the device and set Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" to 0 (see <u>"Supplement"</u>).
- 4 After setting Pr6.10 "Function expansion setup" :bit 14 = 0, set bit 1 = 0 to disable the load fluctuation control function.
- The Pr0.04 "Inertia ratio", Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" (see <u>"Supplement"</u>) values, which are the results of real-time auto gain tuning, are automatically written to and saved in EEPROM every 30 minutes. When power is restored, auto tuning is performed using the saved EEPROM values as the initial values. If turning OFF the power without 30 minutes having

elapsed since values were automatically saved in EEPROM, manually write the latest real-time auto gain tuning results to EEPROM before turning OFF the power.

 Since control gain is updated when the motor stops, changes to Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2" settings are not reflected if the motor does not stop (if the gain is extremely low or if a command is continuously given in one direction).

Before changing any of the above parameters related to stiffness setup, stop the motor once to make sure that the stiffness setup has been reflected. Depending on the stiffness setup reflected after the motor is stopped, abnormal noise or oscillation may occur.

- In torque control of two-degree-of-freedom control mode, when real-time auto tuning is enabled, torque feedforward is disabled (equivalent to Pr1.12 = 0) regardless of the Pr1.12 "Torque feed forward gain" set value. Operation continues with torque feedforward disabled until the next operation is performed.
  - Set Pr1.12 "Torque feed forward gain" to a value other than the current parameter (1000) after switching real-time auto tuning from enabled to disabled.
- The following are linked in the Set-up Support Software (PANATERM ver.7) Manual TUNING screen.
  - Feedback gain setting: Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"

#### Notes

• Pr2.52, Pr2.53 and Pr2.54

Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection". The initial value is Pr2.45: bit 2 = 1.

- Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
- Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.
  - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
  - Pr2.45: bits 5 to 4 = 10b : Pr0.27
  - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

Pr0.28 is disabled.

# 4.1.2.6 Basic Gain Parameter Setup Table

											—: None
Stiff	Stiffness		1st gain/2nd gain			Tuning filter	For load fluctua- tion con- trol func- tion	Only in	load fluctua (Pr0.0	ation suppo 02 = 6)	ort mode
Pr0.03 (*1)	Pr0.27 (*1)	Pr1.00 Pr1.05	Pr1.01 Pr1.06	Pr1.02 Pr1.07	Pr1.04 Pr1.09 (*2)	Pr6.48 (*3)	Pr6.24	Pr1.00 Pr1.05	Pr6.24	Pr6.74	Pr6.75
		Position [0.1 s <sup>-1</sup> ]	Speed [0.1 Hz]	Speed integra- tion [0.1 ms]	Torque [0.01 ms ]	Time constant [0.1 ms]	Load change compen- sation filter [0.01 ms ]	Load fluctua- tion po- sition loop gain [0.1 s <sup>-1</sup> ]	Load change compen- sation filter [0.01 ms ]	Torque compen- sation frequen- cy L [0.1 Hz]	Torque compen- sation frequen- cy H [0.1 Hz]
0	0	20	15	3700	1500	155	2500	15	1330	25	10
1	1	25	20	2800	1100	115	2500	20	990	34	10
2	2	30	25	2200	900	94	2500	25	800	42	12
3	3	40	30	1900	800	84	2500	30	660	51	15
4	4	45	35	1600	600	64	2500	35	570	59	17
5	5	55	45	1200	500	54	2500	45	440	76	22
6	6	75	60	900	400	44	2500	60	330	104	30
7	7	95	75	700	300	34	2120	75	270	129	37
8	8	115	90	600	300	34	1770	90	220	153	44
9	9	140	110	500	200	24	1450	110	180	184	53
10	10	175	140	400	200	23	1140	140	140	231	66
_	11	250	160	350	163	19	1000	160	120	264	75
11	12	320	180	310	126	16	880	180	110	290	83
_	13	355	200	280	114	14	795	200	100	322	92
12	14	390	220	250	103	13	720	220	90	346	99
_	15	435	245	225	93	12	650	245	80	385	110
13	16	480	270	210	84	11	590	270	70	413	118
_	17	535	300	190	74	10	535	300	65	458	131
14	18	630	350	160	65	9	450	350	60	512	146
15	19	720	400	140	57	8	400	400	50	570	163
_	20	810	450	125	51	7	355	450	45	641	183
16	21	900	500	120	45	7	320	500	40	678	194
_	22	990	550	110	41	6	290	550	40	678	194
17	23	1080	600	110	38	6	270	600	40	678	194
_	24	1170	650	105	35	5	250	650	40	678	194
-	25	1260	700	100	32	5	235	700	40	678	194
18	26	1350	750	90	30	5	210	750	40	678	194
-	27	1490	825	85	27	5	190	825	40	678	194
19	28	1620	900	80	25	5	180	900	40	678	194
-	29	1850	1025	70	22	4	160	1025	40	678	194
20	30	2060	1150	70	20	4	140	1150	40	678	194

Stiff	Stiffness 1st gain/2nd gain				Tuning filter	For load fluctua- tion con- trol func- tion	Only in load fluctuation support mode (Pr0.02 = 6)			ort mode	
Pr0.03 (*1)	Pr0.27 (*1)	Pr1.00 Pr1.05	Pr1.01 Pr1.06	Pr1.02 Pr1.07	Pr1.04 Pr1.09 (*2)	Pr6.48 (*3)	Pr6.24	Pr1.00 Pr1.05	Pr6.24	Pr6.74	Pr6.75
		Position [0.1 s <sup>-1</sup> ]	Speed [0.1 Hz]	Speed integra- tion [0.1 ms]	Torque [0.01 ms ]	Time constant [0.1 ms]	Load change compen- sation filter [0.01 ms ]	Load fluctua- tion po- sition loop gain [0.1 s <sup>-1</sup> ]	Load change compen- sation filter [0.01 ms ]	Torque compen- sation frequen- cy L [0.1 Hz]	Torque compen- sation frequen- cy H [0.1 Hz]
_	31	2260	1260	65	18	4	130	1260	40	678	194
21	32	2510	1400	60	16	4	110	1400	40	678	194
_	33	2780	1550	55	14	3	100	1550	40	678	194
22	34	3050	1700	50	13	3	90	1700	40	678	194
_	35	3410	1900	45	12	3	80	1900	40	678	194
23	36	3770	2100	40	11	3	80	2100	40	678	194
24	37	4490	2500	40	9	3	60	2500	40	678	194
25	38	5000	2800	35	8	2	60	2800	40	678	194
26	39	5600	3100	30	7	2	50	3100	40	678	194
27	40	6100	3400	30	7	2	50	3400	40	678	194
28	41	6600	3700	25	6	2	40	3700	40	678	194
29	42	7200	4000	25	6	2	40	4000	40	678	194
30	43	8100	4500	20	5	2	40	4500	40	678	194
31	44	9000	5000	20	5	2	40	5000	40	678	194

\*1 Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.

• Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03

• Pr2.45: bits 5 to 4 = 10b : Pr0.27

• Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

Pr0.28 is disabled for synchronization type.

- \*2 The values in the table are used only when Pr2.45 "Function expansion setup 10" :bit 1 to 0 = 0.
- \*3 Pr6.48 "Tuning filter" may be +1 depending on the combination of servo driver and motor. Also, Pr6.48 is not used because Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2" =1 (enabled) in the initial settings. The Pr2.46 "Tuning filter 2" value is set automatically when real-time auto tuning is enabled.

# 4.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)

#### 4.1.3.1 Function Overview

This is a type of real-time auto tuning function without two-degree-of-freedom control. Set Pr6.47 "Function expansion setup 2" :bit 0 "Two-degree-of-freedom control mode" = 0 (disabled) to set this type.

# 4.1.3.2 Operation Mode

In real-time auto tuning (two-degree-of-freedom control mode disabled type), the operation mode can be changed according to Pr0.02 "Real-time auto-gain tuning setup". In each operation mode, automatic inertia ratio updates, basic gain setting, unbalanced load compensation, and friction compensation can be enabled or disabled. Also, when Pr0.02 = 7, automatic inertia ratio updates, basic gain setting, unbalanced load compensation can be enabled or disabled individually. Select Pr0.02 = 7 (set value 7) to optimize each function according to device characteristics.

Details on Pr0.02 "Real-time auto-gain tuning setup"

Setup value	Operation mode	Description
0	Disabled	The real-time auto tuning function is disabled.
1	Standard	This is a mode with an emphasis on stability. Unbalanced load compensation and friction compensation are not performed, and gain switching is not used.
2	Positioning	This is a positioning-focused mode. Use for devices such as low-friction ball screw driven devices that do not have unbalanced load on the horizontal axis.
		In terms of speed control and torque control, this mode is the same as standard mode.
3	Vertical axis	In addition to positioning mode, this mode suppresses variation in positioning settling time using unbalanced load compensation, such as a vertical axis.
		In terms of torque control, this mode is the same as standard mode.
4	Friction compensation	In addition to the vertical axis mode, this mode shortens the positioning settling time with a belt mechanical shaft with high friction, etc.
		In terms of speed control, this mode is the same as vertical axis mode. In terms of torque control, this mode is the same as standard mode.
5	Load characteristic measurement	The basic gain setting and friction compensation setting are not changed, only load char- acteristic estimation is performed. Used in combination with Set-up Support Software (PANATERM ver.7).
6	Customize 1	Although two-degree-of-freedom control mode disabled type has the same function as Customize 2 (Pr0.02 = 7), the change ratio cannot be set for the basic gain setting.
7	Customize 2	The combination of real-time auto tuning functions can be customized for each applica- tion by configuring advanced settings in Pr6.32 "Real time auto tuning custom setup".
		A change ratio can be set for the basic gain setting.
		Some functions are not available depending on the control mode. See <u>"Details on Pr6.32</u> <u>"Real time auto tuning custom setup"</u> .

# 4.1.3.3 Operational Conditions

Item	Operational Conditions					
Control mode	Position control, speed control, and full-closed control					
	• Pr6.47:bit 0 = 0 (disabled)					

Real-time auto tuning may not work normally under the following conditions. In such cases, change the load conditions, operation pattern, or refer to the manual TUNING function description and manually set the related parameters.



# 4.1.3.4 Related Parameters

4.1.3.4.1	Parameters	<b>That Control</b>	the Operation	of This Function
-----------	------------	---------------------	---------------	------------------

						—: None
Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
0	02	В	Real-time auto- gain tuning setup	0 to 7	-	Sets the real-time auto tuning operation mode.
0	03	В	Real-time auto- tuning machine stiffness setup	0 to 31	_	Sets responsiveness when real-time auto tuning is ena- bled. Higher settings result in higher speed responsive- ness and servo stiffness, but make it more likely that vi- bration will occur. Values should be changed from low to high with a close eye on operation. Enabled with Pr2.45 "Function expansion setup 10" : bit 5 = 0 (32 stiffness settings).
0	27	В	Selection of ma- chine stiffness at real-time auto- gain tuning 2	0 to 44	_	Sets responsiveness when real-time auto tuning is ena- bled. Higher settings result in higher speed responsive- ness and servo stiffness, but make it more likely that vi- bration will occur. Values should be changed from low to high with a close eye on operation. Allows finer gain adjustment than Pr0.03. Enabled with Pr2.45 "Function expansion setup 10" : bit 5 = 1 (45 stiffness settings).
0	28	В	Selection of feed forward stiffness at real-time auto- gain tuning	0 to 44	_	Cannot be used when two-degree-of-freedom control mode is disabled.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	74	A	Tuning auto tun- ing application se- lection	-32768 to 32767	_	For Pr0.02 = 7 (Customize 2), any change ratio can be set for the basic gain setting to fit the application when the set value = 3. 0: Positioning 3: Customize
6	10	В	Function expan- sion setup	-32768 to 32767	_	bit 14: Load fluctuation suppression function automatic tuning 0: Disabled 1: Enabled
6	31	В	Real time auto tuning estimation speed	0 to 3	-	Sets load characteristics estimated speed when real-time auto-tuning is enabled. Higher settings result in faster re- sponses to changes in load characteristics, but they also increase variations in disturbance estimation. Estimation results are saved in EEPROM every 30 mi- nutes regardless of the load characteristic estimated speed setting. When automatic vibration detection is enabled from Set- up Support Software (PANATERM ver.7), this setting will be ignored and the setting value will be set to 3.
	Set	up ue	Mode			Description
	0	)	Does not change	Stops load cha	racteri	stics estimation.
	1		Changes very little	Estimates char	nges in	load characteristics in minutes.
	2	2	Changes slowly	Estimates char	nges in	load characteristics in seconds.
	3	}	Changes precipitously	y Fastest estima	tion of	changes in load characteristics.
6	32	В	Real time auto tuning custom setup	-32768 to 32767	_	Makes advanced settings for the automatic adjustment function when the Pr0.02 = 7 (Customize 2) is selected as an operation mode for real-time auto tuning.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# Details on Pr6.32 "Real time auto tuning custom setup"

bit	Mode	Description
1 to 0	Load characteristics estimation	<ul> <li>Set to enable or disable the load characteristics estimation function.</li> <li>0: Disabled</li> <li>1: Enabled</li> <li>— Precautions —</li> <li>When this setting is disabled, the target parameters are not updated from the current settings even if bit 3 to 2 "Inertia Ratio Update", bit 6 to 4 "Torque compensation", and bit 15 to 12 "Individual torque compensation settings" are set to enable updates.</li> <li>To enable load characteristic estimation, set Pr6.31 "Real time auto tuning estimation speed" to a value other than 0 (no change).</li> </ul>
3 to 2	Inertia ratio update	<ul> <li>Set updates in load characteristic estimation results for Pr0.04 "Inertia ratio".</li> <li>0: Disabled</li> <li>1: Enabled</li> <li>Precautions –</li> <li>To enable inertia ratio updates, set bit 1 to 0 "Load characteristics estimation" to 1 (enabled). If both are not enabled, the inertia ratio will not be updated.</li> </ul>

bit	Mode		Description						
6 to 4	Torque compensa- tion <sup>(*1)</sup>	Set updat value 2" , tion torque	es in load characteristic es Pr2.53 "Positive direction t e compensation value 2" ar	timation results for Pr2.52 "Torque command additional orque compensation value 2", Pr2.54 "Negative direc- nd Pr6.50 "Viscous friction compensating gain".					
		Setup value	Mode	Description					
		0	Use current settings	Uses current settings.					
		1	Disable torque compen- sation	Clear Pr2.52, Pr2.53, Pr2.54, and Pr6.50 to 0.					
		2	Vertical axis mode	Update Pr2.52 and clear Pr2.53, Pr2.54 and Pr6.50 to 0.					
		3	Friction compensation (weak)	Update Pr2.52 and set weak compensation for Pr2.53, Pr2.54, and Pr6.50.					
		4	Friction compensation (medium)	Update Pr2.52 and set medium compensation for Pr2.53, Pr2.54, and Pr6.50.					
		5	Friction compensation (strong)	Update Pr2.52 and set strong compensation for Pr2.53, Pr2.54 and Pr6.50.					
		<ul> <li>Precautions –</li> <li>Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection". The initial value is Pr2.45: bit 2 = 1.</li> <li>Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09</li> <li>Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54</li> </ul>							
7	Stiffness setup <sup>(*2)</sup>	Set to ena stiffness s Pr0.28 "Su 0: Disab 1: Enabl <b>— Preca</b> • Chan expan switch • Pr • Pr • Pr • Pr • Pr	<ul> <li>Set to enable or disable the basic gain setting using Pr0.03 "Real-time auto-tuning machine stiffness setup", Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2" or Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning".</li> <li>0: Disabled</li> <li>1: Enabled</li> <li>Precautions –</li> <li>Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.</li> <li>Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03</li> <li>Pr2.45: bits 5 to 4 = 10b : Pr0.27, Pr0.28</li> <li>Pr0.28 is disabled.</li> </ul>						
8	Fixed parameter setup <sup>(*2)</sup>	Set wheth ing is ena For details <u>to 4, 6, 7)</u> 0: Use c 1: Set to	Set whether or not to change parameters that become fixed values when real-time auto tun- ing is enabled. For details, see the table <u>"Values Set When Real-Time Auto Tuning is Enabled (Pr0.02 = 1</u> <u>to 4, 6, 7)"</u> in <u>"4.1.3.4.3 Parameters Changed By This Function"</u> . 0: Use current settings 1: Set to fixed values						
10 to 9	Gain switching set- up <sup>(*2)</sup>	Select the ing is ena 0: Use c 1: Gain s 2: Gain s	method for setting parame bled. urrent settings switching disabled switching enabled	eters related to gain switching when real-time auto tun-					
11	Torque compensa- tion setting switch- ing	Select wh 0: Enabl 1: Enabl	ether to enable bits 6 to 4 o e bits 6 to 4 e bits 15 to 12	or bits 15 to 12 for torque compensation.					

bit	Mode	Description								
15 to 12	Individual torque compensation set- tings <sup>(*1)</sup>	Select whether to use or update the current setting for the corresponding parameters whe bit 11 "Torque compensation setting switching" = 1. 0: Use current settings 1: Update								
			bit 15 bit 14 bit 13 bit 12							
		When Pr2.45:bit 2 = 1 Pr6.50 Pr2.54 Pr2.53 Pr2.52								
		When Pr2.45:bit 2 = 0	When Pr2.45:bit 2 = 0         Pr6.50         Pr6.09         Pr6.08         Pr6.07							

\*1 To set to enable updates to torque compensation, set bit 1 to 0 "Load characteristics estimation" and bit 3 to 2 "Inertia Ratio Update" to 1 (enabled). Updates are not applied with update settings for torque compensation only.

\*2 To set this set value to a value other than 0, set bit 3 to 2 "Inertia Ratio Update" to 1 (enabled). Whether or not inertia ratio update is enabled at this time can be set with bit 1 to 0 "Load characteristics estimation".

### – Precautions –

- These parameters must be set in bit units. Operation cannot be guaranteed with incorrect settings. Using Set-up Support Software (PANATERM ver.7) is recommended for changing parameter setup values.
- Do not change these parameters during motor operation. Actually updating of parameters takes place when the motor stops after the load characteristic measurement results are confirmed.

### Notes

Calculating Pr6.32 set value from values in bit units

When configuring each setting to a value other than 0, use the following procedure to calculate the set value for Pr6.32.

1 Confirm the least significant bit for each setting.

(Example) The least significant bit of the torque compensation function is 4

2 Multiply 2 to the power of (LSB) by the set value.

(Example) If bit 6 to 4 "Torque compensation" = 3 (friction compensation (weak)), then  $2^4 \times 3$ .

3 For each setting, calculate <u>"1"</u> and <u>"2"</u> and then add them all together to obtain the set value for Pr6.32.

(Example) When load characteristic measurement = enabled, inertia ratio update = enabled, torque compensation = friction compensation (weak), stiffness setting = enabled, fixed parameters = set to fixed values, gain switching setup = enabled

 $2^0 \times 1 + 2^2 \times 1 + 2^4 \times 3 + 2^7 \times 1 + 2^8 \times 1 + 2^9 \times 2 = 1461$ 

# 4.1.3.4.2 Parameters to Switch the Parameters Used by This Function to Minas A6 Series-Compatible Specification

In real-time auto tuning, the parameters used in real-time auto tuning can be switched to MINAS A6 Seriescompatible specification parameters by setting Pr2.45 "Function expansion setup 10".

- Parameters related to stiffness, unbalanced load and friction compensation and tuning filters
- Calculation method when updating torque filter time constant and some parameters for load fluctuation compensation (Pr6.73 "Load estimation filter" and Pr6.76 "Load estimation count" )

Item	Parameters for switching to MINAS A6 Series-compatible specification	Initial value (*1)
Stiffness	Can be changed with Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness set- ting resolution, individual FB/FF setting switching" .	bits 5 to 4 = 11b

Item	Parameters for switching to MINAS A6 Series-compatible specification	Initial value (*1)
Unbalanced load/fric- tion compensation	Can be changed with Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection" .	bit 2 = 1
Tuning filter	Can be changed with Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2".	bit 1 = 1
Torque filter time constant	Determined by the value of Pr2.45 "Function expansion setup 10" :bit 1 to 0 "Two-degree-of-freedom control function setting" .	bits 1 to 0 = 01b
Load fluctuation compensation	Determined by the value of Pr2.45 "Function expansion setup 10" :bit 3 "Load fluctua- tion suppression function automatic calculation" .	bit 3 = 1

#### \*1 Normally used with initial values.

						—: None
Class	No.	Attribute <sup>(*1)</sup>	Parameter name	Setting range	Unit	Function
2	38	В	Filter function switching	-32768 to 32767	_	<ul> <li>Select a tuning filter. Normally, set to bit 1 = 1.</li> <li>bit 1: Tuning filter 2</li> <li>0: Use Pr6.48 "Tuning filter" (MINAS A6 Series-compatible specification)</li> <li>1: Use Pr2.46 "Tuning filter 2" (MINAS A7 Series specification)</li> </ul>
2	45	В	Function expan- sion setup 10	-2147483648 to 2147483647	_	Sets various functions. bit 1 to 0: Two-degree-of-freedom control function setting bit 2: Friction torque compensation parameter selection bit 3: Load fluctuation suppression function automatic cal- culation bit 5 to 4: Stiffness setting resolution, individual FB/FF set- ting switching bit 31 to 6: Unused

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# Details on Pr2.45 "Function expansion setup 10"

—: N/A

bit	Name	Description	Initial value
1 to 0	Two-degree-of-freedom control function setting	00b: Two-degree-of-freedom control (MINAS A6 Series-compatible specification)	01b
		01b: Two-degree-of-freedom control (MINAS A7 Series specifica- tion)	
		10b: Manufacturer use	
		11b: Manufacturer use	
2	Friction torque compen- sation parameter selec- tion	0: MINAS A6 Series-compatible specification settings Unbalanced load compensation value: Use Pr6.07 Dynamic friction compensation value: Use Pr6.08, Pr6.09 1: MINAS A7 Series specification settings Unbalanced load compensation value: Use Pr2.52 Dynamic friction compensation value: Use Pr2.53, Pr2.54	1
3	Load fluctuation sup- pression function auto- matic calculation	0: Conventional setting (MINAS A6 Series specification) 1: The following parameters are automatically calculated. Pr6.73 "Load estimation filter" Pr6.76 "Load estimation count"	1

bit	Name	Description	Initial value
5 to 4	Stiffness setting resolu- tion, individual FB/FF setting switching	00b: 32 stiffness settings, FB/FF common setting (MINAS A6 Ser- ies-compatible specification) Use Pr0.03 01b: Same as 00b 10b: 45 stiffness settings, FB/FF common setting (MINAS A7 Series specification) Use Pr0.27 11b: 45 stiffness settings, individual FB/FF settings (MINAS A7 Ser- ies specification) Use Pr0.27 and Pr0.28	11b
31 to 6	Not used	-	_

#### 4.1.3.4.3 Parameters Changed By This Function

#### Parameters updated using estimated values for load characteristics

When Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4, real-time auto tuning updates the parameters in the table below using the estimated value for load characteristics.

When Pr0.02 "Real-time auto-gain tuning setup" is 6 or 7, the parameters in the table below are updated using the estimated value for load characteristics estimates based on the contents of Pr6.32 "Real time auto tuning custom setup".

Target para	Conditions for update	
Pr2.45:bit 2 = 1	Pr2.45:bit 2 = 0	
Pr0.04 "Inertia ratio"		When inertia ratio update is enabled (Pr0.02 = 1 to 4, 6, 7)
Pr2.52 "Torque command additional value 2"	Pr6.07 "Torque command additional value"	When vertical axis mode or friction compensa- tion mode is enabled (Pr0.02 = 3, 4, 6, 7)
Pr2.53 "Positive direction torque compensation value 2"	Pr6.08 "Positive direction torque compensation value"	When friction compensation mode is enabled (Pr0.02 = 4, 6, 7)
Pr2.54 "Negative direction torque compensation value 2"	Pr6.09 "Negative direction torque compensation value"	When friction compensation mode is enabled (Pr0.02 = 4, 6, 7)
Pr6.50 "Viscous friction compensating gain"		When Pr0.02 = 6, 7 (customize mode) with vis- cous friction compensation enabled

\*1 Change the parameters to be used depending on Pr2.45 "Function expansion setup 10" and bit 2 "Friction torque compensation parameter selection" set values. The initial setting is Pr2.45:bit 2 = 1.

#### Basic gain setting parameters updated according to machine stiffness settings

Real-time auto tuning updates the basic gain setting parameters according to the parameter settings below when Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4, 6, or 7. For details, see <u>*'4.1.3.6 Basic Gain Parameter Setup Table*</u>".

- Pr0.03 "Real-time auto-tuning machine stiffness setup"
- Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"

#### Notes

- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.
  - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
  - Pr2.45: bits 5 to 4 = 10b : Pr0.27
  - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

Pr0.28 is disabled.

#### Basic gain setting

Target parameter	Conditions for update according to stiffness
Pr1.00 "1st gain of position loop"	<ul> <li>When stiffness setup is enabled (Pr0.02 = 1 to 4, 7)</li> </ul>
Pr1.01 "1st velocity loop gain"	
Pr1.02 "1st velocity loop integration time con- stant"	
Pr1.04 "1st torque filter time constant"	
Pr1.05 "2nd gain of position loop"	
Pr1.06 "2nd velocity loop gain"	
Pr1.07 "2nd velocity loop integration time con- stant"	
Pr1.09 "2nd torque filter time constant"	

When Pr0.02 = 7 (Customize 2) and Pr2.74 "Tuning auto tuning application selection" = 3, any change ratio can be set for the values in the Basic Gain Parameter Settings Table.

Target parameter	Basic gain parameter setting in stiffness setup values when gain change ra- tio is enabled
Pr1.106 "1st position loop gain change ratio"	Sets the change ratio for Pr1.00 "1st gain of position loop"
	• When this setup value is 0, this is set to 100 %.
Pr1.107 "1st velocity integration change ratio"	• Sets the change ratio for Pr1.02 "1st velocity loop integration time con- stant"
	• When this setup value is 0, this is set to 100 %.
Pr1.108 "1st torque filter change ratio"	Sets the change ratio for Pr1.04 "1st torque filter time constant"
Pr1.109 "2nd position loop gain change ratio"	Sets the change ratio for Pr1.05 "2nd gain of position loop"
	• When this setup value is 0, this is set to 100 %.
Pr1.110 "2nd velocity loop gain change ratio"	Sets the change ratio for Pr1.06 "2nd velocity loop gain"
	• When this setup value is 0, this is set to 100 %.
Pr1.111 "2nd velocity integration change ratio"	<ul> <li>Sets the change ratio for Pr1.07 "2nd velocity loop integration time con- stant"</li> </ul>
	• When this setup value is 0, this is set to 100 %.
Pr1.112 "2nd torque filter change ratio"	Sets the change ratio for Pr1.09 "2nd torque filter time constant"
Pr1.113 "Load fluctuation compensation filter change ratio"	• Sets the change ratio for Pr6.24 "Load change compensation filter" (time constant)
	• When this setup value is 0, this is set to 100 %.
Pr1.114 "Smoothing filter change ratio"	• Cannot be used with two-degree-of-freedom control mode disabled type.
Pr1.115 "Tuning filter change ratio"	• Cannot be used with two-degree-of-freedom control mode disabled type.

#### Parameters set based on Fixed Parameter Setup

For real-time auto tuning, set the parameters in the table below in any of the following cases.

- When Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4
- When Pr0.02 "Real-time auto-gain tuning setup" is 6 or 7 and Pr6.32 "Real time auto tuning custom setup" :bit 8 "Fixed Parameter Setup" is 1

Target parameter	Value set to (Pr0.02 = 1 to 4, 6, 7) when real-time auto tuning is enabled
Pr1.03 "1st filter of velocity detection"	Set to 0
Pr1.08 "2nd filter of velocity detection"	Set to 0
Pr1.10 "Velocity feed forward gain"	Set to 300
Pr1.11 "Velocity feed forward filter"	Set to 50
Pr1.12 "Torque feed forward gain"	Set to 0
Pr1.13 "Torque feed forward filter"	Set to 0

### Parameters set based on Gain Switching Setup

For real-time auto tuning, set the parameters in the table below in any of the following cases.

- When Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4
- When Pr0.02 "Real-time auto-gain tuning setup" is 6 or 7 and Pr6.32 "Real time auto tuning custom setup" :bit 10 to 9 "Gain Switching Setup" is 1

Target parameter	Value to be set					
	Pr0.02 = 1	Pr0.02 = 2	Pr0.02 = 3	Pr0.02 = 4	Pr0.02 = 6	Pr0.02 = 7
Pr1.14 "2nd gain setup"	Set to 1					
Pr1.15 "Mode of position control switching"	Set to 0	Set to 10				
Pr1.16 "Delay time of position control switch- ing"	Set to 50 (5	ms).				
Pr1.17 "Level of position control switching"	Set to 50					
Pr1.18 "Hysteresis at position control switch- ing"	Set to 33					
Pr1.19 "Position gain switching time"	Set to 33 (3.	.3 ms).				
Pr1.20 "Mode of velocity control switching"	Set to 0					
Pr1.21 "Delay time of velocity control switch- ing"	Set to 0					
Pr1.22 "Level of velocity control switching"	Set to 0					
Pr1.23 "Hysteresis at velocity control switch- ing"	Set to 0					
Pr1.24 "Mode of torque control switching"	Set to 0					
Pr1.25 "Delay time of torque control switching"	Set to 0					
Pr1.26 "Level of torque control switching"	Set to 0					
Pr1.27 "Hysteresis at torque control switching"	Set to 0					

#### Parameters set based on Load fluctuation suppression function automatic tuning

When Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4, 6, or 7, set the following parameters according to Pr6.10 "Function expansion setup" :bit 14 "Load fluctuation suppression function automatic tuning".

Target parameter	Condition	Value to be set		
		Pr6.10:bit 14 = 1	Pr6.10:bit 14 = 0	
Pr6.10 "Function expan- sion setup"	10 "Function expan- setup"When stiffness setup is enabled trol function" = 1 (enabled)		bit 1 "Load fluctuation con- trol function" = 0 (disabled)	
Pr6.23 "Load change com- pensation gain"	When stiffness setup is enabled	Set to 90 (90%)	Set to 0	
Pr6.24 "Load change com- pensation filter"	When stiffness setup is enabled	Updates to set value ac- cording to stiffness	Retain value	
Pr6.73 "Load estimation fil- ter"	When stiffness setup is enabled and Pr2.45 "Function expansion setup 10" :bit 3 = 0	Set to 13	Set to 0	
	When stiffness setup is enabled and Pr2.45 "Function expansion setup 10" :bit 3 = 1	Set automatically		
Pr6.74 "Torque compensa- tion frequency 1"	Set to 0 regardless of the value of Pre	ne value of Pr6.10:bit 14.		
Pr6.75 "Torque compensa- tion frequency 2"	Set to 0 regardless of the value of Pre	f Pr6.10:bit 14.		
Pr6.76 "Load estimation count"	When stiffness setup is enabled and Pr2.45 "Function expansion setup 10" :bit 3 = 0	Set to 4	Set to 0	

Target parameter	Condition	Value to be set	
		Pr6.10:bit 14 = 1	Pr6.10:bit 14 = 0
Pr6.76 "Load estimation count"	When stiffness setup is enabled and Pr2.45 "Function expansion setup 10" :bit 3 = 1	Automatically set according to stiffness	

## 4.1.3.5 How to Use

- When Pr0.02 "Real-time auto-gain tuning setup" is set to 1 to 4, 6 or 7, real-time auto tuning is enabled. The parameter values used for tuning are automatically set according to the parameter settings below.
  - Pr0.03 "Real-time auto-tuning machine stiffness setup"
  - Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
  - Pr6.10 "Function expansion setup" :bit 14 "Load fluctuation suppression function automatic tuning"
- Input the operation command after approximately 100 ms have elapsed since servo-on.
- Pr0.04 "Inertia ratio" changes when load characteristics estimation is complete. Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" also change depending on the mode setting (see <u>"Supplement"</u>).
- Increasing the set value of either of the following parameters will increase motor responsiveness. While checking the positioning settling time and vibration state, increase the setup values by increments of 1 and tune to the optimal values.
  - Pr0.03 "Real-time auto-tuning machine stiffness setup"
  - Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
- Setting Pr0.02 "Real-time auto-gain tuning setup" to 0 disables real-time auto tuning. Automatic estimation of Pr0.04 "Inertia ratio" stops, but the inertia ratio value at the time of estimation stopping is retained. If the value of the inertia ratio is clearly abnormal, set a reasonable value manually.

# Notes

• Pr2.52, Pr2.53 and Pr2.54

Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection". The initial value is Pr2.45: bit 2 = 1.

- Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
- Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.
  - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
  - Pr2.45: bits 5 to 4 = 10b : Pr0.27
  - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28
  - Pr0.28 is disabled.

#### Precautions —

- When real-time auto tuning is enabled, the response to estimated values after power-up to completion of load characteristic estimation may be faster regardless of the set value for Pr6.31 "Real time auto tuning estimation speed".
- Immediately after power-up, there is not enough operation data effective for load characteristic estimation, meaning estimated values may be abnormal and operation instable due to disturbance, etc. Once tuning is finished, we recommended that real-time auto tuning is set to disabled (Pr0.02 "Real-time auto-gain tuning setup" = 0).

- Until load characteristic estimation results stabilize, abnormal noise or oscillation may occur. For example, if abnormal noise or oscillation occurs immediately after the first servo-on after activation or when the Pr0.03 "Real-time auto-tuning machine stiffness setup" set value is increased, it is not abnormal for the operation to stabilize immediately. After abnormal noise or oscillation occurs ,Pr0.04 "Inertia ratio", Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2" , or Pr2.54 "Negative direction torque compensation value 2" may change to extreme values. Take the following measures. The following measures should also be taken if abnormal noise or oscillation occurs frequently.
  - 1 Lower the set value for Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2".
  - 2 Set Pr0.02 "Real-time auto-gain tuning setup" to 0 to disable real-time auto tuning.
  - 3 Set Pr0.04 "Inertia ratio" to the value calculated on the device and set Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" to 0 (see <u>"Supplement"</u>).
  - 4 After setting Pr6.10 "Function expansion setup" :bit 14 = 0, set bit 1 = 0 to disable the load fluctuation control function.
- The Pr0.04 "Inertia ratio", Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" (see <u>"Supplement"</u>) values, which are the results of real-time auto gain tuning, are automatically written to and saved in EEPROM every 30 minutes. When power is restored, auto tuning is performed using the saved EEPROM values as the initial values. If turning OFF the power without 30 minutes having elapsed since values were automatically saved in EEPROM, manually write the latest real-time auto gain tuning results to EEPROM before turning OFF the power.
- Since control gain is updated when the motor stops, changes to Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2" settings are not reflected if the motor does not stop (if the gain is extremely low or if a command is continuously given in one direction).

Before changing any of the above parameters related to stiffness setup, stop the motor once to make sure that the stiffness setup has been reflected. Depending on the stiffness setup reflected after the motor is stopped, abnormal noise or oscillation may occur.

- The following are linked in the Set-up Support Software (PANATERM ver.7) Manual TUNING screen.
  - Feedback gain setting: Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"

#### Notes

• Pr2.52, Pr2.53 and Pr2.54

Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection". The initial value is Pr2.45: bit 2 = 1.

- Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
- Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.
  - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
  - Pr2.45: bits 5 to 4 = 10b : Pr0.27
  - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

Pr0.28 is disabled.

# 4.1.3.6 Basic Gain Parameter Setup Table

		-				-: None					
Stiffi	ness		1st	gain			2nd	gain		For load fluc- tuation control function	
Pr0.03 (*1)	Pr0.27 (*1)	Pr1.00	Pr1.01	Pr1.02	Pr1.04 (*2)	Pr1.05	Pr1.06	Pr1.07 (*3)	Pr1.09 (*2)	Pr6.24	
		Position [0.1 s <sup>-1</sup> ]	Speed [0.1 Hz]	Speed integra- tion [0.1 ms]	Torque [0.01 ms]	Position [0.1 s <sup>-1</sup> ]	Speed [0.1 Hz]	Speed integra- tion [0.1 ms]	Torque [0.01 ms]	Load change compensation filter [0.01 ms]	
0	0	20	15	3700	1500	25	15	10000	1500	2500	
1	1	25	20	2800	1100	30	20	10000	1100	2500	
2	2	30	25	2200	900	40	25	10000	900	2500	
3	3	40	30	1900	800	45	30	10000	800	2500	
4	4	45	35	1600	600	55	35	10000	600	2500	
5	5	55	45	1200	500	70	45	10000	500	2500	
6	6	75	60	900	400	95	60	10000	400	2500	
7	7	95	75	700	300	120	75	10000	300	2120	
8	8	115	90	600	300	140	90	10000	300	1770	
9	9	140	110	500	200	175	110	10000	200	1450	
10	10	175	140	400	200	220	140	10000	200	1140	
_	11	250	160	350	163	300	160	10000	163	1000	
11	12	320	180	310	126	380	180	10000	126	880	
_	13	355	200	280	114	425	200	10000	114	795	
12	14	390	220	250	103	460	220	10000	103	720	
_	15	435	245	225	93	515	245	10000	93	650	
13	16	480	270	210	84	570	270	10000	84	590	
_	17	535	300	190	74	635	300	10000	74	535	
14	18	630	350	160	65	730	350	10000	65	450	
15	19	720	400	140	57	840	400	10000	57	400	
_	20	810	450	125	51	945	450	10000	51	355	
16	21	900	500	120	45	1050	500	10000	45	320	
_	22	990	550	110	41	1160	550	10000	41	290	
17	23	1080	600	110	38	1260	600	10000	38	270	
_	24	1170	650	105	35	1370	650	10000	35	250	
_	25	1260	700	100	32	1480	700	10000	32	235	
18	26	1350	750	90	30	1570	750	10000	30	210	
_	27	1490	825	85	27	1730	825	10000	27	190	
19	28	1620	900	80	25	1880	900	10000	25	180	
-	29	1850	1025	70	22	2150	1025	10000	22	160	
20	30	2060	1150	70	20	2410	1150	10000	20	140	
-	31	2260	1260	65	18	2640	1260	10000	18	130	
21	32	2510	1400	60	16	2930	1400	10000	16	110	
-	33	2780	1550	55	14	3250	1550	10000	14	100	
22	34	3050	1700	50	13	3560	1700	10000	13	90	

Stiffi	ness		1st	gain		2nd gain				For load fluc- tuation control function
Pr0.03 (*1)	Pr0.27 (*1)	Pr1.00	Pr1.01	Pr1.02	Pr1.04 (*2)	Pr1.05	Pr1.06	Pr1.07 (*3)	Pr1.09 (*2)	Pr6.24
		Position [0.1 s <sup>-1</sup> ]	Speed [0.1 Hz]	Speed integra- tion [0.1 ms]	Torque [0.01 ms]	Position [0.1 s <sup>-1</sup> ]	Speed [0.1 Hz]	Speed integra- tion [0.1 ms]	Torque [0.01 ms]	Load change compensation filter [0.01 ms]
_	35	3410	1900	45	12	3980	1900	10000	12	80
23	36	3770	2100	40	11	4400	2100	10000	11	80
24	37	4490	2500	40	9	5240	2500	10000	9	60
25	38	5000	2800	35	8	5900	2800	10000	8	60
26	39	5600	3100	30	7	6500	3100	10000	7	50
27	40	6100	3400	30	7	7100	3400	10000	7	50
28	41	6600	3700	25	6	7700	3700	10000	6	40
29	42	7200	4000	25	6	8400	4000	10000	6	40
30	43	8100	4500	20	5	9400	4500	10000	5	40
31	44	9000	5000	20	5	10500	5000	10000	5	40

\*1 Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.

• Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03

• Pr2.45: bits 5 to 4 = 10b : Pr0.27

• Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

Pr0.28 is disabled.

- \*2 The values in the table are used only when Pr2.45 "Function expansion setup 10" :bit 1 to 0 = 0.
- \*3 For vertical axis mode or friction compensation mode (Pr0.02 "Real-time auto-gain tuning setup" = 3, 4), Pr1.07 "2nd velocity loop integration time constant" is 9999 (retained) until estimation of load characteristics is complete.

# 4.2 Gain Switching Function

#### 4.2.1 Function Overview

This function optimizes control based on the operating state of the servo driver by changing settings such as applied gain types and setting conditions based on command inputs such as torque commands and speed commands. Gain switching is expected to have the following effects:

- Reduce gain when stopped (servo lock) to suppress vibration
- Increase the gain when stopped (settling time) to shorten the settling time
- Increase the gain during operation to improve command tracking
- Switch gain using external signal based on the device status

# 4.2.2 Operational Conditions

Item	Operational Conditions
Control mode	All control modes

## 4.2.3 Related Parameters

The parameters that can be switched vary depending on the control mode.

#### Common

						—: N/A
Class	No.	Attribute <sup>(*1)</sup>	Parameter name	Setting range	Unit	Function
1	14	В	2nd gain setup	0 to 1	_	<ul> <li>Set when performing optimum tuning using the gain switching function.</li> <li>0: Disabled (Fixes 1st gain)</li> <li>1: Enabled (Enables gain switching between 1st gain and 2nd gain)</li> </ul>

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

### Position control mode, full-closed control mode

						—: N/A
Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	15	В	Mode of position control switching	0 to 10	_	Sets the trigger condition for gain switching during po- sition control and full-closed control. (Setup value): (switching condition) 0: 1st gain fixed 1: 2nd gain fixed 2: Manufacturer use (setting is prohibited) 3: Torque command 4: Disabled (1st gain fixed) 5: Speed command 6: Position deviation 7: With position command 8: Positioning not completed 9: Actual speed 10: With position command + actual speed
1	16	В	Delay time of po- sition control switching	0 to 10000	0.1 ms	Sets the time from trigger detection to actual gain switching when switching from 2nd gain to 1st gain during position control and full-closed control when Pr1.15 "Mode of position control switching" is 3, or 5 to 10.
1	17	В	Level of position control switching	0 to 20000	Depends on the mode	<ul> <li>Sets triggering level during position control and full-closed control when Pr1.15 "Mode of position control switching" is 3, 5, 6, 9, or 10.</li> <li>Units vary with switching mode setting.</li> <li>Set the level equal to or higher than the hysteresis.</li> </ul>
1	18	В	Hysteresis at po- sition control switching	0 to 20000	Depends on the mode	<ul> <li>Sets triggering hysteresis during position control and full-closed control when Pr1.15 "Mode of position control switching" is 3, 5, 6, 9, or 10.</li> <li>Units vary with switching mode setting.</li> <li>When the level is less than the hysteresis, the hysteresis is re-set internally so that it is equal to the level.</li> </ul>
1	19	В	Position gain switching time	0 to 10000	0.1 ms	Sudden increases in position loop gain can be sup- pressed during position control and full-closed control if there is a large difference between Pr1.00 "1st gain of position loop" and Pr1.05 "2nd gain of position loop". If the position loop gain increases, gain will change over the set time.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

The target parameters referred to in the above description in terms of 1st gain and 2nd gain are as follows.

- 1st gain
  - Pr1.00 "1st gain of position loop"
  - Pr1.01 "1st velocity loop gain"
  - Pr1.02 "1st velocity loop integration time constant"
  - Pr1.03 "1st filter of velocity detection"
  - Pr1.04 "1st torque filter time constant"
- 2nd gain

- Pr1.05 "2nd gain of position loop"
- Pr1.06 "2nd velocity loop gain"
- Pr1.07 "2nd velocity loop integration time constant"
- Pr1.08 "2nd filter of velocity detection"
- Pr1.09 "2nd torque filter time constant"

### Speed control modes

						—: N/A
Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	20	В	Mode of velocity control switching	0 to 5	_	Sets gain switching trigger conditions during velocity control. (Setup value): (switching condition) 0: 1st gain fixed 1: 2nd gain fixed 2: Manufacturer use (setting is prohibited) 3: Torque command 4: Speed command variation 5: Speed command
1	21	В	Delay time of ve- locity control switching	0 to 10000	0.1 ms	Sets the time from trigger detection to actual gain switching when switching from 2nd gain to 1st gain during velocity control when Pr1.20 "Mode of velocity control switching" is 3 to 5.
1	22	В	Level of velocity control switching	0 to 20000	Depends on the mode	<ul> <li>Sets triggering level during velocity control when Pr1.20 "Mode of velocity control switching" is 3 to 5.</li> <li>Units vary with switching mode setting.</li> <li>Set the level equal to or higher than the hysteresis.</li> </ul>
1	23	В	Hysteresis at ve- locity control switching	0 to 20000	Depends on the mode	<ul> <li>Sets triggering hysteresis during velocity control when Pr1.20 "Mode of velocity control switching" is 3 to 5.</li> <li>Units vary with switching mode setting.</li> <li>When the level is less than the hysteresis, the hysteresis is re-set internally so that it is equal to the level.</li> </ul>

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

The target parameters referred to in the above description in terms of 1st gain and 2nd gain are as follows.

- 1st gain
  - Pr1.01 "1st velocity loop gain"
  - Pr1.02 "1st velocity loop integration time constant"
  - Pr1.03 "1st filter of velocity detection"
  - Pr1.04 "1st torque filter time constant"
- 2nd gain
  - Pr1.06 "2nd velocity loop gain"
  - Pr1.07 "2nd velocity loop integration time constant"
  - Pr1.08 "2nd filter of velocity detection"
  - Pr1.09 "2nd torque filter time constant"

### Torque control modes

						—: N/A
Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	24	В	Mode of torque control switching	0 to 3	_	Sets gain switching trigger conditions during torque control. (Setup value): (switching condition) 0: 1st gain fixed 1: 2nd gain fixed 2: Manufacturer use (setting is prohibited) 3: Torque command
1	25	В	Delay time of tor- que control switching	0 to 10000	0.1 ms	Sets the time from trigger detection to actual gain switching when switching from 2nd gain to 1st gain during torque control when Pr1.24 "Mode of torque control switching" is 3.
1	26	В	Level of torque control switching	0 to 20000	Depends on the mode	<ul><li>Sets triggering level during torque control when Pr1.24 "Mode of torque control switching" is 3.</li><li>Units vary with switching mode setting.</li><li>Set the level equal to or higher than the hysteresis.</li></ul>
1	27	В	Hysteresis at tor- que control switching	0 to 20000	Depends on the mode	<ul> <li>Sets triggering hysteresis during torque control when Pr1.24 "Mode of torque control switching" is 3.</li> <li>Units vary with switching mode setting.</li> <li>When the level is less than the hysteresis, the hysteresis is re-set internally so that it is equal to the level.</li> </ul>

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

The target parameters referred to in the above description in terms of 1st gain and 2nd gain are as follows.

- 1st gain
  - Pr1.01 "1st velocity loop gain"
  - Pr1.02 "1st velocity loop integration time constant"
  - Pr1.03 "1st filter of velocity detection"
  - Pr1.04 "1st torque filter time constant"
- 2nd gain
  - Pr1.06 "2nd velocity loop gain"
  - Pr1.07 "2nd velocity loop integration time constant"
  - Pr1.08 "2nd filter of velocity detection"
  - Pr1.09 "2nd torque filter time constant"

# Each control switching mode and gain switching details

The gain switching method differs depending on the set values for Pr1.15 "Mode of position control switching", Pr1.20 "Mode of velocity control switching", and Pr1.24 "Mode of torque control switching". Check 0, 1, 3, 5 to 10 for mode of position control switching, 0, 1, 3 to 5 for mode of velocity control switching, and 0, 1 and 3 for mode of torque control switching.

 $\bigcirc:$  Enabled X: Disabled

Control	Switching con-	Gain switching details		Contro	l mode	
mode setting values	altion		Posi- tion	Full- closed	Speed	Torque
0	1st gain fixed	Fixed to 1st gain (Pr1.00 to Pr1.04)	0	0	0	0
1	2nd gain fixed	Fixed to 2nd gain (Pr1.05 to Pr1.09)	0	0	0	0
2	Manufacturer use (setting is prohibited)	Do not set.	×	×	×	×
3	Torque com- mand magni- tude	Switches to 2nd gain if previously the absolute value of the torque command exceeded (level + hysteresis) [%] in 1st gain. Returns to 1st gain if previously the absolute value of the torque command remained below (level - hystere- sis) [%] for the delay time in 2nd gain	0	0	0	0
4	Large amount of speed com- mand variation	Switches to 2nd gain if previously the absolute value of speed command variation exceeded (level + hyste- resis) [10 r/min/s] in 1st gain. Returns to 1st gain if previously the absolute value of speed command variation remained below (level - hysteresis) [10 r/min/s] for the delay time in 2nd gain. <b>Notes</b> • Except with speed control, the 1st gain is fixed.	×	×	0	×
5	Speed com- mand magni- tude	Switches to 2nd gain if previously the absolute value of the speed command exceeded (level + hysteresis) [r/min] in 1st gain. Returns to 1st gain if previously the absolute value of the speed command remained below (level - hystere- sis) [r/min] for the delay time in 2nd gain.	0	0	0	×
6	Position devia- tion magnitude	<ul> <li>Switches to 2nd gain if previously the absolute value of position deviation exceeded (level + hysteresis) [pulse] in 1st gain.</li> <li>Returns to 1st gain if previously the absolute value of position deviation remained below (level - hysteresis) [pulse] for the delay time in 2nd gain.</li> <li>Notes <ul> <li>Level and hysteresis units [pulse] are set by encoder resolution for position control and by feedback scale resolution for full-closed control. The position deviation in this description refers to the deviation between the internal command position after the filter and the actual position, regardless of the set value for Pr7.23 "Communication function extended setup 2" :bit 14.</li> </ul> </li> </ul>	0	0	×	×
7	With position command	Switches to 2nd gain if previously the position com- mand was not 0 in 1st gain. Returns to 1st gain if previously the position com- mand remained 0 for the delay time in 2nd gain.	0	0	×	×
8	Positioning not completed	Switches to 2nd gain if previously positioning was not completed in 1st gain. Returns to 1st gain if previously the positioning com- pleted state continued for the delay time in 2nd gain.	0	0	×	×
9	Actual Speed - Large	Shifts to 2nd gain when the actual speed absolute value exceeds (level + hysteresis) [r/min] in the previ- ous 1st gain. Returns to 1st gain when the actual speed absolute value remains (level - hysteresis) [r/min] or less for the delay time in the previous 2nd gain.	0	0	×	×

Control	Switching con-	Gain switching details	Control mode				
switching mode setting values	dition		Posi- tion	Full- closed	Speed	Torque	
10	With Position Command + Actual Speed	Switches to 2nd gain if previously the position com- mand was not 0 in 1st gain. Returns to 1st gain when position command remains at 0 for the delay time and the actual speed absolute value is (level - hysteresis) [r/min] or less in the previ- ous 2nd gain.	0	0	×	×	

# 4.2.4 How to Use

### 4.2.4.1 For Manual Setting

After setting the gain switching mode for each control mode used, enable the gain switching function (Pr1.14 "2nd gain setup" = 1). Change the related parameters for each control mode.

### 4.2.4.1.1 Example of Gain Switching Function Use

Assume that when the load moves from position A to position B, the internal state of the servo driver changes as shown in the figure below. This section describes how to set the related parameters when using the gain switching function under such conditions.



#### << Procedure >>

- **1.** The following parameters are used to set the conditions for switching gain.
  - Pr1.15 "Mode of position control switching"
  - Pr1.20 "Mode of velocity control switching"
  - Pr1.24 "Mode of torque control switching"

2. Set the switching level and hysteresis according to the gain switching conditions.

When there is a small fluctuation such as noise in the input signal change based on the Pr1.15 "Mode of position control switching", Pr1.20 "Mode of velocity control switching", and Pr1.24 "Mode of torque control switching" settings, set the hysteresis to a value greater than the fluctuation range to prevent unnecessary gain switching from occurring continuously and to enable smooth gain switching.



**3.** Set the switching time.

The switching time sets the delay time from trigger detection to actual gain switching when switching from 2nd gain to 1st gain.

2nd gain switches to 1st gain when the input signal exceeds the set switching level and hysteresis continuously for a set switching time or longer.



4. Set the position gain switching time.

The following parameters are switched instantly during gain switching.

- 1st gain
  - Pr1.00 "1st gain of position loop"
  - Pr1.01 "1st velocity loop gain"
  - Pr1.02 "1st velocity loop integration time constant"
  - Pr1.04 "1st torque filter time constant"
- 2nd gain
  - Pr1.05 "2nd gain of position loop"
  - Pr1.06 "2nd velocity loop gain"
  - Pr1.07 "2nd velocity loop integration time constant"
  - Pr1.09 "2nd torque filter time constant"

Position loop gain can be switched gradually and stepwise to avoid problems caused by sudden changes to high gain.

In this case, the number of steps is "position gain switching time / resolution  $62.5 \,\mu$ s". If there is a fraction instead of a multiple of 62.5, the number of steps is rounded down.

When Pr1.19 "Position gain switching time" is 2 in the figure below, the set time is 0.2 ms. Therefore, 0.2 ms / 62.5  $\mu$ s = 3.2, which is a rise of 3 steps. (Actual switching time is 62.5  $\mu$ s × 3 = 250  $\mu$ s = 187.5  $\mu$ s) \*The gain switching flag changes at the moment of switching from low gain.

When Pr1.19 "Position gain switching time" is 0



#### 4.2.4.1.2 Example Tuning Procedure for Vibration Suppression

The following is an example tuning procedure for suppressing vibration by lowering the gain after settling due to high position deviation vibration after positioning settling during position control.

#### << Procedure >>

- **1.** Set Pr1.15 "Mode of position control switching" to 7 or 10.
- Set Pr1.16 "Delay time of position control switching" = 50, Pr1.17 "Level of position control switching" = 50, Pr1.18 "Hysteresis at position control switching" = 33, Pr1.19 "Position gain switching time" = 33.
- Lower Pr1.00 "1st gain of position loop" and Pr1.01 "1st velocity loop gain" by the same ratio.
   Raise Pr1.04 "1st torque filter time constant" by the same ratio. Tune Pr1.02 "1st velocity loop integration time constant" so that vibration is suppressed.
- **4.** To change the timing of vibration suppression, tune Pr1.16 "Delay time of position control switching", Pr1.17 "Level of position control switching", and Pr1.18 "Hysteresis at position control switching".

At this time, tune so that Pr1.18 "Hysteresis at position control switching"  $\leq$  Pr1.17 "Level of position control switching".







# 4.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

# << Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7).
- 2. Select one device that you want to tune in the device tree and click the "Tuning" tab.

892				PANATERM ver./				
File(F)	Troubleshooting(T)	Help(H)						_
		E Device tree		{ĝ} Setting	嬰 Monitor	比 Logging	🕞 Tuning	🚺 Device Info
	-	MINAS A7BR		All parameters	EtherCAT object	IO Setting	Alarm	Analog input
₫∨	Online	Axis0_No name set SRV-OFF						
	USB	MADN085BRU 23080001		Open file	Save file	Copy Load initia	l values Load	Write
	U.	Encod	er Info			Config Reset	:	
	<b>I</b>	MHMG022U1A2 24020001	· puise	Search	Compar	rison None	Add/delete d	olumn
				Switch to HEX input	Display A6-compati	ible control parameters	Allow out-of-range setting	igs

**3.** In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

5									
F	File(F) Troubleshooting(T) Help(H)								
Devie		Ŀб	ogging	프 <mark>은</mark> Tuning	Device Info	Ø	) Trial run	Z-pl	hase search
ce tree	< Manual TUNING		🗸 Graph			Trial run/2	1	2	
	Selected driver:Axis0_No name set		Wave graph	Frequency response		Z-pha	Limit setting	Trial ru	in
	Basic Load characteri Notch settings		Start m	easurement Stop	Single trigger	ise s	Protection Functions		
	Damping settin Application Manual	1				earch	Pr5.12 Overload level[%]	0	
			Measureme	ent data management Edit	display range Fixed display range	-	Pr5.13 Overspeed level[r/min]		
	Mode setting () 0:Disabled V		Reset zoom	Align with center of Y-axi	s			🛃 Automatic	setting (overspee
			Display as e	elapsed time Display as tim	ne standard Load file		Pr5.14 Motor mova[0.1 rotation	10	
	A7 recommended settingis recommended		Cause fills				Operation limit		
	When upgrading from A6 <u>A6 compatibility setting</u> is recommended		Save The	2			Pr5.04 Over-travel inhibit input s	1: CoE-side (C	iA402) deceler 🗸
	Load characteristic settings Automatic settingOFF		🗸 Graph di	splay settings			Operating range		
	Inertia ratio 0						Use JOG to move to the Max./M	in. positions or i	nput a numeric value
	For more advanced settings Load characteristic settings		Measuren	hent Condition Edit displaye	ed data Cursor		JOG speed[r/min]	60	
	Gain setting		Acquire	from driver Acquire from	n file Load condition presets		JOG acceleratio[ms/JOG speed	50	
1	Feedback gain setting - 29 +	•				= 1			
	Speed response frequenc 102.5		<ul> <li>Monitor</li> </ul>						
	Automatic oscillation su OFF		Simple mor	nitor IO monitor					
	Safety function								
	FF gain setting - 31 +		Start mea	surem Measurement mod	e With Position C 💙 Measurement count	2			
	Positional command smo 0.8		Trial No.	Settling time INP change cou	unt Vibration level Effective load factor Takt				
	Overshoot suppression [%] - 100.0 +		[times]	[ms] [times]	[%] [%] [ms]		Servo-on Operates	only while the bu	utton is pressed.
	Notch filter settings Automatic setting:OFF						- direction	o to 0	+ direction
	3rd notch frequency [Hz] 5000							·····	1
	4th notch frequency [Hz] 5000						Current position	Command unit	
	Damping filter setup								
	1st damping frequency [Hz] 0						Minimum position		Maximum position
	For more advanced settings Damping settings						[command unit]		[command unit]
	What if I have a problem?						0		0
	Refer to Tuning Help <u>when problems occur</u> such as vibration or abnormal noise						Troubl	eshooting	To trial run

**4.** Click the [Application] button.

< Manual TUNING								
Selected driver:Axis0_No name set								
Basic Load characteristic settings Notch settings								
Damping settings Application Manual								
> Feedforward function	> Feedforward function							
> Load fluctuation control f	unction							
> High response current cor	ntrol function							
> Gain switching function								
> Quadrant glitch suppressi	on function							
> Hybrid vibration suppress	ion function							

5. Click on ">" of "> Gain switching function" to expand "Gain switching function".

elected anvertexibe_140 hame			
Basic	Load characteristic settings Application		Notch settings Manual
Damping settings			
> Feedforward function			
<ul> <li>Load fluctuation control fur</li> </ul>	nction		
> High response current cont	rol function		
<ul> <li>Gain switching function</li> </ul>			
Enabling this allows gain to be	changed durin	g operation or i	mmediately after stopping
1st gain of position loop		480	
1st velocity loop gain		270	
1st velocityintegral time constant		210	
1st torque filter		10	
2nd gain of position loop		480	
2nd velocity loop gain		270	
2nd velocity integral time constant		210	
2nd torque filter		10	
2nd gain setup		1: Gain switchi	ng enabled 🗸 🗸
Mode of position control switching		0: 1st gain fixe	d 🗸
Delay time of position control switching [0		10	
Level of position control switching [mode		0	
Hysteresis at position control switching [m		0	
Position gain switching time [0.1 ms]		10	
Position 3rd gain valid time [0.1 ms]			
Position 3rd gain scale factor [%]			
> Quadrant glitch suppression	n function		

**6.** After setting the "Mode of position control switching", select "1: Gain switching enabled" from the "2nd gain setup" drop-down list. Change the related parameters.

# – Precautions –

• In the current version of Set-up Support Software (PANATERM ver.7), the parameter setup screen for gain switching supports only position control and full-closed control. To set the gain switching parameters for speed control and torque control, click the [Manual] button.
# 4.3 3rd Gain Switching Function

## 4.3.1 Function Overview

In addition to the normal gain switching function (see <u>"4.2 Gain Switching Function</u>"), this function sets the gain just before stopping as the 3rd gain.

The positioning settling time can be shortened by setting the gain just before stopping higher for a fixed period of time.

# 4.3.2 Operational Conditions

Item	Operational Conditions
Control mode	Position control and full-closed control

# 4.3.3 Related Parameters

						—: N/A
Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	14	В	2nd gain setup	0 to 1	_	<ul> <li>Set when performing optimum tuning using the gain switching function.</li> <li>0: Disabled (Fixes 1st gain)</li> <li>1: Enabled (Enables gain switching between 1st gain and 2nd gain)</li> </ul>
1	15	В	Mode of position control switching	0 to 10	_	Sets the trigger condition for gain switching during posi- tion control and full-closed control. (Setup value): (switching condition) 0: 1st gain fixed 1: 2nd gain fixed 2: Manufacturer use (setting is prohibited) 3: Torque command 4: Disabled (1st gain fixed) 5: Speed command 6: Position deviation 7: With position command 8: Positioning not completed 9: Actual speed 10: With position command + actual speed
6	05	В	Position 3rd gain valid time	0 to 10000	0.1 ms	Sets time for 3rd gain to be enabled.
6	06	В	Position 3rd gain scale factor	50 to 1000	%	Sets the scale factor of the 3rd gain with respect to the 1st gain. 3rd gain = 1st gain × Pr6.06/100

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# 4.3.4 How to Use

## 4.3.4.1 For Manual Setting

Set the time for applying 3rd gain to Pr6.05 "Position 3rd gain valid time" when the normal gain switching function operates normally (Pr1.14 "2nd gain setup" = 1 and Pr1.15 "Mode of position control switching" = 3, with gain switching occurring at 5 to 10). Set the scale factor of the 3rd gain with respect to the 1st gain in Pr6.06 "Position 3rd gain scale factor".

- If 3rd gain is not used, set Pr6.05 "Position 3rd gain valid time" = 0 and Pr6.06 "Position 3rd gain scale factor" = 100.
- In the 3rd gain section, the position loop gain and speed loop gain become 3rd gain, and 1st gain settings are applied to the speed loop integral time constant, speed detection filter and torque filter time constant parameters.
- If 2nd gain switching conditions are satisfied in the 3rd gain section, the gain is switched to 2nd gain.
- When switching from 2nd gain to 3rd gain, Pr1.19 "Position gain switching time" is applied.

Note that a 3rd gain section is also generated when the gain is switched from 2nd gain to the 1st gain due to a parameter change, etc.

(Example) Gain transition when Pr1.15 "Mode of position control switching" = 7 (with position command)



## – Precautions -

• If Pr6.06 "Position 3rd gain scale factor" is raised too high, oscillation may occur.

## 4.3.4.1.1 Example Tuning Procedure for Overshoot/Undershoot Suppression

The following is an example procedure for suppressing overshoot/undershoot by increasing the gain near settling due to large overshoot/undershoot at positioning settling during position control.

#### << Procedure >>

- 1. Determine the section to be suppressed while observing amounts of overshoot/undershoot.
- 2. Set the value determined by "Step 1" to Pr6.05 "Position 3rd gain valid time".
- **3.** Increase Pr6.06 "Position 3rd gain scale factor" by increments of 10 from 100 within the range of oscillation does not occur.
- **4.** If the overshoot/undershoot suppression is ineffective, try tuning Pr6.05 "Position 3rd gain valid time" and Pr6.06 "Position 3rd gain scale factor" to a setting at which overshoot/undershoot is suppressed.

**5.** If still ineffective after executing <u>"Step 4"</u>, try finding the optimal setting values, including for 1st gain and 2nd gain.

# 4.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

Refer to <u>"4.2 Gain Switching Function"</u> <u>"4.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used"</u>.

# 4.4 Feedforward Function

## 4.4.1 Function Overview

This function performs compensation to minimize the effect of delay caused by feedback control on the command value before the effect is apparent.

- The speed feedforward function generates a speed feedforward value by adding a speed control command calculated from the internal position command to the speed command from the position control processing part. The use of this speed feedforward value results in less position deviation while operating at a constant speed compared to with feedback control alone, thus increasing the responsiveness of position control.
- The torque feedforward function generates a torque feedforward value by adding the torque command calculated from the speed control command to the torque command from the speed control processing part. The use of this torque feedforward value results in position deviation of close to 0 at constant acceleration and deceleration, thus increasing the responsiveness of speed control.
- In addition to this function, feedforward values can also be set and sent using EtherCAT communication. With EtherCAT communication, the speed feedforward value can be set with Obj.60B1h:00h "Velocity offset" and the torque feedforward value with Obj.60B2h:00h "Torque offset". Each feedforward value given by EtherCAT communication is added to each internally calculated feedforward value according to the parameter setup of this function. For details, see Operating Instructions (Overall) "6.6.5 Position Control Function (pp, csp, ip, hm)", "6.6.6 Velocity Control Function (pv, csv)" and "6.6.7 Torque Control Function (tq, cst)".

# 4.4.2 Operational Conditions

ltem	Operational Conditions			
Control mode	<ul> <li>Position control, speed control, and full-closed control</li> </ul>			
	<ul> <li>In speed control, only the torque feedforward function works</li> </ul>			

• Each feedforward that can be set using EtherCAT communication supports the control modes listed below.

Index	csp	рр	hm	CSV	pv	cst	tq
Obj.60B1h:00h "Velocity offset"	0	0	0	0	0	×	×
Obj.60B2h:00h "Torque offset"	0	0	0	0	0	0	0

#### – Precautions –

• If the control mode is switched during motor operation from a control mode other than torque control mode to torque control mode, feedforward may operate even though torque control is in progress.

# 4.4.3 Related Parameters

01433	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	10	В	Velocity feed for- ward gain	0 to 4000	0.1%	Multiply the velocity control command calculated ac- cording to the internal position command by the ratio of this parameter and add the result to the speed com- mand resulting from the position control process.

Class

\_\_. N/∆

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	11	В	Velocity feed for- ward filter	0 to 6400	0.01 ms	Sets the time constant of first order lag filter which af- fects the input of velocity feedforward. Disabled when the set value is 0 to 3. Invalid during two-degree-of-freedom control mode.
1	12	В	Torque feed for- ward gain	0 to 2000	0.1%	Multiply the torque command calculated according to the velocity control command by the ratio of this param- eter and add the result to the torque command resulting from the velocity control process.
1	13	В	Torque feed for- ward filter	0 to 6400	0.01 ms	Set the time constant of first order lag filter which affects the input of torque feedforward. Disabled when the set value is 0 to 3.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# 4.4.4 How to Use

## 4.4.4.1 For Manual Setting

In the initial setting, two-degree-of-freedom control mode is set to enabled, and both Pr1.10 "Velocity feed forward gain" and Pr1.12 "Torque feed forward gain" are set to 100%.

This setting does not usually require tuning, as this value obtains the highest responsiveness if Pr0.04 "Inertia ratio" is set correctly.

However, the value can be tuned to suppress overshoot during positioning.

Setting Pr1.10 "Velocity feed forward gain" lower suppresses position deviation overshoot during positioning. Reduce the set value by increments of 50 from 1000. Tune to the optimal value, as too small a value may increase the settling time.

On the Manual TUNING screen for Set-up Support Software (PANATERM ver.7), Pr1.10 "Velocity feed forward gain" is linked to "Overshoot Suppression".

## Image of overshoot suppression

Position deviation - Dotted line: before suppression, Solid line: after suppression



If setting Pr1.10 "Velocity feed forward gain" or Pr1.12 "Torque feed forward gain" anything other than 100%, see <u>"Tuning speed feedforward"</u> and <u>"Tuning torque feedforward"</u> below.

## Tuning speed feedforward

With Pr1.11 "Velocity feed forward filter" set to about 50 (0.5 ms), position deviation in the constant speed range can be reduced by gradually increasing Pr1.10 "Velocity feed forward gain".

If the speed feedforward gain is set to 100%, the calculated position deviation becomes zero, but large overshoot occurs during acceleration and deceleration. Tune the value of Pr1.10 "Velocity feed forward gain" while observing the overshoot response.



Position deviation during operation at a constant speed reduces as the velocity feed forward gain is increased.

If the position command input updating cycle is longer than the servo driver control cycle, or if the input command frequency is not uniform, operation sound may become louder when speed feedforward is enabled.

In this case, apply a position command filter (1st order lag or FIR smoothing) or set a higher value for the speed feedforward filter.

## Tuning torque feedforward

When using torque feedforward, the inertia ratio must be set correctly. Just use the estimated value from when realtime auto tuning was executed, or set Pr0.04 "Inertia ratio" to the inertia ratio that can be calculated from the mechanical specifications.

Next, with Pr1.13 "Torque feed forward filter" set to about 50 (0.5 ms), position deviation during constant acceleration and deceleration can be brought close to 0 by gradually increasing Pr1.12 "Torque feed forward gain". Position deviation can be reduced to almost zero over the entire operating range when driving in a trapezoidal speed pattern under ideal conditions in which torque feedforward gain is set to 100% and disturbance torque is not an issue. Tune the value of Pr1.12 "Torque feed forward gain" while observing the position deviation response.



Position deviation during operation at a constant acceleration reduces as the torque feed forward gain is increased.

If the position command input updating cycle is longer than the servo driver control cycle, or if the input command frequency is not uniform, operation sound may become louder when speed feedforward is enabled. In this case, apply a position command filter (1st order lag or FIR smoothing) or set a higher value for the speed feedforward filter. Although operation sound decreases when the torque feedforward filter time constant is increased, the position deviation at the point of acceleration change also increases. Tune Pr1.13 "Torque feed forward filter" while observing the position deviation response.

# 4.4.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

# << Procedure >>

14

- 1. Activate Set-up Support Software (PANATERM ver.7).
- **2.** Select one device that you want to tune in the device tree and click the "Tuning" tab.

829									
File(F)	Troubleshooting(T)	Help(H)							_
		E Device tree			{ĝ} Setting	閥 Monitor	I∕G Logging	🕞 Tuning	🚺 Device Info 🖉
	-	MINAS A7BR				EtherCAT object	IO Setting	Alarm	Analog input
₫⋎	Online	Axis0_No name set	SRV-OFF	I.					
	USB	MADN085BRU 23080001			Open file	Save file	Copy Load initia	values Load	Write
	ฟ		Encoder Info				Config Reset		se sear
		MINAS A7BR MHMG022U1A2 24020001	39405786 pulse	•	Search	Compar	ison None	✓ Add/delete d	column
					Switch to HEX input	Display A6-compati	ble control parameters	Allow out-of-range settin	ngs

**3.** In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

5									
F	File(F) Troubleshooting(T) Help(H)								
Devie		Ŀб	ogging	프 <mark>은</mark> Tuning	Device Info	Ø	) Trial run	Z-pl	hase search
ce tree	< Manual TUNING		🗸 Graph			Trial run/2	1	2	
	Selected driver:Axis0_No name set		Wave graph	Frequency response		Z-pha	Limit setting	Trial ru	in
	Basic Load characteri Notch settings		Start m	easurement Stop	Single trigger	ise s	Protection Functions		
	Damping settin Application Manual	1				earch	Pr5.12 Overload level[%]	0	
			Measureme	ent data management Edit	display range Fixed display range	-	Pr5.13 Overspeed level[r/min]		
	Mode setting () 0:Disabled V		Reset zoom	Align with center of Y-axi	s			🛃 Automatic	setting (overspee
			Display as e	elapsed time Display as tim	ne standard Load file		Pr5.14 Motor mova[0.1 rotation	10	
	A7 recommended settingis recommended		Cause fills				Operation limit		
	When upgrading from A6 <u>A6 compatibility setting</u> is recommended		Save The	2			Pr5.04 Over-travel inhibit input s	1: CoE-side (C	iA402) deceler 🗸
	Load characteristic settings Automatic settingOFF		🗸 Graph di	splay settings			Operating range		
	Inertia ratio 0						Use JOG to move to the Max./M	in. positions or i	nput a numeric value
	For more advanced settings Load characteristic settings		Measuren	hent Condition Edit displaye	ed data Cursor		JOG speed[r/min]	60	
	Gain setting		Acquire	from driver Acquire from	n file Load condition presets		JOG acceleratio[ms/JOG speed	50	
1	Feedback gain setting - 29 +	•				= 1			
	Speed response frequenc 102.5		<ul> <li>Monitor</li> </ul>						
	Automatic oscillation su OFF		Simple mor	nitor IO monitor					
	Safety function								
	FF gain setting - 31 +		Start mea	surem Measurement mod	e With Position C 💙 Measurement count	2			
	Positional command smo 0.8		Trial No.	Settling time INP change cou	unt Vibration level Effective load factor Takt				
	Overshoot suppression [%] - 100.0 +		[times]	[ms] [times]	[%] [%] [ms]		Servo-on Operates	only while the bu	utton is pressed.
	Notch filter settings Automatic setting:OFF						- direction	o to 0	+ direction
	3rd notch frequency [Hz] 5000							·····	1
	4th notch frequency [Hz] 5000						Current position	Command unit	
	Damping filter setup								
	1st damping frequency [Hz] 0						Minimum position		Maximum position
	For more advanced settings Damping settings						[command unit]		[command unit]
	What if I have a problem?						0		0
	Refer to Tuning Help <u>when problems occur</u> such as vibration or abnormal noise						Troubl	eshooting	To trial run

**4.** Click the [Application] button.

<	Manual TUNING				
Selected driver:Axis0_No name set					
Basic Load characteristic settings Notch settings					
Damping settings	Damping settings Application Manual				
> Feedforward function	> Feedforward function				
> Load fluctuation control f	unction				
> High response current cor	ntrol function				
> Gain switching function					
> Quadrant glitch suppressi	> Quadrant glitch suppression function				
> Hybrid vibration suppress	on function				

5. Click on ">" of "> Feedforward function" to expand "Feedforward Function".

< Manual TUNING					
Selected driver:Axis0_No name set					
Basic	Load characte	eristic settings	Notch settings		
Damping settings	Appli	cation	Manual		
Feedforward function Tuning may reduce overshoot/undershoot.					
Speed FF gain [0.1%]		1000			
Speed FF filter [0.01 ms]		0			
Torque FF gain [0.1%]		1000			
Torque FF filter [0.01 ms]		0			
> Load fluctuation control fu	inction				
> High response current con	trol function				
> Gain switching function					
> Quadrant glitch suppression	> Quadrant glitch suppression function				
> Hybrid vibration suppressi	on function				

6. For details on tuning each parameter, see <u>"4.4.4.1 For Manual Setting"</u>.

# 4.5 Friction Torque Compensation Function

## 4.5.1 Function Overview

This function reduces the effect of mechanical system friction and improves responsiveness.

The following three types of friction torque compensation are possible.

## **Unbalanced load compensation**

A constant offset value is always added to the torque command to provide friction compensation.

In situations such as when a constant unbalanced load torque is continuously applied to the motor due to gravity on a vertical axis, a torque command value is added to reduce the variation in the positioning operation caused by the direction of movement.

## **Dynamic friction compensation**

Performs friction compensation by adding a compensation value based on positive-direction and negative-direction position commands to the torque command.

For loads that require high dynamic friction torque due to radial loads, such as a belt mechanical shaft, setting friction torque for each parameter in each rotational direction can reduce positioning settling times that are worsened or varied due to dynamic friction.

## Viscous friction compensation

A compensation value proportional to the command speed is added to the torque command to provide friction compensation.

Setting a torque command value for viscous load can reduce response delay during acceleration.

# 4.5.2 Operational Conditions

Item	Operational Conditions							
Control mode	Possible modes of operation depend on the type of friction torque compensation.							
	Compensation descrip- tion	Operable modes						
	Unbalanced load com- pensation	Position control mode, speed control mode, full-closed control mode						
	Dynamic friction com- pensation	Position control mode, full-closed control mode						
	Viscous friction compen- sation	When two-degree-of-freedom control mode is enabled in position control mode, speed control mode, or full-close control mode						

# 4.5.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	45	В	Function expan- sion setup 10	-2147483648 to 2147483647	_	bit 2: Friction torque compensation parameter selection 0: Use Pr6.07, Pr6.08, Pr6.09 1: Use Pr2.52, Pr2.53, Pr2.54
2	52	В	Torque command additional value 2	-1000 to 1000	0.1%	Sets the offset torque to be added to the torque com- mand when Pr2.45: bit 2 "Friction torque compensation parameter selection" = 1.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	53	В	Positive direction torque compen- sation value 2	-1000 to 1000	0.1%	Sets the value to be added to the torque command dur- ing positive direction operation when Pr2.45: bit 2 "Fric- tion torque compensation parameter selection" = 1.
2	54	В	Negative direc- tion torque com- pensation value 2	-1000 to 1000	0.1%	Sets the value to be added to the torque command dur- ing negative direction operation when Pr2.45: bit 2 "Fric- tion torque compensation parameter selection" = 1.
6	07	В	Torque command additional value	-100 to 100	%	Sets the offset torque to be added to the torque com- mand when Pr2.45: bit 2 "Friction torque compensation parameter selection" = 0.
6	08	В	Positive direction torque compen- sation value	-100 to 100	%	Sets the value to be added to the torque command dur- ing positive direction operation when Pr2.45: bit 2 "Fric- tion torque compensation parameter selection" = 0.
6	09	В	Negative direc- tion torque com- pensation value	-100 to 100	%	Sets the value to be added to the torque command dur- ing negative direction operation when Pr2.45: bit 2 "Fric- tion torque compensation parameter selection" = 0.
6	50	В	Viscous friction compensating gain	0 to 10000	0.1 %/ (10000 r /min)	When the two-degree-of-freedom control mode is ena- bled, the product of the command speed and the setup value is used as the viscous friction torque compensa- tion and the torque command is added to the torque.
						• Setting the value of the viscous friction coefficient es- timation of real-time auto tuning can improve the en- coder position deviation of the settling area.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# 4.5.4 How to Use

Friction torque compensation is added according to the direction and speed of the input position command as shown in the figure below.

Friction torque compensation is the sum of the following three values.

- Unbalanced load compensation value set by the torque command additional value that is always constantly added
- Dynamic friction compensation value set by the positive direction torque compensation value or negative direction torque compensation value, which is added according to the command speed and direction input last
- Viscous friction compensating value added according to command speed

Command speed and direction are reset at power-up and when the motor is not energized.



## – Precautions –

- Although it is possible to use both unbalanced load compensation and dynamic friction compensation in combination or individually, note that the following restrictions will apply depending on the control mode switching or servo-on status.
  - Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection". The initial value is Pr2.45: bit 2 = 1.
    - Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
    - Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
  - During torque control:

Unbalanced load compensation and dynamic friction compensation are set to 0 regardless of the parameter settings.

• During speed control and servo-off:

Unbalanced load compensation is enabled according to Pr2.52 "Torque command additional value 2" and Pr6.07 "Torque command additional value" . Dynamic friction compensation is set to 0 regardless of the parameter setting.

During servo-on in position control or full-closed control:

Until the first position command is received, the previous unbalanced load compensation and dynamic friction compensation values are retained.

Once a position command is received, unbalanced load compensation updates according to the settings for Pr2.52 "Torque command additional value 2" and Pr6.07 "Torque command additional value".

Depending on the command direction, the dynamic friction compensation value is updated according to the positive direction (Pr2.53 "Positive direction torque compensation value 2", Pr6.08 "Positive direction torque compensation value") or negative direction (Pr2.54 "Negative direction torque compensation value 2", Pr6.09 "Negative direction torque compensation value") settings.

# 4.5.4.1 When Set-up Support Software (PANATERM ver.7) Is Used

#### << Procedure >>

1. Activate Set-up Support Software (PANATERM ver.7).

2. Select one device that you want to tune in the device tree and click the "Tuning" tab.

0				PANATERM ver.7				- 🗆 X
File(F)	Troubleshooting(T)	Help(H)						_
		E Device tree		{ĝ} Setting	嬰 Monitor	ピ Logging	프운 Tuning	👖 Device Info
	-	MINAS A7BR		All parameters	EtherCAT object	IO Setting	Alarm	Analog input
@~	Online	Axis0_No name set SRV-OFF		Open file	Save file	Copy Load initia	values Load	Write
USB MADNUBSERU MINAS A7BR MHMG022U17		Encoder Info MINAS A7BR 39405786 pulse		Sauch	(ama	X Add/delate c		
		MHMG022U1A2 24020001		Switch to HEX input	Display A6-compat	ible control parameters	Allow out-of-range settin	

**3.** In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

ŝ	D									
	File	(F) Troubleshooting(T)	Help(H)							
Devio		🔅 Setting	閥 Monitor	ŀĄ	Logging	📑 Tuning	Device Info	Ø	) Trial run	Z-phase search
e tree		< Manu	al TUNING		✓ Graph				1	2
	5	Selected driver:Axis0_No na	ame set		wave graph	Frequency response		pha	Limit setting	Trial run
		Basic Load o	characteri Notch setti	ings	Start m	easurement Stop	Single trigger Acc	quire	Protection Functions	
	10	Damping settin App	plication Manua	d l				arch	Pr5.12 Overload level[%]	0
	Ľ		ap:		Measureme	nt data management Edit	display range Fixed display range	ge	Pr5.13 Overspeed level[r/min]	
	r	Mode setting ()	U:Disabled	<u> </u>	Reset zoom	Align with center of Y-axi	s	- 11		Automatic setting (overspee
			Customize settings		Display as e	lapsed time Display as tim	e standard Load file		Pr5.14 Motor mova[0.1 rotation]	10
		A7 recommended settingis	recommended		Save file				Operation limit	
		<ul> <li>When upgrading from , is recommended</li> </ul>	A6A6 compatibility setting	L	Jave me				Pr5.04 Over-travel inhibit input s	1: CoE-side (CiA402) deceler 🗸
	ι	oad characteristic settings.	Automatic settingOFF		🗸 Graph di	splay settings			Operating range	
		Inertia ratio	0		Moscuror	ont Condition Edit displaye	d data Curror		Use JOG to move to the Max./Mi	n. positions or input a numeric value
		For more advanced setting	s Load characteristic setting	35	Weasuren	ent condition Eult displaye	d data Cuisor		JOG speed[r/min]	60
	(	Gain setting			Acquire	from driver Acquire from	n file Load condition pre	esets	JOG acceleratio[ms/JOG speed]	50
		Feedback gain setting	- 29	+						
		Speed response frequenc	10	02.5	<ul> <li>Monitor</li> </ul>					
		Automatic oscillation su	OFF Safety function		Simple mon	itor IO monitor				
		FF gain setting		+	Start meas	urem Measurement mod	e With Position C 🖌 Measurer	ment count 2		
		Positional command smo		0.8	Trial No. 9	ettling time INP change cou	unt Vibration level Effective load	factor Takt		
		Overshoot suppression [%]	- 100.0	+	[times] [	ms] [times]	[%] [%]	[ms]	Servo-on Operates o	only while the button is pressed.
	r	Notch filter settings	Automatic setting:OFF						- direction	o to 0 + direction
		3rd notch frequency [Hz]	5	5000						
		4th notch frequency [Hz]	5 Notch settings	5000					Current position	[command unit] 0
	١,	Por more advanced setting:	Automatic setting(ON							
	1	1st damping filter setup	Automatic setting:ON	0					1.0 × 1.0	►
	F	or more advanced settings	Damping settings						Minimum position [command unit]	Maximum position [command unit]
	1	What if I have a problem?							0	0
		Refer to Tuning Help when	problems occur such as						Trauble	- Ta trial run
		vibration or abnormal noise	9						Iroubie	Io trial run

4. Select "Mode setting" from the drop-down list. Select "7: Customize 2" and click the [Customize settings] button.

Mode setting (j)	7:Customize2							
	Customize settings							
<ul> <li>When launching for the first time<u>A7 recommended setting</u>is recommended</li> <li>When upgrading from A6<u>A6 compatibility setting</u>is recommended</li> </ul>								
Tuning conditions	Positioning/general-purpose							
	O Processing machine							
O Customize								
> Parameters for tuning conditions								

- To set automatically, go to "Step 5".
- To set manually, go to "Step 6" to "Step 7".

Customize settings	×
In the auto tuning function customization setting: Manual setting/automatic setting of each control Load characteristics estimation	s, parameter can be selected.
Inertia Ratio Update	
Stiffness Setup	
Fixed Parameter Setup	OFF
Gain Switching Setup	0:Use current settings 🗸
Torque compensation setting switching	
Tuning torque command additional value	OFF
Tuning positive direction torque compensation	OFF
Tuning negative direction torque compensation	OFF
Tuning viscous friction compensating gain	OFF
ОК	Cancel

- 5. To set automatically, set all of the following items to "ON" (automatic).
  - "Torque compensation setting switching" (A7 recommended setting)
  - "Torque command additional value tuning"
  - "Positive direction torque compensation tuning"
  - "Negative direction torque compensation tuning"
  - "Viscous friction compensating gain adjustment"

When setup is complete, close the screen with the [OK] button.

To finish without changing any settings, close the screen with the [Cancel] button.

Once the motor has operated for a while, estimated values for each parameter are calculated and set.

- **6.** To set manually, set all of the following items to "OFF" (manual) and manually set the values calculated from the actual measured data.
  - "Tuning torque command additional value"
  - "Tuning positive direction torque compensation"
  - "Tuning negative direction torque compensation"
  - "Viscous friction compensating gain adjustment"

When setup is complete, close the screen with the [OK] button.

To finish without changing any settings, close the screen with the [Cancel] button.

Set values for each parameter. Use the following procedure to calculate the values.

- **6-1** Drive the motor with an operation command that includes constant speed and use the waveform measurement function of Set-up Support Software (PANATERM ver.7) to measure the torque in the constant speed section. Measure the torque multiple times by changing this constant speed value.
- **6-2** Based on these measurement results, create a graph that combines speed and torque and calculate the value of each parameter.

The unit [%] of torque is a percentage of the motor rated torque.

The viscous friction compensation gain is calculated by calculating the inclination of the graph and the torque at 10000 r/min.



7. Click the [Load characteristic settings] button to display the "Load characteristic settings" screen. Set the values calculated by <u>"Step 6"</u>.

# 4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)

There are the following two types of load fluctuation control functions.

- Disturbance suppression applications
- Load fluctuation stabilization applications

This section describes "Disturbance Suppression Applications".

# 4.6.1 Function Overview

In devices with which disturbance torque is applied, velocity change may occur due to the disturbance torque. This function reduces this velocity change and improves stability. An overshoot/undershoot suppression effect may also be obtained during positioning.



# 4.6.2 Operational Conditions

ltem	Operational Conditions
Control mode	Position control, speed control, and full-closed control

Under the following conditions, the effect of the load fluctuation control function may not be seen.

Item	Conditions that obstruct the effectiveness of the load fluctuation control function
Load	Low stiffness (antiresonance points exists in the low frequency range of 10 Hz or less)
	<ul> <li>Looseness, backlash, etc. are present and the load non-linearity is strong</li> </ul>

# 4.6.3 Related Parameters

-: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	45	A	Function expan- sion setup 10	-2147483648 to 2147483647	_	Sets automatic calculation of parameters for load fluctu- ation suppression. bit 3: Load fluctuation suppression function automatic calculation
						0: Conventional setting (MINAS A6 Series specifica- tion)
						1: The following parameters are automatically calculat- ed
						Pr6.73 "Load estimation filter"
						Pr6.76 "Load estimation count"

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	10	В	Function expan- sion setup	-32768 to 32767		<ul> <li>Sets the load fluctuation suppression function.</li> <li>bit 1: Load fluctuation control function <ol> <li>Disabled</li> <li>Enabled</li> </ol> </li> <li>bit 2: Load fluctuation stabilization setting <ol> <li>Disabled</li> <li>Enabled</li> </ol> </li> <li>bit 14: Load fluctuation suppression function automatic tuning <ol> <li>Disabled</li> <li>Enabled</li> </ol> </li> <li>Notes <ol> <li>Depending on the settings for two-degree-of-freedom control and real-time auto tuning, bit 1 may be set automatically according to the setting for bit 14.</li> </ol> </li> </ul>
6	23	В	Load change compensation gain	-100 to 100	%	Sets compensation gain with respect to load fluctuation.
6	24	В	Load change compensation fil- ter	10 to 2500	0.01 ms	Sets filter time constant with respect to load fluctuation. Disabled when the set value is 0 to 3.
6	73	В	Load estimation filter	0 to 2500	0.01 ms	Sets filter time constant for load estimation. Disabled when the set value is 0 to 3.
6	74	В	Torque compen- sation frequency 1	0 to 5000	0.1 Hz	Sets filter frequency 1 with respect to velocity control output. Torque compensation is valid when the relationship be- tween Pr6.74 "Torque compensation frequency 1" and Pr6.75 "Torque compensation frequency 2" is within the range of the following formula. 1.0 Hz $\leq$ Pr6.75 $\leq$ Pr6.74 $\leq$ (Pr6.75 $\times$ 32)
6	75	В	Torque compen- sation frequency 2	0 to 5000	0.1 Hz	Sets filter frequency 2 with respect to velocity control output. Torque compensation is valid when the relationship be- tween Pr6.74 "Torque compensation frequency 1" and Pr6.75 "Torque compensation frequency 2" is within the range of the following formula. $1.0 \text{ Hz} \le \text{Pr6.75} < \text{Pr6.74} \le (\text{Pr6.75} \times 32)$
6	76	В	Load estimation count	0 to 8	-	Sets count relating to load estimation.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# 4.6.4 How to Use

# 4.6.4.1 For Manual Setting

#### << Procedure >>

- Operate the motor with Pr0.02 "Real-time auto-gain tuning setup" enabled and the load fluctuation control function disabled (Pr6.10 bit 1 = 0). Increase the stiffness settings (Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2", Pr0.03 "Real-time auto-tuning machine stiffness setup") by increments of 1 to the largest possible values.
- 2. After setting the load fluctuation suppression function automatic setting to enable (Pr6.10 "Function expansion setup" :bit 14 = 1), operate the motor to check the disturbance suppression effect.

#### – Precautions –

- To enable or disable load fluctuation suppression function automatic setting, turn the servo off once.
- If this change causes the motor to oscillate or make abnormal noises, go back to <u>"Step 1"</u>, reduce the servo stiffness by one or two steps, and repeat the procedure thereafter.
- **3.** If the disturbance suppression effect is insufficient and further tuning is required, perform the following operations.
  - Set Pr0.02 "Real-time auto-gain tuning setup" = 0 (disabled).
  - Set Pr6.10 "Function expansion setup" :bit 14 = 0 to enable load fluctuation suppression function automatic tuning.
  - Reduce the set value for Pr6.24 "Load change compensation filter". The set value should be changed by decreasing by 10% at a time.

By reducing the filter setting within the range where abnormal noise and torque command fluctuations are not noticeable, disturbance suppression performance is improved, resulting in smaller motor speed fluctuation and encoder position deviation. During positioning, the following effects may be obtained.

- Overshoot/undershoot suppression
- Velocity fluctuation suppression during constant speed control
- Improved disturbance suppression performance
- If high frequency (1 kHz or higher) abnormal noise is generated, increase Pr6.76 "Load estimation count" by increments of 1. Set an appropriate value as too large a value may result in unstable control.
- If low frequency (10 Hz or less) vibration is generated, after stopping, for example, decrease Pr6.23 "Load change compensation gain" by increments of 5.
- Pr6.73 "Load estimation filter" does not normally need to be changed, but may be fine-tuned to an optimal point between 0.00 and 0.20 ms.

#### 4.6.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

#### << Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7).
- 2. Select one device that you want to tune in the device tree and click the "Tuning" tab.

2									
File(F)	Troubleshooting(T)	Help(H)							_
		E Device tree				閥 Monitor	년 <sub>신 Logging</sub>	프 <mark>은</mark> Tuning	🚺 Device Info 💐
	-	MINAS A7BR				EtherCAT object	IO Setting	Alarm	Analog input
യെ∨	Online	Axis0_No name set	SRV-OFF	I.					
	USB	MADN085BRU 23080001			Open file	Save file	Copy Load initia	values Load	Write
	M.		Encoder Info				Config Reset		se sear
	<b>I</b>	MINAS A7BR MHMG022U1A2 24020001	39405786 puise	•	Search	Compa	rison None	✓ Add/delete c	olumn 4
					Switch to HEX input	Display A6-compati	ible control parameters	Allow out-of-range settin	gs

3. In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

Field         Transformed in the provide settings         Selected driver-AxieD No name set         Basic       Ladd characterin       Notice settings         Manual TUNING         Selected driver-AxieD No name set         Basic       Ladd characterin       Notice settings         More advanced setting Sead       Calcomize settings       Selected driver-AxieD No name set         Basic       Ladd characterin       Notice settings       Calcomize settings       Setting Sead drapping response       Protection functions         Measurement data management       East measurement       Secting single trigger Acquire       Protection functions         Measurement data management       East drapping setting Single trigger Acquire       Protection functions         Secting single trigger Acquire       Secting single trigger Acquire       Protection functions         Site measurement       Site function       Protection functions         Secting single trings testings       Acquire from drive       Carsor drive drive Acquire from file	5												
Besting       Wontor       Vic logging       25 mining       Device Info       Find run       Z phase a         Selected diverx/side No name set       Image: Selected diverx/side No name set         Demping settin:       Application       Manual       Mode setting:       Image: Selected diverx/side No name set       <	File(F)	Troubleshootir	ng(T) Help(H)										
K       Menual TUNING         Selected driver.Axiol No name set         Damping settin.       Application         Menual TUNING       Start measurement         Solabled       Catomize setting:         Obselved       Catomize setting:         Obselved       Catomize setting:         Other setting:       Catomize setting:         Owner setting:       Catomize setting:         Second setting:       Second setting:         Second setting:       Second setting:         Match Illiter setting:       Second setting:         Second setting:       Second setting:         Second setting:       Second setting:         Match Illiter setting:       Second setting:         Second setting:       Second setting:         Notch Il	Devie	🖏 Setting	閥 Mo	nitor	比 Loggin	ng	프 <mark>아</mark> Tuning	Device Info	89	D Trial rur	ı	Z-ph	ase search
Basic       Load character.       Notch setting:         Damping settin.       Application       Manual         Mode setting ()       CDisabled	ce tree <	cted driver:Axis0	Manual TUNING		Wa	Graph we graphic F	requency response			Trial ann/7-p Lim	1 it setting	2 Trial ru	n
What if I have a problem? Refer to Tuning Help <u>when problems occur</u> such as	Selection Select	cted driver:Axis0         Rasic         mmping settin     de setting ①         When launching         recommended se         vertice of the setting ①         When upgrading         recommended se         vertice of the setting         adback gain settin         adback gain setting         adback gain setting         adback gain setting         adback feel newnonse freq         uutomatic oscillatio         gain setting         adback feel newnonse freq         uutomatic oscillatio         gain setting         adon frequency         n notch frequency         the setup t         damping frequer         ming filter setup         tamping frequer         ming Help         Coming Help         Coming Help         Coming Help         Coming Help         Coming Help         command         advanced se         de         recommended setup         command         recommended         advanced setup         command         advanced setup         advanced         advanced setup         advanc	No name set Load characteri Application  ODisabled Customize for the first time from A6A6 compat tings Automatic s 0  uent: on su OFF Safety func - 3 31 smo on (% - 100.0 Automatic s (H2 H2) Automatic s voy (H2) when problems occo	Notch settings Manual Settings d d billity setting ettingOFF teristic settings tion + 102.5 tion + 0.8 0.8 0.8 0.8 0.8 0.8 0.8 0.9 0.8 0.9 0.8 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9	Me Res Dis Sim	Start measure assurement dat set zoom A applay as elapsec save file Graph display as Graph display as Acquire from c Monitor nple monitor tart measurem ial No. Settlini mes] [ms]	equency response ement Stop a management Edit lign with center of Y-axi settings ondition Edit displaye driver Acquire fror IO monitor Measurement mod g time INP change cos times	Visingle trigger  A display range Fixed display ra s s te standard Load file d data Cursor file Load condition p Vibr Position C Measur [\$6] Kessur (\$6] Kessur	resets [	in Lim Protection Functions Pr5.12 Overload lea Pr5.13 Overspeed J Pr5.14 Motor move Operation limit Pr5.04 Over-travel i Operating range Use JOG to move JOG speed[r/min] JOG acceleratio[ direction Command unit] 0	it setting rel[%] evel[r/min] (0.1 rotation] inhibit input s to the Max/Mi ms/JOG speed] Coperates of Coperates of Coperates of Coperates of Coperates of Coperates of Coperates of Coperates of Coperates of Coperates of Coperates of Coperates of Coperates of Coperates of Coperates of Coperates of Coperates	Trial run	A402) deceler  A402) deceler   tton is pressed. direction  Maximum position [command unit] 0 To trial num

**4.** After changing "Mode setting" to a mode that enables real-time auto tuning, operate the motor. Increase the "Feedback gain setting" by increments of 1 and set as large a value as possible.

<	< Manual TUNING					
Selected driver:Axis0_No nar	ne set					
Basic	Load charac	teristic	ttings			
Damping settings	Арр	lication	n	Manu	al	
Mode setting (i)		7:Cus	tomize2		~	
		Cust	omize sett	ings		
(i) When launching for the f	irst time <u>A7 re</u>	comm	ended set	tingis recommend	led	
() When upgrading from A	6 <u>A6 compatib</u>	oility se	ettingis rec	ommended		
Tuning conditions		• Po	sitioning/	general-purpose		
		O Pr	ocessing r	nachine		
		O Ci	ustomize			
> Parameters for tuning	g conditions					
Load characteristic settings		Automatic settingON				
Inertia ratio						
For more advanced settings	Load characte	ristic s	ettings			
Gain setting						
Feedback gain setting		-	16		+	
Speed response frequency [ł	lz]				27.0	
Automatic oscillation supp	ression	OFF				
		Safe	ty functior	1		
FF gain setting		-	16		+	
Positional command smooth	ing filter [				3.7	
Overshoot suppression [%]		-	100.0		+	
Notch filter settings		Autor	natic setti	ng:ON		
3rd notch frequency [Hz]					5000	
4th notch frequency [Hz]					5000	
For more advanced settings	Notch setting:	<u>S</u>				
Damping filter setup Automatic setting:ON 1st damping frequency [Hz]						
1st damping frequency [Hz] 0 For more advanced settings Damping settings						
What if I have a problem? Refer to Tuning Help <u>when problems occur</u> such as vibration or abnormal noise						

## **5.** Click the [Application] button.



6. Click ">" of "> Load fluctuation control function" to expand "Load fluctuation control function".

<	Manual TUNING					
Selected driver:Axis0_No name set						
Basic	Load characte	eristic settin	Notch settings			
Damping settings	Appli	cation	Manual			
> Feedforward function						
✓ Load fluctuation control for	unction					
the movement of other axes, Use to suppress overshoot, e to occur. Load fluctuation suppression	etc. etc. Be aware th function en	at increasing co	ntrol may cause oscillation			
Load fluctuation suppression	function aut					
Load change compensation g	gain [%]	90				
Load change compensation f	filter [0.01 ms]	590				
Load estimation filter [0.01 m	ns]	4				
Torque compensation freque	ncy 1 [0.1 Hz]	0				
Torque compensation freque	ncy 2 [0.1 Hz]	0				
Load estimation count		0				
High response current control function						
> Gain switching function						
> Quadrant glitch suppression function						
> Hybrid vibration suppress	ion function					

**7.** After setting "Load fluctuation suppression function automatic tuning" to ON, operate the motor to check the disturbance suppression effect.

## - Precautions -

- When switching "Load fluctuation suppression function automatic tuning" from OFF to ON, turn the servo off once.
- If the motor oscillates or makes an abnormal noise after this tuning, click the [Basic] button to return to the "Manual TUNING" screen. After lowering the feedback gain setting by one or two steps on the "Manual TUNING" screen, run the motor again to check the disturbance suppression effect.
- Changing the feedback gain setting changes several parameters, including the speed loop gain. Save previous parameters if necessary.

- **8.** If the disturbance suppression effect is insufficient and further tuning is required, perform the following operations.
  - Click the [Basic] button and set "Mode setting" to "0: disabled".

<	< Manual TUNING						
Selected driver:Axis0_No na	me set						
Basic	Load chara	cteristic settings Notch settin					
Damping settings	App	olication	Manual				
Mode setting (i)		0:Disabled		~			
		Customize sett	ings				
When launching for the first time <u>A7 recommended setting</u> recommended     When upgrading from A6 <u>A6 compatibility setting</u> recommended							
Load characteristic settings		Automatic settir	ngOFF				
Inertia ratio		250					
For more advanced settings	Load characte	ristic settings					
Gain setting							
Feedback gain setting		- 16		+			
Speed response frequency	[Hz]			27.0			
Automatic oscillation supp	pression	OFF					
		Safety function					
FF gain setting		- 16		+			
Positional command smoot	thing filter [ms]	]		9.2			
Overshoot suppression [%]		- 100.0		+			
Notch filter settings		Automatic settir	ng:OFF				
3rd notch frequency [Hz]				5000			
4th notch frequency [Hz]				5000			
For more advanced settings	Notch setting	<u>s</u>					
Damping filter setup		Automatic settir	ng:ON				
Tist damping frequency [Hz]	) Damping settir	in the second seco		0			
What if I have a problem?	sumping setur	195					
Refer to Tuning Help when	problems occu	r such as vibratio	n or abnormal noise				

- After clicking on the [Application] button, click ">" of "Load fluctuation control function" to expand "Load fluctuation control function".
- After setting "Load fluctuation suppression function automatic tuning" to OFF, set Load change compensation filter as small as possible. The set value should be changed by decreasing by 10% at a time.
- If high frequency (1 kHz or higher) abnormal noise is generated, increase Load estimation count by increments of 1. Set an appropriate value, as too large a value may result in unstable control.
- If low frequency (10 Hz or less) vibration is generated, after stopping, for example, decrease Load change compensation gain by increments of 5.
- Load estimation filter does not normally need to be changed, but may be fine-tuned to an optimal point between 0.00 and 0.20 ms.

# 4.7 Load Fluctuation Control Function (Load Fluctuation Stabilization Applications)

There are the following two types of load fluctuation control functions.

- Disturbance suppression applications
- Load fluctuation stabilization applications

This section describes "Load Fluctuation Stabilization Applications".

# 4.7.1 Function Overview

In devices where load inertia fluctuates, vibration may occur due to the effect of load inertia fluctuations. This function reduces this vibration and improves stability.

Example of operation before tuning

Example of operation after tuning





# 4.7.2 Operational Conditions

Item	Operational Conditions		
Control mode	Position control, speed control, and full-closed control		

Under the following conditions, the effect of the load fluctuation control function may not be seen.

Item	Conditions that obstruct the effectiveness of the load fluctuation control function
Load	Low stiffness (antiresonance points exists in the low frequency range of 10 Hz or less)
	<ul> <li>Looseness, backlash, etc. are present and the load non-linearity is strong</li> </ul>

# 4.7.3 Related Parameters

—: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	45	A	Function expan- sion setup 10	-2147483648 to 2147483647	_	<ul> <li>Sets automatic calculation of parameters for load fluctuation suppression.</li> <li>bit 3: Load fluctuation suppression function automatic calculation</li> <li>0: Conventional setting (MINAS A6 Series specification)</li> <li>1: The following parameters are automatically calculated</li> <li>Pr6.73 "Load estimation filter"</li> <li>Pr6.76 "Load estimation count"</li> </ul>
6	10	В	Function expan- sion setup	-32768 to 32767		Sets the load fluctuation suppression function. bit 1: Load fluctuation control function 0: Disabled 1: Enabled bit 2: Load fluctuation stabilization setting 0: Disabled 1: Enabled bit 14: Load fluctuation suppression function automatic tuning 0: Disabled 1: Enabled Notes • Depending on the settings for two-degree-of-free- dom control and real-time auto tuning, bit 1 may be set automatically according to the setting for bit 14.
6	23	В	Load change compensation gain	-100 to 100	%	Sets compensation gain with respect to load fluctuation.
6	24	В	Load change compensation fil- ter	10 to 2500	0.01 ms	Sets filter time constant with respect to load fluctuation. Disabled when the set value is 0 to 3.
6	73	В	Load estimation filter	0 to 2500	0.01 ms	Sets filter time constant for load estimation. Disabled when the set value is 0 to 3.
6	74	В	Torque compen- sation frequency 1	0 to 5000	0.1 Hz	Sets filter frequency 1 with respect to velocity control output. Torque compensation is valid when the relationship be- tween Pr6.74 "Torque compensation frequency 1" and Pr6.75 "Torque compensation frequency 2" is within the range of the following formula. 1.0 Hz $\leq$ Pr6.75 $\leq$ Pr6.74 $\leq$ (Pr6.75 $\times$ 32)
6	75	В	Torque compen- sation frequency 2	0 to 5000	0.1 Hz	Sets filter frequency 2 with respect to velocity control output. Torque compensation is valid when the relationship be- tween Pr6.74 "Torque compensation frequency 1" and Pr6.75 "Torque compensation frequency 2" is within the range of the following formula. $1.0 \text{ Hz} \le \text{Pr6.75} < \text{Pr6.74} \le (\text{Pr6.75} \times 32)$

Class	No.	Attribute (*1)	Parameter name	Setting range	Chit	Function
6	76	В	Load estimation count	0 to 8	_	Sets count relating to load estimation.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# 4.7.4 How to Use

# 4.7.4.1 For Manual Setting

## << Procedure >>

- Set to two-degree-of-freedom position control mode (synchronization type) (Pr0.01 "Control mode setup" = 0, Pr6.47 "Function expansion setup 2" :bit 0 = 1 bit 3 = 1), and then turn on control power.
- 2. Set Pr2.22 "Positional command smoothing filter" to 10.0 ms.
- **3.** Set real-time auto tuning to load fluctuation support mode (Pr0.02 "Real-time auto-gain tuning setup" = 6) (this sets Pr6.10 "Function expansion setup" :bit 1 and bit 2 to 1) and operate the motor in a pattern that generates as large a load fluctuation as possible in this state.
- **4.** Increase the stiffness settings (Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2", Pr0.03 "Real-time auto-tuning machine stiffness setup") by increments of 1 to the largest possible values.
- **5.** While checking the motor response, change the Pr2.22 "Positional command smoothing filter" value to a small value and set so that the motor response vibration is smaller.

If locus control for multiple axes is required, tune Pr2.22 "Positional command smoothing filter" for all axes, changing them to the same value.

# 4.7.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

## << Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7).
- 2. Select one device that you want to tune in the device tree and click the "Tuning" tab.

822								
File(F)	Troubleshooting(T)	Help(H)						_
		E Device tree		ô Setting	嬰 Monitor	ピ Logging	프 <del>은</del> Tuning	🚺 Device Info 🔌
	-	MINAS A7BR		All parameters	EtherCAT object	IO Setting	Alarm	Analog input
രം	Online	Axis0_No name set SRV-OFF						
	USB	MADN085BRU 23080001		Open file	Save file	Copy Load initia	I values Load	Write
	*0	Encod	er Info			Config Reset		se sea
		MINAS A7BR 3940578	5 pulse					
	129	MHMG022U1A2 24020001		Search	Compa	rison	Add/delete c	column
				Switch to HEX input	Display A6-compati	ible control parameters	Allow out-of-range settin	ngs

**3.** In the "Tuning" tab screen, select "Load fluctuation suppression tuning (Load fluctuation stabilization applications)", and click the [Go to the Tuning screen] button.



A dialog box for enabling the load fluctuation control function is displayed.

4. Check the contents, and click the [OK] button or [Cancel] button.

×
The parameters will be changed to the following values to enable this function. If there is no problem, press OK.
<ul> <li>PR0.02 (Real -time auto tuning setting) = 6 (Load fluctuation mode)</li> <li>PR6.10 Bit1: 1 (Load fluctuation suppression function Valid)</li> <li>PR6.10 bit2: 1 (Load fluctuation stabilization settings Valid)</li> <li>PR6.10 bit14: 1 (Load fluctuation suppression function automatically adjusted Valid)</li> <li>PR6.47 bit 0 (2 freedom control mode) = 1 (Valid)</li> <li>PR6.47 bit 3 (Auto tuning selection) = 1 (Synchronous type)</li> </ul>
OK Cancel

## – Precautions –

• If the power needs to be restored, the following dialog box is displayed. Check the contents, and click the [OK] button or [Cancel] button.

×
o enable this function, it is necessary to reset the control power supply. After writing the previous parameter changes to EEPROM, reset the control power supply. *After this, automatic parameter recovery is no longer possible.
f there is no problem, please press "OK". f "Cancel" is pressed, you will exit this screen without changing the parameters.
OK Cancel

The load fluctuation suppression tuning screen is displayed.

6	)			PANATERM	ver.7			- 🗆 X
F	ile(F) Tro	ubleshooting(T) Help(H)				_		
Devic	÷	Setting 🛛 🐯 Monitor	Ľ∕ Logging	프 <del>을</del> Tuning	Device Info	1	Trial run	Z-phase search
ce tree	<	Load fluctuation suppression	tuning	✓ Graph		frial run/	1	2
	Selected d	river:Axis0_No name set		Wave graphic Frequency resp	onse	Z-pha	Limit setting	Trial run
	B:	asic Notch settings	Damping settings	Start measurement	Stop Single trigger	ase searc	Protection Functions Pr5.12 Overload level[%]	0
	while drivin	g.	load liner nucluates			-	Pr5.13 Overspeed level[r/min]	120
	Tuning con	ditions 💿 Easy tu	ining O Manual tuning	Edit display range Fixed disp	lay range Keset zoom			Automatic setting (overspee
	Feedback	gain setting - 16	+	Align with center of Y-axis Display as elapsed time Disp	lav as time standard		Pr5.14 Motor mova[0.1 rotation]	10
	Automa	tic oscillation suppressi OFF		Load file Save file		ш	Operation limit	
		Safety fu	nction	Load me			Pr5.04 Over-travel inhibit input s	1: CoE-side (CiA402) deceler 🗸
				<ul> <li>Graph display settings</li> </ul>			Operating range	n, positions or input a numeric value
	Pr6.23 Load	I change compensation 0		Measurement Condition Ed	t displayed data Cursor		JOG speed[r/min]	60
۲	Pr6.24 Load	I change compensation 53				•	JOG acceleratio[ms/JOG speed]	50
	Pr6.73 Load	estimation filter[0.01 0		✓ Monitor	(2)	-		
	Pr6.74 Torq	ue compensation frequ 0		Internal status :is0_No name s	Physical s O Logical st	11	(*	2)
	Pr6.75 lorg	ue compensation frequ 0		Control mode Position con	Function name 🗸		(•	5)
	Pr6.76 Load	estimation count[]		Power suppl 276	Connector Pin Si Status			
	P12.22 P051	uonai command smoot 92		Command 0	SI1 input 5		Servo-on 🔘 🕂 Operates o	only while the button is pressed.
				Actual spee 0	SI2 input 7		- direction	o to 0 + direction
		(1)		Torque com 0	SI4 input 9	ш	Current position	[command unit]
				Regenerativ 0	SI5 input 1			0
				Warning 0x00	SI6 input 1		A	
				Error 0.0	SI7 input 1		Minimum position [command unit]	Maximum position [command unit]
				Driver derati 0	SO1 output 1		0	0
				OFF Pulse offset display	SO2 output 2		Trouble	eshooting To trial run
				an lineu		-		
	(1)	This is the main s	creen. This dis	plays the paramet	er tuning screen.			
	(2)	This displays the	waveform mea	surement and freq	uency response me	asu	rement screens.	
	(3)	This displays the	trial run operati	on screen.				

The following describes tuning with focus on the operations on the main screen (left side of the screen).

5. Click the [Basic] button and then select "Easy tuning" for the tuning condition.

<ul> <li>Load fluctuation suppression tuning</li> </ul>						
Selected driver:Axis0_No n	ame set					
Basic	Notch s	settings	Damping settings			
It is a function to properly a	djust even wh	en the load inr	ner fluctuates while driving.			
Tuning conditions		Easy tunir	ng 🔿 Manual tuning			
Feedback gain setting		- 16	+			
Automatic oscillation sup	pression	OFF				
		Safety funct	ion			
Pr6.23 Load change comper	nsation gain	0				
Pr6.24 Load change comper	nsation filter	. 53				
Pr6.73 Load estimation filter	[0.01ms]	0				
Pr6.74 Torque compensation	n frequency	0				
Pr6.75 Torque compensation	n frequency	0				
Pr6.76 Load estimation cour	nt[]	0				
Pr2.22 Positional command	smoothing	92				

**6.** In order to generate as large a load fluctuation as possible, the motor is operated in multiple patterns using the trial run function or via commands from the host device.

7. Check the motor operation by waveform measurement while gradually changing the feedback gain setting to a higher value. Tune so that motor response vibration is reduced in any operation pattern. If "Easy tuning" does not satisfy the response performance, proceed to <u>"Step 8"</u>.

<ul> <li>Load fluctuation suppression tuning</li> </ul>							
Selected driver:Axis0_No name set							
Basic	Notch s	ettings	Damping settings				
It is a function to properly adju	st even whe	en the load inr	ner fluctuates while driving.				
Tuning conditions		Easy tunir	ng O Manual tuning				
Feedback gain setting		- 16	+				
Automatic oscillation suppre	ession	OFF					
		Safety funct	ion				
Pr6.23 Load change compensat	tion gain	0					
Pr6.24 Load change compensat	tion filter	53					
Pr6.73 Load estimation filter[0.0	01ms]	0					
Pr6.74 Torque compensation fr	equency	0					
Pr6.75 Torque compensation fr	equency	0					
Pr6.76 Load estimation count[]		0					
Pr2.22 Positional command sm	oothing	92					

A safety function (for automatically lowering the set value to eliminate oscillation when tuning is in progress) can be set. To set, click the [Safety function] button. The "Safety function" dialog box is displayed. "Enable (Yes)" or "Disable (No)" can be selected for the safety function. When enabled, the "Oscillation detection level" can be set.

Safety function	×
Safety functions can be set during gain adjustment. When this function is enabled, the Feedback gain settin immediately suppress vibration if any vibrations occur the torque command.	g is automatically lowered to that exceed the detection level set by
Safety function (Automatic oscillation suppression function)	🔿 Yes 💿 No
Oscillation detection level	15 %
	OK Cancel

8. Select "Manual tuning" for the tuning condition.

The parameters at the bottom of the screen can now be changed. Tune these parameters.

<ul> <li>Load fluctuation suppression tuning</li> </ul>							
Selected driver:Axis0_No name set							
Basic	Notch s	ettings	Damping settings				
It is a function to properly a	djust even whe	en the load inr	ner fluctuates while driving.				
Tuning conditions		O Easy tunir	ng 💿 Manual tuning				
Feedback gain setting		- 16	+				
Automatic oscillation sup	pression	OFF					
		Safety funct	ion				
Pr6.23 Load change compen	sation gain	0					
Pr6.24 Load change compen	sation filter	53					
Pr6.73 Load estimation filter	[0.01ms]	0					
Pr6.74 Torque compensatior	n frequency	0					
Pr6.75 Torque compensation	n frequency	0					
Pr6.76 Load estimation coun	nt[]	0					
Pr2.22 Positional command	smoothing	92					

Lower the set value for Pr2.22 "Positional command smoothing filter" while checking the motor response. The set value should be changed by decreasing by 10% at a time to decrease motor response vibration.

- If locus control for multiple axes is required, tune Pr2.22 "Positional command smoothing filter" for all axes, changing them to the same value.
- If high frequency (1 kHz or higher) abnormal noise is generated, increase Pr6.76 "Load estimation count" by increments of 1.
- If low frequency (10 Hz or less) vibration is generated, after stopping, for example, decrease Pr6.23 "Load change compensation gain" by increments of 5.
- Pr6.73 "Load estimation filter" does not normally need to be changed, but may be fine-tuned to an optimal point between 0.00 and 0.20 ms.

## Notes

- If sounds or vibrations of specific frequencies occur in the high frequency range when tuning is in progress, these may be suppressed by tuning the notch filter. Select the [Notch settings] button at the top of the main screen and tune the notch filter parameters. For details, see <u>"5.3 Notch Filter Function"</u>.
- Residual vibration that occurs at the moving part tip or the overall device when tuning is in progress may be suppressed by tuning the damping filter or model-type damping filter. Select the [Damping settings] button at the top of the main screen and tune the damping filter and model-type damping filter parameters. For details, see <u>"5.5 Damping Control Function"</u> and <u>"5.6 Model-type Damping Filter Function"</u>.

# 4.8 High Response Current Control Function

## 4.8.1 Function Overview

This function improves the responsiveness of the current controller by changing the current response setting to a value greater than the initial value in order to improve the current control responsiveness when operating at low current, such as with a processing machine. Improved current response may provide the following effects during positioning

- Overshoot/undershoot suppression
- Velocity fluctuation suppression during constant speed control
- Improved disturbance suppression performance

Changing the current response setting to a value smaller than the initial value enables this to also be used for suppressing fine vibration when stopped.

# 4.8.2 Operational Conditions

Item	Operational Conditions
Control mode	All control modes

# 4.8.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range		Unit	Function
6	11	В	Current loop gain response setup		10 to 300	%	Tunes the current response with the current response default as 100%.
6	121	В	Current feed for- ward response setup		0 to 300	%	Tunes the current feedforward response with the current feedforward response default as 100%.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

## – Precautions –

- Setting Pr6.11 "Current loop gain response setup" and Pr6.121 "Current feed forward response setup" to values greater than 100% of the initial values can cause vibration and noise. As with tuning of the position control part and speed control part, tune to the appropriate values according to the operating status of the applicable device.
- Changing Pr6.11 "Current loop gain response setup" and Pr6.121 "Current feed forward response setup" to values smaller than 100% of the initial values reduces the responsiveness of the current control part.
- Although the maximum value in the setting range for Pr6.11 "Current loop gain response setup" and Pr6.121 "Current feed forward response setup" is 300%, the maximum value capable of being set will depend on the motor and may be less than 300%. The set value is limited by the maximum value that can be set for the motor (Pr6.11 and Pr6.121 are different limit values, even though they are for one motor). Check the parameters after input.
- The parameter name for Pr6.11 is "Current response setting" for the MINAS A6B Series, but was changed to "Current loop gain response setup" from the MINAS A7B Series.

If the value is 100% or higher, the responsiveness is the same as for the MINAS A6BSeries. If the value is 99% or less, set Pr6.121 "Current feed forward response setup" to 0% to obtain responsiveness equivalent to the MINAS A6B Series.

# 4.8.4 How to Use

## 4.8.4.1 For Manual Setting

• To improve current responsiveness

Set Pr6.11 "Current loop gain response setup" and Pr6.121 "Current feed forward response setup" to values greater than 100% within the range where no noise or vibration is generated, while observing the operating status of the applicable equipment. The set value should be changed by increasing by 30% at a time.

• To suppress fine vibration when stopped

Set Pr6.11 "Current loop gain response setup" to less than 100% while observing the operating status of the applicable device. The set value should be changed by decreasing by 10% at a time. If the value is set too low, control may become unstable. Set the value within the range that does not cause problems in actual operation.

## 4.8.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

## << Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7).
- 2. Select one device that you want to tune in the device tree and click the "Tuning" tab.

2									— ⊔ ×
File(F)	Troubleshooting(T)	Help(H)							_
		E Device tree				閥 Monitor	ピ Logging	프 <b>은</b> Tuning	🗓 Device Info 🕲
	-	MINAS A7BR				EtherCAT object	IO Setting	Alarm	Analog input
₫Υ	Online	Axis0_No name set	SRV-OFF						/Z
	USB	MADN085BRU 23080001			Open file	Save file	Copy Load initia	values Load	Write
	1		Encoder Info				Config Reset		ie sea
	je je se	MINAS A7BR MHMG022U1A2 24020001	39405786 pulse	•	Search	Compari	ison None	✓ Add/delete d	column
					Switch to HEX input	Display A6-compatib	ole control parameters	Allow out-of-range settin	ngs

**3.** In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

5									
F	File(F) Troubleshooting(T) Help(H)								
Devi	袋 Setting	Ŀάι	ogging	프 <mark>아</mark> Tuning	Device Info	Ø	) Trial run	Z-ph	ase search
ce tree	Manual TUNING		✓ Graph			Trial run/Z	0	2	
	Selected driver:Axis0_No name set		wave grap	frequency response		-pha	Limit setting	Trial rur	ı
	Basic Load characteri Notch settings		Start n	neasurement Stop	Single trigger Acquire	se se	Protection Functions	0	
	Damping settin Application Manual					arch	Pr5.12 Overload level[%]	0	
	Mada antiine ()		Measureme	ent data management	display range Fixed display range		Pr5.13 Overspeed level[r/min]		
			Reset zoon	Align with center of Y-axi	s	ш		🛃 Automatic s	etting (overspee
	When launching for the first time		Display as e	elapsed time Display as tim	ne standard Load file		Pr5.14 Motor mova[0.1 rotation]	10	
	A7 recommended settingis recommended		Cauce fill				Operation limit		
	(i) When upgrading from A6A6 compatibility setting is recommended		Save III	e		81	Pr5.04 Over-travel inhibit input s	1: CoE-side (CiA	A402) deceler 🗸
	Load characteristic settings Automatic settingOFF		🗸 Graph d	isplay settings			Operating range		
	Inertia ratio 0						Use JOG to move to the Max./M	n. positions or in	put a numeric value
	For more advanced settings Load characteristic settings		Measuren	nent Condition Edit displaye	ed data Cursor		JOG speed[r/min]	60	
	Gain setting		Acquire	from driver Acquire from	n file Load condition presets		JOG acceleratio[ms/JOG speed]	50	
	Feedback gain setting - 29 +	•				_			
	Speed response frequenc 102.5		<ul> <li>Monitor</li> </ul>						
	Automatic oscillation su OFF		Simple mor	nitor IO monitor					
	Satety function		Start mea	surem Measurement mode	e With Position C Y Measurement count	2			
	Presitional command amo								
	Overshoot suppression [%] - 100.0 +		[times]	[ms] [times]	[%] [%] [%] [%]	1		only while the but	tton is pressed.
	Notch filter settings Automatic setting:OFF								
	3rd notch frequency [Hz] 5000						- direction 🕨 G	o to 0 +	direction
	4th notch frequency [Hz] 5000						Current position	[command unit]	
	For more advanced settings Notch settings							0	
	Damping filter setup Automatic setting:ON								
	1st damping frequency [Hz] 0						Minimum position		Maximum position
	For more advanced settings Damping settings						[command unit]		[command unit]
	What if I have a problem? Refer to Tuning Help when problems occur such as						0		0
	vibration or abnormal noise						Trouble	eshooting	To trial run

**4.** Click the [Application] button.

Manual TUNING							
Selected driver:Axis0_No name set							
Basic	Basic Load characteristic settings Notch settings						
Damping settings	Damping settings Application Manual						
> Feedforward function							
> Load fluctuation control f	unction						
> High response current cor	ntrol function						
> Gain switching function	> Gain switching function						
> Quadrant glitch suppressi	on function						
> Hybrid vibration suppress	ion function						

5. Click on ">" of "> High response current control function" to expand "High response current control function".

elected driver:Axis0 No na								
	Selected driver:Axis0_No name set							
Basic	Load characte	eristic settings	Notch settings					
Damping settings	Appli	cation	Manual					
• Feedforward function								
Load fluctuation control	function							
<ul> <li>High response current co</li> </ul>	ontrol function							
Enabling this can suppress on ncreasing control may caus	vershoot just be e high-frequency	efore stopping. / abnormal nois	e to be generated.					
Current loop gain response	setup [%]	100						
Current feed forward respor	nse setup [%]	100						
Gain switching function								
> Quadrant glitch suppression function								
<ul> <li>Hybrid vibration suppres</li> </ul>	sion function							

6. For details on tuning each parameter, see <u>"4.8.4.1 For Manual Setting"</u>.

# 4.9 Quadrant Glitch Suppression Function

## 4.9.1 Function Overview

This function suppresses quadrant glitches that occur when drawing an arc with two or more axes. Although the load fluctuation control function (disturbance suppression applications) can be used to suppress load fluctuations, this function can be used to further suppress fluctuations when levels are still unsatisfactory.

Example of waveform before tuning

Example of waveform after tuning





# 4.9.2 Operational Conditions

Item	Operational Conditions
Control mode	Position control and full-closed control

Under the following conditions, the quadrant glitch suppression function may not be effective.

Item	Conditions that obstruct the effectiveness of the quadrant glitch suppression function
Load	<ul> <li>Low stiffness (antiresonance points exists in the low frequency range of 10 Hz or less)</li> <li>Looseness, backlash, etc. are present and the load non-linearity is strong</li> <li>When the operation pattern changes</li> </ul>

# 4.9.3 Related Parameters

-: None Class Attribute (\*1) Unit Parameter name Setting range Š Functior 45 Quadrant glitch -1000 to 1000 0.1% Sets the compensation value to be added to the torque 5 В positive-direction command when the position command is in positive dicompensation rection when the quadrant glitch compensation function value is enabled. 5 46 В Quadrant glitch -1000 to 1000 0.1% Sets the compensation value to be added to the torque negative-direccommand when the position command is in negative dition compensarection when the quadrant glitch compensation function tion value is enabled. 0 to 1000 5 47 Quadrant glitch Sets the delay time until the compensation value is В ms compensation switched when the initial position command is input or delay time after reversing the position command when the quadrant glitch compensation function is enabled.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
5	48	В	Quadrant glitch compensation fil- ter setting L	0 to 6400	0.01 ms	Sets the time constant of the low-pass filter applied to the torque command compensation value when the quadrant glitch compensation function is enabled. Disabled when the set value is 0 to 3.
5	49	В	Quadrant glitch compensation fil- ter setting H	0 to 10000	0.1 ms	Sets the time constant of the high pass filter applied to the torque command compensation value when the quadrant glitch compensation function is enabled.
6	47	R	Function expan- sion setup 2	-32768 to 32767	-	<ul> <li>bit 14: Quadrant glitch compensation function</li> <li>Enables and disables the quadrant glitch compensation function.</li> <li>0: Disabled</li> <li>1: Enabled</li> </ul>
6	97	В	Function expan- sion setup 3	-2147483648 to 2147483647	_	<ul> <li>bit 0: Quadrant glitch compensation HPF clear</li> <li>Enables and disables expansion of the quadrant glitch compensation function.</li> <li>0: Disabled</li> <li>1: Enabled</li> <li>To set the compensation amount of quadrant glitch by inversion direction when the direction of the velocity has changed, set to 1.</li> </ul>

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# 4.9.4 How to Use

## 4.9.4.1 For Manual Setting

## << Procedure >>

- **1.** Set the quadrant glitch suppression function to enable (Pr6.47:bit 14 = 1), and then turn the control power back on.
- **2.** Set the following parameters to their initial settings.
  - Pr5.47 "Quadrant glitch compensation delay time" = 0
  - Pr5.48 "Quadrant glitch compensation filter setting L" = Pr1.04 "1st torque filter time constant"

Pr5.49 "Quadrant glitch compensation filter setting H" = 0

- **3.** Fine tune Pr5.45 "Quadrant glitch positive-direction compensation value" and Pr5.46 "Quadrant glitch negative-direction compensation value" for each axis while measuring the size of the quadrant glitch.
  - If quadrant glitch occurs later than the movement direction inversion timing, configure the following settings.
    - 1 Change Pr5.47 "Quadrant glitch compensation delay time" and Pr5.48 "Quadrant glitch compensation filter setting L".
  - Use the following procedure to set the amount of quadrant glitch compensation for each direction when reversing the direction of movement.
    - 1 Set Pr6.97 "Function expansion setup 3" :bit 0 "Quadrant glitch compensation HPF clear" to 1.
    - 2 Set Pr5.45 "Quadrant glitch positive-direction compensation value", Pr5.46 "Quadrant glitch negative-direction compensation value".
    - 3 Tune the Pr5.49 "Quadrant glitch compensation filter setting H" value.

## 4.9.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

# << Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7).
- 2. Select one device that you want to tune in the device tree and click the "Tuning" tab.

892				PANATERM ver./					
File(F)	Troubleshooting(T)	Help(H)						_	
		E Device tree		{ĝ} Setting	閥 Monitor	K Logging	프운 Tuning	🚺 Device Info 🖉	
	-	MINAS A7BR		All parameters	EtherCAT object	IO Setting	Alarm	Analog input	
@∨	Online	Axis0_No name set SRV-C	DFF		· · · · ·				
	USB	MADN085BRU 23080001		Open file	Save file	Copy Load initia	I values Load	Write	
¢٦.		Enc	Encoder Info	Config Reset					
	(a)	MINAS A78K 55405 MHMG022U1A2 24020001	, oo huse	Search	Compar	rison None	✓ Add/delete c	olumn	
Switch to HEX input Display A6-						play A6-compatible control parameters Allow out-of-range settings			
**3.** In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

5									
F	File(F) Troubleshooting(T) Help(H)								
Devie		Ŀб	ogging	프 <mark>은</mark> Tuning	Device Info	Ø	) Trial run	Z-pl	hase search
ce tree	< Manual TUNING		🗸 Graph			Trial run/2	1	2	
	Selected driver:Axis0_No name set		Wave graph	Frequency response		Z-pha	Limit setting	Trial ru	in
	Basic Load characteri Notch settings		Start m	easurement Stop	Single trigger	ise s	Protection Functions		
	Damping settin Application Manual	1				earch	Pr5.12 Overload level[%]	0	
			Measureme	ent data management Edit	display range Fixed display range	-	Pr5.13 Overspeed level[r/min]		
	Mode setting () 0:Disabled V		Reset zoom	Align with center of Y-axi	s			🛃 Automatic	setting (overspee
			Display as e	elapsed time Display as tim	ne standard Load file		Pr5.14 Motor mova[0.1 rotation	10	
	A7 recommended settingis recommended		Cause fills				Operation limit		
	When upgrading from A6 <u>A6 compatibility setting</u> is recommended		Save The	2			Pr5.04 Over-travel inhibit input s	1: CoE-side (C	iA402) deceler 🗸
	Load characteristic settings Automatic settingOFF		🗸 Graph di	splay settings			Operating range		
	Inertia ratio 0						Use JOG to move to the Max./M	in. positions or i	nput a numeric value
	For more advanced settings Load characteristic settings		Measuren	hent Condition Edit displaye	ed data Cursor		JOG speed[r/min]	60	
	Gain setting		Acquire	from driver Acquire from	n file Load condition presets		JOG acceleratio[ms/JOG speed	50	
1	Feedback gain setting - 29 +	•				= 1			
	Speed response frequenc 102.5		<ul> <li>Monitor</li> </ul>						
	Automatic oscillation su OFF		Simple mor	nitor IO monitor					
	Safety function								
	FF gain setting - 31 +		Start mea	surem Measurement mod	e With Position C 💙 Measurement count	2			
	Positional command smo 0.8		Trial No.	Settling time INP change cou	unt Vibration level Effective load factor Takt				
	Overshoot suppression [%] - 100.0 +		[times]	[ms] [times]	[%] [%] [ms]		Servo-on Operates	only while the bu	utton is pressed.
	Notch filter settings Automatic setting:OFF						- direction	o to 0	+ direction
	3rd notch frequency [Hz] 5000							·····	1
	4th notch frequency [Hz] 5000						Current position	Command unit	
	Damping filter setup								
	1st damping frequency [Hz] 0						Minimum position		Maximum position
	For more advanced settings Damping settings						[command unit]		[command unit]
	What if I have a problem?						0		0
	Refer to Tuning Help <u>when problems occur</u> such as vibration or abnormal noise						Troubl	eshooting	To trial run

**4.** Click the [Application] button.

<	Manual TUNING								
Selected driver:Axis0_No name set									
Basic	Basic Load characteristic settings Notch settings								
Damping settings	Damping settings Application Manual								
> Feedforward function	Feedforward function								
> Load fluctuation control f	unction								
> High response current cor	ntrol function								
> Gain switching function									
> Quadrant glitch suppressi	on function								
> Hybrid vibration suppress	ion function								

5. Click on ">" of "> Quadrant glitch suppression function" to expand "Quadrant glitch suppression function".

<	Manual TUNING								
Selected driver:Axis0_No name set									
	Basic Load characteristic settings Notch setting								
Dam	Damping settings Application Manual								
> Feedfo	rward function								
> Load fl	uctuation control f	unction							
> High re	esponse current cor	ntrol function							
> Gain sv	witching function								
<ul> <li>Quadra</li> <li>Enabling t</li> <li>reversed.</li> </ul>	ant glitch suppressi his can suppress qu	on function uadrant glitchin	g when the dire	ction of movement is					
Enable qu Enable qu	adrant glitch comp adrant glitch comp	ensation func ensation HPF	OFF						
Quadrant	glitch positive-dire	ction compen	0						
Quadrant	glitch negative-dire	ection compe	0						
Quadrant	glitch compensatio	on delay time	0						
Quadrant	uadrant glitch compensation filter settin 0								
Quadrant	glitch compensatio	on filter settin	0						
> Hybrid	vibration suppress	ion function							

- **6.** Turn "Enable quadrant glitch compensation function" to ON. Power must be restored. In the message dialog box displayed, click the [OK] button to restore the power.
- 7. Set related parameters to the following values.
  - Quadrant glitch compensation delay time = 0
  - Quadrant glitch compensation filter setting L = Pr1.04 "1st torque filter time constant"
  - Quadrant glitch compensation filter setting H = 0
- **8.** Fine tune Quadrant glitch positive-direction compensation value and Quadrant glitch negative-direction compensation value for each axis while measuring the size of the quadrant glitch.
  - If quadrant glitch occurs later than the movement direction inversion timing, configure the following settings.
    - 1 Set Quadrant glitch compensation delay time, Quadrant glitch compensation filter setting L.
  - Use the following procedure to set the amount of quadrant glitch compensation for each direction when reversing the direction of movement.
    - 1 Turn on "Quadrant glitch compensation HPF clear enabled".
    - 2 Set Quadrant glitch positive-direction compensation value, Quadrant glitch negative-direction compensation value.
    - 3 Set Quadrant glitch compensation filter setting H.

## 4.10 Backlash Compensation Function

### 4.10.1 Function Overview

When driving a device with backlash (mechanical gap in the drive system), the amount of movement commanded by the host device will differ from the actual amount of movement of the mechanical axis. The backlash compensation function adds a backlash compensation value to the host device position command and drives the motor axis by the command to which the compensation value has been added, thereby matching the amount of movement commanded by the host device with the actual amount of movement of the mechanical axis.

## 4.10.2 Operational Conditions

Item	Operational Conditions
Control mode	Position control

#### – Precautions –

• Although the backlash compensation function is disabled when switching from position control to speed or torque control, the backlash compensation state is retained. After switching to position control again, movement resumes from the backlash compensation state in the previous position control.

## 4.10.3 Related Parameters

						. None
Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	97	В	Function expan- sion setup 3	-2147483648 to 2147483647	_	bit 6: Switches position information during backlash cor- rection 0: Obj.6064h:00h "Position actual value" = Obj.6063h:00h "Position actual internal value" - Pr7.05 1: Obj.6064h:00h "Position actual value" = Obj.6063h:00h "Position actual internal value" *Obj.6064h is the command unit, Obj.6063h, Pr7.05 is the Pulse unit, and conversion by electronic gear is in- cluded in the above formula.
7	04	В	Backlash com- pensation enable	0 to 7	_	bits 1 to 0: Enable or disable backlash compensation and select the direction of operation during compensa- tion 00b: Disabled 01b: Compensates during the first positive direction operation after servo-on 10b: Compensates during the first negative direction operation after servo-on 11b: Manufacturer use bit 2: Expand backlash compensation retention condi- tions 0: Conventional specifications (A6B specification) 1: Expanded specification
7	05	В	Backlash com- pensation value	-1073741824 to 1073741823	pulse	Sets the backlash (mechanical clearance in the drive system) compensation amount during position control.

None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
7	06	В	Time constant for backlash com- pensation	0 to 6400	0.01 ms	Sets the backlash (mechanical clearance in the drive system) compensation time constant during position control. Disabled when the set value is 0 to 3.
7	18	В	Backlash com- pensation value holding range	0 to 2147483647	Com- mand unit	Sets dead zone for backlash compensation when turned from servo-off to servo-on. When this setup value is 0, this function is disabled. This parameter does not depend on Pr7.04:bit 2 setup.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

#### – Precautions –

- Do not change Pr7.04 "Backlash compensation enable" :bit 2 or Pr7.05 "Backlash compensation value" and Pr7.06 "Time constant for backlash compensation" while the motor is running or during command transfer. If changes are made while the motor is running or during command transfer, changes will be applied at uncertain times.
- The actual motor position is shifted by the backlash compensation value from the motor position information read via EtherCAT communication. (When Pr6.97 "Function expansion setup 3" :bit 6 = 0)
- Do not latch position information, initialize position information, or switch control modes when the backlash compensation output is not fully transferred (cases other than when "the backlash compensation output set value is 0 or Pr7.05 "Backlash compensation value" "). Also, be sure to change backlash compensation-related parameters during servo-off.
- Pr7.05 "Backlash compensation value" and Pr7.06 "Time constant for backlash compensation" should not exceed the command limit value (the threshold at which Err27.4.□ "Position command error protection" occurs). When Err27.4.□ "Position command error protection" occurs, increase Pr7.06 "Time constant for backlash compensation" to a larger value.
- If the device moving part is moved by external force during servo-off, or if the servo is turned off during backlash compensation value transfer, the backlash compensation value is shifted. Run homing again.
- If the following conditions are met, Obj.6063h:00h "Position actual internal value" = Obj.60FCh:00h "Position demand internal value" = Pr7.05 "Backlash compensation value" .
  - At the time of homing operation.
  - Backlash compensation is enabled.
  - The homing return operation direction (the final command speed and direction output) is the backlash compensation enable direction.
  - At Pr6.97 "Function expansion setup 3" :bit 6 = 0.
- When the motor is run with the backlash compensation function enabled with Pr6.97 "Function expansion setup 3" :bit 6 = 0,Obj.60FCh:00h "Position demand internal value" = Obj.6062h:00h "Position demand value" + Pr7.05 "Backlash compensation value" .

### Details of Pr7.04:bit 1 to 0

Enables or disables backlash compensation and sets the direction of operation during compensation. Pr7.04 "Backlash compensation enable" :bit 1 to 0 reflects changes at servo-on timing.

Pr7.04:bit 1 to 0	Pr7.05	5 value
	Positive	Negative
01b	Positive direction compensation setting during posi- tive direction operation	Negative direction compensation setting during posi- tive direction operation
10b	Positive direction compensation setting during nega- tive direction operation	Negative direction compensation setting during neg- ative direction operation

#### Details of Pr7.04:bit 2

The conditions under which the backlash compensation state is cleared depends on the setting of Pr7.04 "Backlash compensation enable" :bit 2 "Expand backlash compensation retention conditions".

• When Pr7.04 "Backlash compensation enable" :bit 2 = 0

When turned to the servo-off state with backlash compensated, the backlash compensation value is cleared by presetting command position information inside the servo driver using motor position information, including the backlash compensation value.

When turned back to servo-on, the first backlash compensation operation after servo-on is performed.

• When Pr7.04 "Backlash compensation enable" :bit 2 = 1

Even in servo-of state, the backlash compensation value is not cleared and the backlash compensation state is retained. When turned back to servo-on, the motor can be run from the backlash compensation state when in the previous servo-on state.

#### – Precautions –

• During servo-off, make sure that the positional relationship between the device moving part and the motor is maintained. If the positional relationship is not maintained, depending on the Pr7.06 "Time constant for backlash compensation" setting, abnormal noise or oscillation may occur during motor operation after the next servo-on.

Pr7.04:bit 2	Conditions under which the backlash compensation state is cleared
0	When in servo-off state
(Conventional	When ESM state becomes Init state
specifications)	<ul> <li>When Obj.6040h:00h "Controlword" is mapped to PDO, when not in OP state</li> </ul>
	When an alarm is triggered
	In Safe Torque Off (STO) state
	When position deviation is cleared
	<ul> <li>When the servo driver side decelerates to a stop due to an over-travel inhibit input</li> </ul>
1	When ESM state becomes Init state
(Expanded specification)	

### 4.10.4 How to Use

### When compensating in the positive direction during positive direction operation

(Condition)

- Pr7.04 "Backlash compensation enable" = 1
  - bit 1 to 0 = 01b (compensation during positive direction operation)
- Pr7.05 "Backlash compensation value" = 100 pulse
- Pr7.06 "Time constant for backlash compensation" = 0 ms

When switching from negative direction operation to

positive direction operation

- Electronic gear ratio: 1/1
  - When switching from positive direction operation to negative direction operation



#### Precautions —

- When the backlash compensation state is cleared to 0, such as when the power is turned on or when at servo-off, position the device so that the device moving part is positioned against the backlash compensation direction as the initial state of the device. If this initial state is not set correctly, displacement may occur.
- Depending on the Pr7.06 "Time constant for backlash compensation" setting, abnormal noise or oscillation may occur while the motor is running.

#### When a dead zone is set

To prevent backlash compensation from working in an unintended direction due to an Obj.607Ah:00h "Target position" communication delay on the Main Device side, a position dead zone can be set for the backlash compensation state update after servo-on using Pr7.18 "Backlash compensation value holding range". (Condition)

- Pr6.97 "Function expansion setup 3" :bit 6 "Switches position information during backlash correction" = 0
- Pr7.04 "Backlash compensation enable" = 5
  - bit 1 to 0 = 01b (compensation during positive direction operation)
  - bit 2 = 1 (Compensation state retained during servo-off)
- Pr7.05 "Backlash compensation value" = 100 pulse
- Pr7.06 "Time constant for backlash compensation" = Any
- Pr7.18 "Backlash compensation value holding range" = 50
- Electronic gear ratio: 1/1

## (Example) When the backlash compensation value is retained 50 pulses in the positive direction during servo-off



If the relative position (\*1) after servo-on is within the dead zone, the backlash compensation value of 50 pulse is maintained. If the dead zone in the positive direction is exceeded, the compensation value is 100 pulse.

If the relative position (\*1) after servo-on is within the dead zone, the backlash compensation value of 50 pulse is maintained. If the dead zone in the negative direction is exceeded, the compensation value becomes 0 pulse.

\*1 Relative position after servo-on = Obj.6062h during servo-on - Obj.6062h just before servo-on

If homing (other than Methods 35 and 37) accompanying motor operation is executed when the relative position

 $\frac{((*l))}{(*l)}$  after servo-on is within the dead zone, the dead zone status is released, the backlash compensation status is updated, and homing operation is performed.

When homing not accompanying motor operation (Methods 35 and 37) is executed, and homing is performed with the dead zone state not released.

### First backlash compensation action after servo-on

After servo-on, compensation is applied to the position command when first moved in the direction set above (the direction set by Pr7.04 "Backlash compensation enable" and Pr7.05 "Backlash compensation value"). If the operation is reversed before that time, no compensation is applied.

Furthermore, when the first operation is performed in the opposite direction after backlash compensation, compensation is applied in that direction.

Once backlash compensation is applied, new compensation is not applied as long as the operation is repeated in the same direction.

# 5 Details of Control Function to Suppress Abnormal Noise and Vibration

5.1 Torque Filter Function	100
5.1.1 Eurotion Overview	
5.1.2 Operational Conditions	190
5.1.3 Related Parameters	190
5.1.4 How to Use	190
5.1.4.1 For Manual Setting	190
5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	191
5.2 2-stage Torque Filter Function	
5.2.1 Function Overview	194
5.2.2 Operational Conditions	194
5.2.3 Related Parameters	194
5.2.4 How to Use	195
5.2.4.1 For Manual Setting	195
5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	195
5.3 Notch Filter Function	
5.3.1 Function Overview	198
5.3.2 Operational Conditions	198
5.3.3 Related Parameters	198
5.3.4 How to Use	201
5.3.4.1 For Manual Setting	201
5.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	201
5.4 Adaptive Filter Function	205
5.4.1 Function Overview	205
5.4.2 Operational Conditions	205
5.4.3 Related Parameters	206
5.4.4 How to Use	207
5.4.4.1 For Manual Setting	207
5.4.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	208
5.5 Damping Control Function	211
5.5.1 Function Overview	211
5.5.2 Operational Conditions	211
5.5.3 Related Parameters	211
5.5.4 How to Use	215
5.5.4.1 For Manual Setting	215
5.5.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	
5.5.4.3 Error Troubleshooting	219
5.6 Model-type Damping Filter Function	220
5.6.1 Function Overview	220
5.6.2 Operational Conditions	220
5.6.3 Related Parameters	221
5.6.4 How to Use	223

5.6.4.1 When Set-up Support Software (PANATERM ver.7) Is Used	223
5.6.4.2 Error Troubleshooting	228
5.7 Position Command Filter Function	229
5.7.1 Function Overview	229
5.7.2 Operational Conditions	229
5.7.3 Related Parameters	229
5.7.4 How to Use	230
5.7.4.1 For Manual Setting	232
5.7.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	
5.7.4.3 Error Troubleshooting	235
5.8 Speed Command Acceleration/Deceleration Setting Function	
5.8.1 Function Overview	236
5.8.2 Operational Conditions	236
5.8.3 Related Parameters	236
5.8.4 How to Use	236
5.9 Hybrid Vibration Suppression Function	238
5.9.1 Function Overview	238
5.9.2 Operational Conditions	238
5.9.3 Related Parameters	238
5.9.4 How to Use	238
5.9.4.1 For Manual Setting	238
5.9.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	239

## 5.1 Torque Filter Function

#### 5.1.1 Function Overview

By setting a torque filter, this function suppresses sounds and vibrations in the high frequency range that may occur when gain is increased.

## 5.1.2 Operational Conditions

Item	Operational Conditions
Control mode	All control modes

### 5.1.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	04	В	1st torque filter time constant	0 to 2500	0.01 ms	Sets the time constant of the 1st torque filter. Disabled when the set value is 0 to 3.
1	09	В	2nd torque filter time constant	0 to 2500	0.01 ms	Sets the time constant of the 2nd torque filter. Disabled when the set value is 0 to 3.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

The two types of torque filter are 1st torque filter and 2nd torque filter.

See <u>"4.2 Gain Switching Function</u>" for details on the use of both torque filters.

The torque filter cut-off frequency can be obtained using the following formula.

Cut-off frequency [Hz] fc =  $1/(2 \pi \times \text{parameter setup value} \times 0.00001)$ 

#### Torque filter frequency response



### 5.1.4 How to Use

#### 5.1.4.1 For Manual Setting

If there is noticeable noise during operation, increase Pr1.04 "1st torque filter time constant". The set value should be changed by increasing by 10% at a time. The larger the set value, the stronger the effect of the filter.

However, if set too large, control may become unstable and vibration may occur. Therefore, when increasing the set value, tune it while maintaining balance with other parameters (especially Pr1.01 "1st velocity loop gain").

Precautions —

• If Pr0.02 "Real-time auto-gain tuning setup" is not 0 (disabled), the related parameters are set automatically and cannot be set manually. If you want to set the parameters manually, set Pr0.02 "Real-time auto-gain tuning setup" to 0 (disabled) before setting.

#### 5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

#### << Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7).
- 2. Select one device that you want to tune in the device tree and click the "Tuning" tab.



3. In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

4. Click on the [Notch settings] button or "Notch settings" in blue text.

5			PANATERM ver.7	- 🗆 X			
Fi	le(F) Troubleshooting(T) Help(H)						
Devic	🐼 Setting 🛛 🕅 Monitor	Ŀć	Logging 또 Tuning 🗒 Device Info 🔊 Trial run	Z-phase search			
e tree	< Manual TUNING		→ Graph 1	2			
	Selected driver:Axis0_No name set		Wave graphic Frequency response	Trial run			
	Basic Load characteri Notch settings	1	Start measurement Stop Single trigger Acquire Protection Functions				
	Damping settin Application Manual		P5.12 Overload level(%)	0			
	Mode setting () (Pirabled X		Measurement data management Edit display range Fixed display range Pr5.13 Overspeed level[r/min]	120			
			Reset zoom Align with center of Y-axis	Automatic setting (overspee			
	Customize settings		Display as elapsed time Display as time standard Load file Pr5.14 Motor mova[0.1 rotation]	10			
	A7 recommended setting is recommended		Operation limit	Operation limit			
	<ol> <li>When upgrading from A6<u>A6 compatibility setting</u> is recommended</li> </ol>		Pr5.04 Over-travel inhibit input s	1: CoE-side (CiA402) deceler 🗸			
	Load characteristic settings Automatic settingOEE		Graph display settings     Operating range				
	Inertia ratio 0		Use JOG to move to the Max./M	in. positions or input a numeric value			
	For more advanced settings Load characteristic settings		Measurement Condition Edit displayed data Cursor JOG speed[r/min]	60			
	Gain setting		Acquire from driver Acquire from file Load condition presets JOG acceleratio[ms/JOG speed	50			
1	Feedback gain setting - 29 +	•					
	Speed response frequenc 102.5		✓ Monitor				
	Automatic oscillation su OFF Safety function		Simple monitor ID monitor				
	FF gain setting - 31 +		Start measurem Measurement mode With Position C V Measurement count 2				
	Positional command smo 0.8		Trial No. Settling time INP change count Vibration level Effective load factor Takt				
	Overshoot suppression [%] - 100.0 +		[times] [ms] [times] [%] [%] [ms] Servo-on O A Operates	only while the button is pressed.			
	Notch filter settings Automatic setting:OFF		- direction	o to 0 + direction			
	3rd notch frequency [Hz] 5000 Ath notch frequency [Hz] 5000		Current position	fcommand unit			
	For more advanced settings Notch settings			0			
	Damping filter setup Automatic setting:ON						
	1st damping frequency [Hz] 0		Minimum position	Maximum position			
	For more advanced settings Damping settings		[command unit]	[command unit]			
	What if I have a problem? Refer to Tuning Help when problems occur such as		0				
	vibration or abnormal noise		Troubl	eshooting To trial run			

The advanced notch settings screen is displayed.

5. Tune the "1st torque filter". For details on parameter tuning, see <u>"5.1.4.1 For Manual Setting"</u>.

When the "Display notch filter characteristics in a graph" check box is checked, the frequency response of the torque filter set here and the frequency response of the notch filter set separately as parameters are displayed on the frequency response graph.

K Manual TUNING										
Selected driver:Axis0_No name set										
Basic		Load chara	cteristic s	ettings	Notch settings					
Damping setting	plication		Manual							
Resonance monitor				No	ot dete	cted				
Resonance frequency	[Hz] 🚺	)					5000			
(i) "5000" is displaye	d until r	esonance is	detected.							
Tuning based on positioning operation (1) To perform tuning based on the positioning operation, use the following settings 1 to 5.										
Pr2.00 Adaptive filter	mode			5: High	n-prec	ision a	daptive fi 🗸			
Tuning based on freque	ency cha	aracteristics	🗌 Disp	lay notch	n filter	charac	teristics in a			
					Offse	t [dB]	0.0			
	Free	quency [Hz]		Width			Depth			
1th notch	5000		2			0				
2th notch	5000		2			0				
3th notch (i)										
4th notch 🕕										
5th notch	5000		2			0				
Costom notch	5000		2			0				
i) The 3rd and 4th n Adaptive filter mo	otches ode.	are automati	cally set d	epending	g on tl	ne sett	ng for Pr2.00			
Torque filter										
1st torque filter [0.01	ms]			10						
2-stage torque filter t	ime cor	istant [0.01 n	ns]	0						
2-stage torque filter a	ittenuat	ion term		1000						
Mode setting				7:Custo	omizei	2	~			
Gain setting										
Feedback gain setting	I			-	16		+			
1st velocity loop gain	[0.1 Hz	]		270						
1st velocityintegral tir	ne cons	tant [0.01 ms	5]	210						
<ul> <li>Load fluctuation or</li> </ul>	ontrol fi	unction								
Enabling this can mor the movement of oth Use to suppress overs to occur.	e effect er axes, shoot, e	ively suppres etc. tc. Be aware	s the effe	cts of mo asing cor	otion o ntrol m	caused nay cau	by friction or use oscillation			
Load fluctuation supp	ression	function ena	bled							
Load fluctuation supp	pression	function aut	omatic t	ON						
Load change compen	Load change compensation gain [%]									
Load change compen	590									
Load estimation filter	[0.01 m	is]		4						
Torque compensation	freque	ncy 1 [0.1 Hz	]							
Torque compensation	freque	ncy 2 [0.1 Hz	]							
Load estimation coun	t			0						

## 5.2 2-stage Torque Filter Function

#### 5.2.1 Function Overview

This function sets a 2-stage torque filter to suppress high-frequency vibration components that cannot be suppressed by the <u>"5.1 Torque Filter Function</u>" torque filter alone.

#### 5.2.2 Operational Conditions

ltem	Operational Conditions
Control mode	All control modes

### 5.2.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	42	В	2-stage torque fil- ter time constant	0 to 2500	0.01 ms	<ul> <li>Sets the 2-stage torque filter time constant.</li> <li>When Pr6.43 = 0 to 49</li> <li>0 to 3: 2-stage torque filter disabled</li> <li>4 to 2500: Setting value [×0.01 ms]</li> <li>When Pr6.43 = 50 to 1000</li> <li>0: 2-stage torque filter disabled</li> <li>1 to 3: 4 [×0.01 ms]</li> <li>4 to 159: Setting value [×0.01 ms]</li> <li>159 to 2500: 159 [×0.01 ms]</li> </ul>
6	43	В	2-stage torque fil- ter attenuation term	0 to 1000	_	<ul> <li>Sets the 2-stage torque filter attenuation term.</li> <li>0 to 49: Operates as the first order lag filter.</li> <li>50 to 1000: Operates as the second order lag filter. With a setting value of 1000, becomes a second order lag filter with ζ = 1.0. The smaller the setting value, the more it vibrates. Normally use with a setting value of 1000.</li> </ul>

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

The torque filter cut-off frequency of the 2-stage torque filter can be obtained using the following formula. Cut-off frequency [Hz] fc =  $1/(2 \pi \times \text{parameter setup value} \times 0.00001)$ 

#### 2-stage torque filter characteristics figure

Frequency responses when first order lag filter

Frequency responses when second order lag filter



## 5.2.4 How to Use

#### 5.2.4.1 For Manual Setting

If there is noticeable noise during operation, increase Pr6.42 "2-stage torque filter time constant". The set value should be changed by increasing by 10% at a time. The larger the set value, the stronger the effect of the filter.

If set too large, control may become unstable and vibration may occur. Therefore, when increasing the set value, tune it while maintaining balance with other parameters (especially Pr1.01 "1st velocity loop gain").

Pr6.43 "2-stage torque filter attenuation term" is normally used with a set value of 1000.

#### – Precautions –

- If Pr6.42 "2-stage torque filter time constant" is set too large, control may become unstable and vibration may occur.
- Changing Pr6.43 "2-stage torque filter attenuation term" during operation may cause vibration. Stop operation before making changes.

#### 5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

#### << Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7).
- 2. Select one device that you want to tune in the device tree and click the "Tuning" tab.



**3.** In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

4. Click on the [Notch settings] button or "Notch settings" in blue text.

5		PANATERM ver.7	- 🗆 X
Fil	le(F) Troubleshooting(T) Help(H)		
Devic	儆 Setting	ố Logging 프중 Tuning 🗊 Device Info 🔯 Trial run	Z-phase search
ce tree	< Manual TUNING	v Graph reprint to the second	2
ree Arrowski and Ar	Manual TUNING       Selected driver:Axis0_No name set       Basic     Load characteri       Notch setting:       Damping settin     Application       Manual       Mode setting ①     Disabled       ①     When launching for the first time       AI recommended     O       ①     When upgrading from A646 compatibility setting is recommended       Load characteristic settings     Automatic settingOFF       Inertia ratio     0       For more advanced settings Load characteristic settings       Gain setting     -       Feedback gain setting     -       Speed response frequenc     102.5       Automatic oscillation su     OFF       Soft function     -       FF gain setting     -       3rd notch frequency [Hz]     5000       4th notch frequency [Hz]     5000       For more advanced settings     Automatic setting:ON       1st damping frequency [Hz]     0       For more advanced settings     Automatic setting:ON	Graph     Wave graphic     Frequency response     Imit setting     Protection functions     Prist2 Overload level(%)     Measurement data management     Edit display range     Fixed display range     Fixed display range     Fixed display range     Fixed display range     Prist2 Overload level(%)     Pisit3 Overspeed level(/min)     Reset zoom Align with center of Y-axis     Display as elapsed time     Display as elapsed time     Display as elapsed time     Display as time standard     Load file     Save file     Graph display settings     Measurement Condition     Edit displayed data     Cursor     Acquire from driver     Acquire from file     Load condition presets     Measurement mode     With Position C     Measurement condition     Start measurem     Measurement mode     With Position C     Measurement condition     Start measurem     Measurement mode     With Position C     Measurement condition     Start measurem     Measurement mode     With Position C     Measurement condition     Start measurement mode     With Position C     Measurement condition     Start measurem     Measurement mode     With Position C     Measurement condition     Setting time     I/P share     Mainum position     Current position     Current position     Current position     Corrent	2         Trial run         0         120         2         120         2         Automatic setting (overspee         in]         10         i         1: CoE-side (CiA402) deceler ∨         Min. positions or input a numeric value         60         30         sonly while the button is pressed.         Go to 0       + direction         on (command unit)         0         Maximum position (command unit)
	What if I have a problem? Refer to Tuning Help <u>when problems occur</u> such as vibration or abnormal noise		0 bleshooting To trial run

The advanced notch settings screen is displayed.

5. Tune the "2-stage torque filter time constant". For details on parameter tuning, see <u>"5.2.4.1 For Manual Setting</u>". When the "Display notch filter characteristics in a graph" check box is checked, the frequency response of the torque filter set here and the frequency response of the notch filter set separately as parameters are displayed on the frequency response graph.

K Manual TUNING							
Selected driver:Axis0_I	No name set						
Basic	Load cha	racteristic	settings	Notch settings			
Damping setting	Application	1		1	Manual		
Resonance monitor				No	ot dete	cted	
Resonance frequency	[Hz] (i)					5000	
(i) "5000" is displayed	d until resonance i	s detected					
Tuning based on positio To perform tuning to 5.	oning operation based on the pos	itioning o	peration, u	use the	e follov	ving settings 1	
Pr2.00 Adaptive filter	mode		5: High	n-preci	sion a	daptive fi 🗸	
Tuning based on freque	ncy characteristics	Dis	play notch	n filter	charac	teristics in a	
	F		147.44	Offse	t [dB]	0.0	
1th notch	5000	2	wath		0	Depth	
2th notch	5000	2			0		
2th notch	5000	2		_			
Ath notch							
Eth notch	5000	2					
Costom notch	5000	2	2				
		2					
Torque filter	msl		10				
2-stage torque filter ti	me constant (0.01	msl	0	0			
2-stage torque filter a	ttenuation term		1000	1000			
Mode setting			7:Custo	omizeź	2	~	
Gain setting							
Feedback gain setting			-	16		+	
1st velocity loop gain	[0.1 Hz]		270	270			
1st velocityintegral tin	ne constant [0.01 r	ns]	210	210			
the local floor to the second	utual for attac						
Enabling this can more the movement of othe Use to suppress overs to occur.	e effectively suppr er axes, etc. hoot, etc. Be awar	ess the eff e that incr	ects of mo easing cor	otion o ntrol m	aused ay cau	by friction or se oscillation	
Load fluctuation supp	ression function e	nabled					
Load fluctuation supp	ression function a	utomatic t	ON O				
Load change compension	90						
Load change compen	sation filter [0.01 r	ns]	590				
Load estimation filter	[0.01 ms]		4				
Torque compensation	frequency 1 [0.1 H	lz]					
Torque compensation	frequency 2 [0.1 H	łz]	0				
Load estimation count	t		0				

## 5.3 Notch Filter Function

#### 5.3.1 Function Overview

When the gain is increased, sounds and vibrations of specific frequencies in the high frequency range may occur. This function suppresses sound and vibration at specific frequencies in the high frequency range by setting a notch filter. Up to six notch filters (1st to 5th notch filters and a custom notch filter) can be set simultaneously for different vibration frequencies.

## 5.3.2 Operational Conditions

Item	Operational Conditions
Control mode	All control modes

## 5.3.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	01	В	1st notch fre- quency	10 to 5000	Hz	Sets 1st notch filter center frequency. A setup value of 5000 disables the notch filter.
2	02	В	1st notch width selection	0 to 20	-	Sets 1st notch filter frequency width.
2	03	В	1st notch depth selection	0 to 99	-	Sets depth in 1st notch filter center frequency.
2	04	В	2nd notch fre-	10 to 5000	Hz	Sets 2nd notch filter center frequency.
			quency			A setup value of 5000 disables the notch filter.
2	05	В	2nd notch width selection	0 to 20	-	Sets 2nd notch filter frequency width.
2	06	В	2nd notch depth selection	0 to 99	-	Sets depth in 2nd notch filter center frequency.
2	07	В	3rd notch fre- quency	10 to 5000	Hz	Sets 3rd notch filter center frequency. A setup value of 5000 disables the notch filter. The pa- rameter value is set automatically when the adaptive fil- ter function is used.
2	08	В	3rd notch width selection	0 to 20	-	Sets 3rd notch filter frequency width. The parameter value is set automatically when the adap- tive filter function is used.
2	09	В	3rd notch depth selection	0 to 99	-	Sets depth in 3rd notch filter center frequency. The parameter value is set automatically when the adap- tive filter function is used.
2	10	В	4th notch fre-	10 to 5000	Hz	Sets 4th notch filter center frequency.
			quency			A setup value of 5000 disables the notch filter. The parameter value is set automatically when the adaptive filter function is used.
2	11	В	4th notch width	0 to 20	_	Sets 4th notch filter frequency width.
			selection			The parameter value is set automatically when the adap- tive filter function is used.
2	12	В	4th notch depth	0 to 99	_	Sets depth in 4th notch filter center frequency.
			selection			The parameter value is set automatically when the adap- tive filter function is used.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	24	В	5th notch fre- quency	10 to 5000	Hz	Sets 5th notch filter center frequency. A setup value of 5000 disables the notch filter.
2	25	В	5th notch width selection	0 to 20	_	Sets 5th notch filter frequency width.
2	26	В	5th notch depth selection	0 to 99	_	Sets depth in 5th notch filter center frequency.
2	39	В	Custom notch compensation co- efficient	0 to 1000	0.01	Sets the custom notch compensation coefficient. A set value of 100 or less disables compensation. Normally, leave it at the initial value.
2	40	В	Custom notch compensation frequency 1	0 to 10000	0.1 Hz	Sets custom notch compensation frequency 1. A setup value of 0 disables compensation. Normally, leave it at the initial value.
2	41	В	Custom notch compensation frequency 2	0 to 10000	0.1 Hz	Sets custom notch compensation frequency 2. A setup value of 0 disables compensation. Normally, leave it at the initial value.
2	42	В	Custom notch frequency	10 to 5000	Hz	Sets the notch frequency of the custom notch filter. A setup value of 5000 disables the custom notch filter.
2	43	В	Custom notch width	0 to 20	-	Sets the notch width of the custom notch filter.
2	44	В	Custom notch depth	0 to 99	-	Sets the notch depth of the custom notch filter.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

#### Notch filter set values

#### Notch filter frequency response



#### Notch frequency

The frequency at which the most gain is attenuated.

#### Notch depth

The input/output ratio (attenuation rate) for the notch frequency.

The notch depth values corresponding to the set values are shown in the table below.

For the input in notch frequency, a set value of 0 is complete cutoff and a set value of 100 is complete pass.

#### Notch width

The frequency bandwidth in which the attenuation ratio is -3 dB when the notch depth set value is 0 (complete cutoff).

This is expressed as a ratio to the notch frequency.

The notch width values for the set values are shown in the table below.

Relation between notch depth set value and notch

depth Notch depth set value Notch depth (ra-Notch depth ([dB] display) tio) Pr2.03, Pr2.06, Pr2.09, Pr2.12, Pr2.26, Pr2.44 0 0.00 -00 1 0.01 -40.0 2 0.02 -34.0 3 0.03 -30.5 4 0.04 -28.0 0.05 -26.0 5 6 0.06 -24.4 7 0.07 -23.1 8 0.08 -21.9 9 0.09 -20.9 10 0.10 -20.0 15 0.15 -16.5 0.20 -14.0 20 25 0.25 -12.0 0.30 -10.5 30 35 0.35 -9.1 -8.0 40 0.40 45 0.45 -6.9 0.50 50 -6.0 60 0.60 -4.4 0.70 -3.1 70 80 0.80 -1.9 90 -0.9 0.90

Relation between notch width set value and notch width

Notch width set value Pr2.02, Pr2.05, Pr2.08, Pr2.11, Pr2.25, Pr2.43	Notch width
0	0.25
1	0.3
2	0.35
3	0.42
4	0.5
5	0.59
6	0.71
7	0.84
8	1.00
9	1.19
10	1.41
11	1.68
12	2.00
13	2.38
14	2.83
15	3.36
16	4.00
17	4.76
18	5.66
19	6.73
20	8.00

### Example of notch filter characteristics

100

1.00

The following is an example of the change in characteristics when the notch frequency setting is fixed and the notch depth and notch width settings are changed.

0.0

(Example) For a notch frequency of 100 Hz



#### – Precautions –

- If the notch filter parameters are not set normally, noise and vibration may increase.
- Using more notch filters may cause unstable control and vibration.
- If the notch filter frequency is too low, control may become unstable and vibration may occur.
- Note that when adaptive filter is enabled, parameters of either or both the 3rd notch filter and 4th notch filter cannot be set manually, but are automatically set (overwritten) by adaptive operation. For details, see <u>"5.4 Adaptive Filter Function"</u>.

#### 5.3.4 How to Use

#### 5.3.4.1 For Manual Setting

Tune using an adaptive filter. For details, see <u>"5.4 Adaptive Filter Function"</u>.

#### 5.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

#### << Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7).
- 2. Select one device that you want to tune in the device tree and click the "Tuning" tab.

<u></u>									
File(F)	Troubleshooting(T)	Help(H)							
		E Device tree			ôð Setting		l∕ <sub>€ Logging</sub>	프 <mark>은</mark> Tuning	🗊 Device Info 🖉
	-	MINAS A7BR				EtherCAT object	IO Setting	Alarm	Analog input
₫⋎	Online	Axis0_No name set SF	RV-OFF	IF.					
	USB	MADN085BRU 23080001			Open file	Save file	Copy Load initia	values Load	Write
	Encoder Info		Encoder Info				Config Reset		se sear
	<b>A</b>	MINAS A7BR 39 MHMG022U1A2 24020001	405766 puise	•	Search	Compari	ison None	✓ Add/delete c	olumn 4
					Switch to HEX input	Display A6-compatib	ole control parameters	Allow out-of-range settin	gs

**3.** In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

4. Click on the [Notch settings] button or "Notch settings" in blue text.

	2										
	File	(F) Troubleshooting(T) Help(H)									
DEVIN		Setting     Of Monitor	ピ Logging	프 <mark>아</mark> Tuning	Device Info	1	) Trial run	Z-phase search			
ce nee		< Manual TUNING	✓ Gra	bh		Trial run/.	1	2			
	s	Selected driver:Axis0_No name set	Wave	raphic Frequency response		Z-pha	Limit setting	Trial run			
	ļ	Basic Load characteri Notch settings	<b>S</b>	art measurement Stop	Single trigger Acquire	ise searc	Protection Functions Pr5.12 Overload level[%]	0			
		Damping setur Approation Manual	Meas	rement data management Edi	t display range Fixed display range	5	Pr5.13 Overspeed level[r/min]				
		Customics antilana	Reset	oom Align with center of Y-av	is			Automatic setting (overspee			
		When launching for the first time	Displa	as elapsed time Display as ti	ne standard Load file		Pr5.14 Motor mova[0.1 rotation]	10			
		A7 recommended settingis recommended	Sa	e file			Operation limit				
		When upgrading from A6A6 compatibility setting is recommended				11	Pr5.04 Over-travel inhibit input s	1: CoE-side (CiA402) deceler 🗸			
	ι	Load characteristic settings Automatic settingOFF	🗸 Gra	oh display settings		Operating range					
		Inertia ratio 0		Edited in the	d data Comme		Use JOG to move to the Max./M	in. positions or input a numeric value			
		For more advanced settings Load characteristic settings	IVIEZ	urement condition Edit display		JOG speed[r/min]	60				
		Gain setting	Ad	Acquire from driver Acquire from file Load condition presets JOG acceleratio[ms/JOG speed] 50							
		Feedback gain setting - 29 +	•			- 1					
		Speed response frequenc 102.5	✓ Mo	hitor							
		Safety function	Simpl	monitor IO monitor							
		FF gain setting - 31 +	Star	measurem Measurement mod	le With Position C 💙 Measurement count	2					
		Positional command smo 0.8	Trial	o. Settling time INP change co	unt Vibration level Effective load factor Takt	1					
		Overshoot suppression [%] - 100.0 +	[time	] [ms] [times]	[%] [%] [ms]		Servo-on Operates of	only while the button is pressed.			
	٢	Notch filter settings Automatic setting:OFF					- direction	o to 0 + direction			
		3rd notch frequency [Hz] 5000									
		4th notch frequency [Hz] 5000 For more advanced settings Notch settings					Current position	[command unit] 0			
	6	Damping filter setup Automatic setting:ON									
		1st damping frequency [Hz] 0					Minimum position	Maximum position			
	F	For more advanced settings Damping settings					[command unit]	[command unit]			
	1	What if I have a problem?					0	0			
		Refer to Tuning Help <u>when problems occur</u> such as vibration or abnormal noise					Troubl	eshooting To trial run			

The advanced notch settings screen is displayed.

5. Set "Tuning based on positioning operation" or "Tuning based on frequency characteristics".

Settings can be configured from either menu, but usually settings are configured using "Tuning based on positioning operation".

<	< Manual TUNING							
Selected driver:Axis0_	No nan	ne set						
Basic		teristic s	ettings		Not	ch settings		
Damping setting	Appl	ication				Manual		
Resonance monitor					No	ot dete	cted	
Resonance frequency	[Hz] (	)					5000	
(i) "5000" is displaye	d until	esonance is de	etected.					
Tuning based on positi (i) To perform tuning to 5.	oning o I based	peration on the positio	ning ope	eration, u	ise the	e follo	wing settings 1	
Pr2.00 Adaptive filter	mode			5: High	-preci	ision a	daptive fi 💙	
Tuning based on freque	ency chi	aracteristics (	Displ	ay notch	filter	charad	teristics in a	
	Fro	ausona (Hai)		Width	Offse	t [dB]	0.0 Depth	
1th notch	5000	quency [nz]	2	width		0	Depth	
2th notch	5000		2			0		
3th notch (i)	5000		2			0		
4th notch (i)								
5th notch	5000		2		_	0		
Costom notch	5000		2			0		
(i) The 3rd and 4th n	otches	are automatica	lly set d	epending	) on ti	ne sett	ing for Pr2.00	
Torque filter 1st torque filter (0.01 2-stage torque filter t 2-stage torque filter a	ms] ime cor ittenuat	istant [0.01 ms ion term	]	10 0 1000				
Mode setting				7:Custo	omize	2	~	
Gain setting								
reedback gain setting	10.4.11			- 16 +				
1st velocity loop gain	[0.1 Hz	]		270				
1st velocityintegral tin	ne cons	tant (0.01 ms)		210				
✓ Load fluctuation control function Enabling this can more effectively suppress the effects of motion caused by friction or the movement of other axes, etc. Use to suppress overshoot, etc. Be aware that increasing control may cause oscillation to occur.								
Load fluctuation suppression function enabled								
Load fluctuation suppression function automatic t 000								
Load change compen	590							
Load estimation filter	[0.01 m	[]		4				
Torque compensation	freque	ncy 1 [0.1 Hz]		0				
Torque compensation	freque	ncy 2 [0.1 Hz]						
Load estimation coun	0							

• To set with "Tuning based on positioning operation"

Up to two adaptive filters can be used for auto tuning.

For details, see <u>"5.4 Adaptive Filter Function</u>".

• To set with "Tuning based on frequency characteristics"

Make the following preparations.

- Measure frequency response. For details, see <u>"6.2 Frequency Response Measurement"</u>.
- Turn the servo off.

Set according to the following procedure.

- 1 Read the resonance frequency (the frequency with the highest gain peak) from the measurement results and set that frequency as the notch frequency.
- 2 Check the "Display notch filter characteristics in a graph" check box. The notch filter characteristics configured are displayed on the graph screen (frequency response).
- 3 Tune the notch width and notch depth settings so that the resonance shape in the measurement results is inverted vertically compared to the shape of the notch filter.

#### – Precautions –

• Noise and vibration may not be suppressed if the lowest notch frequency is lower than the Pr1.01 "1st velocity loop gain" setting frequency or close to the Pr1.01 "1st velocity loop gain" setting frequency.

When this happens, click the [Basic] button to return to the "Manual TUNING" screen, lower the feedback gain setting, and then tune the notch filter.

## 5.4 Adaptive Filter Function

#### 5.4.1 Function Overview

This function auto tunes parameters related to notch filters by estimating the resonance frequency from vibration components that appear due to motor speed during actual operation. Up to two notch filters (3rd notch filter and 4th notch filter) can be tuned automatically.

#### Adaptive filter operation image



## 5.4.2 Operational Conditions

Item	Operational Conditions	
Control mode	Position control, speed control, and full-closed control	

Under the following conditions, adaptive filters may not work normally. In such cases, set the notch filters manually to suppress resonance.

ltem	Conditions that obstruct the operation of adaptive filters
Resonance	<ul> <li>Resonance frequency is less than three times the speed response frequency [Hz]</li> <li>When the resonance peak is low or the control gain is low and the effect is not apparent in the motor speed</li> <li>When there are three or more resonance points</li> </ul>
Load	When motor speed fluctuations with high-frequency components occur due to non-linear characteristics such as backlash
Command pat- tern	When acceleration and deceleration are 30000 r/min or more every second
Other	In the event of sudden disturbances such as a collision

### 5.4.3 Related Parameters

			—: None
Class No. Attribute (*1) Parameter name	Setting range	Unit	Function
2 00 B Adaptive filter mode setup	0 to 6		<ul> <li>Sets adaptive filter operation mode.</li> <li>When changing modes, temporarily set this parameter to 0 (adaptive filter disabled) or 4 (adaptation results cleared). Then set this parameter to the next value to be changed.</li> <li>0: Disable adaptive filter</li> <li>Adaptive filter is disabled. Maintains current values of parameters related to 3rd and 4th notch filters.</li> <li>1: Enable one adaptive filter</li> <li>One adaptive filter is enabled. Updates parameters related to 3rd notch filters according to adaptation results.</li> <li>2: Enable two adaptive filters</li> <li>Two adaptive filters are enabled. Updates parameter related to 3rd and 4th notch filters according to adaptation results.</li> <li>3: Resonance frequency measurement mode</li> <li>Measures resonance frequency. Measurement results can be checked using the Set-up Support Software (PANATERM ver.7) . Retains current values of parameters related to 3rd and 4th notch filters.</li> <li>4: Clear adaptation results</li> <li>Clears adaptation results by disabling parameters related to 3rd and 4th notch filters.</li> <li>5: High-precision adaptive filter</li> <li>Two adaptive filters are enabled. Updates parameter related to 3rd and 4th notch filters.</li> <li>5: High-precision adaptive filter</li> <li>Two adaptive filters are enabled. Updates parameters related to 3rd and 4th notch filters.</li> <li>5: High-precision adaptive filter</li> <li>Two adaptive filters are enabled. Updates parameter related to 3rd and 4th notch filters.</li> <li>5: High-precision adaptive filter</li> <li>Two adaptive filters are enabled. Updates parameter related to 3rd and 4th notch filters according to adaptation results.</li> <li>6: Manufacturer use (setting is prohibited)</li> <li>Do not use this setting value</li> </ul>

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

The following parameters are set automatically when adaptive filter is enabled.

						—: None
Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	07	В	3rd notch fre- quency	10 to 5000	Hz	The 1st resonance frequency estimated by the adaptive filter is automatically set. Is set to 5000 when the resonance point cannot be found.
2	08	В	3rd notch width selection	0 to 20	-	Set automatically when adaptive filter is enabled.
2	09	В	3rd notch depth selection	0 to 99	-	Set automatically when adaptive filter is enabled.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	10	В	4th notch frequen- cy	10 to 5000	Hz	The 2nd resonance frequency estimated by the adaptive filter is automatically set. Is set to 5000 when the resonance point cannot be found.
2	11	В	4th notch width selection	0 to 20	-	Set automatically when two adaptive filters are enabled or a high-precision adaptive filter is used.
2	12	В	4th notch depth selection	0 to 99	-	Set automatically when two adaptive filters are enabled or a high-precision adaptive filter is used.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

## 5.4.4 How to Use

#### 5.4.4.1 For Manual Setting

#### << Procedure >>

- When Pr2.07 "3rd notch frequency" and Pr2.10 "4th notch frequency" are set to a value other than 5000 (disabled), set Pr2.00 "Adaptive filter mode setup" = 4 and initialize 3rd notch frequency and 4th notch frequency. Then, set Pr2.00 "Adaptive filter mode setup" to 1, 2, or 5 to enable the adaptive filter (5 is recommended).
- **2.** Run the motor in actual operation. When the effect of the resonance point is apparent in the motor speed, the parameters of one or both of the 3rd notch filter and 4th notch filter are automatically set, depending on the number of adaptive filters.

#### – Precautions –

- Abnormal noise or oscillation may occur until the adaptive filter stabilizes, such as immediately after the first servo-on after activating the motor, or when the stiffness setting is increased when real-time auto tuning is enabled. However, if oscillation or continuous abnormal noise for three or more reciprocating operations occur frequently, take the following measures.
  - 1 Write the parameters to EEPROM once in normal operation.
  - 2 Lower the set value for Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2" or Pr0.03 "Real-time auto-tuning machine stiffness setup".
  - 3 Set Pr2.00 "Adaptive filter mode setup" to 0 to disable the adaptive filter.
  - 4 Manually set the notch filter.
- After an abnormal noise or oscillation occurs, the 3rd notch filter and 4th notch filter settings may have changed to extreme values. When this happens, disable the adaptive filter once using the procedure <u>"1"</u> to <u>"3"</u> above. Then, enable the adaptive filter again (set Pr2.00 "Adaptive filter mode setup" to either 1, 2, or 5 (5 is recommended)).
- Pr2.07 "3rd notch frequency" and Pr2.10 "4th notch frequency" are written to EEPROM every 30 minutes. When power is restored, the adaptive filter starts processing with this data as the initial values.
- Depending on the Pr2.00 "Adaptive filter mode setup" set value, parameters of one or both of the 3rd notch filter and 4th notch filter are automatically set. Note that these parameters are automatically updated.

#### 5.4.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

#### << Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7).
- **2.** Select one device that you want to tune in the device tree and click the "Tuning" tab.

2									
File(F)	Troubleshooting(T)	Help(H)							
		E Device tree			ôð Setting	閔 Monitor	比 Logging	프 <mark>은</mark> Tuning	🚺 Device Info 🖉
	-	MINAS A7BR				EtherCAT object	IO Setting	Alarm	Analog input
⊕∨	Online	Axis0_No name set	SRV-OFF						
	USB	MADN085BRU 23080001			Open file	Save file	Copy Load initia	values Load	Write
	*1		Encoder Info				Config Reset		se se
	<b>N</b>	MINAS A7BR MHMG022U1A2 24020001	39405786 pulse	•	Search	Compar	rison None	✓ Add/delete c	olumn 🗧
					Switch to HEX input	Display A6-compati	ble control parameters	Allow out-of-range settin	gs

3. In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

4. Click on the [Notch settings] button or "Notch settings" in blue text.

5		PANATERM ver.7	- 🗆 X
F	ile(F) Troubleshooting(T) Help(H)		
Devic	袋 Setting	석 Logging 프중: Tuning 📳 Device Info 🔊 Trial run	Z-phase search
ce tree	K Manual TUNING	v Graph	2
	Selected driver:Axis0_No name set           Basic         Load characteri         Notch settings	Start measurement     Stop     Single trigger     Acquire     Protection Functions     Protection functions     Protection functions     Protection functions     Protection functions     Protection functions	Trial run
	Damping settin Application Manual Mode setting (i) 0:Disabled	Measurement data management Edit display range Fixed display range Pf.13 Overspeed level(r/min)	120
	Customize settings     When launching for the first time     A7 recommended settingis recommended     When upgrading from A6 <u>A6 compatibility setting</u>	Reset zoom         Align with center of Y-axis           Display as elapsed time         Display as time standard           Load file         Operation limit           Save file         Operation limit	Automatic setting (overspee
	is recommended Load characteristic settings Inertia ratio 0	Graph display settings     Operating ange     Use JOG to move to the Ma     Use JOG to move to the Ma	x/Min. positions or input a numeric value
•	For more advanced settings <u>Load characteristic settings</u> Gain setting Feedback gain setting - <u>29</u> +	Acquire from driver         Acquire from file         Load condition presets         I/OG speed[r/min]	60 need] 50
	Speed response frequenc 102.5 Automatic oscillation su OFF Safety function	V Monitor Simple monitor IO monitor	
	FF gain setting         -         31         +           Positional command smo         0.8         0.9         0.9         0.9           Overshoot suppression (%)         -         100.0         +         100.0         +	Start measurem         Measurement mode         With Position C         V         Measurement count         2           Trial No.         Settling time         INP change count         Vibration level         Effective load factor         Takt           [times]         [ms]         [times]         [%]         [%]         [%]         Second of the count         Conercion	tes only while the button is pressed.
	Notch filter settings Automatic setting:OFF 3rd notch frequency [Hz] 5000 4th notch frequency [Hz] 5000 For more advanced settings Notch settings Damping filter setting Automatic setting ON	Serve-on Current pos	<ul> <li>Go to 0 + direction</li> <li>ition [command unit]</li> </ul>
	Damping frequency [Hz]         0           For more advanced settings Damping settings         0           What if I have a problem?         Refer to Turing Help when problems occur such as vibration or abnormal noise	Minimum position (command unit) 0 Tr	Maximum position [command unit] 0 

The advanced notch settings screen is displayed.

**5.** In "Pr2.00 Adaptive filter mode" select "4: Clear adaptive results" from the drop-down list to initialize the 3rd notch and 4th notch.

Next, select either "1: One adaptive filter enabled", "2: Two adaptive filters enabled" or "5: High-precision adaptive filter" to enable the adaptive filter ("5: High-precision adaptive filter" is recommended).

< Manual TUNING								
Selected driver:Axis0_	No nam	ie set						
Basic	Load charac	teristic s	ettings		Not	ch settings		
Damping setting	App	lication			Manual			
Resonance monitor					No	ot dete	cted	
Resonance frequency	[Hz] (i	)					5000	
(i) "5000" is displaye	d until i	esonance is d	etected.					
Tuning based on positi	oning o	peration						
To perform tuning     to 5	) based	on the positio	ning op	eration,	use the	e follov	wing settings 1	
Pr2.00 Adaptive filter	mode			5: Hig	h-preci	sion a	daptive fi 🗸	
				[9				
Tuning based on freque	ency cha	racteristics	🗌 Displ	ay notc	h filter	charac	teristics in a	
					Offse	t [dB]	0.0	
	Free	quency [Hz]		Width		0	Depth	
2th potch	5000		2		_	0		
2th notch	5000		2			0		
Stn notch ()								
4th notch ()	5000					0		
Sin noich	5000		2			0		
	5000		2				. ( D 2 02	
Adaptive filter mo	otches de.	are automatica	illy set d	epenain	g on tr	ie sett	ing for Pr2.00	
Torque filter								
1st torque filter [0.01	ms]			10				
2-stage torque filter t	ime cor	istant (0.01 ms	;]	0				
2-stage torque filter a	ittenuat	ion term		1000				
Mode setting				7:Customize2 V				
Gain setting								
reedback gain setting				- 16 +				
1st velocity loop gain	[0.1 Hz	]		270				
1st velocityintegral tir	ne cons	tant [0.01 ms]		210				
<ul> <li>Load fluctuation co</li> </ul>	ontrol fi	unction						
Enabling this can mor	e effect	ively suppress	the effe	ets of m	otion o	aused	by friction or	
Use to suppress over	er axes, shoot, e	etc. tc. Be aware th	at increa	ising co	ntrol m	iay cau	use oscillation	
to occur.								
Load fluctuation supp	pression	function enab	led		)			
Load fluctuation suppression function automatic t ONO								
Load change compen	90							
Load change compen	590							
Load estimation filter	[0.01 m	is]		4				
Torque compensation	freque	ncy 1 [0.1 Hz]						
Torque compensation	freque	ncy 2 [0.1 Hz]		0				
Load estimation coun	t			0				

- **6.** Click the [Basic] button to return to the "Manual TUNING" screen. Check that automatic setting is turned ON for the notch filter.
- **7.** Operate the motor. When the effect of the resonance point is apparent in the motor speed, the parameters of one or both of the 3rd notch filter and 4th notch filter are automatically set, depending on the number of adaptive filters.

## 5.5 Damping Control Function

#### 5.5.1 Function Overview

This function reduces residual vibration of approximately 100 Hz or less that occurs at the moving part tip or the overall device during positioning operation by setting a damping filter. Positioning settling time can be shortened by reducing residual vibration. Up to three of the four damping filters can be used simultaneously.



## 5.5.2 Operational Conditions

Item	Operational Conditions
Control mode	Position control and full-closed control

Under the following conditions, damping control may not work normally, and its effects may not be seen.

Item	Conditions that obstruct the operation of damping control
Load condi- tions	<ul> <li>When vibration is excited by primary causes other than commands (external forces, etc.)</li> <li>When the ratio of resonance frequency to antiresonance frequency is large</li> <li>When the vibration frequency is outside the range of 0.5 to 300.0 Hz</li> </ul>

## 5.5.3 Related Parameters

						-: None
Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	13	В	Selection of damping filter switching	0 to 7	_	Sets the switching method of the four filters used for damping control. For details, see "Pr2.13 "Selection of damping filter switching" details" below.
2	14	В	1st damping fre- quency	0 to 3000	0.1 Hz	Sets the 1st control frequency of damping control that suppresses the vibration at load edge. Measure the fre- quency of vibration at load edge and set it in units of 0.1 Hz.
						The valid frequency range for the setting is 0.5 to 300.0 Hz. Disabled if the setting value is set to 0 to 4.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	15	В	1st damping filter setup	0 to 1500	0.1 Hz	When the 1st damping frequency is set to enabled, set it smaller if torque saturation occurs, and set it larger to speed up operation. Use 0 under normal conditions. The setting value is capped by the corresponding damp- ing frequency, or (3000-damping frequency), whichever is smaller.
6	41	В	1st damping depth	0 to 1000	_	Sets the depth for the 1st damping frequency. Setting value 0 is the deepest, and the larger the setting value, the shallower the depth. The deeper the depth, the better the damping effect, but the greater the delay. As the depth decreases, the delay decreases, but the damping effect also decreases. Use the parameter to make fine adjustments to the damping effect and delay.
2	27	В	1st damping width setting	0 to 1000	_	Sets width for the 1st control frequency. The valid range of setting is 10 to 1000, and 0 to 9 works as setup value 100. Within the effective range, the larger the value, the wider the width, improving the robustness against changes in vibration.
2	16	В	2nd damping fre- quency	0 to 3000	0.1 Hz	Sets the 2nd control frequency of damping control that suppresses the vibration at load edge. Measure the fre- quency of vibration at load edge and set it in units of 0.1 Hz. The valid frequency range for the setting is 0.5 to 300.0 Hz. Disabled if the setting value is set to 0 to 4.
2	17	В	2nd damping fil- ter setup	0 to 1500	0.1 Hz	When the 2nd damping frequency is set to enabled, set it smaller if torque saturation occurs, and set it larger to speed up operation. Use 0 under normal conditions. The setting value is capped by the corresponding damp- ing frequency, or (3000-damping frequency), whichever is smaller.
6	60	В	2nd damping depth	0 to 1000	_	Sets the depth for the 2nd damping frequency. Setting value 0 is the deepest, and the larger the setting value, the shallower the depth. The deeper the depth, the better the damping effect, but the greater the delay. As the depth decreases, the delay decreases, but the damping effect also decreases. Use the parameter to make fine adjustments to the damping effect and delay.
2	28	В	2nd damping width setting	0 to 1000	_	Sets width for the 2nd control frequency. The valid range of setting is 10 to 1000, and 0 to 9 works as setup value 100. Within the effective range, the larger the value, the wider the width, improving the robustness against changes in vibration.
2	18	В	3rd damping fre- quency	0 to 3000	0.1 Hz	Sets the 3rd control frequency of damping control that suppresses the vibration at load edge. Measure the fre- quency of vibration at load edge and set it in units of 0.1 Hz. The valid frequency range for the setting is 0.5 to 300.0 Hz. Disabled if the setting value is set to 0 to 4.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	19	В	3rd damping filter setup	0 to 1500	0.1 Hz	When the 3rd damping frequency is set to enabled, set it smaller if torque saturation occurs, and set it larger to speed up operation. Use 0 under normal conditions. The setting value is capped by the corresponding damp- ing frequency, or (3000-damping frequency), whichever is smaller.
6	71	В	3rd damping depth	0 to 1000	_	Sets the depth for the 3rd damping frequency. Setting value 0 is the deepest, and the larger the setting value, the shallower the depth. The deeper the depth, the better the damping effect, but the greater the delay. As the depth decreases, the delay decreases, but the damping effect also decreases. Use the parameter to make fine adjustments to the damping effect and delay.
2	29	В	3rd damping width setting	0 to 1000	_	Sets width for the 3rd control frequency. The valid range of setting is 10 to 1000, and 0 to 9 works as setup value 100. Within the effective range, the larger the value, the wider the width, improving the robustness against changes in vibration.
2	20	В	4th damping fre- quency	0 to 3000	0.1 Hz	Sets the 4th control frequency of damping control that suppresses the vibration at load edge. Measure the fre- quency of vibration at load edge and set it in units of 0.1 Hz. The valid frequency range for the setting is 0.5 to 300.0 Hz. Disabled if the setting value is set to 0 to 4.
2	21	В	4th damping filter setup	0 to 1500	0.1 Hz	When the 4th damping frequency is set to enabled, set it smaller if torque saturation occurs, and set it larger to speed up operation. Use 0 under normal conditions. The setting value is capped by the corresponding damp- ing frequency, or (3000-damping frequency), whichever is smaller.
6	72	В	4th damping depth	0 to 1000	_	Sets the depth for the 4th damping frequency. Setting value 0 is the deepest, and the larger the setting value, the shallower the depth. The deeper the depth, the better the damping effect, but the greater the delay. As the depth decreases, the delay decreases, but the damping effect also decreases. Use the parameter to make fine adjustments to the damping effect and delay.
2	30	В	4th damping width setting	0 to 1000	_	Sets width for the 4th control frequency. The valid range of setting is 10 to 1000, and 0 to 9 works as setup value 100. Within the effective range, the larger the value, the wider the width, improving the robustness against changes in vibration.
2	50	В	Detection start vi- bration count	0 to 100	_	This parameter is related to automatic frequency settings for damping control, and sets the number of vibrations for the position deviation that starts the vibration frequen- cy detection process after the command is completed.
2	51	В	Detected vibra- tion amplitude	0 to 134217728	Com- mand unit	This parameter is related to automatic frequency settings for damping control, and sets the vibration amplitude for the position deviation detected as vibrations after the command is completed. If 0, the parameters are set au- tomatically inside the driver.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

#### Setup Description value 0 Each damping control filter can be enabled or disabled as follows. 1st damping 2nd damping 3rd damping 4th damping Setup value 0 Disabled Enabled Enabled Disabled 1 to 2 Manufacturer use (setting is prohibited) 3 Depending on the direction of the position command, each damping control filter is switched between enabled and disabled as follows. Position command direction 4th damping Setup 1st damping 2nd damping 3rd damping value 3 Positive direction Enabled Disabled Enabled Disabled Negative direction Disabled Enabled Disabled Enabled 4 to 6 Depending on the control mode, each damping control filter is switched between enabled and disabled as follows. Position Control (Two-degree-of-freedom Control Mode Enabled) Setup Position command direction 1st model-type damping control 2nd model-type damping control value 4 Enabled Enabled 5 Manufacturer use (setting is prohibited) 6 Positive direction Enabled Disabled Negative direction Disabled Enabled Position Control (Two-degree-of-freedom Control Mode Disabled) Setup 1st damping 2nd damping 3rd damping 4th damping value 4 Enabled Enabled Enabled Disabled 5,6 Enabled Enabled Disabled Disabled **Full-closed Control** 2nd damping 3rd damping 4th damping Setup 1st damping value 4 to 6 Enabled Enabled Disabled Disabled 7 Depending on the control mode, each damping control filter is switched between enabled and disabled as follows. Position Control (Two-degree-of-freedom Control Mode Enabled), Full-closed Control 1st damping 2nd damping 3rd damping 4th damping Setup value 7 Enabled Enabled Enabled Disabled Position Control (Two-degree-of-freedom Control Mode Disabled) Setup 1st damping 2nd damping 3rd damping 4th damping value 7 Enabled Enabled Disabled Disabled

### Pr2.13 "Selection of damping filter switching" details

### 5.5.4 How to Use

#### 5.5.4.1 For Manual Setting

Depending on the Pr2.13 "Selection of damping filter switching" setting, the damping filters that can be used may be limited. Check before tuning.

<< Procedure >>

1. Tune the damping frequency (Pr2.14, Pr2.16, Pr2.18, Pr2.20).

Measure the vibration frequency at the tip of the device. If the tip vibration can be measured directly with a laser displacement meter or similar instrument, the vibration frequency is read from the measured waveform in 0.1 Hz increments and set for each parameter.

If there is no measuring instrument, the frequency is read from the residual vibration of the position deviation measured by the vibration frequency monitor using Set-up Support Software (PANATERM ver.7) or the waveform measurement function, and then set for each parameter.



2. Tune the damping filter settings (Pr2.15, Pr2.17, Pr2.19, Pr2.21).

Initially, set each parameter to 0 to check the position deviation waveform and torque waveform during operation.

To shorten the settling time, gradually increase the damping filter setting from 0. The amount of change in the set value per change is approximately 10% of the damping frequency. If increased too much, torque saturation (hitting the torque limit) occurs as shown in the figure below, causing vibration suppression to be ineffective. Tune within the range where torque saturation does not occur under actual operating conditions.

Note that the damping filter setting is limited by the following equation.

10.0 Hz - Damping frequency  $\leq$  Damping filter setting  $\leq$  Damping frequency



**3.** Tune the damping depth settings (Pr6.41, Pr6.60, Pr6.71, Pr6.72) and damping width settings (Pr2.27, Pr2.28, Pr2.29, Pr2.30).

Initially, set each parameter to 0 to check for tip vibration or residual vibration in the position deviation waveform.

To further increase the effectiveness of vibration suppression, gradually increase the damping depth setting from 0 (make it shallower). The amount of change in the set value per change is approximately 50.

To reduce delays in command responses, set a smaller (narrower) damping width setting. To track fluctuations in vibration frequency, increase (widen) the damping width setting. The amount of change in the set value per change is approximately 20 for each.

#### Precautions —

• Parameter switching when changing damping filter-related parameter settings



- If damping filter-related parameters (damping frequency, damping filter setup, damping depth and damping width settings) are changed during command input, parameter switching occurs at the rising up of the command (before position command filter) from 0 during positioning complete (Inposition) output.
- When the positioning complete (in-position) range is set to a large value, a large accumulated pulse (the area obtained by integrating the difference between the position command before the filter and the position command after the filter over time) may remain in the filter during parameter switching. In particular, if the setting is changed to increase damping frequency or disable the filter, the motor may temporarily run at a higher speed than the original command speed because the accumulated pulses are transferred rapidly when switching occurs. Take due care.
- After changing the parameter settings of the filter during velocity control or torque control, the setting will not change even if the control mode is changed to position control.

### 5.5.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

#### << Procedure >>

1. Activate Set-up Support Software (PANATERM ver.7).
2. Select one device that you want to tune in the device tree and click the "Tuning" tab.

0				PANATERM ver.7				- 🗆 X
File(F)	Troubleshooting(T)	Help(H)						_
		E Device tree		{ĝ} Setting	嬰 Monitor	匕 Logging	프운 Tuning	🚺 Device Info 🖇
	-	MINAS A7BR		All parameters	EtherCAT object	IO Setting	Alarm	Analog input
⊕∨	Online	Axis0_No name set	SRV-OFF		· · · · ·			
	USB	MADN085BRU 23080001		Open file	Save file	Copy Load initia	l values Load	Write
	.0		Encoder Info			Config Reset		
	<u> </u>	MINAS A7BR	39405786 pulse					
	127	MHMG022U1A2 24020001		Search	Compar	rison	Add/delete c	olumn
				Switch to HEX input	Display A6-compati	ble control parameters	Allow out-of-range settin	as

**3.** In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

4. Click on the [Damping settings] button or "Damping settings" in blue text.

6				PANATE	RM ver.7			- 🗆 X
F	File(F) Troubleshooting(T) Help(H)							
Devic	袋 Setting 昭 Monitor	Ľۆ	Logging	🖻 Tuning	Device Info	20	Trial run	Z-phase search
e tree	< Manual TUNING		🗸 Graph	_			1	2
	Selected driver:Axis0_No name set		Wave grap	hic Frequency response		/2-pna	Limit setting	Trial run
	Basic Load characteri Notch setting	-	Start	measurement Stop	Single trigger Acquire	se sean	Protection Functions Pr5.12 Overload level[%]	0
	Damping settin Application Manual		Measurem	ent data management Edit	display range Fixed display range	9	Pr5.13 Overspeed level[r/min]	120
	Customize settings		Reset zoo	m Align with center of Y-axi	s	- 11		Automatic setting (overspee
	(i) When launching for the first time		Display as	elapsed time Display as tim	e standard Load file	- 11	Pr5.14 Motor mova[0.1 rotation	] 10
	A7 recommended setting is recommended		Save fi	le		- 11	Operation limit	
	is recommended						Pr5.04 Over-travel inhibit input s	. 1: CoE-side (CiA402) deceler 💙
	Load characteristic settings Automatic settingOFF		🗸 Graph o	display settings			Operating range	
	Inertia ratio 0		Measure	ment Condition Edit displaye	d data Cursor		Use JOG to move to the Max./N	lin. positions or input a numeric value
	For more advanced settings Load characteristic settings						JOG speed[r/min]	00
►	Gain setting		Acquin	e from driver Acquire from	n file Load condition presets	JL 📋 ,	JOG acceleratio[ms/JOG speed	] 50
	Feedback gain setting - 29 +	•				_		
	Speed response frequenc 102.		<ul> <li>Monito</li> </ul>	r				
	Automatic oscillation su OFF Safety function		Simple mo	onitor IO monitor				
	FF gain setting - 31 +		Start me	asurem Measurement mod	With Position C 💙 Measurement	count 2		
	Positional command smo 0.		Trial No. (times)	Settling time INP change cou Ims1 Itimes1	Int Vibration level Effective load facto	or Takt		
	Overshoot suppression [%] - 100.0 +		tennesi	[maj [mmaj	[vo] [vo]	1 [113]	Servo-on Operates	only while the button is pressed.
	Notch filter settings Automatic setting:OFF						- direction	Go to 0 + direction
	3rd notch frequency [Hz] 500						Current parities	a (command unit)
	For more advanced settings Notch settings						current position	0
	Damping filter setup Automatic setting:ON							
	1st damping frequency [Hz]						Minimum position	Maximum position
	For more advanced settings Damping settings						[command unit]	[command unit]
	What if I have a problem?						0	0
	Reter to luning Help when problems occur such as vibration or abnormal noise						Troub	leshooting To trial run

The advanced damping settings screen is displayed.

<	Manual TUNING								
Select	ted driver:Axis0_No nam	ie set							
	Basic	Load characteristic se	ettings Notch settings						
	Damping settings		Manual						
Vibrat	ion monitor			Not detected					
Vibra	tion frequency [Hz] 🛈				0.0				
(j)	'0.0" is displayed until vib	ration is detected							
Damp	ing filter setup								
Pr2.1	3 Damping filter switchin	g	0: Use	up to two simultaneo	~				
Auto	matic frequency setting (	D	1st dar	nping frequency	~				
()	When vibrations are deter to the damping frequence	cted, the vibration frequeries of the target filter	lency va	lue is automatically app	lied				
IN	to the dumping frequency	of the target filter.							
Ţ									
	FIR filter		Auton	natic setting					
Ļ	Pr2.23 Positional comm	and FIR filter [0.1 ms]	10						
	Smoothing filter								
	Pr2.22 Positional comm	and smoothing filter							
	Pr6.49 Command respo	nse filter attenuation	5: 1 ~						
	Damping filter 1								
	Pr2.14 1st damping free	uency [0.1 Hz]	0						
	Pr2.15 1st damping filte	r setup [0.1 Hz]	0						
	Pr2.27 1st damping wid	th setting	0						
¥	Pr6.41 1st damping dep	th	0						
	Damping filter 2								
	Pr2.16 2nd damping fre	quency [0.1 Hz]	0		_				
	Pr2.17 2nd damping filt	er setup [0.1 Hz]	0						
	Pr2.28 2nd damping wid	dth setting	0						
¥	Pr6.60 2nd damping de	pth	0						
OUT	T : 40								
-	Filter function switching		A7 mo	de	~				
	Tuning filter time	nt0.01msl		uc	<u> </u>				
	D C 40 T	nto.o (msj	4	44					
	Pr6.49 Tuning filter atter	uation term setup	1: No a	ttenuation term	~				

#### – Precautions –

- The parameters displayed vary depending on the set value for "Pr2.13 Damping filter switching".
- 5. Select "Pr2.13 Damping filter switching" from the drop-down list. For details, see <u>"5.5.3 Related Parameters"</u>.

# – Precautions –

- Only damping filter parameters that can be used are displayed.
- 6. Select "Automatic frequency setting" from the drop-down list.

The choices displayed depend on the "Pr2.13 Damping filter switching" setting.

Automatic fre- quency setting	Description
Disabled	None of the damping frequencies are set automatically.
1st damping fre- quency	When vibrations are detected, the vibration frequency value is automatically applied to the damping frequency of the target filter.
2nd damping fre- quency	
3rd damping fre- quency	
4th damping fre- quency	

**7.** If not setting the damping frequency automatically with "Automatic frequency setting", set "Automatic frequency setting" to "Disabled" and set manually.

For details on parameter settings, see <u>"5.5.4.1 For Manual Setting"</u>.

# 5.5.4.3 Error Troubleshooting

• When Err24.0.0 "Position deviation excess protection" occurs

Tuning related parameters may cause the position deviation excess setup value to deviate from the appropriate value.

Review the set value using the formula for calculating the position deviation excess setup value shown in Operating Instructions (Overall) "7.2.9 Before Gain Tuning Protection Function Setup".

# 5.6 Model-type Damping Filter Function

## 5.6.1 Function Overview

This function reduces residual vibration of approximately 100 Hz or less that occurs at the moving part tip of the device during positioning operation by setting a model-type damping filter. Positioning settling time can be shortened by reducing residual vibration.

The model-type damping filter eliminates both resonance frequency components and antiresonance frequency components while increasing the effectiveness of conventional damping filters to achieve smooth torque commands and improve the damping effect.

By removing the antiresonance frequency components and resonance frequency components, the responsiveness of the command response filter can be increased and the settling time can be reduced.

However, to measure antiresonance frequency components and resonance frequency components, it is necessary to perform frequency characteristics analysis to set optimal parameter values, since vibration components cannot be acquired from position sensors, as is the case with conventional damping filters. (For details of conventional damping filters, see <u>"5.5 Damping Control Function"</u>.)



# 5.6.2 Operational Conditions

Item	Operational Conditions
Control mode	Position control and two-degree-of-freedom control mode enabled
Other	Set-up Support Software (PANATERM ver.7) is required.

Under the following conditions, the model-type damping filter may not work normally, and its effects may not be seen.

Item	Conditions that obstruct the operation of model-type damping filters
Load condi- tions	<ul> <li>When vibration is excited by primary causes other than commands (external forces, etc.)</li> <li>When the resonance frequency and antiresonance frequency are not between 5.0 and 300.0 Hz</li> </ul>

If the parameter settings are as follows, the filter operates as a conventional damping filter (see <u>"5.5 Damping Control Function"</u>).

Item	Conditions for operating as a conventional damping filter
Parameter set- up	<ul> <li>When the resonance frequency and antiresonance frequency do not have the following relationship 5.0 Hz ≤ antiresonance frequency &lt; resonance frequency ≤ 300.0 Hz</li> <li>When the response frequency and antiresonance frequency do not have the following relationship 5.0 Hz ≤ antiresonance frequency ≤ response frequency ≤ antiresonance frequency × 4 ≤ 300.0 Hz</li> <li>When Pr2.13 "Selection of damping filter switching" is set to 4, both the 1st and 2nd model-type damping filters are enabled, and the ratio of the 1st and 2nd response frequencies and antiresonance frequencies multiplied exceeds 8 (in this case, only the 2nd model-type damping filter is a conventional type damping filter)</li> </ul>

When operating as a conventional damping filter, the following three types of parameters of antiresonance frequency, anti-resonance damping ratio, and response frequency, are used as the damping frequency, damping depth and damping filter setting, respectively.

To completely disable this function, all five parameters (resonance frequency, resonance damping ratio, antiresonance frequency, anti-resonance damping ratio, response frequency) must be set to 0.

Pr6.61 "1st resonance frequency", Pr6.66 "2nd resonance frequency"

Pr6.62 "1st resonance attenuation ratio", Pr6.67 "2nd resonance attenuation ratio"

Pr6.63 "1st anti-resonance frequency", Pr6.68 "2nd anti-resonance frequency"

Pr6.64 "1st anti-resonance attenuation ratio", Pr6.69 "2nd anti-resonance attenuation ratio"

Pr6.65 "1st response frequency", Pr6.70 "2nd response frequency"

# 5.6.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	13	В	Selection of damping filter switching	0 to 7	-	Sets the switching method of the four filters used for damping control. For details, see "Pr2.13 "Selection of damping filter switching" details" below.
6	61	В	1st resonance frequency	0 to 3000	0.1 Hz	Sets model-type damping filter load resonance frequen- cy.
6	62	В	1st resonance at- tenuation ratio	0 to 1000	_	Sets the model-type damping filter load resonance damping ratio. The damping ratio can be set as the setup value multi- plied by 0.001. A setting value of 1000 results in an at- tenuation of 1 (no peak). The smaller the setting value, the smaller the damping ratio (higher resonance peak).
6	63	В	1st anti-reso- nance frequency	0 to 3000	0.1 Hz	Sets the model-type damping filter load anti-resonance frequency.
6	64	В	1st anti-reso- nance attenua- tion ratio	0 to 1000	_	Sets the model-type damping filter load anti-resonance damping ratio. The damping ratio can be set as the setup value multi- plied by 0.001. A setting value of 1000 results in an at- tenuation of 1 (no peak). The smaller the setting value, the smaller the damping ratio (higher resonance peak).
6	65	В	1st response fre- quency	0 to 3000	0.1 Hz	Sets the model-type damping filter load response fre- quency.
6	66	В	2nd resonance frequency	0 to 3000	0.1 Hz	Sets the model-type damping filter load 2nd resonance frequency.
6	67	В	2nd resonance attenuation ratio	0 to 1000	_	Sets the model-type damping filter load 2nd resonance attenuation ratio. The damping ratio can be set as the setup value multi- plied by 0.001. A setting value of 1000 results in an at- tenuation of 1 (no peak). The smaller the setting value, the smaller the damping ratio (higher resonance peak).
6	68	В	2nd anti-reso- nance frequency	0 to 3000	0.1 Hz	Sets the model-type damping filter load 2nd anti-reso- nance frequency.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	69	В	2nd anti-reso- nance attenua- tion ratio	0 to 1000	_	Sets the model-type damping filter load 2nd anti-reso- nance attenuation ratio The damping ratio can be set as the setup value multi- plied by 0.001. A setting value of 1000 results in an at- tenuation of 1 (no peak). The smaller the setting value, the smaller the damping ratio (higher resonance peak).
6	70	В	2nd response fre- quency	0 to 3000	0.1 Hz	Sets the model-type damping filter load 2nd response frequency. The unit is 0.1 Hz.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# Pr2.13 "Selection of damping filter switching" details

Setup value	Description									
0	Each damp	ping control filt	er can be enab	led or disable	d as follows.					
	Setup value	1st damping	2nd damping	3rd damping	4th damping					
	0	Enabled	Enabled	Disabled	Disabled					
1 to 2	Manufactu	rer use (setting	g is prohibited)							
3	Depending on the direction of the position command, each damping control filter is switched between enabled an disabled as follows.								ed and	
	Setup value	Position com	mand direction	1st damping	2nd damping	3rd dai	mping	4th damping		
	3	Positive	direction	Enabled	Disabled	Enat	bled	Disabled		
		Negative	e direction	Disabled	Enabled	Disal	bled	Enabled		
4 to 6	Depending	on the contro	l mode, each d	amping contro	l filter is switch	ed betw	een en	abled and disa	abled as fo	llows.
	Position	Control (Tw	o-degree-of-	freedom Cor	ntrol Mode Ei	nabled	)			
	Setup value	Position com	mand direction	1st model-ty	pe damping co	ntrol 2n	nd mod	el-type dampir	ng control	
	4		_	E	Enabled		Enabled			
	5		_		Manufacturer	use (set	ting is p	prohibited)		
	6	Positive	direction	E	Enabled		Disabled			
		Negative	e direction		lisabled			Enabled		
	Position	Control (Tw	o-degree-of-	freedom Cor	ntrol Mode Di	isabled	1)			
	Setup value	1st damping	2nd damping	3rd damping	4th damping					
	4	Enabled	Enabled	Enabled	Disabled					
	5, 6	Enabled	Enabled	Disabled	Disabled					
	Full-closed Control									
	Setup value	1st damping	2nd damping	3rd damping	4th damping					
	4 to 6	Enabled	Enabled	Disabled	Disabled					

Setup value		Description										
7	Depending	Depending on the control mode, each damping control filter is switched between enabled and disabled as follows.										
Position Control (Two-degree-of-freedom Control Mode Enabled), Full-closed Control												
	Setup value	1st damping	2nd damping	3rd damping	4th damping							
	7	Enabled	Enabled	Enabled	Disabled							
	Position	Position Control (Two-degree-of-freedom Control Mode Disabled)										
	Setup value	1st damping	2nd damping	3rd damping	4th damping							
	7	Enabled	Enabled	Disabled	Disabled							

# 5.6.4 How to Use

Manual setting is not possible. Use Set-up Support Software (PANATERM ver.7).

## 5.6.4.1 When Set-up Support Software (PANATERM ver.7) Is Used

## << Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7).
- 2. Select one device that you want to tune in the device tree and click the "Tuning" tab.

89								
File(F)	Troubleshooting(T)	Help(H)						_
		E Device tree		{ĝ} Setting	閥 Monitor	I∕ <sub>Q Logging</sub>	🕞 Tuning	🗓 Device Info 🔮
	-	MINAS A7BR		All parameters	EtherCAT object	IO Setting	Alarm	Analog input
യ∨	Online	Axis0_No name set	SRV-OFF					
	USB	MADN085BRU 23080001		Open file	Save file	Copy Load initia	values Load	Write
	NL.	141115 1700	Encoder Info 39405786 pulse			Config Reset		se searc
	2	MINAS A78K MHMG022U1A2 24020001	, 100 paise	Search	Compar	ison None	✓ Add/delete d	olumn
				Switch to HEX input	Display A6-compati	ble control parameters	Allow out-of-range settin	igs

**3.** In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

4. Click on the [Damping settings] button or "Damping settings" in blue text.

							L
	File(F) Troubleshooting(T) Help(H)						
Devic	ŵ Setting 昭 Monitor	k∕o Logging	프 <mark>은</mark> Tuning	Device Info	Y	Trial run	Z-phase search
ce tree	Manual TUNING	✓ Graph			Trial run/.	1	2
	Selected driver:Axis0_No name set	Wave graph	Frequency response		Z-pha	Limit setting	Trial run
	Basic Load characteri Notch settings Damping settin Application Manual	Start n	easurement Stop	Single trigger Acquire	ise search	Protection Functions Pr5.12 Overload level[%]	0
	Mode setting (i) 0:Disabled V	Reset zoon	nt data management Edi	t display range Fixed display range		Pr5.13 Overspeed level[r/min]	120 Automatic setting (overspee
	Customize settings  (1) When launching for the first time	Display as e	lapsed time Display as ti	me standard Load file		Pr5.14 Motor mova[0.1 rotation]	10
	A7 recommended setting is recommended (i) When upgrading from A6 <u>A6 compatibility setting</u> is recommended	Save file				Operation limit Pr5.04 Over-travel inhibit input s	1: CoE-side (CiA402) deceler 🗸
	Load characteristic settings Automatic settingOFF Inertia ratio 0	✓ Graph d	splay settings			Operating range Use JOG to move to the Max./Mi	n. positions or input a numeric value
	For more advanced settings Load characteristic settings	Measuren	ent Condition Edit display	ved data Cursor		JOG speed[r/min]	60
	Gain setting	Acquire	from driver Acquire fro	m file Load condition presets	•	JOG acceleratio[ms/JOG speed]	50
	Feedback gain setting - 29 +	•					
	Speed response frequenc 102.5	<ul> <li>Monitor</li> </ul>	_				
	Automatic oscillation su OFF	Simple mor	itor IO monitor				
	FF gain setting - 31 +	Start mea	urem Measurement mo	de With Position C 💙 Measurement count			
	Positional command smo 0.8 Overshoot suppression [%] - 100.0 +	Trial No. [times]	ettling time INP change co ms] [times]	Vibration level         Effective load factor         Takt           [%]         [%]         [ms]		Servo-on Operates o	only while the button is pressed.
	Notch filter settings Automatic setting:OFF					- direction	o to 0 + direction
	3rd notch frequency [Hz] 5000 4th notch frequency [Hz] 5000					Current position	[command unit]
	For more advanced settings Notch settings					Current position	0
	Damping filter setup Automatic setting:ON						
	1st damping frequency [Hz] 0 For more advanced settings Damping settings					Minimum position [command unit]	Maximum position [command unit]
	What if I have a problem? Refer to Tuning Help <u>when problems occur</u> such as vibration or abnormal noise					0 Trouble	0 To trial run

The advanced damping settings screen is displayed.

<	Manual TUNING							
Selec	ted driver:Axis0_No nam	ne set						
	Basic	Load characteristic se	ettings	Notch settings				
	Damping settings	Application		Manual				
Vibrat	tion monitor			Not detected				
Vibra	ition frequency [Hz] (i)	0.0						
(j)	1) "0.0" is displayed until vibration is detected							
Damping filter setup								
Pr2.1	3 Damping filter switchir	ıg	4: No s	witching (model type) 🛛 🗸				
Auto	matic frequency setting (	j)	Disable	ed 🗸				
(j)	When vibrations are dete	cted, the vibration frequence of the target filter	iency va	lue is automatically applied				
INI	to the damping nequenc	y of the target filter.						
	FIR filter		Auton	natic setting				
Ţ	Pr2.23 Positional comm	and FIR filter [0.1 ms]	10					
Ě	Smoothing filter							
	Pr2.22 Positional comm	and smoothing filter						
	Pr6.49 Command respo	nse filter attenuation	5: 1 ~					
	Model-type damping fi							
	Pr6.61 1st resonance frequency [0.1 Hz]			0				
	Pr6.62 1st resonance attenuation ratio			0				
	Pr6.63 1st anti-resonand	ce frequency [0.1 Hz]	0					
	Pr6.64 1st anti-resonand	ce attenuation ratio	0					
¥	Pr6.65 1st response free	quency [0.1 Hz]	0					
	Model-type damping fi	lter 2						
	Pr6.66 2nd resonance fr	equency [0.1 Hz]	0					
	Pr6.67 2nd resonance a	ttenuation ratio	0					
	Pr6.68 2nd anti-resonance frequency [0.1 Hz]							
	Pr6.69 2nd anti-resonance attenuation ratio							
↓	Pr6.70 2nd response fre	0						
OUT								
	🗌 D	isplay model-type dam	ping filt	er characteristics in a graph				
				Offset [dB] 0.0				
	Tuning filter		17					
	Filter function switching		A7 mo	de 🗸				
	Tuning filter time consta	int0.01ms]	4					
	Pr6.49 Tuning filter atter	nuation term setup	1: No a	ttenuation term 🗸				

#### – Precautions –

- The parameters displayed vary depending on the set value for "Pr2.13 Damping filter switching".
- 5. Select "Pr2.13 Damping filter switching" from the drop-down list. For details, see <u>"5.6.3 Related Parameters"</u>.
   Precautions
  - Only parameters for model-type damping filter that can be used are displayed.
- Frequency response is measured using the torque speed mode of the frequency response measurement function. For details, see <u>"6.2 Frequency Response Measurement"</u>.

7. Read a maximum of two each of large peaks and troughs for gain from the measurement results, and set Pr6.61 "1st resonance frequency", Pr6.63 "1st anti-resonance frequency", Pr6.66 "2nd resonance frequency", and Pr6.68 "2nd anti-resonance frequency".

An example of measurement with a belt device is shown below. Ignoring small resonances, the resonance frequencies that are peaks of the gain, as well as the antiresonance frequencies that are troughs of the gain, are as follows.

1st resonance frequency = 130 Hz ((2) in the figure below), 1st anti-resonance frequency = 44 Hz ((1) in the figure below)

2nd resonance frequency = 285 Hz ((4) in the figure below), 2nd anti-resonance frequency = 180 Hz ((3) in the figure below)





**8.** For the 1st and 2nd resonance damping ratios and anti-resonance damping ratios, set the initial value to 50 (0.050).

Check the "Display model-type damping filter characteristics in a graph" check box to display the model-type damping filter characteristics based on the set parameter.

The validity of the set parameters can be checked by comparing them with the measurement results for frequency response.

9. Set response frequency to the same value as antiresonance frequency.

- **10.** Run the motor to check for tip vibration or residual vibration in the position deviation waveform. Then, fine tune the parameters in the following order to reduce vibration components.
  - Pr6.63 "1st anti-resonance frequency" > Pr6.64 "1st anti-resonance attenuation ratio" > Pr6.61 "1st resonance frequency" > Pr6.62 "1st resonance attenuation ratio"
  - Pr6.68 "2nd anti-resonance frequency" > Pr6.69 "2nd anti-resonance attenuation ratio" > Pr6.66 "2nd resonance frequency" > Pr6.67 "2nd resonance attenuation ratio"
- 11. Find the setting with the lowest vibration and increase the response frequency setting. Although higher frequencies result in less control delay caused by the model-type damping filter, they also result in gradual decreases in damping effectiveness. This makes it important to find a balanced setting. Note that, according to the specifications of the model-type damping filter, the response frequency setting should be less than four times the antiresonance frequency.

#### - Precautions -

• Parameter switching when changing model-type damping filter-related parameter settings



- If the model-type damping filter-related parameters (resonance frequency, resonance damping ratio, antiresonance frequency, anti-resonance damping ratio, and response frequency) are changed during command input, parameter switching occurs at the rising up of the command (before position command filter) from 0 during positioning complete (in-position) output.
- When the positioning complete (in-position) range is set to a large value, a large accumulated pulse (the area obtained by integrating the difference between the position command before the filter and the position command after the filter over time) may remain in the filter during parameter switching. In particular, if the setting is changed to increase the antiresonance frequency or disable the filter, the motor may temporarily run at a higher speed than the original command speed because the accumulated pulses are transferred rapidly when switching occurs. Take due care.
- After changing the parameter settings of the filter during velocity control or torque control, the setting will not change even if the control mode is changed to position control.

## 5.6.4.2 Error Troubleshooting

• When Err24.0.0 "Position deviation excess protection" occurs

Tuning related parameters may cause the position deviation excess setup value to deviate from the appropriate value.

Review the set value using the formula for calculating the position deviation excess setup value shown in Operating Instructions (Overall) "7.2.9 Before Gain Tuning Protection Function Setup".

# 5.7 Position Command Filter Function

## 5.7.1 Function Overview

A function that applies a positional command smoothing filter to a position command to gently accelerate or decelerate the motor. This is expected to suppress vibration and velocity change caused by the command resolution and command updating cycle roughness.

# 5.7.2 Operational Conditions

Item	Operational Conditions
Control mode	Position control, speed control, and full-closed control

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	22	В	Positional com- mand smoothing filter	0 to 10000	0.1 ms	When two-degree-of-freedom control mode is enabled: Functions as a command response filter and sets the fil- ter time constant. When two-degree-of-freedom control mode is disabled: Sets the time constant of the first order lag filter for the position command.
2	23	В	Positional com- mand FIR filter	0 to 10000	0.1 ms	Sets the average movement time for the position com- mand.
6	49	В	Command re- sponse/tuning fil- ter attenuation term	0 to 99		Sets the "command response filter" and "tuning filter" at- tenuation terms in the two-degree-of-freedom control. • Sets each filter in decimal notation. Ones: Command response filter Tens: Tuning filter <target digit="" setting="" values=""> 0 to 4: No attenuation terms (operates as first order lag filter) 5 to 9: Attenuation term <math>\zeta</math> is 1.0, 0.86, 0.71, 0.50, 0.35, in that order (operates as second order lag filter) &lt; Example of this parameter setup &gt; To set the command response filter to <math>\zeta = 1.0</math> and the tuning filter to <math>\zeta = 0.71</math>, set the setting value to 75 (ones <math>= 5 (\zeta = 1.0)</math>, tens = 7 (<math>\zeta = 0.71</math>)). Note that Pr2.22 "Positional command smoothing filter" is applied to the command response filter time constant.</target>

5.7.3 Related Parameters

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

#### Precautions —

• Changing the damping control-related parameters changes the recommended setting value for position deviation excess protection.

As a result, the set value for position deviation may be too small to cause an unexpected error, or the set value may be too large to detect. Review the set values.

## 5.7.4 How to Use

#### Details on Pr2.22 "Positional command smoothing filter"

#### Setting the time constant of the command response filter

Set the time constant of the "command response filter" when two-degree-of-freedom control mode is enabled.

In the following cases, set the time constant of the first order lag filter or the second order lag filter based on the set value for the ones place of Pr6.49, "Command response filter attenuation term setup".

• When two-degree-of-freedom control mode is enabled, and the set value for the ones place of Pr6.49, "Command response filter attenuation term setup", is 5 to 9

Normally, the ones place of Pr6.49, "Command response filter attenuation term setup", should be set to 5.

The figure below shows a waveform after filtering for the target speed Vc square wave command using a second-order lag filter.



Ones place of Pr6.49	Attenuation term value	K1	K2
5	1.0	4.7	1.00
6	0.86	3.8	1.01
7	0.71	2.9	1.04
8	0.5	2.3	1.16
9	0.35	2.0	1.31

#### Setting the time constant of the first order lag filter

Sets the time constant of the first order lag filter for the target speed Vc square wave command in the following cases.

- When two-degree-of-freedom control mode is disabled
- When two-degree-of-freedom control mode is enabled and the set value for the ones place of Pr6.49, "Command response filter attenuation term setup", is 0 to 4



- \*1 The actual filter time constant is (set value × 0.1 ms) with a relative error of up to 0.2% above 20 ms, and the error increases to a maximum of 0.4 ms until 100 ms.
- \*2 Parameter switching when changing Pr2.22 "Positional command smoothing filter" settings



- If the positional command smoothing filter-related parameters (Pr2.22 "Positional command smoothing filter", Pr6.49 "Command response/tuning filter attenuation term") are changed during command input, parameter switching occurs at the rising up of the command (before position command filter) from 0 during positioning complete (in-position) output.
- When the positioning complete (in-position) range is set to a large value, a large accumulated pulse (the area obtained by integrating the difference between the position command before the filter and the position command after the filter over time) may remain in the filter during parameter switching. In particular, if the setting is changed to reduce the positional command smoothing filter value or disable the filter, the motor may temporarily run at a higher speed than the original command speed because the accumulated pulses are transferred rapidly when switching occurs. Take due care.
- After changing the parameter settings of the filter during velocity control or torque control, the setting will not change even if the control mode is changed to position control.

\*3 There is a delay between when the set value for Pr2.22 "Positional command smoothing filter" is changed and when it is applied to the internal calculation. Therefore, if the switching of <u>"\*2"</u> occurs during that delay period, the change may be put on hold.

#### Details on Pr2.23 "Positional command FIR filter"

#### For square wave commands

Sets the time to reach Vc for the target speed Vc square wave command. (See figure below)



#### For trapezoidal wave commands

If the position command is a trapezoidal wave, the waveform after passing through the filter will be an S-curve.



- \*1 The actual average movement time has an absolute error of up to 0.2 ms for time periods of less than 10 ms and a relative error of up to 1.6% for time periods of 10 ms or more, with respect to (set value × 0.1 ms).
- \*2 If the setting for Pr2.23 "Positional command FIR filter" is changed during command input, parameter switching will take place when the amount time remaining until the next command pulse is received exceeds the filter switch waiting time. The filter switching waiting time is (set value × 0.1 ms + 0.25 ms) for a set value of 10 ms or less and (set value × 0.1 ms × 1.05) for 10 ms or more.
- \*3 There is a delay between when the set value for Pr2.23 "Positional command FIR filter" is changed and when it is applied to the internal calculation. Therefore, if the switching of <u>"2"</u> occurs during that delay period, the change may be put on hold.

#### 5.7.4.1 For Manual Setting

#### << Procedure >>

1. Tuning "FIR filter"

Tune Pr2.23 "Positional command FIR filter" to suppress vibration and velocity change caused by infrequent command updating cycles.

Tune the value of Pr2.23 "Positional command FIR filter" to a value greater than or equal to the command updating cycle.

2. Tuning "Smoothing filter"

Increase the set value of Pr2.22 "Positional command smoothing filter" to suppress vibration and velocity changes caused by command resolution. The set value should be changed by increasing by 10% at a time.

- If the beginning of the movement is vibratory, increasing the Pr2.22 "Positional command smoothing filter" set value results in a smoother movement, but with a longer command time. Tune to the optimal value.
- The ones place of Pr6.49 "Command response/tuning filter attenuation term" "Command response filter attenuation term setup" does not require tuning.
- When two-degree-of-freedom control mode is enabled, this functions as the command response filter. The smaller the set value, the smaller the delay caused by the filter, and thus the higher the command responsiveness.

#### Precautions —

• Pr2.22 "Positional command smoothing filter" cannot be changed manually because it is automatically set based on the Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning" set value when the auto tuning function is enabled in the two-degree-of-freedom control mode for standard type settings. If you want to change the parameters manually, set Pr0.02 "Real-time auto-gain tuning setup" to 0 (disabled) before changing. For details of the relationship between Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning" and Pr2.22 "Positional command smoothing filter", see <u>"4.1.1.6 Basic Gain Parameter Setup Table"</u>.

## 5.7.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

For manual setting, see <u>"Step 5"</u> onward.

#### << Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7).
- 2. Select one device that you want to tune in the device tree and click the "Tuning" tab.

0				PANATERM ver.7				– 🗆 ×
File(F)	Troubleshooting(T)	Help(H)						_
		E Device tree		{ĝ} Setting	嬰 Monitor	匕 Logging	프 <mark>은</mark> Tuning	🚺 Device Info 🖉
	-	MINAS A7BR		All parameters	EtherCAT object	IO Setting	Alarm	Analog input
@Υ	Online	Axis0_No name set	SRV-OFF					
	USB	MADN085BRU 23080001		Open file	Save file	Load initia	Load	Write
	*0		Encoder Info			Config Reset		e se
	, in the second	MINAS A7BR MHMG022U1A2 24020001	39405786 pulse	Search	Compar	ison None	✓ Add/delete c	:olumn
				Switch to HEX input	Display A6-compati	ble control parameters	Allow out-of-range settin	ngs

**3.** In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

4. Click on the [Damping settings] button or "Damping settings" in blue text.

	rile(F) Troublesbooting(T) Help(H)					U
De	ŵ Setting 問 Monitor	K Logging	ing Device Info	19	Trial run	Z-phase search
wice tree	Annual TUNING  Selected driver: Aviet No name set	Graph     Wave graphic Frequency re	sponse	Trial run/Z-p	Limit setting	2 Trial run
	Basic     Load characteri     Notch settings       Damping settin     Application     Manual       Mode setting ①     0:Disabled        ①     When launching for the first time        A7 recommended settings recommended     ①     When vagrading from A6A6 compatibility setting	Start measurement data managen Measurement data managen Reset zoom Align with ce Display as elapsed time C Save file	Stop Single trigger Acquire Left display range Fixed display range hter of Y-axis isplay as time standard Load file	hase search	Protection Functions Pr5.12 Overload level[%] Pr5.13 Overspeed level[r/min] Pr5.14 Motor mova[0.1 rotation] Operation limit Pr5.04 Over-travel inhibit input s	0 120 2 Automatic setting (overspee 10 1: CoE-side (CiA402) deceler V
Þ	Load characteristic settings Automatic settingOFF Inertia ratio 0 For more advanced settings Load characteristic settings Gain setting Feedback gain setting - 29 + Speed response frequenc 102.5 Automatic oscillation su OFF Safety function FF gain setting - 31 +	Graph display settings     Measurement Condition     Acquire from driver     Monitor     Simple monitor     Io monitor     Start measurem     Measurem	Edit displayed data Cursor Acquire from file Load condition presets	2	Operating range Use JOG to move to the Max/Mi JOG speed[r/min] JOG acceleratio[ms/JOG speed]	n. positions or input a numeric value 60 50
	Positional command smo 0.8 Overshoot suppression [%] - 100.0 + Notch filter settings Automatic setting:OFF 3rd notch frequency [Hz] 5000 4th notch frequency [Hz] 5000 For more advanced settings Notch setting:ON 1st damping frequency [Hz] 0 For more advanced settings Damping settings What if I have a problem? Refer to Tuning Help when problems occur such as vibration or abnormal noise	Trial No. Settling time   INi [times] [ms] [tin	P change count Vibration level Effective load factor Tak nes] [%] [%] [%]	t ]	Servo-on Operates of -direction Grant of Current position [command unit] [0] Trouble	Inly while the button is pressed.

The advanced damping settings screen is displayed.

5. Tune the Pr2.23 Positional command FIR filter and the Pr2.22 Positional command smoothing filter.

<	Manual TUNING						
Selec	ted driver:Axis0_No nam	ne set					
	Basic	Load characteristic se	ettings	Notc	h settings		
	Damping settings	Application		M	1anual		
Vibrat	ion monitor			Not detec	ted		
Vibra	tion frequency [Hz] ()				0.0		
(j)	() "0.0" is displayed until vibration is detected						
Damp	Damping filter setup						
Pr2.1	3 Damping filter switchin	g	0: Use	up to two sim	ultaneo 🗸		
Auto	matic frequency setting (	D	1st dar	nping frequer	ncy 🗸		
(j)	When vibrations are dete	cted, the vibration frequence of the target filter	uency va	lue is automa	tically applied		
IN	to the dumping nequenc	y of the target litter.					
Ţ							
Ť	FIR filter	natic setting					
Ļ	Pr2.23 Positional comm	and FIR filter [0.1 ms]	10				
	Smoothing filter						
	Pr2.22 Positional command smoothing filter 37						
	Pr6.49 Command response filter attenuation 5: 1 V						
	Damping filter 1						
	Pr2.14 1st damping free	quency [0.1 Hz]	0				
	Pr2.15 1st damping filte	er setup [0.1 Hz]	0				
	Pr2.27 1st damping wid	th setting	0				
¥	Pr6.41 1st damping dep	oth	0				
	Damping filter 2						
	Pr2.16 2nd damping fre	quency [0.1 Hz]	0				
	Pr2.17 2nd damping filt	er setup [0.1 Hz]	0				
	Pr2.28 2nd damping width setting 0						
¥	Pr6.60 2nd damping depth 0						
OUT							
-	Tuning filter						
	Filter function switching		A7 mo	de	~		
	Tuning filter time consta	int0.01ms]	4				
	Pr6.49 Tuning filter atter	nuation term setup	1: No a	ttenuation te	rm 🗸		

• Tuning "FIR filter"

Tune Pr2.23 "Positional command FIR filter" to suppress vibration and velocity change caused by infrequent command updating cycles.

• To set automatically

Click the [Auto tuning] button. The Pr2.23 "Positional command FIR filter" value is automatically set based on the command updating cycle setting and communication cycle setting.

• To set manually

See <u>"5.7.4.1 For Manual Setting"</u>.

• Tuning "Smoothing filter"

Tune Pr2.22 "Positional command smoothing filter" to suppress vibration and velocity change caused by command resolution.

• See <u>"5.7.4.1 For Manual Setting"</u>.

## 5.7.4.3 Error Troubleshooting

• When Err24.0.0 "Position deviation excess protection" occurs

Tuning related parameters may cause the position deviation excess setup value to deviate from the appropriate value.

Review the set value using the formula for calculating the position deviation excess setup value shown in Operating Instructions (Overall) "7.2.9 Before Gain Tuning Protection Function Setup".

# 5.8 Speed Command Acceleration/Deceleration Setting Function

#### 5.8.1 Function Overview

This function performs speed control by applying a speed command for which acceleration and deceleration have been tuned inside the servo driver with respect to the speed command input from the host device. Smooth acceleration and deceleration is possible when stepwise speed commands are input.

To reduce shock caused by acceleration changes, the S-curve acceleration/deceleration function can be used to suppress vibration by reducing the change in acceleration at the start and end of acceleration.

# 5.8.2 Operational Conditions

Item	Operational Conditions
Control mode	Speed control

## 5.8.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
3	12	В	Acceleration time setup	0 to 10000	ms/ (1000 r/ min)	Sets the acceleration time for acceleration processing with respect to speed command input.
3	13	В	Deceleration time setup	0 to 10000	ms/ (1000 r/ min)	Sets the deceleration time for deceleration processing with respect to speed command input.
3	14	В	Sigmoid acceler- ation / decelera- tion time setup	0 to 1000	ms	Sets the S-curve time for acceleration/deceleration processing with respect to speed command input.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

#### Precautions –

• Do not use Pr3.12 "Acceleration time setup" and Pr3.13 "Deceleration time setup" if a position loop is configured outside the servo driver. Use all of the above settings with the value set to 0.

#### 5.8.4 How to Use

#### Pr3.12 "Acceleration time setup", Pr3.13 "Deceleration time setup"

When a stepwise speed command is input, these parameters set the time it takes for the speed command to reach 1000 r/min in Pr3.12 "Acceleration time setup". They also set the time it takes for the speed command to reach 0 r/min from 1000 r/min in Pr3.13 "Deceleration time setup". The time required for acceleration and deceleration can be calculated by the following formula, assuming the target value of the speed command is Vc [r/min].

Acceleration time (ta)  $[ms] = Vc/1000 \times Pr3.12 \times 1 ms$ 

Deceleration time (td)  $[ms] = Vc/1000 \times Pr3.13 \times 1 ms$ 



#### Pr3.14 "Sigmoid acceleration / deceleration time setup"

Sets the time of the S-curve part in the time width with the inflection point during acceleration and deceleration at the center and with respect to the acceleration and deceleration time set by Pr3.12 "Acceleration time setup" and Pr3.13 "Deceleration time setup".



# 5.9 Hybrid Vibration Suppression Function

#### 5.9.1 Function Overview

This function suppresses vibration caused by the amount of torsion between the motor and the load in full-closed control mode.





# 5.9.2 Operational Conditions

Item	Operational conditions
Control mode	Full-closed control

Command

Under the following conditions, the effects of the hybrid vibration suppression function may not be seen.

Item	Conditions that obstruct operation of the hybrid vibration suppression function
Load condi- tions	<ul> <li>Looseness, backlash, etc. are present and the load non-linearity is strong</li> </ul>

# 5.9.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	34	В	Hybrid vibration suppression gain	0 to 30000	0.1 s <sup>-1</sup>	Sets hybrid vibration suppression gain. Normally set to the same value as the position loop gain, and then fine-tune as necessary.
6	35	В	Hybrid vibration suppression filter	0 to 32000	0.01 ms	Sets the hybrid vibration suppression filter. Disabled when the set value is 0 to 3.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

#### 5.9.4 How to Use

# 5.9.4.1 For Manual Setting

#### << Procedure >>

**1.** Set Pr6.34 "Hybrid vibration suppression gain" to the same setting as the position loop gain (Pr1.00 "1st gain of position loop" or Pr1.05 "2nd gain of position loop").

- Set the Pr6.35 "Hybrid vibration suppression filter" [ms] value using the vibration cycle confirmed when this function is unused. This can be obtained with the following equation:
   Pr6.35 "Hybrid vibration suppression filter" [Ms] value = vibration cycle/(2 π)
- **3.** While driving in full-closed control, gradually increase the Pr6.35 "Hybrid vibration suppression filter" set value to check the change in response. The set value should be changed by increasing by 10% at a time. If the response seems to improve, tune Pr6.34 "Hybrid vibration suppression gain" and Pr6.35 "Hybrid vibration suppression filter" to find the combination that provides the best response.

# 5.9.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

## << Procedure >>

9

- 1. Activate Set-up Support Software (PANATERM ver.7).
- 2. Select one device that you want to tune in the device tree and click the "Tuning" tab.

File(F)	Troubleshooting(T)	Help(H)							
		E Device tree			ôð Setting	閔 Monitor	ピ Logging	프 <mark>은</mark> Tuning	🚺 Device Info
	eli .	MINAS A7BR				EtherCAT object	IO Setting	Alarm	Analog input
⊕∨	Online	Axis0_No name set	SRV-OFF						
	USB	MADN085BRU 23080001			Open file	Save file	Copy Load initia	values Load	Write
	NL.		Encoder Info				Config Reset		se searc
		MINAS A7BR MHMG022U1A2 24020001	33403700 puise	•	Search	Compar	ison None	Add/delete c	olumn
					Switch to HEX input	Display A6-compati	ble control parameters	Allow out-of-range settin	gs

**3.** In the "Tuning" tab screen, select "Manual TUNING", and click the [Go to the Tuning screen] button.



The "Manual TUNING" settings screen is displayed.

5				PANATE	RM ver.7				
F	File(F) Troubleshooting(T) Help(H)								
Devie		Ŀάι	ogging	프 <mark>은</mark> Tuning	Device Info	Ø	Trial run	Z-phas	e search
ce tree	Manual TUNING		✓ Graph			Trial run/2	1	2	
	Selected driver:Axis0_No name set		Wave graph	Frequency response		Z-pha	Limit setting	Trial run	
	Basic Load characteri Notch settings	٦.	Start m	easurement Stop	Single trigger	ise s	Protection Functions		
	Damping settin Application Manual	1				earch	Pr5.12 Overload level[%]	0	
		-	Measureme	ent data management Edit	display range Fixed display range	-	Pr5.13 Overspeed level[r/min]		
	Mode setting () U:Disabled V		Reset zoom	Align with center of Y-axi	s			Automatic set	ting (overspee
	When Isometrian for the first time		Display as e	elapsed time Display as tim	e standard Load file		Pr5.14 Motor mova[0.1 rotation]	10	
	A7 recommended settingis recommended		Cauc file				Operation limit		
	<ol> <li>When upgrading from A6A6 compatibility setting is recommended</li> </ol>		Save In				Pr5.04 Over-travel inhibit input s	1: CoE-side (CiA4	02) deceler 🗸
	Load characteristic settings Automatic settingOFF		🗸 Graph di	splay settings			Operating range		
	Inertia ratio 0				11. 6		Use JOG to move to the Max./M	in. positions or inp	ut a numeric value
	For more advanced settings Load characteristic settings		Measuren	hent Condition Edit displaye	d data Cursor		JOG speed[r/min]	60	
	Gain setting		Acquire	from driver Acquire from	n file Load condition presets		JOG acceleratio[ms/JOG speed	50	
1	Feedback gain setting - 29 +	•				- 1			
	Speed response frequenc 102.5		<ul> <li>Monitor</li> </ul>						
	Automatic oscillation su OFF		Simple mor	nitor IO monitor					
	Safety function								
	FF gain setting - 31 +		Start mea	surem Measurement mod	e With Position C 💙 Measurement count	2			
	Positional command smo 0.8		Trial No.	Settling time INP change cou	Int Vibration level Effective load factor Takt				
	Overshoot suppression [%] - 100.0 +		[times]	imsj [timesj	[%] [%] [ms]		Servo-on Operates	only while the butto	on is pressed.
	Notch filter settings Automatic setting:OFF						- direction	o to 0 + d	lirection
	3rd notch frequency [Hz] 5000						Current position	(command unit)	
	For more advanced settings Notch settings						Current position		
	Damping filter setup Automatic setting:ON								
	1st damping frequency [Hz] 0						Minimum position	<b>_</b>	Aavimum position
	For more advanced settings Damping settings						[command unit]	[	command unit]
	What if I have a problem?						0	[	0
	Refer to Tuning Help <u>when problems occur</u> such as vibration or abnormal noise						Troubl	eshooting	To trial run

**4.** Click the [Application] button.

<	Manual TUNING						
Selected driver:Axis0_No name set							
Basic	Basic Load characteristic settings Notch settings						
Damping settings	Damping settings Application Manual						
> Feedforward function							
> Load fluctuation control fu	unction						
> High response current cor	ntrol function						
> Gain switching function							
> Quadrant glitch suppression	Quadrant glitch suppression function						
> Hybrid vibration suppress	on function						

5. Click on ">" of "> Hybrid vibration suppression function" to expand "Hybrid vibration suppression function".

<	Manual TUNING						
Selected driver:Axis0_No name set							
Basic	Load characteristic settings	Notch settings					
Damping settings	Application	Manual					
> Feedforward function	Feedforward function						
> Load fluctuation control f	unction						
> High response current co	ntrol function						
> Gain switching function							
> Quadrant glitch suppressi	on function						
<ul> <li>Hybrid vibration suppress</li> <li>Enabling this suppresses osc</li> </ul>	<ul> <li>Hybrid vibration suppression function</li> <li>Enabling this suppresses oscillation.</li> </ul>						
Hybrid vibration suppression	Hybrid vibration suppression gain [0.1/s] 0						
Hybrid vibration suppression	n filter [0.01 ms] 10						

6. For details on tuning each parameter, see <u>"5.9.4.1 For Manual Setting"</u>.

# **6** Functions to Assist Tuning

6.1 Waveform Measurement	243
6.1.1 Function Overview	243
6.1.2 Purpose of Use	243
6.1.3 Measurement Procedure	243
6.1.4 Method of Use	245
6.2 Frequency Response Measurement	246
6.2.1 Function Overview	246
6.2.2 Types of Measurement Modes	246
6.2.3 Changes from measurements using A6 Series drivers	247
6.2.4 Restrictions	247
6.2.5 Measurement Procedure	248
6.2.6 Method of Use	254
	254

## 6.1 Waveform Measurement

#### 6.1.1 Function Overview

This function uses Set-up Support Software (PANATERM ver.7).

This function draws up data stored inside drivers and motors into Set-up Support Software (PANATERM ver.7) as time-series data and displays it as waveform graphs.

Waveform graphs can also be displayed within the tuning function screens, such as One Minute TUNING, precAIse TUNING, and Manual TUNING, and can be used to check response during tuning.

#### 6.1.2 Purpose of Use

An example of waveform measurement usage is shown below.

- Checking responsiveness with One Minute TUNING and precAIse TUNING
- Checking the amplitude and frequency of residual vibration for the settling waveform during damping control tuning
- Checking the overshoot amount for the settling waveform when tuning the feedforward function, etc.

#### 6.1.3 Measurement Procedure

<< Procedure >>

1. Select Logging>Wave graphic in Set-up Support Software (PANATERM ver.7) to open the main screen.

<b>@</b>								
File	(F) Troubleshooting(T)	Help(H)						
Devi	🔅 Setting	छ Monitor	්ර Logging	프 <del>아</del> Tuning	Device Info			
ce tree	Wave graphic	Frequency response						
Ĩ	Start measurement	Stop Sing	gle trigger Acquire	Multiple axis measur	ement settings Measuremen	t data management Add graph	Load file Save file	
	Axis0 Graph1 x							
ſ	Edit display range Fixed o	display range Reset zo	om Align with center of	Y-axis		Display as el	apsed time Display as time standard	4
•								
~	Graph display settings							
	Measurement Condition	dit displayed data Curs	sor					
	Acquire from driver	Acquire from file	Load condition presets	Save condition presets				
	Measurement item	Edit	Sampling cycle [ms] 0.7500	)	Measurement time [ms] 1,	535.25		
	Actual speed[r/min]				_			
	Position command speed[r, Torque command[%]	/min]	Trigger condition 1 or 2	✓ Trigger position	1/8 V Data average	je ON O		
	Command position deviation	on[Command unit]	Ta Ta	irget	Level	Slope	Filter	
			Trigger 1 Position comman	a speed[r/min] V -50		Esiling down	No use	-
			rosition comman	iu speeu(i/min) 🔹				

2. In "Measurement condition" of "Graph display settings", set the measurement items, measurement conditions, sampling cycle, and trigger.

~	Graph display settings						
	Measurement Condition Edit displayed data	Cursor					
	Acquire from driver Acquire from file	Load co	ndition presets Save condition pres	sets			
	Measurement item Edit	Sampling	cycle [ms] 0.7500	Measurement time [ms] 1,5	535.25		
	Actual speed[r/min]		0				
	Position command speed[r/min]	Trigger co	ondition 1 or 2 🗸 Trigger p	osition 1/8 V Data averag			
	Torque command[%]	55	55 1				
	Command position deviation[Command unit]		Target	Level	Slope	Filter	
		Trigger 1	Position command speed[r/min] $~~$	50	Rising up 🗸	No use	~
		Trigger 2	Position command speed[r/min] V	-50	Falling down	No use	~

**3.** Click the [Start measurement] button.

6	)		
File(F)		Troubleshooting(T)	Help(H)
Devi		🔅 Setting	<b></b> 曖 Monitor
ce tree		Wave graphic	Frequency response
		Start measurement	Stop Single

The measurement results are displayed.

5							
F	ile(F) Troubleshooting(T) Help(H)						
Devi	袋 Setting 쩐 Monitor	්ර Logging	프 <del>을</del> Tuning	Device Info			Ø
ce tree	Wave graphic Frequency respon	se					Trial ru
	Start measurement Stop	Single trigger Acquire	Multiple axis measurer	nent settings Measurement data n	nanagement A	\dd graph	n/Z-p
	Load file Save file						hase s
	Axis0 Graph1 x						earch
	Edit display range Fixed display range R	eset zoom Align with center of Y-	-axis	Display as e	elapsed time Disp	alay as time standa	rd
	2000000 - 8 - 200 - 120	0-					
		0					
	400 - 400 -	0-	hum	mm /			
		0		hunn			
	-400 - 400 -	0 -					
۲	$\begin{bmatrix} -12000006 - \frac{12}{8} - 80080 \\ -16000008 - \frac{12}{8} - 80080 \\ -8 - \frac{12}{8} - 800 \\ -8 -$	0-					•
	-2000000120012001200	•	129	256	204	511	
		0	El	apsed time [ms]	304	512	2
	<ul> <li>Graph display settings</li> </ul>						
	Measurement Condition Edit displayed data	Cursor					
	Acquire from driver Acquire from file	Load condition presets	Save condition presets				
	Measurement item Edit	Sampling cycle [ms] 0.2500		Measurement time [ms] 511.75			
	Actual speed[r/min]						
	Position command speed[r/min] Torque command[%]	Trigger condition 1 and 2	✓ Trigger position	1/8 V Data average ON	D		
	Command position deviation[Command unit]	Target	Lev	Rising up	✓ No use	Filter	7
		Trigger 2 Position command	spe ✔ -50	Falling down	✓ No use	`	-

# 6.1.4 Method of Use

#### Checking settling time

See Set-up Support Software (PANATERM ver.7) Operating Manual "10.1.14 Measure the Fixed Time from the Measurement Data".

#### Checking vibration frequency

- 1 Check the "Cursor" check box in "Graph display settings" to display the cursor.
- 2 Drag Cursor 1 (green dotted line) or Cursor 2 (red dotted line) on the graph with the mouse to move it to the desired position. You can also enter a numerical value in the numeric field at the bottom of the screen to move the cursor to that position. Set Cursor 1 to match the peak position of the vibration waveform, and set Cursor 2 to match the peak one cycle after Cursor 1.
- 3 The time (in seconds) can be calculated from the difference between the times displayed in Cursors 1-2 for the item "Time", and the frequency can be found from the inverse.

For example, if the difference in time between Cursor 1 and Cursor 2 is 20 ms (0.02 sec), the frequency can be calculated as 1/0.02 sec = 50 Hz.



# 6.2 Frequency Response Measurement

#### 6.2.1 Function Overview

This function uses Set-up Support Software (PANATERM ver.7).

Operate the motor to measure the frequency response including the load and display the Bode diagram.

From the measurement results, the resonance point can be identified, benchmarks for filter setting values decided, and the stability of the feedback control system determined.

The measurement results can also be saved to a file.

#### – Precautions –

- The speed of the motor changes rapidly during measurement. Take necessary safety precautions.
- Perform the measurement with the servo ready to be turned off immediately in case of unexpected operation of the motor or other hazards.
- Do not use this function if there is a possibility that the device could be damaged by violent movement of the motor.
- Setting a large offset may cause movement limits to be exceeded. Take due care.
- Initially, start measurement with the gain as low as possible.
- Frequency response measurement results may vary greatly or show incorrect values due to device characteristics or measurement conditions. Use the measurement results of this function as a reference for gain adjustment.
- Servo parameters during measurement are fixed to 1st gain.
- In measurement modes other than torque speed (normal), the measurement results include the effects of various torque filters and various notch filters.

Measurement mode	Function overview	Application
Speed closed loop characteristics	Measures the characteristics of the speed feedback control system, including mechanical characteristics. Measures in speed control mode.	Checks the stability of the speed feedback control system when parameter tuning is in progress or has finished.
Torque speed (normal)	Measures mechanical characteristics. Takes measurements without applying a control to prevent the falling of moving parts due to gravity.	Used to determine the resonance frequency and resonance strength of a device where gravity is not applied to moving parts, and to obtain a guide for set values of various filters.
Torque speed (vertical)	Measures mechanical characteristics. Measurements are taken while applying a control to prevent the falling of moving parts due to gravity.	Used to determine the resonance frequency and resonance strength of a device where gravity is applied to moving parts, and to obtain a guide for set values of various filters.
Position loop characteristics	Measures the characteristics of the position feedback control system, including mechanical characteristics. Measures in position control mode.	Used to check the disturbance suppression of the position feedback control system when parameter tuning is in progress or has finished.

# 6.2.2 Types of Measurement Modes

# 6.2.3 Changes from measurements using A6 Series drivers

Measurement mode	Change
Speed closed loop characteristics	<ul> <li>Since the operation mode corresponds to "Pr6.47:bit 0 "Two-degree-of-freedom control mode" = 0 (disabled)" during measurement operation, "Pr6.47:bit 0" does not require switching before measurement in Set-up Support Software (PANATERM ver.7).</li> </ul>
	<ul> <li>Measurement results unaffected by the feedforward system can be obtained regardless of the set value of the parameter "Pr6.47:bit 0 "Two-degree-of-freedom control mode" " (0 = disabled, 1 = enabled) at the time of measurement.</li> </ul>
Torque speed (normal)	• Because torque commands are applied as noise signals after various filters, mechanical charac- teristics unaffected by various filters can be obtained. This means that the various torque filters and various notch filters do not need to be disabled during measurement in Set-up Support Soft- ware (PANATERM ver.7).
	• Although the Set-up Support Software (PANATERM ver.6) formerly displayed gain with the same scaling as speed closed loop characteristics by offsetting the gain, this function has been delet-ed.
Torque speed (vertical)	The load fluctuation control function is disabled during measurement.
	<ul> <li>Torque commands are applied as noise signals after the various filters.</li> </ul>
	<ul> <li>Although the Set-up Support Software (PANATERM ver.6) formerly displayed gain with the same scaling as speed closed loop characteristics by offsetting the gain, this function has been delet- ed.</li> </ul>
Position loop charac-	<ul> <li>Torque commands are applied as noise signals after the various filters.</li> </ul>
teristics	• Although the Set-up Support Software (PANATERM ver.6) formerly displayed gain with the same scaling as speed closed loop characteristics by offsetting the gain, this function has been deleted.

# 6.2.4 Restrictions

The waveform graphic function cannot be used at the same time.

# 6.2.5 Measurement Procedure

# << Procedure >>

**1.** Select Logging>Frequency response in Set-up Support Software (PANATERM ver.7) to open the main screen.

89										
Fil	e(F) Troubleshooting(T)	Help(H)								
Devi	🔅 Setting	曖 Monitor		3	📴 Tuning	Device Info				2
ce tree	Wave graphic	Frequency respo	nse							Trial n
Selected driver:Axis0_No name set										ın/Z-p
	Parameter auto-update				Automatic servo-on/o	ff Servo-on	Start measurement	Stop	ement data management	hase sea
	Write to EEPROM	.OM Config Reset			Reset display range	Load file Save file				rch
	Recall presets Load presets Selected preset:All parameters				Smoothing	-0	12			_
	Name	Unit	Value		₩ 0 ₩ 0					
	Pr0.00 manufacturer use		1		-40					
	Pr0.01 Control mode setu	ıp	0: Semi-closed c 🗸		1	0	100	1	000	
	Pr0.02 Real-time auto-gain tu		0: Conventional 🗸			Frequency [Hz]				
	Pr0.03 Real-time auto-tuning		13		☑ Display phase graph					
•	Pr0.04 Inertia ratio	%	100		6 100 - 9 0 -	· · · · · · · · · · · · · · · · · · ·				•
	Pr0.08 manufacturer use		0	•	-200					
	Pr0.09 manufacturer use		1		1	0	100 Frequen	1 Icy [Hz]	000	
	Pr0.10 manufacturer use		1							- 1
	Pr0.11 Number of output	puls pulse/r	2500		Measurement Condition	tic setup/analysis List of displayed data	Resonance/antiresonance fre	quency display		
Pr0.12 Reversal of pulse outpu     ①: Encoder, posit ▼       Pr0.13 1st torque limit     %       350       Sampling rate       0:5000Hz							mporarily changed when measuring.			
	Pr0.14 Position deviation	exce Command	83886080		Input signal 1 amplitud	e [r/ 50				
	Pr0.15 Absolute encoder	setup	1: Used in incre 🗸		Input signal 1 offset [r/	min] 50				
	Pr0.16 External regenerati	ve re	3: No regenerati 🗸		A Setting a large offs	et may cause operating lim	its to be exceeded.			

2. Select the desired measurement mode from the "Measurement mode" drop-down list.

✓ Frequency characteristic setup/analysis						
Measurement Condition List of displayed data Resonance/antiresonance frequency display						
Measurement mode Speed closed loop characteristics						
Sampling rate	0:5000Hz 🗸					
Input signal 1 amplitude [r/	50					
Input signal 1 offset [r/min]	50					
⚠ Setting a large offset may	cause operating limits to be exceeded.					

Check the precautions for the selected measurement mode.

Measurement mode	Precautions
Speed closed loop characteristics	When an offset speed is entered, the load moves. (See details in <u>"Step 5"</u> ) Therefore, if the movable range of the device is narrow, the moving part may collide with the mechanical end.
Torque speed (normal)	Do not use in devices with a Z axis that may cause the mechanism to fall when in servo-on. For such devices, use torque speed (vertical).
Torque speed (vertical)	Before measurement, change Pr1.01 "1st velocity loop gain" to a value lower than the frequency bandwidth you wish to check. Furthermore, Pr1.02 "1st velocity loop integration time constant" should also be tuned by referencing <u>"4.1.1.6 Basic Gain Parameter Setup Table"</u> of <u>"4.1 Real-time Auto Tuning Function"</u> .
	Technically, the measurement results include the effects of various torque filters and various notch filters. Disabling the aforementioned filters can remove their effects, but there is a risk of oscillation if the various filters are disabled when the Pr1.01 "1st velocity loop gain" value is large.

**3.** Select "Sampling rate" from the drop-down list.

The respective upper limits of the frequency range that can be checked are displayed.

• When the upper limit of the frequency range that can be checked is high

Although measuring accuracy in the low frequency band is reduced, a wide range of frequency response can be checked. Measurement time is reduced.

• When the upper limit of the frequency range that can be checked is low

The frequency range that can be checked is narrower, but measuring accuracy in the low frequency band is improved. Measurement time is longer.

Select the sampling rate to include the frequency range you want to view with high accuracy.

If you are unsure of which frequency range you want to view with high accuracy, first measure the frequency response with "0:5000 Hz", which can measure the widest range of frequency response, and then select the optimal sampling rate based on those measurement results.

When the sampling rate is other than "0:5000 Hz", folding due to aliasing may occur.

✓ Frequency characteristic setup/analysis							
Measurement Condition List of displayed data Resonance/antiresonance frequency display							
Measurement mode Speed closed loop characteristics 🔹 🔹 🛈 Some parameters are temporarily changed when measuring							
Sampling rate 0:500	000Hz 🗸						
Input signal 1 amplitude [r/ 50							
Input signal 1 offset [r/min] 50							
▲ Setting a large offset may cause operating limits to be exceeded.							

**4.** Set the amplitude of the noise waveform to be applied to the speed or torque command in "Input signal 1 amplitude".

See table <u>"Amplitude and offset setting ranges</u>" below for the range that can be set for amplitude.

Increasing the amplitude improves measuring accuracy, but too large an amplitude results in torque saturation and reduced accuracy. Start from a small value and gradually increase it as you observe the measurement results.

The torque command units [%] set for torque speed (normal), torque speed (vertical), and position loop characteristics are ratios of the motor rated torque at 100%.

We recommend confirming that amplitude is 50% for torque speed (normal), torque speed (vertical), and position loop characteristics, and that amplitude is 50 r/min for speed closed loop characteristics.

✓ Frequency characteristic setup/analysis							
Measurement Condition List	of displayed data Resonance/antiresonance frequency display						
Measurement mode Speed closed loop characteristics 🗸 🕻 Some parameters are temporarily changed when m							
Sampling rate	0:5000Hz V						
Input signal 1 amplitude [r/	50						
Input signal 1 offset [r/min]	50						
⚠ Setting a large offset may	cause operating limits to be exceeded.						

5. Set the offset value of the noise waveform to be applied to the speed command to "Input signal 1 offset".

See table "Amplitude and offset setting ranges" below for the range that can be set for offset.

During speed closed loop characteristics measurement, the motor operates with the set offset as the average speed command. Polarity is + for positive directions and - for negative directions. Good measurement results are obtained when the offset is greater than the set value for amplitude and the motor always rotates in one direction. (For example, if input signal 1 amplitude is 50 r/min, set input signal 1 offset [r/min] to 50 r/min.)

However, note that if the working range of the device mechanism is narrow, the movement limits may be exceeded.

The approximate amount of motor rotation during measuring operation can be determined by the following equation. Before starting a measurement, always make sure that the movement limits of the device mechanism are not exceeded.

Approximate amount of rotation  $[r] = offset [r/min] \times 0.017 \times (sampling rate + 1)$ 

Measurement mode Amplitude setting range Offset setting range 1 r/min to rated speed [r/min] Speed closed loop - rated speed [r/min] to rated speed [r/min] characteristics Torque speed (normal) 1 to 100% \_ Torque speed (verti-1 to 100% cal) Position loop charac-1 to 100% teristics Frequency characteristic setup/analysis Measurement Condition List of displayed data Resonance/antiresonance frequency display Measurement mode Speed closed loop characteristics Some parameters are temporarily changed when measuring. Sampling rate 0:5000Hz v Input signal 1 amplitude [r/... 50

#### Amplitude and offset setting ranges

Input signal 1 offset [r/min]

50 ▲ Setting a large offset may cause operating limits to be exceeded. -: N/A

- 6. Check the "Automatic servo-on/off" check box to automatically servo-on at the start of measurement.
  - Do not check the box when measuring in servo-on state by external input.

After servo-on by external input, go to "Step 7".

• Uncheck the box if the brake release operation is performed by a host device in a network.

After servo-on, release the brake from the host device and go to "Step 7".



7. Click the [Start measurement] button to execute measurement.

A "buzzing" noise may be heard during operation. This noise is caused by the operation of motor excitation by the noise signal and does not indicate a problem.

To stop in an emergency, click the [Stop] button.
**a** File(F) Troubleshooting(T) Help(H) 🔅 Setting 閥 Monitor 프<mark>라</mark> Tuning Device Info Wave graphic Selected driver:Axis0\_No name set Parameter auto-update Automatic servo-on/off Servo-on Start measurement Measurement data management Reset display range Load file Save file Write to EEPROM Config Reset 0 12 Smoothing Recall presets Load presets Selected preset:All parameters 20 0 <del>-</del> -20 -[dB] Name Unit Value -40 -Pr0.00 manufacturer use Pr0.01 Control mode setup 0: Semi-closed c... ~ 1000 10 100 Frequency [Hz] Pr0.02 Real-time auto-gain tu.. 0: Conventional... 🗸 🕑 Display phase graph Pr0.03 Real-time auto-tuning.. 13 Pr0.04 Inertia ratio 100 0 0 200 Pr0.08 manufacturer use Pr0.09 manufacturer use 10 100 1000 Frequency [Hz] Pr0.10 manufacturer use 1 Frequency characteristic setup/analysis Pr0.11 Number of output puls... pulse/r 2500 Measurement Condition List of displayed data Resonance/antiresonance frequency display Pr0.12 Reversal of pulse outpu. 0: Encoder, posit... 🗸 O
 Some parameters are temporarily changed when measuring. Measurement mode Speed closed loop characteristics Pr0.13 1st torque limit 350 0:5000Hz v Sampling rate Pr0.14 Position deviation exce... Command.. 83886080 Input signal 1 amplitude (r/... 50 Pr0.15 Absolute encoder setup ~ 1: Used in incre... Input signal 1 offset [r/min] 50 ▲ Setting a large offset may cause operating limits to be exceeded. Pr0.16 External regenerative re. 3: No regenerati... 🗸

Depending on the parameter values for the safety function or protection function systems, a measurement error may occur. If an error occurs, see the table below.

#### Measurement error troubleshooting

Error	Solution
After the measurement, a "Torque sa- turated. Lower the amplitude and measure again" pop-up dialog ap- peared. An alarm is not triggered.	Set the amplitude to a smaller value and measure again. If possible, the torque limit determined by Pr5.21 "Selection of torque limit" should be set to a value large enough for the amplitude of the measurement condition. If there are no special constraints, the initial values are recommended for the relevant torque limit-related parameters.
An "Alarm triggered during measure- ment" pop-up dialog appeared. An Err16.0 alarm was triggered.	After clearing the alarm, set the amplitude to a smaller value and measure again. Also, if possible, change Pr5.12 "Motor overload level setup" to a larger value. If there are no special constraints, the initial values are recommended.
An "Alarm triggered during measure- ment" pop-up dialog appeared. An Err26.0 alarm was triggered.	After clearing the alarm, set the amplitude to a smaller value and measure again. This error always occurs when the speed closed loop characteristics are measured and the speed set for offset in the measurement conditions is greater than the speed set by Pr5.13 "Over-speed level setup". Make sure the offset speed is set smaller. Also, if possible, change Pr5.13 "Over-speed level setup" to a larger value. If there are no special constraints, the initial values are recommended.
An "Alarm triggered during measure- ment" pop-up dialog appeared. An Err26.1 alarm was triggered.	After clearing the alarm, set the amplitude to a smaller value and measure again. This error always occurs when the speed closed loop characteristics are measured and the speed set for offset in the measurement conditions is greater than the speed set by Pr6.15 "2nd overspeed level setting". Make sure the offset speed is set smaller. Also, if possible, change Pr6.15 "2nd overspeed level setting" to a larger value. If there are no special constraints, the initial values are recommended.

Error	Solution
An "Alarm triggered during measure- ment" pop-up dialog appeared. Alarms other than the above alarms were triggered.	Take the specified measures for handling each alarm. Measure again after clearing the alarm.

8. After measurement is completed, the gain and phase are displayed on the main screen.

For detailed instructions on how to operate the graph area of the main screen, see Set-up Support Software (PANATERM ver.7) Operating Manual.

Also, if parameters were changed manually prior to measurement, such as torque speed (vertical), do not forget to restore the relevant parameters once the measurement of frequency response is complete.

If the servo-on is performed manually with <u>"Step 6</u>", the waveform is displayed on the main screen after servo-off. If the brake is operated by a host device, apply the brake before servo-off.



#### 6.2.6 Method of Use

- Understanding mechanical resonance and using it as reference for the set values of various filters
- 1 Measure "Torque speed (normal)" or "Torque speed (vertical)" according to <u>"6.2.5 Measurement Procedure"</u>.
- 2 Select the "Resonance/antiresonance frequency display" tab on the screen to view the resonance frequency and antiresonance frequency.

The figure below is an example of "Torque speed (normal)".

For an example of filter settings using these, see <u>"5.6 Model-type Damping Filter Function"</u>.



#### Checking the stability of the feedback control system when parameter tuning is in progress or has finished

- 1 Measure "Speed closed loop characteristics" according to <u>"6.2.5 Measurement Procedure"</u>.
- 2 Check if the peak gain exceeds 0 dB. If this value is exceeded, oscillation may occur. Basically, the lower the stiffness value of the feedback control system, the lower the peak gain. If a device has high friction, oscillation may not occur even though the value is above 0 dB.



For details on how to tune parameters, see <u>"3.2.1 Manual TUNING"</u>.

Resonance peaks from mechanical resonance may also be measured. When doing so, it may be possible to increase the stiffness by setting a notch filter to suppress the resonance peak. For information on how to set notch filters, see <u>"5.3 Notch Filter Function"</u>.



7.1 Object Dictionary List	258
7.1.1 CoE Communication Area (1000h to 1FFFh)	258
7.1.2 Servo Parameter Area (3000h to 3FFFh)	
7.1.2.1 Class 0: Basic Settings	264
7.1.2.2 Class 1: Gain Adjustment	
7.1.2.3 Class 2: Vibration Suppression	
7.1.2.4 Class 3: Velocity/Torque Control/Full-closed Control	272
7.1.2.5 Class 4: I/O Monitor Settings	273
7.1.2.6 Class 5: Enhancing Settings	275
7.1.2.7 Class 6: Special Settings	
7.1.2.8 Class 7: Special Settings 2	
7.1.2.9 Class 8: Special Settings 3	
7.1.2.10 Class 9: Linear Relationship	
7.1.2.11 Class 10: Special Settings 4	
7.1.2.12 Class 11. Manufacturer Ose	200
7.1.3 User-specific Area (4000h to 4FFFh)	
7.1.4 Drive Profile Area (6000h to 6FFFh)	
7.2 Control Mode Block Diagram	
7.2.1 Position Control Mode Block Diagram	
7.2.2 Speed Control Mode Block Diagram	
7.2.3 Torque Control Mode Block Diagram	
7.2.4 Full-closed Control Mode Block Diagram	
7.3 Parameters Related To TUNINGLESS	
7.4 Parameters Related To One Minute TUNING	
7.5 Other Parameters Related To Tuning	
7.6 List of Errors Related to One Minute TUNING	
7.7 Glossary	

### 7.1 Object Dictionary List

For how to view the Object Dictionary List, see Operating Instructions (Overall) "6.1 How to Read the Object Table". For details on abbreviations used for document names, see <u>"1.2 Related Documents"</u>.

### 7.1.1 CoE Communication Area (1000h to 1FFFh)

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
1000h	00h	Device type	-	0 to 4294967295	-	U32	ro	No	ALL	No	x	01_0
1001h	00h	Error register	-	0 to 255	-	U8	ro	No	ALL	No	х	_
		• bit 4: Generation of an alarm defined by AL	. status	code				I				01_0
		<ul> <li>bit 7: Generation of an alarm not defined by</li> </ul>	AL st	atus code								
1008h	00h	Manufacturer device name	-	_	_	VS	ro	No	ALL	No	X	01_0
1009h	00h	Manufacturer hardware version	-	_	_	VS	ro	No	ALL	No	x	
100Ah	00h	Manufacturer software version	-	_	_	VS	ro	No	ALL	No	X	
1010h	_	Store parameters	-	_	_	_	_	_	_	-	-	01_0
	00h	Number of entries	- 1	0 to 255	_	U8	ro	No	ALL	No	x	
	01h	Save all parameters	-	0 to 4294967295	1	U32	rw	No	ALL	No	A	
1018h	-	Identity object	-	_	-	-	-	-	-	-	-	01_0
	00h	Number of entries	-	0 to 255	-	U8	ro	No	ALL	No	х	
	01h	Vendor ID	-	0 to 4294967295	_	U32	ro	No	ALL	No	x	
	02h	Product code	-	0 to 4294967295	_	U32	ro	No	ALL	No	х	
	03h	Revision number	-	0 to 4294967295	_	U32	ro	No	ALL	No	х	
	04h	Serial number	-	0 to 4294967295	-	U32	ro	No	ALL	No	х	
10F3h	_	Diagnosis history	-	_	_	-	-	-	-	-	-	01_0
	00h	Number of entries	-	0 to 255	_	U8	ro	No	ALL	No	Х	
	01h	Maximum messages	-	0 to 255	-	U8	ro	No	ALL	No	Х	
	02h	Newest message	-	0 to 255	-	U8	ro	No	ALL	No	Х	
	03h	Newest acknowledged message	-	0 to 255	0	U8	rw	No	ALL	No	A	
	04h	New messages available	-	0 to 1	-	BOOL	ro	No	ALL	No	Х	
	05h	Flags	-	0 to 65535	39	U16	rw	No	ALL	Yes	A	_
		bit 0: Emergency message execution perm	ission									01_0
		bit 5: Diagnosis message clearing informat	ion									
	06h	Diagnosis message 1	-	_	-	OS	ro	No	ALL	No	Х	01_0
				l	•							
	23h	Diagnosis message 30	-	_	-	OS	ro	No	ALL	No	Х	
1600h	-	Receive PDO mapping 1	-	_	-	-	-	-	-	-	-	01_0
	00h	Number of entries	-	0 to 32	4	U8	rw	No	ALL	Yes	s	
	01h	1st receive PDO mapped	-	0 to 4294967295	1614807056	U32	rw	No	ALL	Yes	S	
	02h	2nd receive PDO mapped	-	0 to 4294967295	1616904200	U32	rw	No	ALL	Yes	S	
	03h	3rd receive PDO mapped	-	0 to 4294967295	1618608160	U32	rw	No	ALL	Yes	S	
	04h	4th receive PDO mapped	-	0 to 4294967295	1622671376	U32	rw	No	ALL	Yes	S	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
1600h	05h	5th receive PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	01_0
	06h	6th receive PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
	07h	7th receive PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
	08h	8th receive PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
				1								
	20h	32nd receive PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	s	
1601h		Receive PDO mapping 2	-	_	-	-	—	-	-	_	-	
	00h	Number of entries	-	0 to 32	7	U8	rw	No	ALL	Yes	S	
	01h	1st receive PDO mapped	-	0 to 4294967295	1614807056	U32	rw	No	ALL	Yes	S	
	02h	2nd receive PDO mapped	-	0 to 4294967295	1616904200	U32	rw	No	ALL	Yes	S	
	03h	3rd receive PDO mapped	-	0 to 4294967295	1618018320	U32	rw	No	ALL	Yes	S	
	04h	4th receive PDO mapped	-	0 to 4294967295	1618608160	U32	rw	No	ALL	Yes	S	
	05h	5th receive PDO mapped	-	0 to 4294967295	1619001376	U32	rw	No	ALL	Yes	S	
	06h	6th receive PDO mapped	-	0 to 4294967295	1622671376	U32	rw	No	ALL	Yes	S	
	07h	7th receive PDO mapped	-	0 to 4294967295	1627324448	U32	rw	No	ALL	Yes	S	
	08h	8th receive PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
		Γ		i								
	20h	32nd receive PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
1602h	_	Receive PDO mapping 3	-	_	-	-	-	-	-	-	-	
	00h	Number of entries	-	0 to 32	6	U8	rw	No	ALL	Yes	S	
	01h	1st receive PDO mapped	-	0 to 4294967295	1614807056	U32	rw	No	ALL	Yes	S	
	02h	2nd receive PDO mapped	-	0 to 4294967295	1616904200	U32	rw	No	ALL	Yes	S	
	03h	3rd receive PDO mapped	-	0 to 4294967295	1618083856	U32	rw	No	ALL	Yes	S	
	04h	4th receive PDO mapped	-	0 to 4294967295	1618608160	U32	rw	No	ALL	Yes	S	
	05h	5th receive PDO mapped	-	0 to 4294967295	1622671376	U32	rw	No	ALL	Yes	S	
	06h	6th receive PDO mapped	-	0 to 4294967295	1627324448	U32	rw	No	ALL	Yes	S	
	07h	7th receive PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
	08h	8th receive PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
				:		1.0-	-				-	
	20h	32nd receive PDO mapped	_	0 to 4294967295	0	U32	rw	No	ALL	Yes	s	
1603h	-	Receive PDO mapping 4	-	-	-	-	-	-	-	-	-	
	00h	Number of entries	-	0 to 32	8	U8	rw	No	ALL	Yes	S	
	01h	1st receive PDO mapped	-	0 to 4294967295	1614807056	U32	rw	No	ALL	Yes	S	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
1603h	02h	2nd receive PDO mapped	-	0 to 4294967295	1616904200	U32	rw	No	ALL	Yes	s	01_0
	03h	3rd receive PDO mapped	-	0 to 4294967295	1618018320	U32	rw	No	ALL	Yes	S	
	04h	4th receive PDO mapped	-	0 to 4294967295	1618083856	U32	rw	No	ALL	Yes	S	
	05h	5th receive PDO mapped	-	0 to 4294967295	1618608160	U32	rw	No	ALL	Yes	S	
	06h	6th receive PDO mapped	-	0 to 4294967295	1619001376	U32	rw	No	ALL	Yes	S	
	07h	7th receive PDO mapped	-	0 to 4294967295	1622671376	U32	rw	No	ALL	Yes	S	
	08h	8th receive PDO mapped	-	0 to 4294967295	1627324448	U32	rw	No	ALL	Yes	S	
	09h	9th receive PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
				1								
	20h	32nd receive PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
1A00h	_	Transmit PDO mapping 1	-	_	_	-	_	_	_	_	-	
	00h	Number of entries	-	0 to 32	8	U8	rw	No	ALL	Yes	s	
	01h	1st transmit PDO mapped	-	0 to 4294967295	1614741520	U32	rw	No	ALL	Yes	s	
	02h	2nd transmit PDO mapped	-	0 to 4294967295	1614872592	U32	rw	No	ALL	Yes	S	
	03h	3rd transmit PDO mapped	-	0 to 4294967295	1616969736	U32	rw	No	ALL	Yes	s	
	04h	4th transmit PDO mapped	-	0 to 4294967295	1617166368	U32	rw	No	ALL	Yes	S	
	05h	5th transmit PDO mapped	-	0 to 4294967295	1622736912	U32	rw	No	ALL	Yes	S	
	06h	6th transmit PDO mapped	-	0 to 4294967295	1622802464	U32	rw	No	ALL	Yes	S	
	07h	7th transmit PDO mapped	-	0 to 4294967295	1626603552	U32	rw	No	ALL	Yes	S	
	08h	8th transmit PDO mapped	-	0 to 4294967295	1627193376	U32	rw	No	ALL	Yes	S	
	09h	9th transmit PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
	20h	32nd transmit PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
1A01h	-	Transmit PDO mapping 2	-	-	-	-	-	-	-	-	-	
	00h	Number of entries	-	0 to 32	9	U8	rw	No	ALL	Yes	S	
	01h	1st transmit PDO mapped	-	0 to 4294967295	1614741520	U32	rw	No	ALL	Yes	S	
	02h	2nd transmit PDO mapped	-	0 to 4294967295	1614872592	U32	rw	No	ALL	Yes	S	
	03h	3rd transmit PDO mapped	-	0 to 4294967295	1616969736	U32	rw	No	ALL	Yes	S	
	04h	4th transmit PDO mapped	-	0 to 4294967295	1617166368	U32	rw	No	ALL	Yes	S	
	05h	5th transmit PDO mapped	-	0 to 4294967295	1617690656	U32	rw	No	ALL	Yes	S	
	06h	6th transmit PDO mapped	-	0 to 4294967295	1618411536	U32	rw	No	ALL	Yes	S	
	07h	7th transmit PDO mapped	-	0 to 4294967295	1622736912	U32	rw	No	ALL	Yes	S	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
1A01h	08h	8th transmit PDO mapped	-	0 to 4294967295	1622802464	U32	rw	No	ALL	Yes	S	01_0
	09h	9th transmit PDO mapped	-	0 to 4294967295	1627193376	U32	rw	No	ALL	Yes	S	
	0Ah	10th transmit PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
		1		:								
	20h	32nd transmit PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
1A02h	_	Transmit PDO mapping 3	-	_	-	-	-	-	-	-	-	
	00h	Number of entries	-	0 to 32	9	U8	rw	No	ALL	Yes	S	
	01h	1st transmit PDO mapped	-	0 to 4294967295	1614741520	U32	rw	No	ALL	Yes	S	
	02h	2nd transmit PDO mapped	-	0 to 4294967295	1614872592	U32	rw	No	ALL	Yes	S	
	03h	3rd transmit PDO mapped	-	0 to 4294967295	1616969736	U32	rw	No	ALL	Yes	S	
	04h	4th transmit PDO mapped	-	0 to 4294967295	1617166368	U32	rw	No	ALL	Yes	S	
	05h	5th transmit PDO mapped	-	0 to 4294967295	1617690656	U32	rw	No	ALL	Yes	S	
	06h	6th transmit PDO mapped	-	0 to 4294967295	1618411536	U32	rw	No	ALL	Yes	S	
	07h	7th transmit PDO mapped	-	0 to 4294967295	1622736912	U32	rw	No	ALL	Yes	S	
	08h	8th transmit PDO mapped	-	0 to 4294967295	1622802464	U32	rw	No	ALL	Yes	S	
	09h	9th transmit PDO mapped	-	0 to 4294967295	1627193376	U32	rw	No	ALL	Yes	S	
	0Ah	10th transmit PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
				ł								
	20h	32nd transmit PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
1A03h	-	Transmit PDO mapping 4	-	_	-	-	-	-	-	-	-	
	00h	Number of entries	-	0 to 32	9	U8	rw	No	ALL	Yes	s	
	01h	1st transmit PDO mapped	-	0 to 4294967295	1614741520	U32	rw	No	ALL	Yes	S	
	02h	2nd transmit PDO mapped	-	0 to 4294967295	1614872592	U32	rw	No	ALL	Yes	S	
	03h	3rd transmit PDO mapped	-	0 to 4294967295	1616969736	U32	rw	No	ALL	Yes	S	
	04h	4th transmit PDO mapped	-	0 to 4294967295	1617166368	U32	rw	No	ALL	Yes	S	
	05h	5th transmit PDO mapped	-	0 to 4294967295	1617690656	U32	rw	No	ALL	Yes	S	
	06h	6th transmit PDO mapped	-	0 to 4294967295	1618411536	U32	rw	No	ALL	Yes	S	
	07h	7th transmit PDO mapped	-	0 to 4294967295	1622736912	U32	rw	No	ALL	Yes	S	
	08h	8th transmit PDO mapped	-	0 to 4294967295	1622802464	U32	rw	No	ALL	Yes	S	
	09h	9th transmit PDO mapped	-	0 to 4294967295	1627193376	U32	rw	No	ALL	Yes	S	
	0Ah	10th transmit PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	
				!								
	20h	32nd transmit PDO mapped	-	0 to 4294967295	0	U32	rw	No	ALL	Yes	S	

Index	Sub-Index	Zame	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
1C00h	-	Sync manager communication type	-	_	_	-	-	-	-	-	-	01_0
	00h	Number of used sync manager channels	-	0 to 255	_	U8	ro	No	ALL	No	х	
	01h	Communication type sync manager 0	-	0 to 4	_	U8	ro	No	ALL	No	Х	
	02h	Communication type sync manager 1	-	0 to 4	_	U8	ro	No	ALL	No	х	
	03h	Communication type sync manager 2	-	0 to 4	_	U8	ro	No	ALL	No	х	
	04h	Communication type sync manager 3	-	0 to 4	_	U8	ro	No	ALL	No	х	
1C12h	-	Sync manager channel 2	-	_	_	-	-	-	-	-	-	01_0
	00h	Number of assigned PDOs	-	0 to 4	1	U8	rw	No	ALL	Yes	s	
	01h	PDO mapping object index of assigned RxPDO 1	-	1600h to 1603h	5632	U16	rw	No	ALL	Yes	S	
	02h	PDO mapping object index of assigned RxPDO 2	-	1600h to 1603h	5633	U16	rw	No	ALL	Yes	S	
	03h	PDO mapping object index of assigned RxPDO 3	-	1600h to 1603h	5634	U16	rw	No	ALL	Yes	S	
	04h	PDO mapping object index of assigned RxPDO 4	-	1600h to 1603h	5635	U16	rw	No	ALL	Yes	S	
1C13h	-	Sync manager channel 3	-	_	_	-	-	—	_	-	-	
	00h	Number of assigned PDOs	-	0 to 4	1	U8	rw	No	ALL	Yes	s	
	01h	PDO mapping object index of assigned TxPDO 1	-	1A00h to 1A03h	6656	U16	rw	No	ALL	Yes	S	
	02h	PDO mapping object index of assigned TxPDO 2	-	1A00h to 1A03h	6657	U16	rw	No	ALL	Yes	S	
	03h	PDO mapping object index of assigned TxPDO 3	-	1A00h to 1A03h	6658	U16	rw	No	ALL	Yes	S	
	04h	PDO mapping object index of assigned TxPDO 4	-	1A00h to 1A03h	6659	U16	rw	No	ALL	Yes	S	
1C32h	_	Sync manager 2 synchronization	-	—	—	-	-	—	—	—	-	01_0
	00h	Number of sub-objects	-	0 to 255	_	U8	ro	No	ALL	No	х	
	01h	Sync mode	-	0 to 65535	2	U16	rw	No	ALL	Yes	S	
	02h	Cycle time	ns	0 to 4294967295	1000000	U32	rw	No	ALL	Yes	S	
	03h	Shift time	ns	0 to 4294967295	_	U32	ro	No	ALL	No	х	
	04h	Sync modes supported	-	0 to 65535	—	U16	ro	No	ALL	No	Х	—
		bit 0: FreeRun mode support										01_0
		bit 1: SM Synchronous mode support										01_0
		• bits 4 to 2: DC synchronous mode support										01_0
		bits 6 to 5: Output shift support							-			01_0
	05h	Minimum cycle time	ns	0 to 4294967295	_	U32	ro	No	ALL	No	Х	01_0
	06h	Calc and copy time	ns	0 to 4294967295	_	U32	ro	No	ALL	No	Х	
	08h	Command	-	0 to 65535	_	U16	ro	No	ALL	No	х	
	09h	Delay time	ns	0 to 4294967295	_	U32	ro	No	ALL	No	Х	
	0Ah	Sync0 cycle time	ns	0 to 4294967295	-	U32	ro	No	ALL	No	х	
	0Bh	SM-event missed	_	0 to 65535	_	U16	ro	No	ALL	No	Х	
	0Ch	Cycle time too small	_	0 to 65535	_	U16	ro	No	ALL	No	Х	
	0Dh	Shift time too short	-	0 to 65535	_	U16	ro	No	ALL	No	Х	
	0Eh	RxPDO toggle failed	-	0 to 65535	-	U16	ro	No	ALL	No	Х	
	20h	Sync error	-	0 to 1	-	BOOL	ro	No	ALL	No	Х	
1C33h	-	Sync manager 3 synchronization	-	_	_	-	-	-	-	-	-	
	00h	Number of sub-objects	-	0 to 255	-	U8	ro	No	ALL	No	х	

Index	Sub-Index	Zame	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
1C33h	01h	Sync mode	-	0 to 65535	2	U16	rw	No	ALL	Yes	S	01_0
	02h	Cycle time	ns	0 to 4294967295	_	U32	ro	No	ALL	No	Х	
	03h	Shift time	ns	0 to 4294967295	0	U32	rw	No	ALL	No	S	
	04h	Sync modes supported	-	0 to 65535	_	U16	ro	No	ALL	No	Х	-
		bit 0: FreeRun mode support										01_0
		bit 1: SM Synchronous mode support										01_0
		• bits 4 to 2: DC synchronous mode support										01_0
		• bits 6 to 5: Output Shift Support Input Shift	Suppo	rt								01_0
	05h	Minimum cycle time	ns	0 to 4294967295	-	U32	ro	No	ALL	No	х	OI_O
	06h	Calc and copy time	ns	0 to 4294967295	-	U32	ro	No	ALL	No	х	
	08h	Command	-	0 to 65535	_	U16	ro	No	ALL	No	Х	
	09h	Delay time	ns	0 to 4294967295	_	U32	ro	No	ALL	No	Х	
	0Ah	Sync0 cycle time	ns	0 to 4294967295	-	U32	ro	No	ALL	No	х	
	0Bh	SM-event missed	-	0 to 65535	_	U16	ro	No	ALL	No	Х	
	0Ch	Cycle time too small	-	0 to 65535	_	U16	ro	No	ALL	No	Х	
	0Dh	Shift time too short	-	0 to 65535	_	U16	ro	No	ALL	No	Х	
	0Eh	RxPDO toggle failed	-	0 to 65535	_	U16	ro	No	ALL	No	Х	
	20h	Sync error	-	0 to 1	_	BOOL	ro	No	ALL	No	Х	

### 7.1.2 Servo Parameter Area (3000h to 3FFFh)

For correspondence between parameter numbers and object numbers, see Operating Instructions (Overall) "6.4 Servo Parameter Area (3000h to 3FFFh) Details".

### 7.1.2.1 Class 0: Basic Settings

										_		—: N/A
Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3000h	00h	Reserved	_	_	1	116	-	-	_	-	-	_
3001h	00h	Control mode setup	_	0 to 6	0	116	rw	No	ALL	Yes	R	01_0
3002h	00h	Real-time auto-gain tuning setup	_	0 to 7	1	I16	rw	No	ALL	Yes	в	<u>"4.1.1.4"</u>
3003h	00h	Real-time auto-tuning machine stiffness setup	_	0 to 31	Sizes A, B: 13 Sizes C, D: 11 (13) <sup>(*3)</sup>	116	rw	No	ALL	Yes	В	<u>"4.1.2.4"</u> <u>"4.1.3.4"</u>
3004h	00h	Inertia ratio	%	0 to 100000	250	132	rw	No	ALL	Yes	В	<u>"7.5"</u>
3008h	00h	Reserved	—	—	0	132	-	—	—	-	-	_
3009h	00h	Reserved	_	_	1	132	-	-	_	-	-	
3010h	00h	Reserved	_	_	1	132	-	-	_	-	-	
3011h	00h	Number of output pulses per mo- tor revolution	pulse/r	1 to 33554432	2500	132	rw	No	ALL	Yes	R	01_0
3012h	00h	Reversal of pulse output logic	_	0 to 3	0	I16	rw	No	ALL	Yes	R	
3013h	00h	1st torque limit	%	0 to 500	500 (*2)	116	rw	No	ALL	Yes	В	01_0
3014h	00h	Position deviation excess setup	Command unit	0 to 1073741824	83886080	132	rw	No	csp pp hm ip	Yes	A	01_0
3015h	00h	Absolute encoder setup	_	0 to 4	1	116	rw	No	csp (S) pp (S) hm (S) ip (S) csv (S) pv (S) cst (S) tq (S)	Yes	С	0I_0
3016h	00h	External regenerative resistor set- up	-	0 to 3	Sizes A, B: 3 Sizes C, D: 0	I16	rw	No	ALL	Yes	С	01_0
3017h	00h	Selection of load factor for exter- nal regenerative resistor	_	0 to 4	0	I16	rw	No	ALL	Yes	С	
3018h	00h	Reserved	_	_	0	116	-	-	_	-	-	_
3022h	00h	Sensor feedback control mode setup (*1)	_	0 to 1	0	I16	rw	No	csp	Yes	R	01_0
3027h	00h	Selection of machine stiffness at real-time auto-gain tuning 2	-	0 to 44	Sizes A, B: 16 Sizes C, D: 12 (16) <sup>(*3)</sup>	116	rw	No	ALL	Yes	В	<u>"4.1.1.4"</u> <u>"4.1.2.4"</u> <u>"4.1.3.4"</u>
3028h	00h	Selection of feed forward stiffness at real-time auto-gain tuning	_	0 to 44	Sizes A, B: 16 Sizes C, D: 12 (16) <sup>(*3)</sup>	116	rw	No	ALL	Yes	В	

\*1 Cannot be used with the standard type or multi-function type. Do not change the factory default value.

\*2 Factory default values vary depending on the servo driver and motor combination.

For details, see Operating Instructions (Overall) "8.1 Torque Limit Switching Function" .

\*3 Values in parentheses are initial values for models with an instantaneous maximum current (peak value) of less than 24 A.

## 7.1.2.2 Class 1: Gain Adjustment

												—: N/A
Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3100h	00h	1st gain of position loop	0.1 s <sup>-1</sup>	0 to 30000	Sizes A, B: 480 Sizes C, D: 320 (480) <sup>(*1)</sup>	116	rw	No	csp pp hm ip	Yes	В	<u>"4.1.1.4"</u> <u>"4.1.2.4"</u> <u>"4.1.3.4"</u>
3101h	00h	1st velocity loop gain	0.1 Hz	1 to 32767	Sizes A, B: 270 Sizes C, D: 180 (270) <sup>(*1)</sup>	116	rw	No	ALL	Yes	В	
3102h	00h	1st velocity loop integration time constant	0.1 ms	1 to 10000	Sizes A, B: 210 Sizes C, D: 310 (210) <sup>(*1)</sup>	I16	rw	No	ALL	Yes	В	
3103h	00h	1st filter of velocity detection	-	0 to 5	0	116	rw	No	ALL	Yes	в	
3104h	00h	1st torque filter time constant	0.01 ms	0 to 2500	Sizes A, B: 84 Sizes C, D: 126 (84) <sup>(*1)</sup>	116	rw	No	ALL	Yes	В	<u>"5.1.3"</u>
3105h	00h	2nd gain of position loop	0.1 s <sup>-1</sup>	0 to 30000	Sizes A, B: 480 Sizes C, D: 320 (480) <sup>(*1)</sup>	116	rw	No	csp pp hm ip	Yes	В	<u>"7.5"</u>
3106h	00h	2nd velocity loop gain	0.1 Hz	1 to 32767	Sizes A, B: 270 Sizes C, D: 180 (270) <sup>(*1)</sup>	116	rw	No	ALL	Yes	В	
3107h	00h	2nd velocity loop integration time constant	0.1 ms	1 to 10000	Sizes A, B: 210 Sizes C, D: 310 (210) <sup>(*1)</sup>	116	rw	No	ALL	Yes	В	
3108h	00h	2nd filter of velocity detection	_	0 to 5	0	I16	rw	No	ALL	Yes	в	
3109h	00h	2nd torque filter time constant	0.01 ms	0 to 2500	Sizes A, B: 84 Sizes C, D: 126 (84) <sup>(*1)</sup>	116	rw	No	ALL	Yes	В	<u>"5.1.3"</u>
3110h	00h	Velocity feed forward gain	0.1%	0 to 4000	1000	116	rw	No	csp pp hm ip	Yes	В	<u>"4.4.3"</u>
3111h	00h	Velocity feed forward filter	0.01 ms	0 to 6400	0	116	rw	No	csp pp hm ip	Yes	В	
3112h	00h	Torque feed forward gain	0.1%	0 to 2000	1000	I16	rw	No	ALL	Yes	В	
3113h	00h	Torque feed forward filter	0.01 ms	0 to 6400	0	I16	rw	No	ALL	Yes	в	
3114h	00h	2nd gain setup	_	0 to 1	1	I16	rw	No	ALL	Yes	в	<u>"4.2.3"</u>
3115h	00h	Mode of position control switching	-	0 to 10	0	116	rw	No	csp pp hm ip	Yes	В	<u>"4.3.3"</u>
3116h	00h	Delay time of position control switching	0.1 ms	0 to 10000	10	116	rw	No	csp pp hm ip	Yes	В	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3117h	00h	Level of position control switching	-	0 to 20000	0	116	rw	No	csp pp hm ip	Yes	В	<u>"4.2.3"</u>
3118h	00h	Hysteresis at position control switching	_	0 to 20000	0	116	rw	No	csp pp hm ip	Yes	В	
3119h	00h	Position gain switching time	0.1 ms	0 to 10000	10	116	rw	No	csp pp hm ip	Yes	В	
3120h	00h	Mode of velocity control switching	-	0 to 5	0	116	rw	No	csv pv	Yes	В	
3121h	00h	Delay time of velocity control switching	0.1 ms	0 to 10000	0	I16	rw	No	csv pv	Yes	В	
3122h	00h	Level of velocity control switching	_	0 to 20000	0	116	rw	No	csv pv	Yes	В	
3123h	00h	Hysteresis at velocity control switching	_	0 to 20000	0	116	rw	No	csv pv	Yes	В	
3124h	00h	Mode of torque control switching	-	0 to 3	0	116	rw	No	cst tq	Yes	В	
3125h	00h	Delay time of torque control switching	0.1 ms	0 to 10000	0	I16	rw	No	cst tq	Yes	В	
3126h	00h	Level of torque control switching	_	0 to 20000	0	I16	rw	No	cst tq	Yes	В	
3127h	00h	Hysteresis at torque control switching	-	0 to 20000	0	I16	rw	No	cst tq	Yes	В	
3128h	00h	Reserved	-	_	0	I16	-	-	_	-	-	_
04705	0.01-	Deserved	:		0	14.0						
3176h	00h		0/	- 0 to 300	100	110	-		_	- Voc		"75"
31A7h	00h	1st velocity integration change ratio	%	0 to 300	100	116	rw	No	ALL	Yes	В	_1.0_
31A8h	00h	1st torque filter change ratio	%	0 to 300	100	116	rw	No	ALL	Yes	В	
31A9h	00h	2nd position loop gain change ratio	%	0 to 300	100	I16	rw	No	ALL	Yes	В	
31B0h	00h	2nd velocity loop gain change ratio	%	0 to 300	100	I16	rw	No	ALL	Yes	В	
31B1h	00h	2nd velocity integration change ratio	%	0 to 300	100	I16	rw	No	ALL	Yes	В	
31B2h	00h	2nd torque filter change ratio	%	0 to 300	100	I16	rw	No	ALL	Yes	В	
31B3h	00h	Load fluctuation compensation filter change ratio	%	0 to 300	100	116	rw	No	ALL	Yes	В	
31B4h	00h	Smoothing filter change ratio	%	0 to 300	100	I16	rw	No	ALL	Yes	В	
31B5h	00h	Tuning filter change ratio	%	0 to 300	100	I16	rw	No	ALL	Yes	В	

\*1 Values in parentheses are initial values for models with an instantaneous maximum current (peak value) of less than 24 A.

# 7.1.2.3 Class 2: Vibration Suppression

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3200h	00h	Adaptive filter mode setup	_	0 to 6	0	116	rw	No	csp pp hm ip csv pv	Yes	В	<u>"5.4.3"</u>
3201h	00h	1st notch frequency	Hz	10 to 5000	5000	I16	rw	No	ALL	Yes	В	<u>"5.3.3"</u>
3202h	00h	1st notch width selection	_	0 to 20	2	I16	rw	No	ALL	Yes	В	
3203h	00h	1st notch depth selection	-	0 to 99	0	I16	rw	No	ALL	Yes	В	
3204h	00h	2nd notch frequency	Hz	10 to 5000	5000	I16	rw	No	ALL	Yes	В	
3205h	00h	2nd notch width selection	-	0 to 20	2	I16	rw	No	ALL	Yes	В	
3206h	00h	2nd notch depth selection	_	0 to 99	0	I16	rw	No	ALL	Yes	В	
3207h	00h	3rd notch frequency	Hz	10 to 5000	5000	I16	rw	No	ALL	Yes	В	<u>"5.3.3"</u>
3208h	00h	3rd notch width selection	-	0 to 20	2	I16	rw	No	ALL	Yes	В	<u>"5.4.3"</u>
3209h	00h	3rd notch depth selection	-	0 to 99	0	I16	rw	No	ALL	Yes	В	
3210h	00h	4th notch frequency	Hz	10 to 5000	5000	I16	rw	No	ALL	Yes	В	
3211h	00h	4th notch width selection	-	0 to 20	2	I16	rw	No	ALL	Yes	В	
3212h	00h	4th notch depth selection	-	0 to 99	0	I16	rw	No	ALL	Yes	В	
3213h	00h	Selection of damping filter switching	_	0 to 7	0	116	rw	No	csp pp hm ip	Yes	В	<u>"5.5.3"</u> "5.6.3"
3214h	00h	1st damping frequency	0.1 Hz	0 to 3000	0	116	rw	No	csp pp hm ip	Yes	В	<u>"5.5.3"</u>
3215h	00h	1st damping filter setup	0.1 Hz	0 to 1500	0	116	rw	No	csp pp hm ip	Yes	В	
3216h	00h	2nd damping frequency	0.1 Hz	0 to 3000	0	116	rw	No	csp pp hm ip	Yes	В	
3217h	00h	2nd damping filter setup	0.1 Hz	0 to 1500	0	116	rw	No	csp pp hm ip	Yes	В	
3218h	00h	3rd damping frequency	0.1 Hz	0 to 3000	0	116	rw	No	csp pp hm ip	Yes	В	
3219h	00h	3rd damping filter setup	0.1 Hz	0 to 1500	0	116	rw	No	csp pp hm ip	Yes	В	
3220h	00h	4th damping frequency	0.1 Hz	0 to 3000	0	116	rw	No	csp pp hm ip	Yes	В	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3221h	00h	4th damping filter setup	0.1 Hz	0 to 1500	0	116	rw	No	csp pp hm ip	Yes	В	<u>"5.5.3"</u>
3222h	00h	Positional command smoothing filter	0.1 ms	0 to 10000	Sizes A, B: 92 Sizes C, D: 139 (92) <sup>(*1)</sup>	116	rw	No	csp pp hm ip csv pv	Yes	В	<u>"5.7.3"</u> OI_O
3223h	00h	Positional command FIR filter	0.1 ms	0 to 10000	10	116	rw	No	csp pp hm ip	Yes	В	<u>"5.7.3"</u>
3224h	00h	5th notch frequency	Hz	10 to 5000	5000	116	rw	No	ALL	Yes	В	<u>"5.3.3"</u>
3225h	00h	5th notch width selection	_	0 to 20	2	116	rw	No	ALL	Yes	В	
3226h	00h	5th notch depth selection	_	0 to 99	0	116	rw	No	ALL	Yes	В	
3227h	00h	1st damping width setting	_	0 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	<u>"5.5.3"</u>
3228h	00h	2nd damping width setting	_	0 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	
3229h	00h	3rd damping width setting	_	0 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	
3230h	00h	4th damping width setting	_	0 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	
3231h	00h	Reserved	-	_	0	I16	-	_	-	_	-	_
			1									
3237h	00h	Reserved	-	_	0	I16	-	-	-	-	-	
3238h	00h	Filter function switching	—	-32768 to 32767	3	116	rw	No	ALL	Yes	В	_
		bit 0: Custom notch filter										01_0
		• bit 1: Tuning filter 2										<u>"4.1.1.4"</u> <u>"4.1.2.4"</u> <u>"4.1.3.4"</u> Ol_O
3239h	00h	Custom notch compensation coefficient	0.01	0 to 1000	0	116	rw	No	ALL	Yes	В	OI_0
3240h	00h	Custom notch compensation frequency1	0.1 Hz	0 to 10000	0	116	rw	No	ALL	Yes	В	<u>"5.3.3"</u>
3241h	00h	Custom notch compensation frequency2	0.1 Hz	0 to 10000	0	116	rw	No	ALL	Yes	В	
3242h	00h	Custom notch frequency	Hz	10 to 5000	5000	116	rw	No	ALL	Yes	В	
3243h	00h	Custom notch width	_	0 to 20	2	116	rw	No	ALL	Yes	В	
3244h	00h	Eulection expansion setup 10	_	0 to 99	61	116	rw	No	ALL	Yes	в	
524511	oon	T anotion expansion setup 10	_	2147483647	UI	132	1.00	140		162		_
		• bit 1 to 0: Two-degree-of-freedom control	function se	tting								<u>"4.1.1.4"</u> "4.1.2.4"
												<u>"4.1.3.4"</u> OL O
		• bit 2: Friction torque compensation param	neter select	ion								<u>"7.5"</u>

Index	Sub-Index	Rame	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3245h	00h	<ul> <li>bit 3: Load fluctuation suppression function</li> <li>bit 5 to 4: Stiffness setting resolution, indi</li> </ul>	on automati	c calculation								<u>"4.1.1.4"</u> <u>"4.1.2.4"</u> <u>"4.1.3.4"</u> <u>"4.6.3"</u> <u>"4.7.3"</u> <u>"4.1.1.4"</u>
												<u>"4.1.2.4"</u> <u>"4.1.3.4"</u>
3246h	00h	Tuning filter 2	0.01 ms	0 to 20000	Size A: 110 Size B: 120 Sizes C, D: 170 (120) <sup>(*1)</sup>	116	rw	No	csp pp hm ip	Yes	В	OI_O
3250h	00h	Detection start vibration count	_	0 to 100	3	I16	rw	No	csp pp	Yes	В	<u>"5.5.3"</u>
3251h	00h	Detected vibration amplitude	Com- mand unit	0 to 134217728	0	132	rw	No	csp pp	Yes	В	
3252h	00h	Torque command additional value 2	0.1%	-1000 to 1000	0	116	rw	No	csp pp hm ip csv pv	Yes	В	<u>"4.5.3"</u>
3253h	00h	Positive direction torque compensation value 2	0.1%	-1000 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	
3254h	00h	Negative direction torque compensation value 2	0.1%	-1000 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	
3261h	00h	Target settling time	ms	0 to 32767	0	116	rw	No	ALL	Yes	А	<u>"7.5"</u>
3262h	00h	Settling time count condition	_	0 to 1	0	116	rw	No	ALL	Yes	А	
3263h	00h	Allowable overshoot amount	%	0 to 500	100	116	rw	No	ALL	Yes	А	
3264h	00h	Tuning amount of movement	Com- mand unit	0 to 2147483647	0	132	rw	No	ALL	Yes	A	
3265h	00h	Tuning max speed	r/min	0 to 20000	0	116	rw	No	ALL	Yes	А	
3266h	00h	Tuning acceleration and deceleration time	ms	0 to 5000	0	I16	rw	No	ALL	Yes	А	
3267h	00h	Tuning wait time	ms	0 to 10000	2000	I16	rw	No	ALL	Yes	А	
3268h	00h	Tuning operating range upper limit	Com- mand unit	0 to 1073741823	8388608	132	rw	No	ALL	Yes	A	
3269h	00h	Tuning operating range lower limit	Com- mand unit	-1073741824 to 0	-8388608	132	rw	No	ALL	Yes	A	
3270h	00h	Tuning overspeed level setting	r/min	0 to 20000	0	I16	rw	No	ALL	Yes	А	
3271h	00h	Tuning torque limit	%	0 to 500	0	116	rw	No	ALL	Yes	А	
3272h	00h	Tuning start RTAT machine stiffness setting	_	0 to 44	8	116	rw	No	ALL	Yes	А	
3273h	00h	Tuning stability margin	%	0 to 100	80	116	rw	No	ALL	Yes	А	
3274h	00h	Tuning auto tuning application selection	_	-32768 to 32767	0	116	rw	No	ALL	Yes	A	<u>"4.1.1.4"</u> <u>"4.1.2.4"</u> <u>"4.1.3.4"</u>
3275h	00h	Tuning step selection	-	-32768 to 32767	3	I16	rw	No	ALL	Yes	А	-
		• bit 0: Advance operation										<u>"7.5"</u>
		bit 1: Homing operation										
3276h	00h	Tuning target function selection	_	-32768 to 32767	1009	116	rw	No	ALL	Yes	А	-

Index	Sub-Index	Aame	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference		
3276h	00h	• bit 0: Inertia ratio		•	•							<u>"7.5"</u>		
		• bit 1: Unbalanced load compensation (de	fault disabl	ed)										
		• bit 2: Dynamic friction compensation (def	ault disable	d)										
		• bit 3: Viscous friction compensation (defa	ult disabled	1)										
		• bit 4: RTAT machine stiffness setting (pos	machine stiffness setting (position and speed gains, speed integration time constant, torque filter)											
		• bit 5: RTAT feedforward control section st	5: RTAT feedforward control section stiffness setting (smoothing filter time constant)											
		• bit 6: Notch filter	6: Notch filter											
		• bit 7: 1st damping filter												
		• bit 8: 2nd damping filter												
		• bit 9: Load fluctuation control function												
3277h	00h	Tuning start position	Com- mand unit	-1073741824 to 1073741823	0	132	rw	No	ALL	Yes	A	<u>"7.5"</u>		
3278h	00h	Tuning vibration automatic suppression ef- fective level	%	0 to 100	15	116	rw	No	ALL	Yes	A			
3279h	00h	Tuning JOG test run command speed	r/min	0 to 500	60	116	rw	No	ALL	Yes	А			
3280h	00h	Tuning JOG test run acceleration and de- celeration time	ms	0 to 5000	50	116	rw	No	ALL	Yes	А			

\*1 Values in parentheses are initial values for models with an instantaneous maximum current (peak value) of less than 24 A.

### 7.1.2.4 Class 3: Velocity/Torque Control/Full-closed Control

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3304h	00h	Reserved	_	_	0	I16	-	-	_	-	-	_
		1		!								
3307h	00h	Reserved	_	-	0	I16	-	-	_	-	-	
3312h	00h	Acceleration time setup	ms/ (1000 r/min)	0 to 10000	0	116	rw	No	csv pv	Yes	В	<u>"5.8.3"</u>
3313h	00h	Deceleration time setup	ms/ (1000 r/min)	0 to 10000	0	116	rw	No	csv pv	Yes	В	
3314h	00h	Sigmoid acceleration / decelera- tion time setup	ms	0 to 1000	0	116	rw	No	csv pv	Yes	В	
3317h	00h	Selection of speed limit	-	2	2	116	rw	No	cst tq	Yes	В	01_0
3321h	00h	Reserved	_	-	0	I16	-	-	_	-	-	_
3322h	00h	Reserved	-	-	0	116	-	-	_	-	-	_
3323h	00h	External scale selection	_	0 to 2	0	116	rw	No	ALL	Yes	R	01_0
3324h	00h	Numerator of external scale division	-	0 to 134217728	0	132	rw	No	csp (F) pp (F) hm (F) ip (F)	Yes	R	01_0
3325h	00h	Denominator of external scale di- vision	_	1 to 134217728	10000	132	rw	No	csp (F) pp (F) hm (F) ip (F)	Yes	R	
3326h	00h	Reversal of direction of external scale	-	0 to 3	0	116	rw	No	ALL	Yes	R	01_0
3327h	00h	External scale Z phase discon- nection detection disable	_	0 to 1	0	116	rw	No	ALL	Yes	R	01_0
3328h	00h	Hybrid deviation excess setup	Command unit	1 to 134217728	16000	132	rw	No	csp (F) pp (F) hm (F) ip (F)	Yes	С	01_0
3329h	00h	Hybrid deviation clear setup	Rotation	0 to 100	0	116	rw	No	csp (F) pp (F) hm (F) ip (F)	Yes	С	
3333h (*1)	00h	Analog input gain	Command unit/mV	0 to 30000	0	116	rw	No	csp	Yes	В	01_0
3334h (*1)	00h	Analog input polarity	-	0 to 1	0	116	rw	No	csp	Yes	В	
3335h (*1)	00h	Analog input integration time con- stant	0.01 ms	0 to 100000	0	132	rw	No	csp	Yes	В	
3336h (*1)	00h	Analog input integration limit	Command unit/mV	0 to 2147483647	0	132	rw	No	csp	Yes	В	

\*1 Cannot be used with the standard type or multi-function type. Do not change the factory default value.

## 7.1.2.5 Class 4: I/O Monitor Settings

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3400h	00h	SI1 input selection	_	0 to 16777215	3289650	132	rw	No	ALL	Yes	С	01_0
3401h	00h	SI2 input selection	_	0 to 16777215	8487297	132	rw	No	ALL	Yes	С	
3402h	00h	SI3 input selection	_	0 to 16777215	8553090	132	rw	No	ALL	Yes	С	
3403h	00h	SI4 input selection	_	0 to 16777215	2236962	132	rw	No	ALL	Yes	С	
3404h	00h	SI5 input selection	_	0 to 16777215	2105376	132	rw	No	ALL	Yes	С	
3405h	00h	SI6 input selection	_	0 to 16777215	2171169	132	rw	No	ALL	Yes	С	
3406h	00h	SI7 input selection	_	0 to 16777215	3158064	132	rw	No	ALL	Yes	С	
3407h	00h	SI8 input selection	_	0 to 16777215	3223857	132	rw	No	ALL	Yes	С	
3410h	00h	SO1 output selection	_	0 to 16777215	197379	132	rw	No	ALL	Yes	С	0I_0
3411h	00h	SO2 output selection	_	0 to 16777215	1052688	132	rw	No	ALL	Yes	С	
3412h	00h	SO3 output selection	_	0 to 16777215	65793	132	rw	No	ALL	Yes	С	
3416h	00h	Type of analog monitor 1	_	0 to 35	0	I16	rw	No	ALL	Yes	А	0I_0
3417h	00h	Analog monitor 1 output gain	_	0 to 214748364	0	132	rw	No	ALL	Yes	А	
3418h	00h	Type of analog monitor 2	_	0 to 35	4	I16	rw	No	ALL	Yes	А	
3419h	00h	Analog monitor 2 output gain	_	0 to 214748364	0	132	rw	No	ALL	Yes	А	
3421h	00h	Analog monitor output setup	_	0 to 2	0	116	rw	No	ALL	Yes	А	
3422h (*1)	00h	Analog input (AIN) offset setting	0.375 mV	-26666 to 26666	0	I16	rw	No	ALL	Yes	В	0I_0
3423h (*1)	00h	Analog input (AIN) filter setting	0.01 ms	0 to 6400	0	I16	rw	No	ALL	Yes	В	
3424h (*1)	00h	Analog input (AIN) excessive setting	0.1 V	0 to 100	0	I16	rw	No	ALL	Yes	В	
3431h	00h	Positioning complete (In-position) range	Command unit	0 to 2097152	8400	132	rw	No	csp pp hm ip	Yes	A	<u>"7.5"</u> Ol_O
3432h	00h	Positioning complete (In-position) output setup	_	0 to 10	0	116	rw	No	csp pp hm ip	Yes	A	01_0
3433h	00h	INP hold time	ms	0 to 30000	0	116	rw	No	csp pp hm ip	Yes	A	
3434h	00h	Zero-speed	r/min	10 to 20000	50	I16	rw	No	ALL	Yes	А	0I_0
3435h	00h	Speed coincidence range	r/min	10 to 20000	50	116	rw	No	csv pv cst tq	Yes	A	01_0
3436h	00h	At-speed (Speed arrival)	r/min	10 to 20000	1000	116	rw	No	csv pv cst tq	Yes	A	OI_O
3437h	00h	Mechanical brake action at stalling setup	ms	0 to 10000	0	I16	rw	No	ALL	Yes	В	OI_0
3438h	00h	Mechanical brake action at running setup	ms	0 to 32000	0	I16	rw	No	ALL	Yes	В	OI_O
3439h	00h	Brake release speed setup	r/min	30 to 3000	30	I16	rw	No	ALL	Yes	В	01_0
3440h	00h	Selection of alarm output 1	-	0 to 32767	0	I16	rw	No	ALL	Yes	А	01_0
3441h	00h	Selection of alarm output 2	_	0 to 32767	0	I16	rw	No	ALL	Yes	А	

Index	Sub-Index	Zame	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3442h	00h	Positioning complete (In-position) range 2	Command unit	0 to 2097152	8400	132	rw	No	csp pp hm ip	Yes	A	01_0
3444h	00h	Position comparison output pulse width setting	0.1 ms	0 to 32767	0	116	rw	No	ALL	Yes	R	01_0
3445h	00h	Position comparison output polarity se- lection	_	0 to 7	0	116	rw	No	ALL	Yes	R	—
		<ul> <li>bit 0: Polarity for SO1 (general-purpose</li> </ul>	e output) or O	CMP1 (encoder/po	sition comparis	on outp	ut te	rmina	l)			0I_0
		<ul> <li>bit 1: Polarity for SO2 (general-purpose</li> </ul>	e output) or O	CMP2 (encoder/po	sition comparis	on outp	ut te	rmina	l)			
		bit 2: Polarity for SO3 (general-purpose	e output) or O	CMP3 (encoder/po	sition comparis	on outp	ut te	rmina	l)			
3447h	00h	Pulse output selection	_	0 to 1	0	116	rw	No	ALL	Yes	R	0I_0
3448h	00h	Position comparison value 1	Command unit	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	A	01_0
3449h	00h	Position comparison value 2	Command unit	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	A	
3450h	00h	Position comparison value 3	Command unit	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	A	
3451h	00h	Position comparison value 4	Command unit	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	A	
3452h	00h	Position comparison value 5	Command unit	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	A	
3453h	00h	Position comparison value 6	Command unit	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	A	
3454h	00h	Position comparison value 7	Command unit	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	A	
3455h	00h	Position comparison value 8	Command unit	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	A	
3456h	00h	Position comparison output delay com- pensation amount	0.1 µs	-32768 to 32767	0	116	rw	No	ALL	Yes	R	
3457h	00h	Position comparison output assignment setting	—	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	R	_
		• bit 3 to 0: Position comparison 1										01_0
		• bit 7 to 4: Position comparison 2										
		• bit 11 to 8: Position comparison 3										
		• bit 15 to 12: Position comparison 4										
		• bit 19 to 16: Position comparison 5										
		• bit 23 to 20: Position comparison 6										
		• bit 27 to 24: Position comparison 7										
		• bit 31 to 28: Position comparison 8										
3463h	00h	Reserved	_	_	5242884	132	-	—	-	-	—	_
3464h	00h	Reserved	_	_	64	132	-	_	_	_	-	_

\*1 Cannot be used with the standard type or multi-function type. Do not change the factory default value.

## 7.1.2.6 Class 5: Enhancing Settings

Index	Sub-Index	Zame	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3503h	00h	Denominator of pulse output division	_	0 to 134217728	0	132	rw	No	ALL	Yes	R	01_0
3504h	00h	Over-travel inhibit input setup	_	0 to 2	1	116	rw	No	ALL	Yes	С	01_0
3505h	00h	Sequence at over-travel inhibit	_	0 to 2	0	I16	rw	No	ALL	Yes	С	01_0
3506h	00h	Sequence at Servo-Off	-	0 to 9	0	116	rw	No	ALL	Yes	В	01_0
3507h	00h	Sequence upon main power off	_	0 to 9	0	I16	rw	No	ALL	Yes	В	0I_0
3508h	00h	L/V trip selection upon main pow- er off	-	0 to 3	0	I16	rw	No	ALL	Yes	В	_
		bit 0: Operation selection with n	nain power supp	ly OFF								01_0
		• bit 1: Main power off warning co	ondition detectio	n time								
3509h	00h	Detection time of main power off	ms	20 to 2000	2000	I16	rw	No	ALL	Yes	С	0I_0
3510h	00h	Sequence at alarm	_	0 to 7	0	116	rw	No	ALL	Yes	В	01_0
3511h	00h	Torque setup for emergency stop	%	0 to 500	0	116	rw	No	ALL	Yes	В	0I_0
3512h	00h	Motor over-load level setup	%	0 to 500	0	I16	rw	No	ALL	Yes	А	0I_0
3513h	00h	Over-speed level setup	r/min	0 to 20000	0	I16	rw	No	ALL	Yes	В	01_0
3514h	00h	Motor working range setup	0.1 rotation	0 to 1000	10	I16	rw	No	csp	Yes	А	0I_0
									рр			
									hm			
3515b	00h	Control input signal reading setup		0 to 3	0	116	744	No		Voc	<u> </u>	
2516h	001	Control input signal reading setup		0103	1	110	TW	INO	ALL	res	C	01_0
351011	000		_	-	1	110	-		_		-	-
3520n	UUN	Position setup unit select	_	0 to 1	0	116	rw	NO	csp pp hm ip	res	U	0_0
3521h	00h	Selection of torque limit	_	0 to 5	1	I16	rw	No	ALL	Yes	В	0I_0
3522h	00h	2nd torque limit	%	0 to 500	500 (*1)	116	rw	No	csp pp hm ip csv pv	Yes	В	
3525h	00h	Reserved	_	_	0	I16	-	-	_	_	-	_
3526h	00h	Reserved	_	_	0	I16	-	-	_	_	-	_
3529h	00h	Reserved	_	_	2	I16	-	-	_	_	-	_
3531h	00h	USB axis address	_	0 to 127	1	I16	rw	No	ALL	Yes	С	PT_OM
3533h	00h	Pulse regenerative output limit setup	_	0 to 1	0	I16	rw	No	ALL	Yes	С	01_0
3534h	00h	Reserved	_	_	4	I16	-	-	_	-	-	_
3536h	00h	Reserved	_	_	0	I16	-	-	_	_	-	_
3545h	00h	Quadrant glitch positive-direction compensation value	0.1%	-1000 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	<u>"4.9.3"</u>
3546h	00h	Quadrant glitch negative-direction compensation value	0.1%	-1000 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	
3547h	00h	Quadrant glitch compensation de- lay time	ms	0 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3548h	00h	Quadrant glitch compensation fil- ter setting L	0.01 ms	0 to 6400	0	116	rw	No	csp pp hm ip	Yes	В	<u>"4.9.3"</u>
3549h	00h	Quadrant glitch compensation fil- ter setting H	0.1 ms	0 to 10000	0	116	rw	No	csp pp hm ip	Yes	В	
3550h	00h	Reserved	-	_	0	132	-	-	-	-	-	-
				:								
3555h	00h	Reserved	_	_	0	132	-	-	-	_	-	
3556h	00h	Slow stop deceleration time set- ting	ms/ (1000 r/min)	0 to 10000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S) csv (S) pv (S) cst (S) tq (S)	Yes	В	OI_O
3557h	00h	Slow stop S-shape acceleration and deceleration setting	ms	0 to 1000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S) csv (S) pv (S) cst (S) tq (S)	Yes	В	
3566h	00h	Deterioration diagnosis conver- gence judgment time	0.1 s	0 to 10000	0	116	rw	No	ALL	Yes	A	01_0
3567h	00h	Deterioration diagnosis inertia ra- tio upper limit	%	0 to 10000	0	116	rw	No	ALL	Yes	A	
3568h	00h	Deterioration diagnosis inertia ra- tio lower limit	%	0 to 10000	0	116	rw	No	ALL	Yes	A	
3569h	00h	Deterioration diagnosis unbal- anced load upper limit	0.1%	-1000 to 1000	0	116	rw	No	ALL	Yes	A	
3570h	00h	Deterioration diagnosis unbal- anced load lower limit	0.1%	-1000 to 1000	0	116	rw	No	ALL	Yes	A	
3571h	00h	Deterioration diagnosis dynamic friction upper limit	0.1%	-1000 to 1000	0	I16	rw	No	ALL	Yes	A	
3572h	00h	Deterioration diagnosis dynamic friction lower limit	0.1%	-1000 to 1000	0	116	rw	No	ALL	Yes	A	
3573h	00h	Deterioration diagnosis viscous friction upper limit	0.1%/ (10000 r/min)	0 to 10000	0	116	rw	No	ALL	Yes	A	
3574h	00h	Deterioration diagnosis viscous friction lower limit	0.1%/ (10000 r/min)	0 to 10000	0	116	rw	No	ALL	Yes	A	
3575h	00h	Deterioration diagnosis velocity setting	r/min	-20000 to 20000	0	116	rw	No	ALL	Yes	A	
3576h	00h	Deterioration diagnosis torque average time	ms	0 to 10000	0	116	rw	No	ALL	Yes	A	
3577h	00h	Deterioration diagnosis torque upper limit	0.1%	-1000 to 1000	0	116	rw	No	ALL	Yes	A	
3578h	00h	Deterioration diagnosis torque lower limit	0.1%	-1000 to 1000	0	116	rw	No	ALL	Yes	A	
3595h	00h	Reserved	_	_	0	I16	-	—	_	-	-	-
35B0h	00h	Driver derating factor	%	0 to 100	100	116	rw	No	ALL	Yes	А	01_0
35B2h	00h	Reserved	—	—	0	116	-	-	—	-	-	_

\*1 Factory default values vary depending on the servo driver and motor combination.

For details, see Operating Instructions (Overall) "8.1 Torque Limit Switching Function" .

## 7.1.2.7 Class 6: Special Settings

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3602h	00h	Speed deviation excess setup	r/min	0 to 20000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S)	Yes	A	01_0
3603h	00h	Reserved	_	_	0	I16	-	-	-	-	-	—
3605h	00h	Position 3rd gain valid time	0.1 ms	0 to 10000	0	116	rw	No	csp pp hm ip	Yes	В	<u>"4.3.3"</u>
3606h	00h	Position 3rd gain scale factor	%	50 to 1000	100	116	rw	No	csp pp hm ip	Yes	В	
3607h	00h	Torque command additional value	%	-100 to 100	0	116	rw	No	csp pp hm ip csv pv	Yes	В	<u>"4.5.3"</u>
3608h	00h	Positive direction torque compen- sation value	%	-100 to 100	0	116	rw	No	csp pp hm ip	Yes	В	
3609h	00h	Negative direction torque com- pensation value	%	-100 to 100	0	116	rw	No	csp pp hm ip	Yes	В	
3610h	00h	Function expansion setup	_	-32768 to 32767	528	I16	rw	No	ALL	Yes	В	—
		bit 1: Load fluctuation control fu	nction									<u>"4.6.3"</u>
		<ul> <li>bit 2: Load fluctuation stabilizati</li> </ul>	on setting									<u><u>"4.7.3"</u></u>
		<ul> <li>bit 4: Current response improve</li> </ul>	ment									<u>"7.5"</u>
		<ul> <li>bit 10: Fall prevention function of</li> </ul>	during an alarm									01_0
		<ul> <li>bit 11: Encoder overheat error p</li> </ul>	protection detect	ion								01_0
		bit 14: Load fluctuation suppres	sion function au	tomatic tuning								<u>"4.1.1.4"</u> <u>"4.1.2.4"</u> <u>"4.6.3"</u> "4.7.3"
		bit 15: Slow stop function										01_0
3611h	00h	Current loop gain response setup	%	10 to 300	100	I16	rw	No	ALL	Yes	в	<u>"4.8.3"</u>
3614h	00h	Emergency stop time at alarm	ms	0 to 1000	200	116	rw	No	ALL	Yes	в	0I_0
3615h	00h	2nd over-speed level setup	r/min	0 to 20000	0	116	rw	No	ALL	Yes	в	01_0
3618h	00h	Power-up wait time	100 ms	0 to 100	0	116	rw	No	ALL	Yes	R	01_0
3619h	00h	Reserved	_	_	0	I16	-	-	-	-	-	_
3620h	00h	Reserved	_	_	0	116	-	-	-	-	_	_
3621h	00h	Reserved	_	_	0	132	-	-	_	-	-	_
3622h	00h	AB phase external scale pulse outputting method selection	_	0 to 1	0	116	rw	No	csp (F) pp (F) hm (F) ip (F)	Yes	R	OI_O

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3623h	00h	Load change compensation gain	%	-100 to 100	0	116	rw	No	csp pp hm ip csv pv	Yes	В	<u>"4.6.3"</u> <u>"4.7.3"</u>
3624h	00h	Load change compensation filter	0.01 ms	10 to 2500	53	116	rw	No	csp pp hm ip csv pv	Yes	В	
3626h	00h	Reserved	—	_	0	132	-	-	_	-	-	-
3627h	00h	Warning latch state setup	—	0 to 3	3	116	rw	No	ALL	Yes	С	-
		• bit 0: Expanded warnings										0I_0
		• bit 1: General warnings										
3630h	00h	Reserved	-	-	0	I16	-	-	_	_	-	-
3631h	00h	Real time auto tuning estimation speed	_	0 to 3	1	116	rw	No	ALL	Yes	В	<u>"4.1.1.4"</u> "4.1.2.4" "4.1.3.4"
3632h	00h	Real time auto tuning custom set-	—	-32768 to 32767	0	116	rw	No	ALL	Yes	В	-
		<ul> <li>bit 1 to 0: Load characteristics e</li> </ul>	estimation									<u>"4.1.1.4"</u>
		• bit 3 to 2: Inertia Ratio Update										<u>"4.1.2.4"</u>
		• bit 6 to 4: Torque compensation										<u>"4.1.3.4"</u>
		• bit 7: Stiffness Setup										
		• bit 8: Fixed Parameter Setup										
		• bit 10 to 9: Gain Switching Setu	р									
		• bit 11: Torque compensation set	tting switching									
		• bit 15 to 12: Individual torque co	ompensation set	tings								
3634h	00h	Hybrid vibration suppression gain	0.1 s <sup>-1</sup>	0 to 30000	0	116	rw	No	csp (F) pp (F) hm (F) ip (F)	Yes	В	<u>"5.9.3"</u>
3635h	00h	Hybrid vibration suppression filter	0.01 ms	0 to 32000	10	116	rw	No	csp (F) pp (F) hm (F) ip (F)	Yes	В	
3636h	00h	Dynamic brake operation input setup	-	0 to 1	0	116	rw	No	ALL	Yes	R	01_0
3637h	00h	Oscillation detecting level	0.1%	0 to 1000	0	I16	rw	No	ALL	Yes	В	01_0
3638h	00h	Warning mask setup	_	-32768 to 32767	4	I16	rw	No	ALL	Yes	С	
3639h	00h	Warning mask setup 2	_	-32768 to 32767	0	I16	rw	No	ALL	Yes	С	
3641h	00h	1st damping depth	_	0 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	<u>"5.5.3"</u>
3642h	00h	2-stage torque filter time constant	0.01 ms	0 to 2500	0	I16	rw	No	ALL	Yes	в	"5.2.3"
3643h	00h	2-stage torque filter attenuation term	_	0 to 1000	1000	116	rw	No	ALL	Yes	В	
3647h	00h	Function expansion setup 2	_	-32768 to 32767	1	116	rw	No	ALL	Yes	R	-
		• bit 0: Two-degree-of-freedom co	ontrol mode									<u>"7.5"</u> OI_O
		• bit 2: Encoder communication e	rror/warning jud	gment setup								01_0

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3647h	00h	• bit 3: Two-degree-of-freedom co	ontrol real-time a	auto tuning selectio	'n							<u>"7.5"</u> OI_O
		• bit 14: Quadrant glitch compense	ation function									<u>"4.9.3"</u>
3648h	00h	Tuning filter	0.1 ms	0 to 2000	Size A: 11 Size B: 12 Sizes C, D: 17 (12) <sup>(*1)</sup>	116	rw	No	csp pp hm ip csv pv	Yes	В	01_0
3649h	00h	Command/tuning filter damping	_	0 to 99	15	116	rw	No	csp pp hm ip	Yes	В	<u>"5.7.3"</u> OI_O
3650h	00h	Viscous friction compensating gain	0.1%/ (10000 r/min)	0 to 10000	0	116	rw	No	csp pp hm ip csv pv	Yes	В	<u>"4.5.3"</u> OI_O
3651h	00h	Wait time for emergency stop	ms	0 to 10000	0	I16	rw	No	ALL	Yes	В	0I_0
3652h	00h	Reserved	-	_	0	I16	-	-	-	-	-	-
				:	1							
3654h	00h	Reserved	_	_	0	116	-	-	—	-	-	
303711	oon	detection time	ms	0 10 5000	U	110	rw	NO	pp hm ip csv pv	res	В	U_U
3658h	00h	Reserved	_	_	0	132	-	-	_	-	-	_
3659h	00h	Reserved	_	_	0	I16	-	_	_	_	-	_
3660h	00h	2nd damping depth	_	0 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	<u>"5.5.3"</u>
3661h	00h	1st resonance frequency	0.1 Hz	0 to 3000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S)	Yes	В	<u>"5.6.3"</u>
3662h	00h	1st resonance attenuation ratio	_	0 to 1000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S)	Yes	В	
3663h	00h	1st anti-resonance frequency	0.1 Hz	0 to 3000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S)	Yes	В	
3664h	00h	1st anti-resonance attenuation ra- tio	_	0 to 1000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S)	Yes	В	
3665h	00h	1st response frequency	0.1 Hz	0 to 3000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S)	Yes	В	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3666h	00h	2nd resonance frequency	0.1 Hz	0 to 3000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S)	Yes	В	<u>"5.6.3"</u>
3667h	00h	2nd resonance attenuation ratio	_	0 to 1000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S)	Yes	В	
3668h	00h	2nd anti-resonance frequency	0.1 Hz	0 to 3000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S)	Yes	В	
3669h	00h	2nd anti-resonance attenuation ratio	-	0 to 1000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S)	Yes	В	
3670h	00h	2nd response frequency	0.1 Hz	0 to 3000	0	116	rw	No	csp (S) pp (S) hm (S) ip (S)	Yes	В	
3671h	00h	3rd damping depth	_	0 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	<u>"5.5.3"</u>
3672h	00h	4th damping depth	_	0 to 1000	0	116	rw	No	csp pp hm ip	Yes	В	
3673h	00h	Load estimation filter	0.01 ms	0 to 2500	0	116	rw	No	csp pp hm ip csv pv	Yes	В	<u>"4.6.3"</u> <u>"4.7.3"</u>
3674h	00h	Torque compensation frequency 1	0.1 Hz	0 to 5000	0	116	rw	No	csp pp hm ip csv pv	Yes	В	
3675h	00h	Torque compensation frequency 2	0.1 Hz	0 to 5000	0	116	rw	No	csp pp hm ip csv pv	Yes	В	
3676h	00h	Load estimation count	-	0 to 8	0	116	rw	No	csp pp hm ip csv pv	Yes	В	
3685h	00h	Retracting operation condition setting	_	-32768 to 32767	0	116	rw	No	ALL	Yes	С	-
		• bits 3 to 0: Non-communication	settings	·				·			·	01_0
		• bits 7 to 4: Communication-relat	ed setting									
		bits 9 to 8: Judgment condition 1	for stopping retra	acting operation	_							
3686h	00h	Retracting operation alarm setting	-	0 to 7	0	116	rw	No	ALL	Yes	С	-

Index	Sub-Index	Aame	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference	
3686h	00h	• bit 0: Err87.1.0 "Retracting oper	ration completion	n (I/O)"								01_0	
		• bit 1: Err87.2.0 "Retracting oper	ration completion	n (communication)'	9								
		• bit 2: Err87.3.0 "Retracting oper	ration error"										
3687h	00h	Reserved	_	_	0	132	_	-	_	-	-	_	
3688h	00h	Absolute encoder multi-turn data upper-limit value	_	0 to 65534	0	132	rw	No	ALL	Yes	С	01_0	
3695h	00h	Motor over-load warning detection level	%	0 to 114	0	116	rw	No	ALL	Yes	A	01_0	
3696h	00h	Motor over-load warning release level	%	0 to 114	0	116	rw	No	ALL	Yes	A		
3697h	00h	Function expansion setup 3	_	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	В	-	
		bit 0: Quadrant glitch compensation HPF clear											
		bit 1: Deterioration Diagnosis W	arning Function									01_0	
		• bit 2: Motor movable range erro	r protection exp	ansion								01_0	
		• bit 3: Selection of external scale	e single-turn dat	a monitor								01_0	
		• bit 6: Switches position information	tion during back	lash correction								<u>"4.10.3"</u>	
		bit 8: Target control mode extension of Obj.607Fh:00h "Max profile velocity"											
		bit 11: External scale position latch during semi-closed control											
		• bit 12: Speed limit priority functi	on during torque	e control								01_0	
		• bit 13: Touch probe latch compl	etion status tog	gle output enabled								01_0	
		• bit 14: Over-travel inhibit warnir	ng									01_0	
		• bit 27: Alarm display switch set	ling									01_0	
3698h	00h	Function expansion setup 4	_	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	R	—	
		• bit 3: Effective bit expansion for	multi-turn data									01_0	
		• bit 8: Control mode switch funct	ion expansion									01_0	
		• bit 10: Selection of external sca	le single-turn da	ta output format								01_0	
		• bit 21: Expand conditions for ca	nceling over-tra	vel inhibit								01_0	
36A0h	00h	Reserved	_	_	4000	I16	-	-	_	-	-	-	
36A1h	00h	Reserved	_	_	0	116	-	-	_	-	-	-	
36A2h	00h	Over-travel inhibit release level setup	Command unit	0 to 2147483647	0	132	rw	No	csp	Yes	В	01_0	
36A4h	00h	Open-phase monitoring setup	_	0 to 3	0	116	rw	No	ALL	Yes	В	01_0	
36A6h	00h	Reserved	_	_	0	116	-	-	-	-	-	_	
36C1h	00h	Current feed forward response setup	%	0 to 300	100	116	rw	No	ALL	Yes	В	<u>"4.8.3"</u>	
36C5h	00h	Reserved	_	_	0	132	-	-	_	-	-	_	
36C6h	00h	Warning2 mask setup	_	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	С	01_0	
36C7h	00h	Warning3 mask setup	_	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	С		

\*1 Values in parentheses are initial values for models with an instantaneous maximum current (peak value) of less than 24 A.

## 7.1.2.8 Class 7: Special Settings 2

Index	Sub-Index	Zame	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference	
3700h	00h	Display on LED	_	0 to 32767	0	I16	rw	No	ALL	Yes	А	TR_FS	
3701h	00h	Display time setup upon power- up	100 ms	0 to 1000	0	116	rw	No	ALL	Yes	R		
3703h	00h	Output setup during torque limit	_	0 to 1	0	116	rw	No	cst tq	Yes	A	01_0	
3704h	00h	Backlash compensation enable	_	0 to 7	0	116	rw	No	csp pp hm ip	Yes	В	-	
		• bits 1 to 0: Enable or disable ba	acklash compensatior	n and select the dir	ection of operati	on duri	ng c	ompe	nsatio	n		<u>"4.10.3"</u>	
		• bit 2: Expand backlash comper	nsation retention cond	litions									
3705h	00h	Backlash compensation value	pulse	-1073741824 to 1073741823	0	132	rw	No	csp pp hm ip	Yes	В	<u>"4.10.3"</u>	
3706h	00h	Constant for backlash compen- sation	0.01 ms	0 to 6400	0	116	rw	No	csp pp hm ip	Yes	В		
3707h	00h	Reserved	_	_	0	I16	_	-	_	-	-	_	
3708h	00h	Reserved	_	-	0	I16	-	-	-	-	-	_	
3709h	00h	Correction time of latch delay 1	25 ns	-2000 to 2000	360	116	rw	No	ALL	Yes	В	01_0	
3710h	00h	Reserved	_	_	3	I16	-	-	_	-	-	_	
3711h	00h	Reserved	_	-	0	132	-	-	-	-	-	_	
3713h	00h	Reserved	_	-	0	132	-	-	-	_	-		
3714h	00h	Main power off warning detection time	ms	0 to 2000	0	116	rw	No	ALL	Yes	С	01_0	
3715h	00h	Reserved	_	-	0	132	-	-	-	-	-	_	
3716h	00h	Torque saturation error protection frequency	Incidences	0 to 30000	0	116	rw	No	csp pp hm ip csv pv	Yes	В	01_0	
3718h	00h	Backlash compensation value holding range	Command unit	0 to 2147483647	0	132	rw	No	csp pp hm ip	Yes	В	<u>"4.10.3"</u>	
3722h	00h	Communication function extend- ed setup 1	_	-32768 to 32767	0	116	rw	No	ALL	Yes	R	-	
		• bit 4: External scale position in	formation monitoring	function setting for	semi-closed cor	ntrol						01_0	
		• bit 5: Command position chang	e saturation function	selection								01_0	
		bit 6: Homing return velocity lin	nit enabled									01_0	
		• bit 7: Over-travel inhibit input d	etection setting during	g Z-phase homing i	eturn operation								
		bit 11: LINK establishment mod	le selection									01_0	
3723h	00h	Communication function extend- ed setup 2	_	-32768 to 32767	16384	116	rw	No	ALL	Yes	В	-	
		bit 14: Position deviation [comr	nand unit] output setu	ip		1					_	01_0	
3724h	00h	Communication function extend- ed setup 3	_	-32768 to 32767	14352	116	rw	No	ALL	Yes	С	_	
		<ul> <li>bit 0: EX-OUT1 output status s lished</li> </ul>	etting at the time of co	ommunication inter	rupted after Eth	erCAT	com	munic	ation i	s estal	b-	01_0	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3724h	00h	• bit 5: Latch position detection of	lelay compensation fu	nction switching								01_0
		• bit 7: TFF clear ON/OFF select	ion from host device									0I_0
		bit 11: Condition setting for Obj	.6041h: bit 12 "drive f	ollows command v	alue"							01_0
3739h	00h	Reserved	_	_	0	116	-	_	-	_	-	_
3740h	00h	Station Alias setup (high)	_	0 to 255	0	116	rw	No	ALL	Yes	R	01_0
3741h	00h	Station Alias selection	_	0 to 2	1	116	rw	No	ALL	Yes	R	
3742h	00h	Maximum continuation communi- cation error	_	-32768 to 32767	-30584	116	rw	No	ALL	Yes	R	_
		• bits 3 to 0: Err80.7.0 detection	threshold									01_0
3743h	00h	Lost link detection time	ms	0 to 32767	0	116	rw	No	ALL	Yes	R	01_0
3744h	00h	Software version	-	-2147483648 to 2147483647	16908546	132	ro	No	ALL	Yes	Х	01_0
3779h	00h	Reserved	_	_	0	116	-	_	-	_	-	_
3780h	00h	Communication function extend- ed setup 8	_	-32768 to 32767	2048	116	rw	No	ALL	Yes	С	_
		• bit 6: Obj.6041h:00h "Statuswo	rd" : bit 12 Expansion	setup for "homing	attained"							01_0
3787h	00h	Communication function extend- ed setup 5	_	-32768 to 32767	3072	116	rw	No	ALL	Yes	С	_
3792h	00h	Correction time of latch delay 2	25 ns	-2000 to 2000	0	116	rw	No	ALL	Yes	В	01_0
3793h	00h	Homing return speed limit value	r/min	0 to 20000	0	116	rw	No	hm	Yes	С	01_0
3799h	00h	Communication function extend- ed setup 6	_	-32768 to 32767	0	116	rw	No	ALL	Yes	В	_
		• bit 0: Enable/disable FFT exect	ution while EtherCAT	communication is e	established							01_0
		• bit 3: Command pulse accumul	ated value [command	l unit] output setting	g							01_0
37A0h	00h	Reserved	-	—	0	132	-	—	—	—	—	—
37A4h	00h	Reserved	_	_	0	132	-	—	_	_	-	
37A8h	00h	Reserved	_	_	7	116	-	-	-	-	-	_
37A9h	00h	Reserved	_	_	1	116	-	_	-	-	-	_
37B0h	00h	Communication function extend- ed setup 7	-	-2147483648 to 2147483647	384	132	rw	No	ALL	Yes	В	—
		• bit 7: Err80.7.0 detection functi	on expansion									01_0
		• bit 8: Err80.3.0 detection function	on expansion									01_0
		bit 12: ERR Indicator off specifi	cation expansion									01_0
37B3h	00h	Torque offset filter	0.01 ms	0 to 6400	0	116	rw	No	csp pp hm ip csv pv	Yes	В	01_0
37B7h	00h	Reserved	-	-2147483648~ 2147483647	0	132	-	—	-	-	-	—
37C0h	00h	Absolute scale offset1	Rotation (multi-turn data), or pulse (external scale upper 32 bits)	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	R	01_0
37C1h	00h	Absolute scale offset2	pulse (single-turn data), or pulse (external scale lower 32 bits)	-2147483648 to 2147483647	0	132	rw	No	ALL	Yes	R	01_0
37C7h	00h	Reserved	_	_	0	132	-	_	-	_	-	_

## 7.1.2.9 Class 8: Special Settings 3

Index	Sub-Index	Rame	Units	Range	Initial value		Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3800h	00h	Reserved	_	_		0	I16	-	—	-	-	Ι	_
3801h	00h	Profile linear acceleration constant	10,000 command units/s <sup>2</sup>	1 to 429496		1	132	rw	No	ALL	Yes	В	01_0
3802h	00h	Reserved	_	_		0	I16	-	—	-	-	Ι	_
3803h	00h	Reserved	_	_		0	I16	-	—	-	-	Ι	_
3804h	00h	Profile linear deceleration constant	10,000 command units/s <sup>2</sup>	1 to 429496		1	132	rw	No	ALL	Yes	В	01_0
3805h	00h	Reserved	_	_		0	I16	-	-	-	-		_
3810h	00h	Reserved	_	—		0	132	-	-	-	-	Ι	_
3812h	00h	Reserved	_	_		0	I16	-	—	-	-		_
3813h	00h	Reserved	_	—		0	132	-	—	-			_
			:										
3815h	00h	Reserved	_	_		0	132	-	—	—	-	-	
3817h	00h	Relative movement of retracting operation	Command unit	-2147483647 to 2147483647		0	132	rw	No	ALL	Yes	В	01_0
3818h	00h	Retracting operation speed	Command unit/s	0 to 2147483647		0	132	rw	No	ALL	Yes	В	
3819h	00h	Reserved	_	-		0	I16	—	_	_	_	-	-

# 7.1.2.10 Class 9: Linear Relationship

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3901h	00h	Feedback scale resolution / Num- ber of scale pulses per rotation	pulse	0 to 536870912	0	132	rw	No	ALL	Yes	R	01_0

## 7.1.2.11 Class 10: Special Settings 4

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3A00h	00h	Reserved	_	_	_	116	-	-	-	-	-	_
3A01h	00h	Reserved	_	0~4	0	116	-	_	-	-	-	_

### 7.1.2.12 Class 11: Manufacturer Use

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
3B00h	00h	Reserved	_	-	1	I16	-	-	-	-	-	—
3B01h	00h	Reserved	_	_	503578880	132	-	—	-	-	-	—
3B02h	00h	Reserved	_	_	658185	132	-	—	-	-	-	—
3B03h	00h	Reserved	_	_	-1	132	-	—	-	-	-	—
			1									
3B06h	00h	Reserved	_	-	-1	132	-	-	-	-	-	
3B07h	00h	Reserved	_	_	16	I16	-	—	-	-	—	—
3B08h	00h	Reserved	_	-	6	I16	-	_	_	-	—	—
3B09h	00h	Reserved	_	-	1	I16	-	-	-	-	-	_
3B10h	00h	Reserved	_	-	129	I16	-	-	-	-	-	—
3B11h	00h	Reserved	_	-	0	116	-	_	-	-	-	_
3B12h	00h	Reserved	_	-	0	132	-	_	-	-	-	—
3B13h	00h	Reserved	_	-	0	116	-	—	-	-	-	—
3B14h	00h	Reserved	_	-	0	116	-	—	-	-	-	—
3B15h	00h	Reserved	_	-	0	132	-	—	-	-	-	_
3B16h	00h	Reserved	-	-	255	116	-	—	-	-	-	_
3B17h	00h	Reserved	_	-	0	I16	-	_	-	-	-	_
3B18h	00h	Reserved	_	-	0	132	-	_	-	-	-	_
3B19h	00h	Reserved	_	-	0	I16	-	_	-	-	-	_
3B20h	00h	Reserved	-	-	0	I16	-	_	-	-	-	_
3B21h	00h	Reserved	_	-	0	132	-	_	-	-	_	_
3B22h	00h	Reserved	_	-	0	116	-	_	-	-	-	_
3B23h	00h	Reserved	_	-	0	132	-	_	-	-	-	_
3B26h	00h	Reserved	_	_	0	132	-	_	-	-	-	
# 7.1.3 User-specific Area (4000h to 4FFFh)

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
4304h	00h	Touch probe function expan- sion setup	_	0 to 65535	0	U16	rw	RxPDO	ALL	Yes	В	_
		• bit 0: Touch probe 1 Extern	al scale position late	h Z-phase switchir	ng in semi-close	d contr	ol					01_0
		• bit 1: Touch probe 1 Chang	e storage location o	f external scale fee	dback position i	n semi	-clos	ed control				
		bit 8: Touch probe 2 Extern	al scale position late	h Z-phase switchir	ng in semi-close	d contr	ol					
		• bit 9: Touch probe 2 Chang	e storage location o	f external scale fee	dback position i	n semi	-clos	ed control				
4308h	00h	History number	_	0 to 3	0	U8	rw	No	ALL	No	A	01_0
430Eh	_	Timestamp reference time	_	_	_	-	-	-	-	_	-	
	00h	Number of entries	_	2	_	U8	ro	No	ALL	No	Х	
	01h	Timestamp reference time setting 1	ns	0 to 4294967295	0	U32	rw	No	ALL	No	A	
	02h	Timestamp reference time setting 2	ns	0 to 4294967295	0	U32	rw	No	ALL	No	A	
4310h	00h	Alarm main no	_	0 to 127	0	U8	rw	No	ALL	No	А	
4311h	00h	Reserved	_	-	_	U8	-	_	-	-	-	-
4312h	00h	Velocity control loop torque limit	0.1%	0 to 65535	0	U16	rw	RxPDO	ALL	No	А	01_0
4314h (*1)	00h	Analog input internal offset	mV	-32768 to 32767	0	116	rw	RxPDO	ALL	Yes	A	01_0
4315h (*1)	00h	Analog input deviation limit	mV	0 to 65535	0	U16	rw	RxPDO	ALL	Yes	A	
4316h	-	Analog input voltage setup	_	_	_	-	-	_	-	_	-	
(1)	00h	Number of entries	_	1	—	U8	ro	No	csp	No	х	
	01h	Analog input voltage dead zone	mV	0 to 65535	0	U16	rw	RxPDO	ALL	Yes	в	
4317h	00h	Alarm sub no	_	0 to 127	0	U8	rw	No	ALL	No	А	0_0
4320h (*5)	00h	Analog monitor output 1	_	-32768 to 32767	0	116	rw	RxPDO	ALL	No	A	_
4321h (*5)	00h	Analog monitor output 2	_	-32768 to 32767	0	116	rw	RxPDO	ALL	No	А	_
4351h	00h	Analog input function	_	0 to 65535	0	U16	rw	RxPDO	csp	Yes	в	-
(^5)		• bit 0: Displacement control	function switch									01_0
		• bit 1: Position command lat	ch switch									
4C00h	_	Analog servo parameters	—	—	—	-	-	—	-	_	-	01_0
(1)	00h	Number of entries	_	7	—	U8	ro	No	csp	No	В	
	01h	Analog input gain	Command unit/mV	0 to 30000	0	116	rw	No	csp	Yes	В	
	02h	Analog input polarity	_	0 to 1	0	116	rw	No	csp	Yes	В	
	03h	Analog input integration time constant	0.01 ms	0 to 100000	0	132	rw	No	csp	Yes	В	
	04h	Analog input integration limit	Command unit	0 to 2147483647	0	132	rw	No	csp	Yes	В	
	05h	Analog input (AIN) offset set- ting	0.375 mV	-26666 to 26666	0	116	rw	No	ALL	Yes	В	
	06h	Analog input (AIN) filter set- ting	0.01 ms	0 to 6400	0	116	rw	No	ALL	Yes	В	
	07h	Analog input (AIN) excessive setting	0.1 V	0 to 100	0	116	rw	No	ALL	Yes	В	
4D00h	-	Special function start	_	_	_	-	-	-	-	_	-	01_0
	00h	Number of entries	_	3	_	U8	ro	No	ALL	No	х	
	01h	Special function start flag 1		0 to 4294967295	0	U32	rw	No	ALL	No	В	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
4D00h	01h	• bit 9: Special function start	trigger	L	1			1				01_0
	02h	Special function start flag 2	_	0 to 4294967295	0	U32	rw	No	ALL	No	В	
	03h	Reserved	_	_	0	U32	rw	_	-	_	-	-
4D01h	00h	Special function setting 9	_	0 to 65535	0	U16	rw	No	ALL	No	В	01_0
4D0Eh	_	Expansion warning flags	_	_	_	_	_	_	_	_	_	01_0
	00h	Number of entries	_	3	_	U8	ro	No	ALL	No	х	
	01h	Expansion warning flags 1	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	02h	Expansion warning flags 2	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	03h	Expansion warning flags 3	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
4D0Fh	00h	Reserved	_	_	_	U16	_	_	-	_	-	_
4D10h	_	External scale ID	_	_	_	_	_	_	-	_	-	01_0
	00h	Number of entries	_	2	_	U8	ro	No	ALL	No	Х	
	01h	External scale vendor ID	_	_	_	VS	ro	No	ALL	No	х	
	02h	External scale model ID	_	_	_	VS	ro	No	ALL	No	Х	
4D11h	_	Reserved	_	_	_	_	_	_	_	_	_	_
	00h	Number of entries	_	13	_	U8	_	_	_	_	_	_
	01h	Reserved 1	_	_	_	U32	_	_	_	_	_	_
				l								
	0Dh	Reserved 13	_	_	_	U32	_	_	_	_	_	
4D12h	00h	Motor serial number	_	_	_	VS	ro	No	ALL	No	х	01 0
4D13h	00h	Reserved	_	_	_	VS	_	_	_	_	_	_
4D14h	00h	Reserved	_	_	_	VS	_	_	_	_	_	_
4D15h	00h	Drive serial number	_	_	_	VS	ro	No	ALL	No	х	01 0
4D29h	00h	Over load factor	0.1%	0 to 65535	_	U16	ro	TxPDO	ALL	No	Х	01 0
4D35h	_	Reserved	_	_	_	_	_	_	_	_	_	_
	00h	Number of entries		2	_	U8	_	_	_	_	_	_
	01h	Reserved 1			_	U16	_	_	_	_	_	_
	02h	Reserved 2		_	_	U16	_	_	_	_	_	_
4D36h	_	Reserved			_	_	_			_	_	
120011	00h	Number of entries		2	_	118	_	_			_	
	01h	Reserved 1		_		1116	_		_	_	_	
	02h	Reserved 2		_	_	U16	_	_	_	_	_	_
4D51h (*2)	00h	Analog input status	_	0 to 65535	_	U16	ro	TxPDO	csp	No	х	01_0
4D52h	00h	Reserved	_	_	_	132	_	_	_	_	_	_
4D53h	00h	Reserved	_	_	_	132	_	_	_	_	_	_
4D54h	00h	Reserved	_	_	_	132	_	_	_	_	_	_
4D55h	00h	Reserved	_	_	_	132	_	_	_	_	_	_
4D57h	00h	Driver derating monitor	%	0 to 65535	_	U16	ro	TxPDO	ALL	No	x	01 0
4DA0h	_	Alarm accessory information	_	_	_	_	_	_	_	_	_	_
(*3)	00h	Number of entries	_	71	_	U8	ro	No	ALI	No	x	01.0
	01h	History number echo	_	0 to 3	_	118	ro	No	ALI	No	x	55
	02h	Alarm code	_	0 to	_	U32	ro	No	ALI	No	x	
	0211	Control mode		4294967295		133	10	No		No		
	0011			2147483647		102	10					

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
4DA0h (*3)	04h	Motor speed	r/min	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	01_0
	05h	Positional command velocity	r/min	-2147483648 to 2147483647	—	132	ro	No	ALL	No	х	
	06h	Velocity control command	r/min	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	
	07h	Torque command	0.05%	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	08h	Position command deviation	Command unit	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	09h	Position actual internal value	pulse	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	0Ah	Reserved 10	_	_	_	132	_	_	_	_	-	_
	0Bh	Input port (logic signal)	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	01_0
	0Ch	Output port (logic signal)	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	0Dh	Analog input	_	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	
	0Eh	Reserved 14	_	_	_	132	-	_	-	_	-	_
	0Fh	Reserved 15	_	_	_	132	_	_	-	_	-	-
	10h	Overload ratio	0.2 %	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	01_0
	11h	Regenerative load ratio	%	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	12h	Voltage across PN	V	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	13h	Temperature of amplifier	°C	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	14h	Warning flags	_	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	
	15h	Inertia ratio	%	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	
	16h	Reserved 22	_	_	_	132	—	_	-	-	-	_
				I								
	18h	Reserved 24	_	_	_	132	_	_	-	_	-	
	19h	Temperature of encoder	C°	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	01_0
	1Ah	Reserved 26	_	_	_	132	_	_	-	_	-	_
				i								
	1Ch	Reserved 28	_	_	_	132	_	_	-	_	-	
	1Dh	U-phase current detection value	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	01_0
	1Eh	W-phase current detection value	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	1Fh	Reserved 31	_	_	_	132	_	_	_	_	-	_
	20h	Reserved 32	_	_	_	132	_	_	_	_	-	_
	21h	Encoder single-turn data	-	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	01_0
	22h	Encoder communication error count (accumulated)	Incidences	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	23h	External scale communica- tion data error count (accu- mulated)	Incidences	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	24h	Reserved 36	-	_	-	132	_	_	-	_	-	-
	25h	Alarm occurrence time on timestamp standard (Lower)	ns	0 to 4294967295	_	U32	ro	No	ALL	No	х	01_0

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
4DA0h (*3)	26h	Alarm occurrence time on timestamp standard (Higher)	ns	0 to 4294967295	-	U32	ro	No	ALL	No	х	01_0
	27h	Alarm occurrence time on power on time	0.5 h	0 to 4294967295	-	U32	ro	No	ALL	No	х	
	28h	Alarm occurrence time on power on time (detail)	62.5 µs	0 to 4294967295	-	U32	ro	No	ALL	No	х	
	29h	Reserved 41	_	_	-	U32	-	—	-	-	-	—
	2Ah	Alarm code (extended)	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	01_0
	2Bh	Warning flags1	-	0 to 4294967295	-	U32	ro	No	ALL	No	х	
	2Ch	Warning flags2	_	0 to 4294967295	-	U32	ro	No	ALL	No	Х	
	2Dh	Warning flags3	-	0 to 4294967295	-	U32	ro	No	ALL	No	Х	
	2Eh	Reserved 46	_	0 to 4294967295	-	U32	ro	No	ALL	No	Х	_
	3Dh	Reserved 61	_	0 to 4294967295	_	U32	ro	No	ALL	No	х	
	3Eh	Reserved 62	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
				÷								
	47h	Reserved 71	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
4DB0h	—	Reserved	_	_	_	-	-	_	-	-	-	_
	00h	Number of entries	_	8	_	U8	-	_	-	-	-	_
	02h	Reserved 2	_	-	_	U32	_	_	-	_	—	_
	08h	Reserved 8	_	-	_	U32	_	_	-	_	—	_
4F01h	00h	Following error actual value (after filtering)	Command unit	-2147483648 to 2147483647	_	132	ro	TxPDO	pp hm csp	No	х	01_0
4F03h (*2)	00h	Analog input internal voltage	mV	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	01_0
4F04h	00h	Position command internal value (after filtering)	Command unit	-2147483648 to 2147483647	-	132	ro	TxPDO	pp hm csp	No	х	01_0
4F0Bh	00h	Reserved	_	_	_	132	_	_	-	_	-	_
4F0Ch	00h	Velocity command value (af- ter filtering)	r/min	-2147483648 to 2147483647	_	132	ro	TxPDO	pp hm csp	No	х	01_0
4F0Dh	00h	External scale position	pulse (External scale)	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	01_0
4F11h	00h	Regenerative load ratio	%	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	0I_0
4F21h	00h	Logical input signal	_	0 to 4294967295	_	U32	ro	TxPDO	ALL	No	х	01_0
4F22h	00h	Logical output signal	_	0 to 4294967295	_	U32	ro	TxPDO	ALL	No	х	
4F23h	00h	Logical input signal (expan- sion portion)	_	0 to 4294967295	_	U32	ro	TxPDO	ALL	No	х	
4F24h	00h	Reserved	_	_	_	U32	-	_	_	_	-	_
4F25h	00h	Physical input signal	_	0 to 4294967295	-	U32	ro	TxPDO	ALL	No	х	01_0
4F26h	00h	Physical output signal	_	0 to 4294967295	_	U32	ro	TxPDO	ALL	No	Х	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
4F31h	00h	Inertia ratio	%	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	01_0
4F32h	00h	Motor automatic identification	_	-2147483648 to 2147483647	-	132	ro	No	ALL	No	Х	01_0
4F33h	00h	Cause of motor no work	_	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	
4F34h	00h	Warning flags	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
4F36h	00h	Reserved	_	_	—	132	-	—	-	_	-	-
4F37h	-	Multiple alarm/warning infor- mation	_	—	-	-	—	—	_	—	—	01_0
	00h	Number of entries	_	35	_	U8	ro	No	ALL	No	х	
	01h	Multiple alarm information 1	_	-2147483648 to 2147483647	-	132	ro	No	ALL	No	Х	
	02h	Multiple alarm information 2	_	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	
	03h	Multiple alarm information 3	_	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	
	04h	Multiple alarm information 4	_	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	
	05h	Reserved 5	—	-	_	132	_	_	-	_	-	_
	0Fh	Reserved 15	—	-	-	132	_	—	-	_	-	
	10h	Multiple sub alarm informa- tion	_	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	01_0
	11h	Multiple warning information 1	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	Х	
	12h	Multiple warning information 2	-	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	13h	Multiple warning information 3	_	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	
	14h	Reserved 20	_	-	_	132	_	—	-	_	-	_
				l								
	1Fh	Reserved 31	—	—	—	132	-	—	-	-	-	
	20h	Multiple alarm cause informa- tion 1	-	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	01_0
	21h	Multiple alarm cause informa- tion 2	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	22h	Multiple alarm cause informa- tion 3	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
	23h	Multiple alarm cause informa- tion 4	_	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
4F41h	-	Motor encoder data	_	_	_	-	-	_	-	_	-	01_0
	00h	Number of entries	—	2	—	U8	ro	No	ALL	No	х	
	01h	Mechanical angle (Single-turn data)	pulse	-2147483648 to 2147483647	-	132	ro	TxPDO	ALL	No	х	
	02h	Multi-turn data	Rotation	-2147483648 to 2147483647	-	132	ro	TxPDO	ALL	No	х	
4F42h	00h	Electrical angle	0.0879°	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	
4F44h	00h	Encoder status		-2147483648 to 2147483647	_	132	ro	No	ALL	No	Х	01_0
4F46h	00h	Reserved	-	-	_	U16	—	_	_	_	-	_
4F48h	00h	External scale pulse total	pulse (External scale)	-2147483648 to 2147483647	-	132	ro	TxPDO	ALL	No	х	01_0
4F49h	00h	External scale absolute posi- tion	pulse (External scale)	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	Х	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
4F4Ah	00h	External scale position devia- tion	pulse (External scale)	-2147483648 to 2147483647	_	132	ro	TxPDO	pp hm csp	No	х	01_0
4F4Bh	00h	Touch probe external scale 1 positive edge	pulse (External scale)	-2147483648 to 2147483647	-	132	ro	TxPDO	ALL	No	х	01_0
4F4Ch	00h	Touch probe external scale 1 negative edge	pulse (External scale)	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	
4F4Dh	00h	Touch probe external scale 2 positive edge	pulse (External scale)	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	
4F4Eh	00h	Touch probe external scale 2 negative edge	pulse (External scale)	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	
4F4Fh (*2)	00h	Analog input value	Command unit	-2147483648 to 2147483647	-	132	ro	TxPDO	csp	No	х	01_0
4F51h	00h	Reserved	_	_	_	132	—	_	_	_	-	_
4F53h	00h	Reserved	_	_	_	U32	—	_	-	_	-	_
4F61h	00h	Power on cumulative time	30 minutes	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	01_0
4F62h	00h	Temperature of amplifier	°C	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
4F63h	00h	Temperature of encoder	°C	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
4F64h	00h	Inrush resistance relay oper- ating count	Incidences	-2147483648 to 2147483647	-	132	ro	No	ALL	No	Х	
4F65h	00h	Dynamic brake operating count	Incidences	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
4F66h	00h	Fan operating time	30 minutes	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
4F67h	00h	Fan life expectancy	0.1%	-2147483648 to 2147483647	-	132	ro	No	ALL	No	Х	
4F68h	00h	Capacitor life expectancy	0.1%	-2147483648 to 2147483647	_	132	ro	No	ALL	No	Х	
4F6Ah	00h	Reserved	_	_	_	132	-	—	-	-	-	—
4F6Bh	00h	Reserved	_	_	_	132	-	_	-	-	-	-
4F6Ch	00h	Motor power consumption	W	-2147483648 to 2147483647	-	132	ro	No	ALL	No	х	01_0
4F6Dh	00h	Amount of motor power con- sumption	Wh	-2147483648 to 2147483647	_	132	ro	No	ALL	No	х	
4F6Eh	00h	Cumulative value of motor power consumption	Wh	-2147483648 to 2147483647	_	132	ro	No	ALL	No	Х	
4F72h	00h	Reserved	—	_	_	132	-	_	-	-	-	_
4F73h	00h	Reserved	_	-	_	132	-	-	-	_	-	-
4F74h	00h	Reserved	_	_	_	U16	-	—	-	-	-	_
4F77h	00h	Lost link error count	Incidences	0 to 65535	_	U16	ro	No	ALL	No	Х	0I_0
4F78h	00h	Synchronization signal error count	Incidences	0 to 65535	_	U16	ro	No	ALL	No	Х	
4F81h	00h	Encoder communication error count (accumulated)	Incidences	-2147483648 to 2147483647	_	132	ro	No	ALL	No	X	
4F82h	00h	Reserved	_	_	_	132	-	_	-	_	-	_
4F83h	00h	External scale communica- tion error count (accumulat- ed)	Incidences	0 to 65535	-	U16	ro	TxPDO	ALL	No	Х	01_0
4F84h	00h	External scale communica- tion data error count (accu- mulated)	Incidences	0 to 65535	_	U16	ro	TxPDO	ALL	No	х	
4F85h	00h	Reserved	—	-	—	132	-	_	-	-	-	—

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
4F86h	00h	Hybrid deviation	Command unit	-2147483648 to 2147483647	_	132	ro	TxPDO	pp hm csp	No	х	01_0
4F87h	00h	External scale data (Higher)	pulse (External scale)	-2147483648 to 2147483647	-	132	ro	TxPDO	ALL	No	х	01_0
4F88h	00h	External scale data (Lower)	pulse (External scale)	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	
4F89h	00h	External scale status	_	0 to 65535	—	U16	ro	TxPDO	ALL	No	х	0I_0
4F8Ah	00h	External scale Z phase coun- ter	-	0 to 65535	-	U16	ro	No	ALL	No	х	
4F8Ch	00h	External scale single-turn da- ta	pulse	-2147483648 to 2147483647	-	132	ro	TxPDO	ALL	No	Х	
4F91h (*4)	00h	Estimation accuracy of mag- netic pole position	Degrees	0 to 180	-	U8	ro	TxPDO	ALL	No	Х	
4F92h (*4)	00h	Execution time of estimation of magnetic pole position	ms	0 to 65535	-	U16	ro	TxPDO	ALL	No	х	
4F93h (*4)	00h	Maximum travel distance to plus direction when estimat- ing magnetic pole position	pulse (Feedback scale unit)	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	
4F94h (*4)	00h	Maximum travel distance to minus direction when estimating magnetic pole position	pulse (Feedback scale unit)	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	Х	
4FA1h	00h	Velocity command value	r/min	-2147483648 to 2147483647	-	132	ro	TxPDO	ALL	No	х	01_0
4FA4h	00h	Reserved	—	—	_	132	-	—	-	-	-	—
4FA5h	00h	Velocity internal position com- mand	r/min	-2147483648 to 2147483647	_	132	ro	TxPDO	pp hm csp	No	х	OI_O
4FA6h	00h	Velocity error actual value	r/min	-2147483648 to 2147483647	_	132	ro	TxPDO	pp hm csp	No	х	
4FA7h	00h	External scale position (Applied polarity)	pulse (External scale)	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	01_0
4FA8h	00h	Positive direction torque limit value	0.05%	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	01_0
4FA9h	00h	Negative direction torque limit value	0.05%	-2147483648 to 2147483647	-	132	ro	TxPDO	ALL	No	х	
4FABh	00h	Gain switching flag	—	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	01_0
4FACh	00h	Reserved	_	_	_	132	-	-	-	_	-	_
4FAFh	00h	Estimated position for seam- less mode change	Command unit	-2147483648 to 2147483647	-	132	ro	TxPDO	ALL	No	х	-
4FB1h	00h	Deterioration diagnosis state	_	-2147483648 to 2147483647	-	132	ro	No	ALL	No	X	01_0
4FB2h	00h	Deterioration diagnosis tor- que command average value	0.1%	-2147483648 to 2147483647	-	132	ro	No	ALL	No	X	
4FB3h	00h	Deterioration diagnosis tor- que command standard value	0.1%	-2147483648 to 2147483647	-	132	ro	No	ALL	No	Х	
4FB4h	00h	Deterioration diagnosis inertia ratio estimate value	%	-2147483648 to 2147483647	-	132	ro	No	ALL	No	Х	
4FB5h	00h	Deterioration diagnosis offset load estimate value	0.1%	-2147483648 to 2147483647	_	132	ro	No	ALL	No	X	
4FB6h	00h	Deterioration diagnosis dy- namic friction estimate value	0.1%	-2147483648 to 2147483647	_	132	ro	No	ALL	No	X	
4FB7h	00h	Deterioration diagnosis vis- cous friction estimate value	0.1%/ (10000 r/min)	-2147483648 to 2147483647	_	132	ro	No	ALL	No	Х	
4FC2h (*2)	00h	Analog input voltage	mV	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	Х	01_0

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
4FF5h	00h	Reserved	_	_	_	132	-	TxPDO	-	-	-	—
4FF6h	00h	Reserved	_	_	_	132	-	-	-	-	-	_
4FF7h	-	Reserved	_	-	_	-	-	-	-	-	-	_
	00h	Number of entries	—	2	_	U8	ro	No	ALL	No	х	-
	01h	Reserved 1	_	_	_	132	-	-	-	-	-	_
	02h	Reserved 2	_	_	_	132	-	-	-	-	-	_
4FF8h	-	Reserved	_	-	_	-	-	-	-	-	-	_
	00h	Number of entries	_	2	_	U8	ro	No	ALL	No	х	—
	01h	Reserved 1	—	_	_	132	-	_	_	_	-	—
	02h	Reserved 2	_	_	_	132	-	-	-	-	-	_
4FFDh	00h	Reserved	_	_	_	132	-	_	-	_	-	_
4FFFh	00h	Target position echo	Command unit	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	х	01_0

\*1 Cannot be used with the standard type or multi-function type. Do not change the factory default value.

\*2 Cannot be used with the standard type or multi-function type.

\*3 Obj.4DA0h: "Alarm accessory information" is not compatible with PDO.

Each sub-index of Obj.4DA0h is read by SDO, so synchronism cannot be guaranteed.

\*4 Cannot be used with the standard type, multi-function type, or application specialized type.

\*5 Cannot be used with the standard type or multi-function type. Do not change the initial value.

# 7.1.4 Drive Profile Area (6000h to 6FFFh)

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
6007h	00h	Abort connection option code	-	0 to 3	1	116	rw	No	ALL	Yes	A	01_0
603Fh	00h	Error code	_	0 to 65535	-	U16	ro	TxPDO	ALL	No	х	OI_O TR_CS
6040h	00h	Controlword	_	0 to 65535	0	U16	rw	RxPDO	ALL	No	A	01_0
		• bit 0: switch on										01_0
		bit 1: enable voltage										
		bit 2: quick stop										-
		bit 3: enable operation										-
		bit 4: operation mode specif	fic (control mode	dependent bit)								01_0
		bit 5: operation mode specif	fic (control mode	dependent bit)								01_0
		bit 6: operation mode specif	fic (control mode	dependent bit)								-
		bit 7: fault reset										01_0
		• bit 8: halt										-
		bit 9: operation mode specif	fic (control mode	dependent bit)								01_0
6041h	00h	Statusword	_	0 to 65535	_	U16	ro	TxPDO	ALL	No	Х	01_0
		bit 0: ready to switch on										01_0
		bit 1: switched on										-
		bit 2: operation enabled										-
		• bit 3: fault										-
		bit 4: voltage enabled										-
		bit 5: quick stop										-
		• bit 6: switch on disabled										
		• bit 7: warning										-
		• bit 9: remote										
		• bit 10: operation mode spec	cific (control mode	e dependent bit)								01_0
		• bit 11: internal limit active										01_0
		• bit 12: operation mode spec	cific (control mode	e dependent bit)								01_0
		• bit 13: operation mode spec	cific (control mode	e dependent bit)								01_0
605Ah	00h	Quick stop option code	_	-2 to 7	2	I16	rw	No	ALL	Yes	Α	01_0
605Bh	00h	Shutdown option code	_	0 to 1	1	I16	rw	No	ALL	Yes	Α	01_0
605Ch	00h	Disable operation option code	_	0 to 1	1	116	rw	No	ALL	Yes	Α	01_0
605Dh	00h	Halt option code	_	-1 to 3	1	116	rw	No	ALL	Yes	Α	01_0
605Eh	00h	Fault reaction option code	_	0 to 2	2	116	rw	No	ALL	Yes	A	01_0
6060h	00h	Modes of operation	_	-128 to 127	0	18	rw	RxPDO	ALL	Yes	Α	01_0
6061h	00h	Modes of operation display	—	-128 to 127	-	18	ro	TxPDO	ALL	No	Х	01_0
6062h	00h	Position demand value	Command unit	-2147483648 to	-	132	ro	TxPDO	рр	No	Х	01_0
				214/40304/					hm			
									csp			
6063h	00h	Position actual internal value	pulse	-2147483648 to 2147483647	-	132	ro	TxPDO	ALL	No	x	01_0
6064h	00h	Position actual value	Command unit	-2147483648 to 2147483647	-	132	ro	TxPDO	ALL	No	х	
6065h	00h	Following error window	Command unit	0 to 4294967295	100000	U32	rw	RxPDO	pp csp	Yes	A	01_0
6066h	00h	Following error time out	ms	0 to 65535	0	U16	rw	RxPDO	pp csp	Yes	A	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
6067h	00h	Position window	Command unit	0 to 4294967295	10	U32	rw	RxPDO	pp ip	Yes	A	01_0
6068h	00h	Position window time	ms	0 to 65535	0	U16	rw	RxPDO	pp ip	Yes	A	
6069h	00h	Velocity sensor actual value	-	-2147483648 to 2147483647	-	132	ro	TxPDO	ALL	No	х	0I_0
606Ah	00h	Sensor selection code	-	-32768 to 32767	0	I16	rw	RxPDO	pv	No	Х	0I_0
606Bh	00h	Velocity demand value	Command unit/s	-2147483648 to 2147483647	_	132	ro	TxPDO	pv csv	No	х	0I_0
606Ch	00h	Velocity actual value	Command unit/s	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	Х	01_0
606Dh	00h	Velocity window	Command unit/s	0 to 65535	52429	U16	rw	RxPDO	pv	Yes	A	01_0
606Eh	00h	Velocity window time	ms	0 to 65535	0	U16	rw	RxPDO	pv	Yes	А	
606Fh	00h	Velocity threshold	Command unit/s	0 to 65535	52429	U16	rw	RxPDO	pv	Yes	A	
6070h	00h	Velocity threshold time	ms	0 to 65535	0	U16	rw	RxPDO	pv	Yes	А	
6071h	00h	Target torque	0.1%	-32768 to 32767	0	116	rw	RxPDO	tq cst	Yes	A	0I_0
6072h	00h	Max torque	0.1%	0 to 65535	5000	U16	rw	RxPDO	ALL	Yes	А	0I_0
6073h	00h	Max current	0.1%	0 to 65535	0	U16	rw	No	tq	No	Х	01_0
6074h	00h	Torque demand	0.1%	-32768 to 32767	_	I16	ro	TxPDO	ALL	No	Х	01_0
6075h	00h	Motor rated current	mA	0 to 4294967295	0	U32	rw	No	ALL	No	х	01_0
6076h	00h	Motor rated torque	mN∙m	0 to 4294967295	-	U32	ro	No	ALL	No	х	01_0
6077h	00h	Torque actual value	0.1%	-32768 to 32767	—	I16	ro	TxPDO	ALL	No	Х	
6078h	00h	Current actual value	0.1%	-32768 to 32767	_	I16	ro	TxPDO	ALL	No	Х	0I_0
6079h	00h	DC link circuit voltage	mV	0 to 4294967295	_	U32	ro	TxPDO	ALL	No	х	
607Ah	00h	Target position	Command unit	-2147483648 to 2147483647	0	132	rw	RxPDO	pp csp	No	A	0I_0
607Bh	_	Position range limit	—	—	—	_	-	—	ALL	-	-	01_0
	00h	Highest sub-index supported	_	2	_	U8	ro	No	ALL	No	Х	
	01h	Min position range limit	Command unit	-2147483648 to 2147483647	-2147483648	132	rw	RxPDO	ALL	Yes	х	
	02h	Max position range limit	Command unit	-2147483648 to 2147483647	2147483647	132	rw	RxPDO	ALL	Yes	х	
607Ch	00h	Home offset	Command unit	-2147483648 to 2147483647	0	132	rw	RxPDO	ALL	Yes	P, H	01_0
607Dh	_	Software position limit	_	_	_	_	_	_	pp ip csp	_	_	01_0
	00h	Number of entries	_	2	_	U8	ro	No	pp ip csp	No	х	
	01h	Min position limit	Command unit	-2147483648 to 2147483647	0	132	rw	RxPDO	pp ip csp	Yes	P, H	
	02h	Max position limit	Command unit	-2147483648 to 2147483647	0	132	rw	RxPDO	pp ip csp	Yes	P, H	
607Eh	00h	Polarity	_	0 to 255	0	U8	rw	No	ALL	Yes	P, H	_
		• bit 5: Torque polarity										0I_0
		• bit 6: Speed polarity										

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
607Eh	00h	• bit 7: Position polarity										01_0
607Fh	00h	Max profile velocity	Command unit/s	0 to 4294967295	999642454	U32	rw	RxPDO	pp hm ip pv	Yes	В	01_0
6080h	00h	Max motor speed	r/min	0 to 4294967295	7150	U32	rw	RxPDO	ALL	Yes	В	01_0
6081h	00h	Profile velocity	Command unit/s	0 to 4294967295	0	U32	rw	RxPDO	pp ip	Yes	A	01_0
6082h	00h	End velocity	Command unit/s	0 to 4294967295	0	U32	rw	RxPDO	pp ip	Yes	х	
6083h	00h	Profile acceleration	Command unit/s <sup>2</sup>	0 to 4294967295	4194304000	U32	rw	RxPDO	pp pv ip	Yes	A	OI_O
6084h	00h	Profile deceleration	Command unit/s <sup>2</sup>	0 to 4294967295	4194304000	U32	rw	RxPDO	pp pv ip csp csv	Yes	A	OI_O
6085h	00h	Quick stop deceleration	Command unit/s <sup>2</sup>	0 to 4294967295	4194304000	U32	rw	RxPDO	pp pv hm ip csp csv	Yes	A	OI_O
6086h	00h	Motion profile type	_	-32768 to 32767	0	116	rw	RxPDO	pp pv ip	Yes	A	01_0
6087h	00h	Torque slope	0.1%/s	0 to 4294967295	1000	U32	rw	RxPDO	tq cst	Yes	A	01_0
6088h	00h	Torque profile type	_	-32768 to 32767	0	I16	rw	RxPDO	tq	Yes	А	01_0
608Fh	—	Position encoder resolution	_	-	_	-	-	-	ALL	-	—	01_0
	00h	Highest sub-index supported	_	2	_	U8	ro	No	ALL	No	Х	
	01h	Encoder increments	pulse	1 to 4294967295	-	U32	ro	No	ALL	No	Х	
	02h	Motor revolutions	r (motor)	1 to 4294967295	-	U32	ro	No	ALL	No	Х	
6091h	-	Gear ratio	_	_	_	-	-	_	ALL	-	-	
	00h	Number of entries	_	2	_	U8	ro	No	ALL	No	Х	
	01h	Motor revolutions	r (motor)	1 to 4294967295	1	U32	rw	No	ALL	Yes	P, H	
	02h	Shaft revolutions	r (shaft)	1 to 4294967295	1	U32	rw	No	ALL	Yes	P, H	
6092h	-	Feed constant	_	_	_	-	-	-	ALL	-		
	00h	Highest sub-index supported	_	2	_	U8	ro	No	ALL	No	Х	
	01h	Feed	Command unit	1 to 4294967295	8388608	U32	rw	No	ALL	Yes	P, H	
	02h	Shaft revolutions	r (shaft)	1 to 4294967295	1	U32	rw	No	ALL	Yes	P, H	
6098h	00h	Homing method	-	-128 to 127	0	18	rw	RxPDO	hm	Yes	В	01_0
6099h	-	Homing speeds	_	_	_	-	_	_	hm	-	_	0I_0
	00h	Number of entries	_	2	_	U8	ro	No	hm	No	Х	
	01h	Speed during search for switch	Command unit/s	0 to 4294967295	873813	U32	rw	RxPDO	hm	Yes	A	
	02h	Speed during search for zero	Command unit/s	0 to 4294967295	87381	U32	rw	RxPDO	hm	Yes	A	

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
609Ah	00h	Homing acceleration	Command unit/s <sup>2</sup>	0 to 4294967295	4194304000	U32	rw	RxPDO	hm	Yes	A	01_0
60A3h	00h	Profile jerk use	-	1 to 2, 255	1	U8	rw	No	pp pv ip	Yes	A	01_0
60A4h	_	Profile jerk	_	_	-	_	_	_	pp pv ip	_	_	
	00h	Highest sub-index supported	_	2	_	U8	ro	No	pp pv ip	No	х	
	01h	Profile jerk1	Command unit/s <sup>3</sup>	0 to 4294967295	0	U32	rw	No	pp pv ip	Yes	A	
	02h	Profile jerk2	Command unit/s <sup>3</sup>	0 to 4294967295	0	U32	rw	No	pp pv ip	Yes	A	
60B0h	00h	Position offset	Command unit	-2147483648 to 2147483647	0	132	rw	RxPDO	csp	Yes	A	01_0
60B1h	00h	Velocity offset	Command unit/s	-2147483648 to 2147483647	0	132	rw	RxPDO	pp pv hm ip csp csv	Yes	A	OI_O
60B2h	00h	Torque offset	0.1%	-32768 to 32767	0	116	rw	RxPDO	ALL	Yes	А	01_0
60B8h	00h	Touch probe function	_	0 to 65535	0	U16	rw	RxPDO	ALL	No	А	_
		• bit 0: Touch Probe 1 execut	e, stop									01_0
		• bit 1: Touch Probe 1 event r	node selection									
		• bit 2: Touch Probe 1 trigger	selection (externa	al input, Z-phase)								
		• bit 4: Touch Probe 1 rising e	edge selection									
		• bit 5: Touch Probe 1 falling	edge selection									
		bit 8: Touch Probe 2 execut	e, stop									
		<ul> <li>bit 9: Touch Probe 2 event r</li> </ul>	node selection (s	ingle, continuous)								
		bit 10: Touch Probe 2 trigge	r selection (extern	nal input, Z-phase)								
		bit 12: Touch Probe 2 rising	edge selection									
		bit 15: Fouch Probe 2 failing     bit 15: External scale monite		nable disable								
60B9h	00h	Touch probe status		0 to 65535	_	U16	ro	TXPDO	ALI	No	x	01.0
60BAh	00h	Touch probe 1 positive edge	Command unit	-2147483648 to 2147483647		132	ro	TxPDO	ALL	No	X	01_0
60BBh	00h	Touch probe 1 negative edge	Command unit	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	Х	
60BCh	00h	Touch probe 2 positive edge	Command unit	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	Х	
60BDh	00h	Touch probe 2 negative edge	Command unit	-2147483648 to 2147483647	_	132	ro	TxPDO	ALL	No	Х	
60C2h	_	Interpolation time period	_	_	-	_	_	_	ip csp csv cst	_	_	01_0
	00h	Highest sub-index supported	_	2	_	U8	ro	No	ip csp csv cst	No	Х	

Index	Sub-Index	Name	Units	Range	Initial value	Data type		PDO	Op-mode	EEPROM	Attribute	Reference	
60C2h	01h	Interpolation time period value	_	0 to 255	1	U8	rw	No	ip csp csv cst	Yes	A	01_0	
	02h	Interpolation time index	_	-128 to 63	-3	18	rw	No	ip csp csv cst	Yes	A		
60C5h	00h	Max acceleration	Command unit/s <sup>2</sup>	0 to 4294967295	4294967295	U32	rw	RxPDO	pp hm pv ip	Yes	A	OI_O	
60C6h	00h	Max deceleration	Command unit/s <sup>2</sup>	0 to 4294967295	4294967295	U32	rw	RxPDO	pp hm pv ip	Yes	A	OI_O	
60E0h	00h	Positive torque limit value	0.1%	0 to 65535	5000	U16	rw	RxPDO	ALL	Yes	А	01_0	
60E1h	00h	Negative torque limit value	0.1%	0 to 65535	5000	U16	rw	RxPDO	ALL	Yes	А		
60E3h	_	Supported homing methods	_	_	_	-	-	-	ALL	-	-	OI_O	
	00h	Number of entries	-	32	_	U8	ro	No	ALL	No	Х		
	01h	1st supported homing method	—	-128 to 127	—	18	ro	No	ALL	No	Х		
				:									
	20h	32nd supported homing meth- od	_	-128 to 127	_	18	ro	No	ALL	No	Х		
60F2h	00h	Position option code     —     0 to 65535     0     U16     rw     RxPDO     pp     Yes     A										_	
		bits 1 to 0: relative option											
		bits 3 to 2: change immediately option											
		bits 5 to 4: request-response option											
		• bit 15: manufacturer-specifi	c										
60F4h	00h	Following error actual value	Command unit	-2147483648 to 2147483647	_	132	ro	TxPDO	pp hm ip csp	No	X	01_0	
60FAh	00h	Control effort	Command unit/s	-2147483648 to 2147483647	_	132	ro	TxPDO	pp hm ip csp	No	x	OI_O	
60FCh	00h	Position demand internal val- ue	pulse	-2147483648 to 2147483647	_	132	ro	TxPDO	pp hm ip csp	No	Х	01_0	
60FDh	00h	Digital inputs	—	0 to 4294967295	_	U32	ro	TxPDO	ALL	No	х	01_0	
60FEh	-	Digital outputs	_	_	—	-	-	-	ALL	-	—	_	
		• bit 0: set brake										01_0	
		• bit 16: EX-OUT1											
		• bit 19: vel-loop torque limit											
		bit 20: vel-loop integral clear											
		• bit 28: Timestamp reference	e time reset										
	00h	Number of entries	_	2	_	U8	ro	No	ALL	No	Х		
	01h	Physical outputs	_	0 to 4294967295	0	U32	rw	RxPDO	ALL	Yes	A		
	02h	Bit mask	_	0 to 4294967295	0	U32	rw	RxPDO	ALL	Yes	A		

Index	Sub-Index	Name	Units	Range	Initial value	Data type	Access	PDO	Op-mode	EEPROM	Attribute	Reference
60FFh	00h	Target velocity	Command unit/s	-2147483648 to 2147483647	0	132	rw	RxPDO	pv csv	No	A	01_0
6403h	00h	Motor catalogue number	—	_	_	VS	ro	No	ALL	No	Х	01_0
6502h	00h	Supported drive modes	-	0 to 4294967295	_	U32	ro	TxPDO	ALL	No	Х	01_0

### 7.2 Control Mode Block Diagram

Block diagrams of each control mode including the various control functions are shown below.

#### 7.2.1 Position Control Mode Block Diagram



\*1 Methods (criteria) for calculating position deviation on Set-up Support Software (PANATERM ver.7) and on an analog monitor will vary depending on the setting for Pr7.23 "Communication function extended setup 2" :bit 14 "Command position deviation output switching". For details, see "When switching analog monitor output signal types" in Operating Instructions (Overall) "3.2.8 Wiring to Connector X7 (Connecting to External Monitor)".

- \*2 Position commands in Set-up Support Software (PANATERM ver.7) depend on Pr7.99 "Communication function extended setup 6" :bit 3 "Command pulse accumulated value [command unit] output setting" settings.
- \*3 When executing a trial run, Z-phase search, or frequency characteristics (position loop characteristics) from Set-up Support Software (PANATERM ver.7), the driver switches to position control internally.
- \* Numbers in italics (e.g., 607Ah) represent EtherCAT object numbers.
- \* Numbers in bold (e.g., 1.00) represent servo parameter numbers.
- \* Some objects such as polarity are omitted.



- \*1 Methods (criteria) for calculating position deviation on Set-up Support Software (PANATERM ver.7) and on an analog monitor will vary depending on the setting for Pr7.23 "Communication function extended setup 2" :bit 14 "Command position deviation output switching". For details, see "When switching analog monitor output signal types" in Operating Instructions (Overall) "3.2.8 Wiring to Connector X7 (Connecting to External Monitor)".
- \*2 Position commands in Set-up Support Software (PANATERM ver.7) depend on Pr7.99 "Communication function extended setup 6" :bit 3 "Command pulse accumulated value [command unit] output setting" settings.
- \*3 When executing frequency characteristics (velocity closed-loop characteristics analysis, torque speed (vertical)) from Setup Support Software (PANATERM ver.7), the driver switches to velocity control internally.
- \* Numbers in italics (e.g., 607Ah) represent EtherCAT object numbers.
- \* Numbers in bold (e.g., **1.00**) represent servo parameter numbers.
- \* Some objects such as polarity are omitted.

### 7.2.2 Speed Control Mode Block Diagram



- \*1 When executing a trial run, Z-phase search, or frequency characteristics (position loop characteristics) from Set-up Support Software (PANATERM ver.7), the driver switches to position control internally.
- \* Numbers in italics (e.g., 607Ah) represent EtherCAT object numbers.
- \* Numbers in bold (e.g., **1.00**) represent servo parameter numbers.
- \* Some objects such as polarity are omitted.



## Control block diagram: Velocity control (when two-degree-of-freedom control mode is disabled)

- \*1 When executing frequency characteristics (velocity closed-loop characteristics analysis, torque speed (vertical)) from Setup Support Software (PANATERM ver.7), the driver switches to velocity control internally.
- \* Numbers in italics (e.g., 607Ah) represent EtherCAT object numbers.
- \* Numbers in bold (e.g., 1.00) represent servo parameter numbers.
- \* Some objects such as polarity are omitted.

## 7.2.3 Torque Control Mode Block Diagram



- \*1 When executing frequency characteristics (torque speed (normal)) from Set-up Support Software (PANATERM ver.7), the driver switches to velocity control internally.
- \* Numbers in italics (e.g., 607Ah) represent EtherCAT object numbers.
- \* Numbers in bold (e.g., 1.00) represent servo parameter numbers.
- \* Some objects such as polarity are omitted.

### 7.2.4 Full-closed Control Mode Block Diagram



\*1 Methods (criteria) for calculating position deviation on Set-up Support Software (PANATERM ver.7) and on an analog monitor will vary depending on the setting for Pr7.23 "Communication function extended setup 2" :bit 14 "Command

position deviation output switching". For details, see "When switching analog monitor output signal types" in Operating Instructions (Overall) "3.2.8 Wiring to Connector X7 (Connecting to External Monitor)".

- \*2 Position commands in Set-up Support Software (PANATERM ver.7) depend on Pr7.99 "Communication function extended setup 6" :bit 3 "Command pulse accumulated value [command unit] output setting" settings.
- \*3 When executing a trial run, Z-phase search, or frequency characteristics (position loop characteristics) from Set-up Support Software (PANATERM ver.7), the driver switches to position control internally.
- \*4 Velocity [r/min] unit calculated from encoder, not external scale.
- \* Numbers in italics (e.g., 607Ah) represent EtherCAT object numbers.
- \* Numbers in bold (e.g., **1.00**) represent servo parameter numbers.
- \* Some objects such as polarity are omitted.



- \*1 Position deviation [command unit] operation criteria in Set-up Support Software (PANATERM ver.7) can be changed with Pr7.23 "Communication function extended setup 2" :bit 14.
- \*2 Position commands in Set-up Support Software (PANATERM ver.7) depend on Pr7.99 "Communication function extended setup 6" :bit 3 "Command pulse accumulated value [command unit] output setting" settings.
- \*3 When executing a trial run, Z-phase search, or frequency characteristics (position loop characteristics) from Set-up Support Software (PANATERM ver.7), the driver switches to position control internally.
- \*4 Velocity [r/min] unit calculated from encoder, not external scale.

- \* Numbers in italics (e.g., 607Ah) represent EtherCAT object numbers.
- \* Numbers in bold (e.g., **1.00**) represent servo parameter numbers.
- \* Some objects such as polarity are omitted.

#### 7.3 Parameters Related To TUNINGLESS

- Pr0.02 "Real-time auto-gain tuning setup"
- Pr0.03 "Real-time auto-tuning machine stiffness setup"
- Pr0.04 "Inertia ratio"
- Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
- Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning"
- Pr1.00 "1st gain of position loop"
- Pr1.01 "1st velocity loop gain"
- Pr1.02 "1st velocity loop integration time constant"
- Pr1.03 "1st filter of velocity detection"
- Pr1.04 "1st torque filter time constant"
- Pr1.10 "Velocity feed forward gain"
- Pr1.11 "Velocity feed forward filter"
- Pr1.12 "Torque feed forward gain"
- Pr1.13 "Torque feed forward filter"
- Pr1.14 "2nd gain setup"
- Pr2.00 "Adaptive filter mode setup"
- Pr2.01 "1st notch frequency"
- Pr2.02 "1st notch width selection"
- Pr2.03 "1st notch depth selection"
- Pr2.04 "2nd notch frequency"
- Pr2.05 "2nd notch width selection"
- Pr2.06 "2nd notch depth selection"
- Pr2.07 "3rd notch frequency"
- Pr2.08 "3rd notch width selection"
- Pr2.09 "3rd notch depth selection"
- Pr2.10 "4th notch frequency"
- Pr2.11 "4th notch width selection"
- Pr2.12 "4th notch depth selection"
- Pr2.13 "Selection of damping filter switching"
- Pr2.14 "1st damping frequency"
- Pr2.15 "1st damping filter setup"
- Pr2.16 "2nd damping frequency"
- Pr2.17 "2nd damping filter setup"
- Pr2.18 "3rd damping frequency"
- Pr2.19 "3rd damping filter setup"
- Pr2.20 "4th damping frequency"
- Pr2.21 "4th damping filter setup"
- Pr2.22 "Positional command smoothing filter"
- Pr2.23 "Positional command FIR filter"
- Pr2.24 "5th notch frequency"
- Pr2.25 "5th notch width selection"

- Pr2.26 "5th notch depth selection"
- Pr2.27 "1st damping width setting"
- Pr2.28 "2nd damping width setting"
- Pr2.29 "3rd damping width setting"
- Pr2.30 "4th damping width setting"
- Pr2.38 "Filter function switching"
- Pr2.39 "Custom notch compensation coefficient"
- Pr2.40 "Custom notch compensation frequency 1"
- Pr2.41 "Custom notch compensation frequency 2"
- Pr2.42 "Custom notch frequency"
- Pr2.43 "Custom notch width"
- Pr2.44 "Custom notch depth"
- Pr2.45 "Function expansion setup 10"
- Pr2.46 "Tuning filter 2"
- Pr2.52 "Torque command additional value 2"
- Pr2.53 "Positive direction torque compensation value 2"
- Pr2.54 "Negative direction torque compensation value 2"
- Pr5.45 "Quadrant glitch positive-direction compensation value"
- Pr5.46 "Quadrant glitch negative-direction compensation value"
- Pr6.05 "Position 3rd gain valid time"
- Pr6.06 "Position 3rd gain scale factor"
- Pr6.07 "Torque command additional value"
- Pr6.08 "Positive direction torque compensation value"
- Pr6.09 "Negative direction torque compensation value"
- Pr6.10 "Function expansion setup"
- Pr6.11 "Current loop gain response setup"
- Pr6.23 "Load change compensation gain"
- Pr6.24 "Load change compensation filter"
- Pr6.32 "Real time auto tuning custom setup"
- Pr6.41 "1st damping depth"
- Pr6.42 "2-stage torque filter time constant"
- Pr6.43 "2-stage torque filter attenuation term"
- Pr6.47 "Function expansion setup 2"
- Pr6.50 "Viscous friction compensating gain"
- Pr6.60 "2nd damping depth"
- Pr6.71 "3rd damping depth"
- Pr6.72 "4th damping depth"
- Pr6.73 "Load estimation filter"
- Pr6.74 "Torque compensation frequency 1"
- Pr6.75 "Torque compensation frequency 2"
- Pr6.76 "Load estimation count"
- Pr6.121 "Current feed forward response setup"

### 7.4 Parameters Related To One Minute TUNING

- Pr0.02 "Real-time auto-gain tuning setup"
- Pr0.04 "Inertia ratio"
- Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
- Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning"
- Pr1.00 "1st gain of position loop"
- Pr1.01 "1st velocity loop gain"
- Pr1.02 "1st velocity loop integration time constant"
- Pr1.03 "1st filter of velocity detection"
- Pr1.04 "1st torque filter time constant"
- Pr1.05 "2nd gain of position loop"
- Pr1.06 "2nd velocity loop gain"
- Pr1.07 "2nd velocity loop integration time constant"
- Pr1.08 "2nd filter of velocity detection"
- Pr1.09 "2nd torque filter time constant"
- Pr1.10 "Velocity feed forward gain"
- Pr1.11 "Velocity feed forward filter"
- Pr1.12 "Torque feed forward gain"
- Pr1.13 "Torque feed forward filter"
- Pr1.14 "2nd gain setup"
- Pr1.15 "Mode of position control switching"
- Pr1.16 "Delay time of position control switching"
- Pr1.17 "Level of position control switching"
- Pr1.18 "Hysteresis at position control switching"
- Pr1.19 "Position gain switching time"
- Pr1.20 "Mode of velocity control switching"
- Pr1.21 "Delay time of velocity control switching"
- Pr1.22 "Level of velocity control switching"
- Pr1.23 "Hysteresis at velocity control switching"
- Pr1.24 "Mode of torque control switching"
- Pr1.25 "Delay time of torque control switching"
- Pr1.26 "Level of torque control switching"
- Pr1.27 "Hysteresis at torque control switching"
- Pr2.00 "Adaptive filter mode setup"
- Pr2.01 "1st notch frequency"
- Pr2.02 "1st notch width selection"
- Pr2.03 "1st notch depth selection"
- Pr2.04 "2nd notch frequency"
- Pr2.05 "2nd notch width selection"
- Pr2.06 "2nd notch depth selection"
- Pr2.07 "3rd notch frequency"
- Pr2.08 "3rd notch width selection"

- Pr2.09 "3rd notch depth selection"
- Pr2.10 "4th notch frequency"
- Pr2.11 "4th notch width selection"
- Pr2.12 "4th notch depth selection"
- Pr2.13 "Selection of damping filter switching"
- Pr2.14 "1st damping frequency"
- Pr2.15 "1st damping filter setup"
- Pr2.16 "2nd damping frequency"
- Pr2.17 "2nd damping filter setup"
- Pr2.18 "3rd damping frequency"
- Pr2.19 "3rd damping filter setup"
- Pr2.20 "4th damping frequency"
- Pr2.21 "4th damping filter setup"
- Pr2.22 "Positional command smoothing filter"
- Pr2.23 "Positional command FIR filter"
- Pr2.24 "5th notch frequency"
- Pr2.25 "5th notch width selection"
- Pr2.26 "5th notch depth selection"
- Pr2.27 "1st damping width setting"
- Pr2.28 "2nd damping width setting"
- Pr2.29 "3rd damping width setting"
- Pr2.30 "4th damping width setting"
- Pr2.38 "Filter function switching"
- Pr2.39 "Custom notch compensation coefficient"
- Pr2.40 "Custom notch compensation frequency 1"
- Pr2.41 "Custom notch compensation frequency 2"
- Pr2.42 "Custom notch frequency"
- Pr2.43 "Custom notch width"
- Pr2.44 "Custom notch depth"
- Pr2.45 "Function expansion setup 10"
- Pr2.46 "Tuning filter 2"
- Pr2.52 "Torque command additional value 2"
- Pr2.53 "Positive direction torque compensation value 2"
- Pr2.54 "Negative direction torque compensation value 2"
- Pr2.61 "Target settling time"
- Pr2.62 "Settling time count condition"
- Pr2.63 "Allowable overshoot amount"
- Pr2.64 "Tuning amount of movement"
- Pr2.65 "Tuning max speed"
- Pr2.66 "Tuning acceleration and deceleration time"
- Pr2.67 "Tuning wait time"
- Pr2.68 "Tuning operating range upper limit"
- Pr2.69 "Tuning operating range lower limit"

- Pr2.70 "Tuning overspeed level setting"
- Pr2.71 "Tuning torque limit"
- Pr2.72 "Tuning start RTAT machine stiffness setting"
- Pr2.73 "Tuning stability margin"
- Pr2.74 "Tuning auto tuning application selection"
- Pr2.75 "Tuning step selection"
- Pr2.76 "Tuning target function selection"
- Pr2.77 "Tuning start position"
- Pr2.78 "Tuning vibration automatic suppression effective level"
- Pr2.79 "Tuning JOG test run command speed"
- Pr2.80 "Tuning JOG test run acceleration and deceleration time"
- Pr5.45 "Quadrant glitch positive-direction compensation value"
- Pr5.46 "Quadrant glitch negative-direction compensation value"
- Pr5.47 "Quadrant glitch compensation delay time"
- Pr5.48 "Quadrant glitch compensation filter setting L"
- Pr5.49 "Quadrant glitch compensation filter setting H"
- Pr6.05 "Position 3rd gain valid time"
- Pr6.06 "Position 3rd gain scale factor"
- Pr6.07 "Torque command additional value"
- Pr6.08 "Positive direction torque compensation value"
- Pr6.09 "Negative direction torque compensation value"
- Pr6.10 "Function expansion setup"
- Pr6.11 "Current loop gain response setup"
- Pr6.23 "Load change compensation gain"
- Pr6.24 "Load change compensation filter"
- Pr6.32 "Real time auto tuning custom setup"
- Pr6.41 "1st damping depth"
- Pr6.42 "2-stage torque filter time constant"
- Pr6.43 "2-stage torque filter attenuation term"
- Pr6.47 "Function expansion setup 2"
- Pr6.48 "Tuning filter"
- Pr6.49 "Command response/tuning filter attenuation term"
- Pr6.50 "Viscous friction compensating gain"
- Pr6.60 "2nd damping depth"
- Pr6.61 "1st resonance frequency"
- Pr6.62 "1st resonance attenuation ratio"
- Pr6.63 "1st anti-resonance frequency"
- Pr6.64 "1st anti-resonance attenuation ratio"
- Pr6.65 "1st response frequency"
- Pr6.66 "2nd resonance frequency"
- Pr6.67 "2nd resonance attenuation ratio"
- Pr6.68 "2nd anti-resonance frequency"
- Pr6.69 "2nd anti-resonance attenuation ratio"

- Pr6.70 "2nd response frequency"
- Pr6.71 "3rd damping depth"
- Pr6.72 "4th damping depth"
- Pr6.73 "Load estimation filter"
- Pr6.74 "Torque compensation frequency 1"
- Pr6.75 "Torque compensation frequency 2"
- Pr6.76 "Load estimation count"
- Pr6.80 "3rd resonance frequency"
- Pr6.121 "Current feed forward response setup"

7.5 Other Parameters Related To Tuning

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
0	04	В	Inertia ratio	0 to 100000	%	Sets the ratio of load inertia to motor rotor inertia.
1	00	В	1st gain of posi- tion loop	0 to 30000	0.1 s <sup>-1</sup>	Sets the 1st position loop gain.
1	01	В	1st velocity loop gain	1 to 32767	0.1 Hz	Sets the 1st velocity loop gain.
1	02	В	1st velocity loop integration time constant	1 to 10000	0.1 ms	Sets the 1st velocity loop integration time constant. The integral is retained at the set value of 9999. Disabled when set value is 10000.
1	03	В	1st filter of veloci- ty detection	0 to 5	_	Sets the 1st filter of velocity detection in 6 stages.
1	106	В	1st position loop gain change ratio	0 to 300	%	Sets the change ratio of Pr1.00 "1st gain of position loop" at the stiffness setting value when the gain change ratio is enabled . When this setup value is 0, this is set to 100 %.
1	107	В	1st velocity inte- gration change ratio	0 to 300	%	Sets the change ratio of Pr1.02 "1st velocity loop inte- gration time constant" at the stiffness setting value when the gain change ratio is enabled . When this setup value is 0, this is set to 100%.
1	108	В	1st torque filter change ratio	0 to 300	%	Sets the change ratio of Pr1.04 "1st torque filter time constant" at the stiffness setting value when the gain change ratio is enabled .
1	109	В	2nd position loop gain change ratio	0 to 300	%	Sets the change ratio of Pr1.05 "2nd gain of position loop" at the stiffness setting value when the gain change ratio is enabled . When this setup value is 0, this is set to 100%.
1	110	В	2nd velocity loop gain change ratio	0 to 300	%	Sets the change ratio of Pr1.06 "2nd velocity loop gain" at the stiffness setting value when the gain change ratio is enabled . When this setup value is 0, this is set to 100%.
1	111	В	2nd velocity inte- gration change ratio	0 to 300	%	Sets the change ratio of Pr1.07 "2nd velocity loop inte- gration time constant" at the stiffness setting value when the gain change ratio is enabled . When this setup value is 0, this is set to 100 %.
1	112	В	2nd torque filter change ratio	0 to 300	%	Sets the change ratio of Pr1.09 "2nd torque filter time constant" at the stiffness setting value when the gain change ratio is enabled .
1	113	В	Load fluctuation compensation fil- ter change ratio	0 to 300	%	Sets the change ratio of Pr6.24 "Load change compen- sation filter" at the stiffness setting value when the gain change ratio is enabled . When this setup value is 0, this is set to 100%.
1	114	В	Smoothing filter change ratio	0 to 300	%	Sets the change ratio of Pr2.22 "Positional command smoothing filter" at the stiffness setting value when the gain change ratio is enabled .
1	115	В	Tuning filter change ratio	0 to 300	%	Sets the change ratio of Pr6.48 "Tuning filter" at the stiffness setting value when the gain change ratio is enabled .
2	61	A	Target settling time	0 to 32767	ms	Sets the target settling time during tuning. If the setup value is 0, the settling time is tuned to be shorter.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	62	A	Settling time count condition	0 to 1	_	<ul> <li>Specifies the condition for counting the settling time during tuning.</li> <li>0: Counted after completion of command transfer judgment.</li> <li>1: Counted at start of command transfer judgment.</li> </ul>
2	63	A	Allowable over- shoot amount	0 to 500	%	Sets the allowable amount of overshoot during tuning as a percentage of Pr4.31 "Positioning complete (In-posi- tion) range" . Set to 0 to tune without overshoot.
2	64	A	Tuning amount of movement	0 to 2147483647	Com- mand unit	Sets the amount of movement when using operation commands during tuning. This can be set when tuning is performed using only op- eration commands from the servo driver. If the setup value is 0, the value automatically deter- mined by the servo driver is used.
2	65	A	Tuning max speed	0 to 20000	r/min	Sets the maximum speed when using operation com- mands during tuning. This can be set when tuning is performed using only op- eration commands from the servo driver. If the setup value is 0, the value automatically deter- mined by the servo driver is used.
2	66	A	Tuning accelera- tion and deceler- ation time	0 to 5000	ms	Sets the acceleration/deceleration time when using op- eration commands during tuning. This can be set when tuning is performed using only op- eration commands from the servo driver. If the setup value is 0, the value automatically deter- mined by the servo driver is used.
2	67	A	Tuning wait time	0 to 10000	ms	Sets the waiting time when using operation commands during tuning. This can be set when tuning is performed using only op- eration commands from the servo driver.
2	68	A	Tuning operating range upper limit	0 to 1073741823	Com- mand unit	Sets the amount of movement that the motor is allowed to move in the positive direction from the tuning start po- sition during tuning.
2	69	A	Tuning operating range lower limit	-1073741824 to 0	Com- mand unit	Sets the amount of movement that the motor is allowed to move in the negative direction from the tuning start position during tuning.
2	70	A	Tuning over- speed level set- ting	0 to 20000	r/min	Sets the upper limit for the allowable motor speed dur- ing tuning. Various speed protection settings are used when the setup value is 0.
2	71	A	Tuning torque limit	0 to 500	%	Sets the upper-limit value (absolute value) for the allow- able torque command during tuning. Torque limit settings are used when the setup value is 0.
2	72	A	Tuning start RTAT machine stiffness setting	0 to 44	_	Specifies the RTAT machine stiffness setting at the start of the tuning.
2	73	A	Tuning stability margin	0 to 100	%	Specifies the stability margin during tuning in %.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	75	A	Tuning step se- lection	-32768 to 32767	_	Specifies the target step for performing tuning. If the bit is 0, it is excluded from the step to be adjusted. If the bit is 1, it is the step to be adjusted. bit 0: Advance operation bit 1: Homing operation bit 2 to 15: Manufacturer use
2	76	A	Tuning target function selection	-32768 to 32767	_	Specifies the function to be tuned. If the bit is 0, it is excluded from the parameters to be tuned. If the bit is 1, it is the parameter to be tuned. bit 0: Inertia ratio bit 1: Unbalanced load compensation (default disabled) bit 2: Dynamic friction compensation (default disabled) bit 3: Viscous friction compensation (default disabled) bit 4: RTAT machine stiffness setting (position and speed gains, speed integration time constant, torque fil- ter) bit 5: RTAT feedforward control section stiffness setting (smoothing filter time constant) bit 6: Notch filter bit 7: 1st damping filter bit 8: 2nd damping filter bit 9: Load fluctuation control function bit 15 to 10: Manufacturer use
2	77	A	Tuning start posi- tion	-1073741824 to 1073741823	Com- mand unit	Sets the initial position at the start of tuning.
2	78	A	Tuning vibration automatic sup- pression effective level	0 to 100	%	Sets the threshold for automatic vibration suppression during tuning.
2	79	A	Tuning JOG test run command speed	0 to 500	r/min	Sets the command speed for JOG trial runs at the time of tuning.
2	80	A	Tuning JOG test run acceleration and deceleration time	0 to 5000	ms	Sets the acceleration/deceleration time during JOG trial run at the time of tuning.
4	31	A	Positioning complete (In-position) range	0 to 2097152	Com- mand unit	Sets the threshold value of position deviation that out- puts the positioning complete signal (INP). The command unit is used as the default unit but can be replaced by the encoder unit or external scale unit by using Pr5.20 "Position setup unit select" . However, in such cases, note that the unit of Pr0.14 "Position devia- tion excess setup" will also be changed. The position deviation value can switch the command before and after the position command filter using the Pr7.23 "Communication function extended setup 2" :bit 14 setting.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	10	В	Function expan- sion setup	-32768 to 32767	_	bit 4: Current response improvement 0: Disabled 1: Enabled Set to bit = 1 (enabled) when in synchronous mode, synchronous friction compensation mode, stiffness set- ting mode, or load fluctuation support mode (Pr0.02 = 1 to 3, or 6).
6	47	R	Function expan- sion setup 2	-32768 to 32767		Set the functions in bit units. bit 0: Two-degree-of-freedom control mode 0: Disabled 1: Enabled bit 3: Two-degree-of-freedom control real-time auto tun- ing selection 0: Standard type 1: Synchronization type <b>Notes</b> • bit 3 can only be used when bit 0 is 1.

\*1 For attributes, see <u>"7.1 Object Dictionary List"</u>.

# 7.6 List of Errors Related to One Minute TUNING

			—: N/A
Error No.	Error name	Primary Causes and Measures	Reference
257	Initial setting error 1	Command conditions are not set. Set Tuning amount of movement [command unit], Tuning max speed [r/min], and Tuning acceleration and deceleration time [ms/max speed] all to a value greater than 0.	<u>"Advanced Settings</u> Items" - "Command conditions" of "3.1.2.4.2 Initial Set- tings"
258	Initial setting error 2	Target settling time is set greater than the command (Tuning wait time - 500 ms). Set Target settling time [ms] to a value smaller than (Tuning wait time -500 ms).	<u>"Advanced Settings</u> <u>Items"</u> - <u>"Required</u> <u>performance"</u> of <u>"3.1.2.4.2 Initial Set-</u> <u>tings"</u>
259	Initial setting error 3	<ul> <li>Target settling time is set greater than the command (operation time +Tuning wait time - 500 ms) in [Command conditions].</li> <li>Set Target settling time [ms] to a value smaller than (operating time + Tuning wait time - 500 ms).</li> <li>The value obtained by adding the operating time and tuning wait time [ms] is 10000 [ms] or more.</li> <li>Set the tuning amount of movement [command unit], tuning max speed [r/min], tuning acceleration and deceleration time [ms/JOG speed], and tuning wait time [ms] so that the sum of the operating time and tuning wait time [ms] is less than 10000 [ms].</li> <li>Notes</li> <li>Operating time is the time from the start of command transfer to the completion of transfer.</li> </ul>	"Advanced Settings Items" - "Required performance" of "3.1.2.4.2 Initial Set- tings" "Advanced Settings Items" - "Command conditions"
260	Initial setting error 4	Positioning complete (In-position) range is set greater than the operating range. Set Positioning complete (In-position) range [command unit] to a value smaller than the operating range [command unit].	<u>"Advanced Settings</u> <u>Items"</u> - <u>"Required</u> <u>performance"</u> of <u>"3.1.2.4.2 Initial Set-</u> <u>tings"</u>
261	Initial setting error 5	Positioning complete (In-position) range is set greater than the command amount of movement. Set Positioning complete (In-position) range [command unit] to a value smaller than Tuning amount of movement [command unit].	<u>"Advanced Settings</u> <u>Items" - "Required</u> <u>performance"</u> of <u>"3.1.2.4.2 Initial Set-</u> <u>tings"</u>
263	Initial setting error 6	Allowable overshoot amount is set greater than the operating range. (Set Positioning complete (In-position) range [command unit] × Allowable overshoot amount[%]/100) to a value smaller than the operating range [command unit].	<u>"Step 5"</u> of <u>"3.1.2.4.2 Initial Set-</u> <u>tings"</u> <u>"Advanced Settings</u> <u>Items" - "Required</u> <u>performance"</u>
264	Initial setting error 7	The command amount of movement exceeds the operating range. Set Tuning amount of movement [command unit] to the operating range [command unit] or less.	"Advanced Settings Items" - "Command conditions" of "3.1.2.4.2 Initial Set- tings" "Step 5"
265 266	Initial setting error 8	The JOG trial run command speed or command maximum speed exceeds Over-speed level setup. Set Tuning JOG test run command speed [r/min] and Tuning max speed [r/min] to Over-speed level setup [r/min] or less.	"Advanced Settings Items" - "Detailed Pro- tection Function" of "3.1.2.4.2 Initial Set- tings" "Step 3"

Error No.	Error name	Primary Causes and Measures	Reference	
267 268	Initial setting error 9	The JOG trial run command speed or command maximum speed exceeds Tuning overspeed level setting. Set Tuning JOG test run command speed [r/min] and Tuning max speed [r/min] to Tuning overspeed level setting [r/min] or less.	<u>"Advanced Settings</u> <u>Items" - "Command</u> <u>conditions"</u> of <u>"3.1.2.4.2 Initial Set-</u> <u>tings"</u> <u>"Advanced Settings</u> <u>Items" - "Detailed Pro-</u> <u>tection Function"</u>	
275	Initial setting error 10	The set command acceleration is outside the allowable range for One Minute TUNING. Set the command acceleration to be in the range of 125001 to 4294967295 [command unit/s <sup>2</sup> ], referring to the formula below. Acceleration [command unit/s <sup>2</sup> ] = Tuning max speed [r/min]/Tun- ing acceleration and deceleration time [ms/max speed] × 1000/60 × (encoder resolution / electronic gear ratio) *For rotary type mo- tor	<u>"Advanced Settings</u> <u>Items"</u> - <u>"Command</u> <u>conditions"</u> of <u>"3.1.2.4.2 Initial Set-</u> <u>tings"</u>	
277	Initial setting error 11	A tuning target is not selected. Turn ON one of the tuning targets.	<u>"Advanced Settings</u> <u>Items"</u> - <u>"Tuning condi-</u> <u>tions"</u> of <u>"3.1.2.4.2 Ini-</u> <u>tial Settings"</u>	
278	Initial setting error 12	Tuning cannot be performed correctly because the set operating range is too small. Set a larger operating range. For One Minute TUNING, a setting of 0.5 rotations or more is rec- ommended for the amount of motor rotations.	<u>"Step 5"</u> of <u>"3.1.2.4.2 Initial Set-</u> <u>tings"</u>	
279	Initial setting error 13	Tuning cannot be performed correctly because the value set for Tuning amount of movement is too small. Increase the value set for Tuning amount of movement.	<u>"Advanced Settings</u> <u>Items" - "Command</u> <u>conditions"</u> of <u>"3.1.2.4.2 Initial Set-</u> <u>tings"</u>	
513	Load characteristic measurement error	<ul> <li>Load characteristic measurement failed.</li> <li>1 Execute One Minute TUNING once more with a larger operating range.</li> <li>2 If the inertia estimating conditions cannot be met due to the device mechanism, set the specification value to the inertia ratio and perform One Minute TUNING with the inertia ratio, unbalanced load compensation, dynamic friction compensation, and viscous friction compensation of Tuning target function selection all turned to OFF.</li> </ul>	<u>"Step 5" of</u> <u>"3.1.2.4.2 Initial Set-</u> <u>tings"</u> <u>"Advanced Settings</u> <u>Items"</u> - <u>"Tuning condi-</u> <u>tions"</u>	
769	Oscillation error	Oscillation detected during operation. Execute One Minute TUNING once more after lowering the speed loop gain value on the Parameter Settings screen.	PT_OM "8.11 All Pa- rameters"	
1025	Torque saturation error	Tuning torque limit exceeded during operation. Execute One Minute TUNING once more after revising command conditions to reduce acceleration.	<u>"Advanced Settings</u> <u>Items" - "Command</u> <u>conditions"</u> of <u>"3.1.2.4.2 Initial Set-</u> <u>tings"</u>	
1281	Stiffness measurement error	RTAT machine stiffness setting, notch, and load fluctuation sup- pression could not be adjusted. Execute One Minute TUNING once more after lowering the speed loop gain value on the Parameter Settings screen.	PT_OM "8.11 All Pa- rameters"	
1537	Device characteristics measuring error 1	Device characteristics could not be measured correctly. Execute One Minute TUNING once more with a larger operating range.	<u>"Step 5"</u> of <u>"3.1.2.4.2 Initial Set-</u> <u>tings"</u>	
1793	Device characteristics measuring error 2	Device characteristics could not be measured correctly. Execute One Minute TUNING once more with a smaller operating range.	<u>"Step 5"</u> of <u>"3.1.2.4.2 Initial Set-</u> <u>tings"</u>	
Error No.	Error name	Primary Causes and Measures	Reference	
--------------	---	--	---	--
2049	Control mode error 1	Not supported in full-closed control.     -       (Supported in position control and speed control modes.)     -		
2050	Control mode error 2	The control mode was changed to something other than position – control mode during operation. Do not switch to a mode other than position control mode when executing One Minute TUNING.		
2305	Control mode error 3	Two-degree-of-freedom control mode for synchronization type is not supported. (Two-degree-of-freedom control mode for standard type and two- degree-of-freedom control mode disabled type are supported.)	ree-of-freedom control mode for synchronization type is – orted. gree-of-freedom control mode for standard type and two- if-freedom control mode disabled type are supported.)	
2306	Auto tuning application selection error	<ul> <li>Customize is not supported with Tuning auto tuning application – selection.</li> <li>(Positioning/general-purpose are supported.)</li> </ul>		
2817	Command input error	A command was input that exceeds the movable range during op- eration. Contact the manufacturer.		

## 7.7 Glossary

Abbreviations used in this document and their official names are shown below.

### Servo Driver-related/Servo Motor-related

Abbreviation	Official Name			
CCW	Counterclockwise Rotation			
csp	Cyclic synchronous position mode			
cst	Cyclic synchronous torque mode			
cstca	Cyclic synchronous torque mode with commutation angle			
CSV	Cyclic synchronous velocity mode			
CW	Clockwise Rotation			
DB	Dynamic Brake			
EDM	External Device Monitoring			
FB	Feedback			
FF	Feed forward			
FFT	Fast Fourier Transform			
FIR	Finite Impulse Response			
hm	Homing mode			
HPF	High Pass Filter			
ip	Interpolated position mode			
LSD	Least Significant Digit			
LV	Low Voltage			
MSD	Most Significant Digit			
OSS	Open Source Software			
рр	Profile position mode			
pv	Profile velocity mode			
Recv	Receive			
RTAT	Real-Time Auto Tuning			
SRV	Servo			
SSU	STO Signal Unmatch			
STO	Safe Torque Off			
TFF	Torque Feed Forward			
tq	Torque profile mode			
vl	Velocity mode			

### EtherCAT Communication-related

Abbreviation	Official Name		
AL	Application Layer		
Boot	Bootstrap		
CoE	CANopen over EtherCAT		
DC	DC Distributed Clocks		
ENI	ENI EtherCAT Network Information		
EoE	EoE Ethernet over EtherCAT		
ESC EtherCAT SubDevice Controller			

Abbreviation	on Official Name			
ESI	EtherCAT SubDevice Information			
ESM	EtherCAT State Machine			
ETG	EtherCAT Technology Group			
FMMU	Fieldbus Memory Management Unit			
FoE	File Access over EtherCAT			
FSA	Finite State Automaton			
OP	Operational			
PDI	Physical Device Interface			
PDO	Process Data Object			
PDS	Power Drive Systems			
PreOP	Pre-Operational			
RxPDO	Receive PDO			
SafeOP Safe-Operational				
SDO	SDO Service Data Object			
SII SubDevice Information Interface				
SM SyncManager				
SoE	SoE Sercos over EtherCAT			
TxPDO	TxPDO Transmit PDO			
VoE Vendor-specific over EtherCAT				

# Object-related

### Data type

Abbreviation	Official Name		
U8	Unsigned8		
U16	Unsigned16		
U32	Unsigned32		
18	Integer8		
I16	Integer16		
132	Integer32		
VS	Visible String		
BOOL	Boolean		
OS	Octet String		

#### Access

Abbreviation	Official Name
r	read
rw	read-write
ro, RO	read-only
с	constant

# REVISIONS

Date	Rev.	Page	Description
Sep. 13, 2024	0.0	_	NEWLY ISSUED
Dec. 20, 2024	0.1	2.1.3, 3.1.3.2, 3.1.3.4.2	Revised the precAIseTUNING specifications and added their asso- ciated Precautions
Feb. 5, 2025	0.2	3.1.3.4.3	Added a note about precAIseTUNING Removed the precAIse TUNING temporary stop function
Apr. 1, 2025	0.3	1.3.4	<ul><li>Changed Function (Add to Unsupported Features)</li><li>position comparison output function</li><li>Monitor Signal Output</li></ul>
Apr. 11, 2025	1.0	1.3.2, 1.3.5	Software version upgrade • CPU1: Ver1.04→Ver1.05 • Manufacture Software: Ver1.00→Ver1.01
		1.3.4	<ul><li>Remove from the list of Unsupported Features</li><li>position comparison output function</li><li>Monitor Signal Output</li></ul>
		7.1.2.8	Updated Object Dictionary List <ul> <li>Changed the Initial value of 3780h</li> <li>Add 37B7h</li> </ul>
		7.1.2.11	Updated Object Dictionary List • Add 3A01h
		7.6	Corrected typographical errors (Err275, Err277)
May 28, 2025	1.1	4.4.3, 4.6.3, 4.7.3, 4.9.3, 4.10.3, 5.1.3, 5.2.3, 5.9.3, 7.2.4	Added Description

# Repairs, Inquiries and Technical Information

### Repairs

Contact your dealer regarding repairs.

If installed in a machine or device, consult with the machine or device manufacturer first.

### Contact us

If you have any questions, please contact the seller of the product (Sales office or Distributor).

### **Technical information**

Operating instructions, technical reference, CAD data downloads, and Web-based inquiries are available online.

"industry.panasonic.com/global/en/"

# Industrial Device Business Division, Panasonic Industry Co., Ltd.

7-1-1 Morofuku, Daito City, Osaka, 574-0044, Japan

(c) Panasonic Industry Co., Ltd. 2024-2025