

Servo System

MINAS A7N Series

Operating Instructions (Tuning)

RTEX Rotary Motor

- Thank you for purchasing a Panasonic product.
- Please use it correctly and safely after reading this document and Operating Instructions (Overall) carefully.
- Read “1.1.1 Safety Precautions” before use.
- Keep these Operating Instructions safe.
- This product is for industrial use. It cannot be used for any other purpose (e.g., household use).

Table of Contents

1 Before Use	8
1.1 Precautions	9
1.1.1 Safety Precautions	9
1.1.2 Precautions for Proper Use	12
1.1.3 Network Security	13
1.2 Related Documents	14
1.3 Software Version	15
1.3.1 Notes Regarding Software	15
1.3.2 Applicable Software Version	15
1.3.3 Software Version Confirmation Method	15
1.3.4 Functions Not Currently Supported	15
1.3.5 Software Version History	16
1.3.6 Functional Differences from Previous Series	16
1.4 Trademarks	17
2 Overview of Tuning Functions	18
2.1 Types of Tuning and Control Functions	19
2.1.1 Auto Tuning (TUNE COMPASS) and Manual Tuning	19
2.1.2 Control Functions to Improve Tracking With Respect to Control Commands	21
2.1.3 Control Functions for Suppressing Abnormal Noise and Vibration	23
2.1.4 List of Control Functions (By Driver Type)	25
2.1.5 List of Control Functions (By Control Mode)	26
2.2 Safety Function Setup Before Tuning	27
2.3 Adjustment Workflow	28
2.3.1 Adjustments at Device Startup	28
2.3.2 Re-adjustment After Device Startup	29
3 Details of Tuning Functions	30
3.1 Auto Tuning (TUNE COMPASS)	31
3.1.1 TUNINGLESS	31
3.1.1.1 Function Overview	31
3.1.1.2 Operational Conditions	31
3.1.1.3 Parameters That Are Automatically Set and Automatically Tuned	31
3.1.1.4 Usage	31
3.1.2 One Minute TUNING	32
3.1.2.1 Function Overview	32
3.1.2.2 Operational Conditions	32
3.1.2.3 Parameters That Are Automatically Set and Automatically Tuned	32
3.1.2.4 Usage	32
3.1.2.5 Use Cases in Re-adjustment	50
3.1.3 precAlse TUNING	52
3.1.3.1 Function Overview	52
3.1.3.2 Operational Conditions	52
3.1.3.3 Parameters That Are Automatically Set and Automatically Tuned	52
3.1.3.4 Usage	53
3.2 Manual Tuning	65
3.2.1 Manual TUNING	65
3.2.1.1 Function Overview	65
3.2.1.2 Operational Conditions	65
3.2.1.3 Tuning Method	65
3.2.1.4 Manual TUNING Using Set-up Support Software (PANATERM ver.7)	70
3.2.2 Load Fluctuation Suppression Tuning (Stabilizing Load Fluctuation Applications)	92
3.2.2.1 Function Overview	92

3.2.2.2	Operational Conditions	92
3.2.2.3	Tuning Procedure	92
4	Control Functions to Improve Tracking With Respect to Control Commands	93
4.1	Real-time Auto Tuning Function	95
4.1.1	Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Standard Type) ...	95
4.1.1.1	Function Overview	95
4.1.1.2	Operation Mode	95
4.1.1.3	Operational Conditions	96
4.1.1.4	Related Parameters	96
4.1.1.5	How to Use	105
4.1.1.6	Basic Gain Parameter Setup Table	107
4.1.2	Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Synchronization Type)	109
4.1.2.1	Function Overview	109
4.1.2.2	Operation Mode	109
4.1.2.3	Operational Conditions	109
4.1.2.4	Related Parameters	110
4.1.2.5	How to Use	115
4.1.2.6	Basic Gain Parameter Setup Table	118
4.1.3	Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)	120
4.1.3.1	Function Overview	120
4.1.3.2	Operation Mode	120
4.1.3.3	Operational Conditions	120
4.1.3.4	Related Parameters	121
4.1.3.5	How to Use	129
4.1.3.6	Basic Gain Parameter Setup Table	131
4.2	Gain Switching Function	133
4.2.1	Function Overview	133
4.2.2	Operational Conditions	133
4.2.3	Related Parameters	133
4.2.4	How to Use	138
4.2.4.1	For Manual Setting	138
4.2.4.2	When Set-up Support Software (PANATERM ver.7) Is Used	142
4.3	3rd Gain Switching Function	145
4.3.1	Function Overview	145
4.3.2	Operational Conditions	145
4.3.3	Related Parameters	145
4.3.4	How to Use	146
4.3.4.1	For Manual Setting	146
4.3.4.2	When Set-up Support Software (PANATERM ver.7) Is Used	147
4.4	Feedforward Function	148
4.4.1	Function Overview	148
4.4.2	Operational Conditions	148
4.4.3	Related Parameters	148
4.4.4	How to Use	149
4.4.4.1	For Manual Setting	149
4.4.4.2	When Set-up Support Software (PANATERM ver.7) Is Used	150
4.5	Friction Torque Compensation Function	153
4.5.1	Function Overview	153
4.5.2	Operational Conditions	153
4.5.3	Related Parameters	153
4.5.4	How to Use	154
4.5.4.1	When Set-up Support Software (PANATERM ver.7) Is Used	155
4.6	Load Fluctuation Control Function (Disturbance Suppression Applications)	159
4.6.1	Function Overview	159
4.6.2	Operational Conditions	159
4.6.3	Related Parameters	159
4.6.4	How to Use	160
4.6.4.1	For Manual Setting	160

4.6.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	161
4.7 Load Fluctuation Control Function (Load Fluctuation Stabilization Applications)	166
4.7.1 Function Overview	166
4.7.2 Operational Conditions	166
4.7.3 Related Parameters	167
4.7.4 How to Use	168
4.7.4.1 For Manual Setting.....	168
4.7.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	168
4.8 High Response Current Control Function	173
4.8.1 Function Overview	173
4.8.2 Operational Conditions	173
4.8.3 Related Parameters	173
4.8.4 How to Use	174
4.8.4.1 For Manual Setting.....	174
4.8.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	174
4.9 Quadrant Glitch Suppression Function	177
4.9.1 Function Overview	177
4.9.2 Operational Conditions	177
4.9.3 Related Parameters	177
4.9.4 How to Use	178
4.9.4.1 For Manual Setting.....	178
4.9.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	179
5 Details of Control Function to Suppress Abnormal Noise and Vibration	182
5.1 Torque Filter Function	184
5.1.1 Function Overview	184
5.1.2 Operational Conditions	184
5.1.3 Related Parameters	184
5.1.4 How to Use	184
5.1.4.1 For Manual Setting.....	184
5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	185
5.2 2-stage Torque Filter Function	188
5.2.1 Function Overview	188
5.2.2 Operational Conditions	188
5.2.3 Related Parameters	188
5.2.4 How to Use	189
5.2.4.1 For Manual Setting.....	189
5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	189
5.3 Notch Filter Function	192
5.3.1 Function Overview	192
5.3.2 Operational Conditions	192
5.3.3 Related Parameters	192
5.3.4 How to Use	195
5.3.4.1 For Manual Setting.....	195
5.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	195
5.4 Adaptive Filter Function	199
5.4.1 Function Overview	199
5.4.2 Operational Conditions	199
5.4.3 Related Parameters	200
5.4.4 How to Use	201
5.4.4.1 For Manual Setting.....	201
5.4.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	202
5.5 Damping Control Function	205
5.5.1 Function Overview	205
5.5.2 Operational Conditions	205
5.5.3 Related Parameters	205
5.5.4 How to Use	209

5.5.4.1 For Manual Setting.....	209
5.5.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	210
5.5.4.3 Error Troubleshooting	213
5.6 Model-type Damping Filter Function	214
5.6.1 Function Overview	214
5.6.2 Operational Conditions	214
5.6.3 Related Parameters	215
5.6.4 How to Use	217
5.6.4.1 When Set-up Support Software (PANATERM ver.7) Is Used	217
5.6.4.2 Error Troubleshooting	222
5.7 Position Command Filter Function.....	223
5.7.1 Function Overview	223
5.7.2 Operational Conditions	223
5.7.3 Related Parameters	223
5.7.4 How to Use	224
5.7.4.1 For Manual Setting.....	226
5.7.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	227
5.7.4.3 Error Troubleshooting	229
5.8 Speed Command Acceleration/Deceleration Setting Function	230
5.8.1 Function Overview	230
5.8.2 Operational Conditions	230
5.8.3 Related Parameters	230
5.8.4 How to Use	230
5.9 Hybrid Vibration Suppression Function.....	232
5.9.1 Function Overview	232
5.9.2 Operational Conditions	232
5.9.3 Related Parameters	232
5.9.4 How to Use	232
5.9.4.1 For Manual Setting.....	232
5.9.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	233
6 Functions to Assist Tuning	236
6.1 Waveform Measurement.....	237
6.1.1 Function Overview	237
6.1.2 Purpose of Use	237
6.1.3 Measurement Procedure	237
6.1.4 Method of Use.....	239
6.2 Frequency Response Measurement.....	240
6.2.1 Function Overview	240
6.2.2 Types of Measurement Modes.....	240
6.2.3 Changes from measurements using A6 Series drivers.....	241
6.2.4 Restrictions	241
6.2.5 Measurement Procedure	242
6.2.6 Method of Use.....	248
7 References.....	251
7.1 List of Parameters	252
7.1.1 Sample Description	252
7.1.2 Class 0: Basic Settings	255
7.1.3 Class 1: Gain Adjustment	256
7.1.4 Class 2: Vibration Suppression	258
7.1.5 Class 3: Velocity/Torque Control/Full-closed Control	261
7.1.6 Class 4: I/O Monitor Settings	262
7.1.7 Class 5: Enhancing Settings	264
7.1.8 Class 6: Special Settings	266
7.1.9 Class 7: Special Settings 2	270
7.1.10 Class 8: Special Settings 3	273

7.1.11 Class 11: Manufacturer Use	274
7.2 Control Mode Block Diagram	275
7.2.1 Position Control Mode Block Diagram	275
7.2.2 Speed Control Mode Block Diagram	277
7.2.3 Torque Control Mode Block Diagram	279
7.2.4 Full-closed Control Mode Block Diagram	280
7.3 Parameters Related To TUNINGLESS	282
7.4 Parameters Related To One Minute TUNING	284
7.5 Other Parameters Related To Tuning	288
7.6 List of Errors Related to One Minute TUNING	292
7.7 Glossary	295

Introduction

Servo drivers have many parameters for realizing various control functions and control performance. To obtain the desired control performance, functions appropriate for the characteristics of the target device must be selected, and parameters set while considering balance. Performing these tasks requires knowledge of controls and tuning experience, which is generally complex.

To facilitate setting parameters, this product is equipped with the following automatic tuning functions which automatically perform parameter setting tasks with no initial setting of control gain, or by simply configuring initial settings such as target control performance.

- TUNINGLESS: The driver automatically tunes the inertia ratio, enabling equipment to be operated immediately
- One Minute TUNING: Measuring the characteristics of equipment enables adjustments with control stability to be made in a short time
- precAIse TUNING: AI automatically optimizes even complex adjustments, enabling expert-level tuning

Notes

- Set-up Support Software (PANATERM ver.7) is equipped with AI.

This manual describes these automatic tuning functions and conventional manual tuning, as well as control functions for resolving various control challenges.

— Precautions —

- Unauthorized reproduction or duplication of the contents of the present text, either in whole or in part, is strictly prohibited.
- The contents of the present text (specifications, software versions, etc.) are subject to change without notice.
- Read “1.1 Precautions” before using this product.
- Before using the tuning and control functions, properly configure the settings described in “2.2 Safety Function Setup Before Tuning”.
- If communication with a host device is required, properly configure communication-related settings to prevent any obstruction to motor rotation.

1 Before Use

1.1	Precautions.....	9
1.1.1	Safety Precautions	9
1.1.2	Precautions for Proper Use.....	12
1.1.3	Network Security	13
1.2	Related Documents	14
1.3	Software Version	15
1.3.1	Notes Regarding Software	15
1.3.2	Applicable Software Version	15
1.3.3	Software Version Confirmation Method.....	15
1.3.4	Functions Not Currently Supported	15
1.3.5	Software Version History	16
1.3.6	Functional Differences from Previous Series	16
1.4	Trademarks.....	17



1.1 Precautions

1.1.1 Safety Precautions



■ Must be adhered to

This section explains precautions that must be taken to prevent harm to people and damage to property.



■ The following symbols represent the extent of the harm or damage that may occur through improper use.

 Danger	This indicates "a significant risk of death or serious injury".
 Caution	This indicates "a risk of injury or property damage".



■ The matters to be observed are explained using the following symbols.

	Must not be done.
	Must be done.

⚠ DANGER

	Do not use in wet places, corrosive atmospheres, inflammable gas atmospheres, atmospheres in which gases of low molecular weight such as helium gas are generated, or near combustible materials.	May cause fire.
	Do not place combustible materials near the motor, driver, regenerative resistor, or dynamic brake resistor.	
	Do not use in places subject to strong vibration or impact.	May cause electric shock, injury, and fire.
	Do not use with the cable immersed in oil or water.	May cause electric shock, malfunction, and damage.
	Do not install next to a heating element, such as a heater or large coil resistor.	May cause fire and malfunction.
	Never connect a commercial power supply directly to the motor.	
	Do not perform wiring or operate with wet hands.	May cause electric shock, injury, and fire.
	Never put your hand inside the driver.	May cause burns and electric shock.
	In the case of a motor with axis end keyway, do not touch the keyway with bare hands.	May cause injury.
	Never touch the rotating portion of the motor while it is running.	
	Do not touch the motor, driver heat sink, regenerative resistor, or dynamic brake resistor, since they become very hot.	May cause burns and parts damage.
	Do not drive the motor with external power.	May cause fire.
	Do not damage the cables, subject them to excessive force, place heavy objects on them, or pinch them.	May cause electric shock, malfunction, and damage.
	Install in an area free from excessive dust, water, oil, etc.	Improper installation site conditions may cause electric shock, fire, malfunction or damage.
	Install the motor, driver, and peripheral devices to nonflammable materials such as metal.	Mounting on a flammable material may cause fire.
	Wiring must be carried out by an expert in electrical work.	Wiring by a person with no expertise may cause electrical shock.
	Carry out wiring in accordance with the Operating Instructions.	Incorrect wiring may cause electrical shock, injury, malfunction, or damage.
	After correctly connecting cables, insulate the live parts with insulating material.	Incorrect wiring and short circuits may cause electrical shock, fire, or malfunction.
	Connect to the earth terminals of the motor and driver without fail.	Not grounding may cause electrical shock.
	Install and mount securely to prevent any possible fire or personal injury during an earthquake.	Failure to install properly may cause electric shock, fire, malfunction, or damage.
	Install an emergency stop circuit externally so that operation can be stopped and power turned off immediately in the event of an emergency.	
	Install an overcurrent protection device, residual current device, overheating prevention device, and emergency stop device without fail.	Failure to install and check these may cause electric shock, injury, or fire.
	After an earthquake, always confirm safety.	
	Before moving, wiring, or inspecting the driver, turn off power, wait at least as long as specified on the main unit side panel nameplate, and ensure that there is no risk of electrical shock.	Not turning off the power before these operations may cause electric shock.

⚠ CAUTION

	When transporting the product, do not hold it by the cable or motor axis.	May cause injury.
	Do not drop or tip over the product during transportation or installation.	May cause injury or malfunction.
	Do not stand on or place heavy objects on the product.	May cause electric shock, injury, malfunction, or damage.
	Do not place any objects that would block air passage around the motor, driver, and peripheral devices.	May cause burns or fires.
	Do not use in direct sunlight.	May cause injury or fire.
	Do not block or insert foreign matter into the heat dissipation holes.	May cause electric shock or fire.
	There should be no strong impact on the product.	May cause malfunction.
	There should be no strong impact on the motor axis.	May cause detectors, etc., to malfunction.
	Do not turn the driver main power on and off frequently.	May cause malfunction.
	Never run or stop the motor with the electromagnetic contactor installed on the main power supply side.	
	Do not make extreme gain adjustments or changes in the driver, or destabilize the driving or operation of the machine.	May cause injury.
	Do not use the motor's built-in brakes to stop a moving load.	May cause injury or malfunction.
	Never modify, dismantle, or repair.	May cause fire, electric shock, injury, or malfunction.
	Mount in a manner appropriately matched to the base machine mass and product rated output.	Improper attachment or installation may cause injury or malfunction.
	Observe the specified mounting method and orientation.	
	Only use the eye bolt of the motor for transportation of the motor.	Use for transportation of the machine may cause injury or malfunction.
	Set the motor and driver ambient temperature within the temperature and humidity ranges for use.	Improper attachment or installation may cause injury or malfunction.
	Create the specified clearance in separating the driver from the control panel inner surface and from other devices when installing.	
	Maintain the specified voltage.	Operation at a voltage outside the rated voltage range may cause electric shock, injury, or fire.
	Connect a relay that disconnects in the event of an emergency stop in series with the brake control relay.	Not connecting it may cause injury or malfunction.
	Install safety devices for built-in brake or gear head idling or locking, or grease leakage from gear head.	Non-installation may cause injury, damage, or pollution.
	The servo drive may start up with no warning when power is restored after a blackout, so the machine must be set to ensure the safety of the operator at all times.	May cause injury.
	Use the specified combination of motor and driver.	May cause malfunction or fire if not used in the correct combination.
	To perform a trial run, secure the motor, and install it in the mechanical system after checking its operation while disconnected from the mechanical system.	Use of the wrong model or incorrect wiring may cause injury.
	When an error occurs, clear the error and only restart after eliminating the cause and ensuring safety.	Not eliminating the cause of the error might cause injury.
	If the driver malfunctions, shut off the power on the power supply side of the driver.	Continued passage of a large current may lead to fire.
	Always disconnect the power when not in use for a long time.	Improper operation may cause injury.
	Use a stabilized power supply with double insulation or reinforced insulation for the DC power supply.	May cause electric shock, fire or malfunction.

■ Other precautions

- When disposing of batteries, insulate them with tape and dispose of them in accordance with local regulations.
- When disposing of the Servo driver and motor, they are treated as industrial waste.
- Wrinkling of the label affixed to the motor will not present a problem in use of the motor.

1.1.2 Precautions for Proper Use

- Observe the following precautions when exporting the product or equipment incorporating the product.
If the end user or end use of this product is related to the military or weaponry, etc., it may be subject to export restrictions as set forth in the Foreign Exchange and Foreign Trade Act or by the regional authority. When exporting, please review and follow the necessary export procedures.
- This product is intended for use with general industrial products. It is not designed or manufactured for use in machines or systems that may cause death on failure. This product is not for use in devices critical to human wellbeing or in specialized environments, such as nuclear power control, aerospace equipment, transportation systems, medical equipment or various safety devices.
- Installation, wiring, operation and maintenance of the equipment should be carried out by qualified and experienced personnel.
- Apply adequate tightening torque to the product mounting screws by taking into consideration the strength of the screws and the characteristics of the material to which the product is installed.
- Install safety equipment when applying this product to systems that could cause serious accidents or damage in the event of product failure.
- Because noise resistance may be affected by wiring conditions (e.g., earthing methods, cable length, signal wire shielding), please confirm the noise resistance of your equipment.
- Ensure that the motor axis is not operated without being electrically grounded, as this may lead to electrolytic corrosion of the motor bearing and increased bearing noise, depending on the machine and the installation environment.
- Some faults may cause the emission of roughly one cigarette's worth of smoke. Please consider these possibilities when using the device in cleanrooms and similar facilities.
- Make sure to follow indications as overloading products can cause loads to collapse.
- Do not use detergents containing benzene, thinner, alcohol, acid, or alkaline, since this may cause discoloration or damage the exterior of the product. When using a neutral detergent, please use a solution diluted to the concentration specified for the neutral detergent you are using.
- Treat as industrial waste on disposal.
- Please ensure that finished equipment complies with standards, laws and regulations, and confirm that the structure, dimensions, lifetime and characteristics of the product are suitable for your installed equipment and components.
- Note that use of this product outside the scope of specifications is not covered under warranty.
- Reverse engineering, decompiling and disassembling of this product is strictly prohibited.

1.1.3 Network Security

As you will use this product connected to a network, your attention is called to the following security risks.

- 1 Leakage or theft of information through this product
- 2 Use of this product for fraudulent operation by persons with malicious intent
- 3 Interference with or stoppage of this product by persons with malicious intent

It is the customer's responsibility to ensure that sufficient network security measures are taken, including the following.

We will not be liable for any damage caused by insufficient network security.

— Precautions —

- This product is to be used in an environment where only a limited number of parties are permitted access to the product.
- This product is not to be installed in locations where the product and its accessories, such as cables, can be easily destroyed.
- This product is to be used on a network that is not connected to the Internet.
- If an external device, such as a computer or tablet, is connected to this product, there are concerns about the effects of computer viruses and unauthorized programs.

Take appropriate security measures with external devices, such as ensuring that they are checked for computer viruses and that regular cleaning of such viruses is performed before connecting them.

- If this product is turned over to a third party for transfer, disposal, repair, etc., important information may be left recorded in the device.

Make deletions, etc.. at your own risk, and handle such matters with sufficient care.

1.2 Related Documents

The following are documents related to this product (including this manual). See each document as necessary for safe use of this product.

The documents can be downloaded from the following site.

<https://industry.panasonic.com/global/en/>

Document name	Abbreviations in this manual	Document No.	Description
Servo System Operating Instructions			
MINAS A7N Series Operating Instructions (Overall) RTEX Rotary Motor	OI_O	IMG11	This manual describes the selection, connection, usage, and error handling of servo drivers and servo motors to ensure correct and safe use of this product.
MINAS A7N Series Operating Instructions (Tuning) RTEX Rotary Motor	OI_A	IMG23	This document describes the adjustment function of the servo driver.
For MINAS Set-up Support Software (PANATERM ver.7) Operating Manual	PT_OM	IMG15	This document describes how to use PANATERM ver. 7, the setup support software for this product.
Servo Driver Standard Specification			
MINAS A7N Series Standard Specifications Rotary Motor (Standard / Multi-function / Application specialized)	SS	SX-DSV03719	This document describes the hardware specifications of the servo driver.
Servo Driver Technical Reference			
MINAS A7N Series Technical Reference Functional Specification Rotary Motor (Standard / Multi-function / Application specialized)	TR_FS	SX-DSV03758	This document describes how to use the various functions of the servo driver.
MINAS A7N Series Technical Reference Communication Specification Rotary Motor (Standard / Multi-function / Application specialized)	TR_CS	SX-DSV03761	This document describes the interface that connects the servo driver to the host device.
Motion Controller User's Manual			
GM1 Controller User's Manual (Operation)	GM1_UM	WUME-GM1OP	This document describes how to use the motion controller GM1.

1.3 Software Version

1.3.1 Notes Regarding Software

This product incorporates open source software (OSS), and usage is pursuant to the terms of the license (see Technical Reference Functional Specification “10 License Terms for Open Source Software (OSS)”). Your company may also have an obligation to use OSS, so please take appropriate measures at your company.

1.3.2 Applicable Software Version

The present manual applies to the following servo driver software versions.

CPU 1 (Software version 1)	Ver.1.05
CPU 2 (Software version 2)	Ver.1.02

1.3.3 Software Version Confirmation Method

The above software versions can be confirmed using the following methods.

- Software version 1, Software version 2
 - RTEX communication command Type_Code 140h (A4N-compatible), 14h (standard)
(See Technical Reference Communication Specification)
 - Set-up Support Software (PANATERM ver.7)

1.3.4 Functions Not Currently Supported

The functions listed in the table below are not currently supported in this software version.

Please note that although the following functions are described in some parts of the text, they are not supported in this software version.

Function name
Profile position control (PP)
Cyclic velocity control (CV)
Cyclic torque control (CT)
Full-closed control function (rotary scale)
Batteryless absolute encoder
Position comparison output function
Continuous rotating absolute encoder function
Virtual full-closed control function
External scale position information monitor function for semi-closed control
Deterioration diagnosis warning function
Latch mode function with stop function
Retracting operation function
Fall prevention function for when alarm is triggered
Slow stop function
Backlash compensation function

1.3.5 Software Version History

- New software versions are upward compatible with old software versions.

The parameters used in the old software version can be used as they are in the new software version.

Parameter factory default values for features added in the new software version are set to values that disable the added features. For this reason, immediately after upgrading, the servo driver will operate in a manner compatible with an older software versions.

- When using the added functions, set parameters in accordance with the explanations of functions in this manual.

Software version		Class	Changed Function Details	Relevant Section	Supported Set-up Support Software (PAN-ATERN ver.7)
CPU1	CPU2				
1.04	1.02	First version	Newly created	—	7.0.0.0 and later
1.05	1.02	Extended Version 1	Monitor Signal Output	OI_O “3.2.8.1”	7.0.3.0 and later

1.3.6 Functional Differences from Previous Series

- For differences from the MINAS A6N Series, see Technical Reference Functional Specification “1.2.6 Functional Differences from Previous Series” and Technical Reference Communication Specification “1.2.6 Functional Differences from Previous Series” .
- The MINAS A7N Series may not operate in complete compatibility with previous series (the A6N Series, etc.). Be sure to carry out an evaluation before changing from a previous series to the MINAS A7N Series, as parameter re-tuning may be required.

The initial values for the MINAS A7N Series are listed in Operating Instructions (Overall) “6.3 List of Parameters” .

1.4 Trademarks

- MINAS, TUNE COMPASS, PANATERM, Realtime Express and RTEX are registered trademarks or trademarks of Panasonic Holdings Corporation in Japan and other countries.

2 Overview of Tuning Functions

- 2.1 Types of Tuning and Control Functions 19
 - 2.1.1 Auto Tuning (TUNE COMPASS) and Manual Tuning 19
 - 2.1.2 Control Functions to Improve Tracking With Respect to Control Commands21
 - 2.1.3 Control Functions for Suppressing Abnormal Noise and Vibration23
 - 2.1.4 List of Control Functions (By Driver Type)25
 - 2.1.5 List of Control Functions (By Control Mode)26
- 2.2 Safety Function Setup Before Tuning..... 27
- 2.3 Adjustment Workflow 28
 - 2.3.1 Adjustments at Device Startup28
 - 2.3.2 Re-adjustment After Device Startup.....29


2.1 Types of Tuning and Control Functions

2.1.1 Auto Tuning (TUNE COMPASS) and Manual Tuning

In order to get the best performance out of the device, parameters must be set to optimal values using appropriate control functions, which is generally complex. This product provides the three automatic tuning functions shown in the table below, which automatically tune parameters with no initial setting of control gain, or by simply configuring initial settings such as target control performance. TUNE COMPASS is the collective name for these automatic tuning functions. The functions selected can be tailored to meet customer requirements.

Manual tuning is also possible to ensure the best responsiveness and stability for individual loads.

For specific instructions on selecting tuning means, see [“2.3 Adjustment Workflow”](#).



○: Supported X: Not supported

Function name	Function overview	Operation command		Set-up Support Software (PANATERM ver.7) needed	Reference
		Internal command	Upper command		
Auto tuning (TUNE COMPASS)					
TUNINGLESS	<p>This function automatically tunes inertia based on the actual operation of the motor, using the initial values as parameters.</p> <p>This function is enabled at the time of shipment.</p> <p>This function is useful when you want to move the motor immediately.</p>	○ (*1)	○	×	<u>“3.1.1 TUNINGLESS”</u>
One Minute TUNING	<p>A function that automatically tunes various parameters to satisfy target performance by measuring device characteristics and ensuring the control tolerance from the actual operation of the device.</p> <p>This is effective for obtaining a higher control performance in a relatively short time.</p> <p>If there is a change in the device workpiece or position, only specific items can be auto tuned again.</p>	○	×	○	<u>“3.1.2 One Minute TUNING”</u>

Function name	Function overview	Operation command		Set-up Support Software (PANATERM ver.7) needed	Reference
		Internal command	Upper command		
precAise TUNING	<p>This function automatically tunes various parameters while the motor is running, with AI determining the response.</p> <p>It is effective for tuning devices that are difficult to tune and require tuning by skilled operators. The tuning results are expected to exceed those of skilled operators.</p> <p>This is also effective for reducing operator labor hours, because it performs automatic operation using Set-up Support Software (PANATERM ver.7) after initial setting of target performance and multiple operation patterns, etc.</p>	○	×	○	<u>“3.1.3 precAise TUNING”</u>
Manual Tuning					
Manual TUNING	<p>Re-adjustment may be necessary to further improve responsiveness and stability, for example, after auto tuning. In such cases, this function manually sets individual parameters to their optimal values.</p> <p>The dedicated user interface for Set-up Support Software (PANATERM ver.7) , groups the related parameters by control function. Gain adjustment and tuning of vibration suppression filters, etc., can easily be performed manually.</p>	○ (*1)	○	○ (*2)	<u>“3.2.1 Manual TUNING”</u>
Load fluctuation suppression tuning (stabilizing load fluctuation applications)	In devices where load inertia fluctuates, vibration may occur due to the effect of load inertia fluctuations. This function reduces this vibration and improves stability.	○ (*1)	○	○ (*2)	<u>“3.2.2 Load Fluctuation Suppression Tuning (Stabilizing Load Fluctuation Applications)”</u>

*1 Use the Set-up Support Software (PANATERM ver.7) trial run function.

*2 Can be implemented without Set-up Support Software (PANATERM ver.7) .

2.1.2 Control Functions to Improve Tracking With Respect to Control Commands

These functions are expected to improve tracking with respect to control commands.

A list of functions is shown below.

The “Auto tuning functions supported” column shows whether or not servo parameters can be tuned by each automatic tuning function.

○: Supported X: Not supported

Function name	Function overview	Auto tuning functions supported			Reference
		TUNING-LESS	One Minute TUNING	precAlse TUNING	
Real-time auto tuning function	This function estimates machine load characteristics in real time and uses those results to automatically perform basic gain setting and load characteristic compensation. The tuning of stiffness parameters should yield a reduction in settling time.	○ (*1)	○	○	“4.1 Real-time Auto Tuning Function”
Gain switching function	A function that switches gain types, setting conditions, etc., based on command inputs such as torque commands and speed commands, in order to perform optimal control based on the operating state of the servo driver. This is expected to shorten the settling time and suppress fine vibration while stopped.	×	×	○	“4.2 Gain Switching Function”
3rd gain switching function	In addition to the normal gain switching function (two-stage gain switching function), this function sets a 3rd gain between both gains. This is expected to shorten the settling time. Overshoot suppression is expected from the gain switching function.	×	×	○	“4.3 3rd Gain Switching Function”
Feedforward function	This function performs compensation to minimize the effect of delay caused by feedback control on the command value before the effect is apparent. This is expected to improve tracking of position control and speed control.	○	○	○	“4.4 Feedforward Function”
Friction torque compensation function	This function reduces the effect of mechanical system friction and improves responsiveness. This is expected to compensate the effect of friction and improve command tracking.	×	○	○	“4.5 Friction Torque Compensation Function”

Function name	Function overview	Auto tuning functions supported			Reference
		TUNING-LESS	One Minute TUNING	precAlse TUNING	
Load fluctuation control function	<p>In devices with which disturbance torque is applied, velocity change may occur due to the disturbance torque. This function reduces this velocity change and improves stability.</p> <p>In devices where load inertia fluctuates, vibration may occur due to the effect of load inertia fluctuations. This function reduces this vibration and improves stability.</p> <p>This is expected to compensate the effect of disturbance torque and inertia change and improve operation stability.</p>	×	○	○	<p>“4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)”</p> <p>“4.7 Load Fluctuation Control Function (Load Fluctuation Stabilization Applications)”</p>
High response current control function	<p>This function improves the responsiveness of the current controller by changing the current response setting to a value greater than the initial value in order to improve the current control responsiveness when operating at low current, such as with a processing machine.</p> <p>This is expected to improve the responsiveness of position control and speed control by enhancing current control performance in locus control.</p>	×	×	○	“4.8 High Response Current Control Function”
Quadrant glitch suppression function	<p>This function suppresses quadrant glitches that occur when drawing an arc with two or more axes.</p> <p>This is expected to suppress quadrant glitches during a change of direction in locus control.</p>	×	×	○	“4.9 Quadrant Glitch Suppression Function”

*1 Pr0.04 “Inertia ratio” is estimated automatically.

2.1.3 Control Functions for Suppressing Abnormal Noise and Vibration

These functions are expected to suppress abnormal noise and vibration, such as abnormal noise caused by oscillation and residual vibration during positioning.

A list of functions is shown below.

The “Auto tuning (TUNE COMPASS) supported” column indicates whether or not the parameters can be tuned by each automatic tuning function.

○: Supported ×: Not supported

Function name	Function overview	Auto tuning (TUNE COMPASS) supported			Reference
		TUNING-LESS	One Minute TUNING	precAlse TUNING	
Torque filter function	Sounds and vibrations in the high frequency range may occur when the gain is increased. By setting a torque filter, this function is expected to suppress this sound and vibration. This function is expected to suppress sound and vibration in the high frequency range ^(*1) .	○	○	○	“5.1 Torque Filter Function”
2-stage torque filter function	This function sets a 2-stage torque filter to suppress high-frequency vibration components that cannot be removed by the “5.1 Torque Filter Function” torque filter alone. This function is expected to suppress sound and vibration in the high frequency range ^(*1) . The suppression effect is stronger than that of a torque filter.	×	×	○	“5.2 2-stage Torque Filter Function”
Notch filter function	When the gain is increased, sounds and vibrations of specific frequencies in the high frequency range may occur. This function suppresses sound and vibration at specific frequencies in the high frequency range by setting a notch filter. This function is expected to suppress noise and vibration caused by mechanical resonance of the device ^(*2) .	×	○	○	“5.3 Notch Filter Function”
Adaptive filter function	This function auto tunes parameters related to notch filters.	×	○	×	“5.4 Adaptive Filter Function”
Damping control function	This function reduces residual vibration of approximately 100 Hz or less that occurs at the moving part tip or the overall device during positioning operation by setting a damping filter. This is expected to suppress residual vibration of the at the moving part tip or the overall device during positioning.	×	○	○	“5.5 Damping Control Function”

Function name	Function overview	Auto tuning (TUNE COMPASS) supported			Reference
		TUNING-LESS	One Minute TUNING	precAlse TUNING	
Model-type damping filter function	<p>This function reduces residual vibration of approximately 100 Hz or less that occurs at the moving part tip or the overall device during positioning operation by setting a model-type damping filter.</p> <p>This is expected to suppress residual vibration of the at the moving part tip or the overall device during positioning. A shorter settling time is expected than with damping control.</p>	×	×	○	“5.6 Model-type Damping Filter Function”
Position command filter function	<p>A function that applies a positional command smoothing filter to a position command to gently accelerate or decelerate the motor.</p> <p>This is expected to suppress vibration and velocity change caused by the command resolution and command updating cycle roughness.</p>	×	○	○	“5.7 Position Command Filter Function”
Speed command acceleration/deceleration setting function	<p>This function performs speed control by applying a speed command for which acceleration and deceleration have been tuned inside the servo driver with respect to the speed command input from the host device.</p> <p>In speed control mode, it is expected that there will be a reduction in shocks caused by acceleration changes and that vibration will be suppressed.</p>	×	×	×	“5.8 Speed Command Acceleration/Deceleration Setting Function”
Hybrid vibration suppression function	<p>This function suppresses vibration caused by the amount of torsion between the motor and the load in full-closed control mode.</p> <p>This is expected to shorten the settling time.</p>	×	×	×	“5.9 Hybrid Vibration Suppression Function”

*1 This product assumes frequencies of 1.5 kHz or more as the high frequency range.

*2 This product assumes frequencies of 600 Hz to 1.5 kHz to be mechanical resonance.

2.1.4 List of Control Functions (By Driver Type)

The table below shows the functions supported by this product by driver type.

○: Supported X: Not supported

Function name	Driver type		
	A7NE Standard type	A7NF Multi-function type	A7NR Application spe- cialized type
Control functions for control performance			
Real-time auto tuning function	○	○	○
Gain switching function	○	○	○
3rd gain switching function	○	○	○
Feedforward function	○	○	○
Friction torque compensation function	○	○	○
Load fluctuation control function	○	○	○
High response current control function	○	○	○
Quadrant glitch suppression function	○	○	○
Control functions to suppress abnormal noise and vibration			
Torque filter function	○	○	○
2-stage torque filter function	○	○	○
Notch filter function	○	○	○
Adaptive filter function	○	○	○
Damping control function	○	○	○
Model-type damping filter function	○	○	○
Position command filter function	○	○	○
Speed command acceleration/deceleration setting function	○	○	○
Hybrid vibration suppression function	○	○	○

2.1.5 List of Control Functions (By Control Mode)

The table below shows the functions supported by this product by control mode.

○: Supported X: Not supported

Function name	Control mode			
	Position control	Speed control	Torque control	Full-closed control
Control functions for control performance				
Real-time auto tuning function	○	○	○	○
Gain switching function	○	○	○	○
3rd gain switching function	○	×	×	○
Feedforward function	○	○	○	○
Friction torque compensation function	○	○	×	○
Load fluctuation control function	○	○	×	○
High response current control function	○	○	○	○
Quadrant glitch suppression function	○	×	×	○
Control functions to suppress abnormal noise and vibration				
Torque filter function	○	○	○	○
2-stage torque filter function	○	○	○	○
Notch filter function	○	○	○	○
Adaptive filter function	○	○	×	○
Damping control function	○	×	×	○
Model-type damping filter function	○	×	×	×
Position command filter function	○	○	×	○
Speed command acceleration/deceleration setting function	×	○	×	×
Hybrid vibration suppression function	×	×	×	○

2.2 Safety Function Setup Before Tuning

Before tuning any parameters, make sure the following settings are properly configured.

This reduces the impact of unforeseen movements and ensures safer tuning.

Over-travel inhibit input setup <ul style="list-style-type: none"> • Pr5.04 "Over-travel inhibit input setup" • Pr5.05 "Sequence at over-travel inhibit" 	This setting prevents moving parts from colliding with the mechanical end.
Torque limit setup <ul style="list-style-type: none"> • Pr0.13 "1st torque limit" • Pr5.11 "Torque setup for emergency stop" • Pr5.21 "Selection of torque limit" • Pr5.22 "2nd torque limit" 	This setting limits the maximum torque to prevent damage to moving parts.
Overspeed protection setup <ul style="list-style-type: none"> • Pr5.13 "Over-speed level setup" 	This setting stops the alarm in the event of abnormally high speed.
Position deviation excess protection setup <ul style="list-style-type: none"> • Pr0.14 "Position deviation excess setup" • Pr5.20 "Position setup unit select" 	This setting stops the alarm when abnormal position deviation from a command occurs in the position control mode.
Motor working range setup <ul style="list-style-type: none"> • Pr5.14 "Motor working range setup" • Pr6.97 "Function expansion setup 3" :bit 2 "Motor movable range error protection expansion" 	This setting stops the alarm when the motor position exceeds the allowable width from the command range in the position control mode.
Hybrid deviation excess protection setup <ul style="list-style-type: none"> • Pr3.28 "Hybrid deviation excess setup" • Pr3.29 "Hybrid deviation clear setup" 	This setting prevents abnormal operation due to incorrect external scale settings, etc., in full-closed control mode.
Speed limit setting <ul style="list-style-type: none"> • Pr3.17 "Selection of speed limit" 	This setting prevents the speed exceeding the speed limit value in torque control mode.


For details, see Operating Instructions (Overall) "7.2.9 Before Gain Tuning Protection Function Setup" and "7.5.2 Velocity Limit Function".

2.3 Adjustment Workflow

2.3.1 Adjustments at Device Startup

Select the tuning function and adjust the parameters with reference to the following workflow.

Adjustment Workflow at Device Startup



2.3.2 Re-adjustment After Device Startup

- When Set-up Support Software (PANATERM ver.7) is used

Tuning is made using one of the following.

- Tuning function - One Minute TUNING: See [“3.1.2.5 Use Cases in Re-adjustment”](#) for details.
- Tuning function - Manual TUNING: See [“3.2.1.4.4 Tuning Procedure When Control Challenges Are Identified”](#) for details.

- When Set-up Support Software (PANATERM ver.7) is not used

The control functions that address the main issues when re-adjusting are listed in the table below.

Perform tuning by referring to the reference tuning procedures.

Issues during re-adjustment	Corresponding control function references
Shortening the settling time.	“4.1 Real-time Auto Tuning Function” “5.7 Position Command Filter Function”
Reducing overshoot/undershoot.	“4.1 Real-time Auto Tuning Function” “4.3 3rd Gain Switching Function” “4.4 Feedforward Function” “4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)” “4.8 High Response Current Control Function”
Reducing abnormal noise and oscillation.	“5.3 Notch Filter Function” “5.7 Position Command Filter Function”
Reducing vibration just before stopping.	“5.5 Damping Control Function” “5.6 Model-type Damping Filter Function”
Suppressing velocity changes during constant speed control.	“4.1 Real-time Auto Tuning Function” “4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)” “4.8 High Response Current Control Function”
Preventing falling on the vertical axis after servo-on.	“4.5 Friction Torque Compensation Function”
Suppressing quadrant glitches when velocity is inverted for processing machines, etc.	“4.9 Quadrant Glitch Suppression Function”
Ensuring own axis is not moved when other axes are moved.	“4.1 Real-time Auto Tuning Function” “4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)” “4.8 High Response Current Control Function”
Reducing vibration when gain is increased in full-closed control.	“5.9 Hybrid Vibration Suppression Function”

3 Details of Tuning Functions

3.1 Auto Tuning (TUNE COMPASS)	31
3.1.1 TUNINGLESS	31
3.1.1.1 Function Overview	31
3.1.1.2 Operational Conditions.....	31
3.1.1.3 Parameters That Are Automatically Set and Automatically Tuned	31
3.1.1.4 Usage.....	31
3.1.2 One Minute TUNING	32
3.1.2.1 Function Overview	32
3.1.2.2 Operational Conditions.....	32
3.1.2.3 Parameters That Are Automatically Set and Automatically Tuned	32
3.1.2.4 Usage.....	32
3.1.2.5 Use Cases in Re-adjustment	50
3.1.3 precAlse TUNING	52
3.1.3.1 Function Overview	52
3.1.3.2 Operational Conditions.....	52
3.1.3.3 Parameters That Are Automatically Set and Automatically Tuned	52
3.1.3.4 Usage.....	53
3.2 Manual Tuning	65
3.2.1 Manual TUNING.....	65
3.2.1.1 Function Overview	65
3.2.1.2 Operational Conditions.....	65
3.2.1.3 Tuning Method	65
3.2.1.4 Manual TUNING Using Set-up Support Software (PANATERM ver.7)	70
3.2.2 Load Fluctuation Suppression Tuning (Stabilizing Load Fluctuation Applications)	92
3.2.2.1 Function Overview	92
3.2.2.2 Operational Conditions.....	92
3.2.2.3 Tuning Procedure.....	92

3.1 Auto Tuning (TUNE COMPASS)

3.1.1 TUNINGLESS

3.1.1.1 Function Overview

This function automatically tunes inertia based on the actual operation of the motor, using the initial values as parameters. This function is enabled in the settings at the time of shipment.

This function is useful when you want to move the motor immediately.

3.1.1.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> All control modes
Other	<ul style="list-style-type: none"> The related parameters (“7.3 Parameters Related To TUNINGLESS”) are not changed from the initial values.

— Precautions —

- Since the real-time auto tuning function is enabled while this function is in use, the automatically set parameters cannot be manually changed to any desired value. For details, see [“4.1 Real-time Auto Tuning Function”](#) .
- While this function is operating, notch filters, damping control, the gain switching function, the load fluctuation control function, the friction compensation function, and the inertia ratio switching function are disabled.
- Under the following conditions, TUNINGLESS inertia estimating may not be performed correctly.

Item	Conditions that obstruct the TUNINGLESS inertia estimation
Load inertia	<ul style="list-style-type: none"> When small or large compared to the rotor inertia of the servo motor (less than 3× or 20× or more) When load inertia fluctuates
Load	<ul style="list-style-type: none"> When machine stiffness is extremely low When non-linear characteristics exist, such as backlash
Operation patterns	<ul style="list-style-type: none"> When used continuously at low speeds of less than 100 r/min When acceleration and deceleration are gentle, less than 2000 r/min in 1 s When the acceleration and deceleration torque is small compared to the unbalanced load and viscous friction torque When the speed is more than 100 r/min and the acceleration and deceleration condition of more than 2000 r/min in 1 s does not continue for more than 50 ms

3.1.1.3 Parameters That Are Automatically Set and Automatically Tuned

- Pr0.04 “Inertia ratio”

3.1.1.4 Usage

If [“3.1.1.2 Operational Conditions”](#) is met, setting tasks are not required.

Tuning is performed automatically by operating the motor.

3.1.2 One Minute TUNING

3.1.2.1 Function Overview

A function that automatically tunes various parameters to satisfy target performance by measuring device characteristics and ensuring control tolerance.

This is effective for obtaining a higher control performance in a relatively short time.

If there is a change in the device workpiece or position, only specific items will be auto tuned again.

3.1.2.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Position control mode, speed control mode
Other	<ul style="list-style-type: none"> Set-up Support Software (PANATERM ver.7) is required.

— Precautions —

- Tuning results that satisfy the required performance may not be obtained. In such cases, the tuning results judged to be the best are displayed.
- This tuning is performed in position control mode.
When One Minute TUNING is started in speed control mode, the driver temporarily changes to position control mode internally to execute tuning.
The tuning results obtained are tuning results from position control mode and may differ from tuning results obtained in speed control mode (Manual TUNING, etc.).
After tuning is completed, check the operation in speed control mode.
- The motor rotates during execution of this function. Be careful not to contact moving parts.
- This tuning changes the values of many parameters. If you need the values before tuning, save the data beforehand.
- Under the following conditions, One Minute TUNING inertia estimating may not be performed correctly.

Item	Conditions that obstruct the One Minute TUNING inertia estimation
Load	<ul style="list-style-type: none"> When load inertia fluctuates When machine stiffness is extremely low When non-linear characteristics exist, such as looseness due to backlash

- Do not use this function in a mechanism that causes the moving part to deviate from the operating range when the servo is OFF.

3.1.2.3 Parameters That Are Automatically Set and Automatically Tuned

See [“7.4 Parameters Related To One Minute TUNING”](#).

3.1.2.4 Usage


Instructions for use are described according to the following steps.

- [“Starting the Tuning Function”](#)
- [“Initial Settings”](#)
- [“Adjustment Operation”](#)
- [“Confirming Tuning Results, Ending One Minute TUNING”](#)


3.1.2.4.1 Starting the Tuning Function

<< Procedure >>

1. Check that Pr0.01 “Control mode setup” is set to the target mode for the operational conditions.
In position control mode, set parameters related to command division/multiplication (electronic gear ratio) correctly to set the operating range in command units in the initial settings.
2. Activate Set-up Support Software (PANATERM ver.7) .
3. Select one device that you want to tune in the device tree and click the “Tuning” tab.



4. In the “Tuning” tab screen, select “One Minute TUNING”, and click the [Go to the Tuning screen] button.



The “One Minute TUNING” settings screen is displayed.

One Minute TUNING

1 Setting 2 Execute tuning 3 Tuning results

Recall conditions

Applications
Positioning/general-purpose

Do not use this function in a mechanism that causes the moving portion to deviate from the operating range when the servo is off.

* Two-degree-of-freedom control is enabled.
To disable, it is necessary to change Pr6.47:bit 0 from the setting screen and write to the driver.

Operating range setting

Protection Functions
Pr5.12 Overload level[%] 0
Pr5.13 Overspeed level[%/min] 120
Automatic setting (overspeed...) ☒
Pr5.14 Motor move...[0.1 rotation] 10
Operation limit
Pr5.04 Over-travel inhibit input s... 1: CoE-side (CIA402) deceler...
Operating range
Use JOG to move to the Max./Min. positions or input a numeric value
JOG speed[%/min] 60
JOG acceleration...[ms/JOG speed] 50
Servo-on ☒ Operates only while the button is pressed.
- direction Go to 0 + direction
Current position [command unit] 0
Minimum position [command unit] 0
Maximum position [command unit] 0
Next

Advanced settings
To perform tuning using operation command settings and operation commands from the host device, or to change the required performance, perform setup using "Advanced settings".

If the set values of the parameters set before tuning are required, save the data before tuning at this point. For details, see Set-up Support Software (PANATERM ver.7) Operating Manual “8.3 Save File” .

3.1.2.4.2 Initial Settings

<< Procedure >>

1. Starts configuration of initial settings.

- To set new initial settings

Go to “Step 2”.

- To use the contents of a previously saved configuration file

Click on the [Recall conditions] button at the top of the screen to load.

To modify the settings, go to “Step 2”.

If you do not wish to modify the settings, go to “3.1.2.4.3 Adjustment Operation”.

One Minute TUNING Settings Screen

One Minute TUNING

1 Setting 2 Execute tuning 3 Tuning results

Recall conditions

Applications

☒ Positioning/general-purpose

Do not use this function in a mechanism that causes the moving portion to deviate from the operating range when the servo is off.

* Two-degree-of-freedom control is enabled.
To disable, it is necessary to change P6.47:bit 0 from the setting screen and write to the driver.

Operating range setting

Protection Functions

P5.12 Overload level[%] 0

P5.13 Overspeed level/min 120

☒ Automatic setting (overspeed...)

P5.14 Motor move...[0.1 rotation] 10

Operation limit

P5.04 Over-travel inhibit input s... 1: CoE-side (CIA402) deceler...

Operating range

Use JOG to move to the Max./Min. positions or input a numeric value

JOG speed/r/min 60

JOG acceleration...[ms/JOG speed] 50

Servo-on ☒ Operates only while the button is pressed.

- direction Go to 0 + direction

Current position [command unit] 0

Minimum position [command unit] 0

Maximum position [command unit] 0

Next

2. Select the application.

One Minute TUNING

1 Setting 2 Execute tuning 3 Tuning results

Recall conditions

Applications

☒ Positioning/general-purpose

Do not use this function in a mechanism that causes the moving portion to deviate from the operating range when the servo is off.

* Two-degree-of-freedom control is enabled.
To disable, it is necessary to change P6.47:bit 0 from the setting screen and write to the driver.

Operating range setting

Protection Functions

P5.12 Overload level[%] 0

P5.13 Overspeed level/min 120

☒ Automatic setting (overspeed...)

P5.14 Motor move...[0.1 rotation] 10

Operation limit

P5.04 Over-travel inhibit input s... 1: CoE-side (CIA402) deceler...

Operating range

Use JOG to move to the Max./Min. positions or input a numeric value

JOG speed/r/min 60

JOG acceleration...[ms/JOG speed] 50

Servo-on ☒ Operates only while the button is pressed.

- direction Go to 0 + direction

Current position [command unit] 0

Minimum position [command unit] 0

Maximum position [command unit] 0

Next

3. Set the protection functions.

- Pr5.12 “Motor overload level setup” [%]

Sets the motor overload level of effective torque. If this setup value is 0, the motor overload level setup is 115%.

- Pr5.13 “Over-speed level setup” [r/min]

Sets the judgment level for overspeed. Checking the “Automatic setting (overspeed level)” check box sets the automatically set value. Uncheck the box to allow input of setup values. If this setup value is 0, the over-speed level setup is the internal value of the applicable motor.

- Pr5.14 “Motor working range setup” [0.1 rotation]


Sets the amount by which the motor is allowed to move outside the input position command range.

4. Sets the operation limit.

- Pr5.04 “Over-travel inhibit input setup”

Sets the input operations for the over-travel inhibit inputs (POT, NOT).

5. Sets the operating range.



The operating range can be set using JOG operation or by entering a numerical value.

- JOG operation method

- 1 Sets the JOG speed and JOG acceleration and deceleration time.

JOG speed

Sets the JOG operation speed.

JOG acceleration and deceleration time

Sets the time it takes for the speed of JOG operation to reach the set JOG speed from 0.

- 2 Sets servo-on.
- 3 Press the [+ direction] or [- direction] button to move the motor to both ends of the movable range.
The motor runs only as long as the button is pressed, and the values in the “minimum position” and “maximum position” text boxes are updated.
- 4 When the motor has finished moving to both ends of the movable range, click the [Go to 0] button to return the motor to its initial position.

— Precautions —

- If oscillation occurs during JOG operation, the value of **Advanced settings>Tuning conditions>Tuning start RTAT machine stiffness setting** should be lowered before performing the JOG operation.

- Numerical value input method

- 1 With the current position as 0, enter the positions at both ends of the operable range in the “Minimum position” and “Maximum position” text boxes in command units.
Check that the set values are appropriate beforehand to prevent the moving part from colliding at both ends.

— Precautions —

- Set the minimum and maximum positions to provide a sufficiently large operable range. Errors occur when the operable range is small. A setting of 0.5 rotations or more is recommended for the motor rotational amount.
- An error may occur if the set value converted to the motor rotational amount is excessive.

6. Each item in “Advanced settings” has a pre-set recommended value. Normally, the settings can be used as they are.
- To change the setting, such as to change the required performance,
Go to “[Step 7](#)”.
 - To proceed with the settings as they are,
Go to “[3.1.2.4.3 Adjustment Operation](#)”.
7. Check the “Advanced settings” check box. The advanced settings items are displayed. Change the settings according to your requirements. See “[Advanced settings items](#)” below for details of advanced settings items. After completing the settings, go to “[3.1.2.4.3 Adjustment Operation](#)”.
- When changing the settings of the tuning target during re-adjustment, also refer to “[3.1.2.5 Use Cases in Re-adjustment](#)” to change the settings.

Advanced Settings Items

Advanced settings for “[Step 7](#)”. Configure items as required.

After configuring the settings, go to “[3.1.2.4.3 Adjustment Operation](#)”.

One Minute TUNING

1 Setting 2 Execute tuning 3 Tuning results

Recall conditions

Applications

Positioning/general-purpose

Do not use this function in a mechanism that causes the moving portion to deviate from the operating range when the servo is off.

* Two-degree-of-freedom control is enabled.
To disable, it is necessary to change Pr6.47:bit 0 from the setting screen and write to the driver.

Operating range setting

Protection Functions

Pr5.12 Overload level[%] 0

Pr5.13 Overspeed level[r/min] 120

☒ Automatic setting (overspeed...)

Pr5.14 Motor move...[0.1 rotation] 10

Operation limit

Pr5.04 Over-travel inhibit input s... 1: CoE-side (CIA402) deceler...

Operating range

Use JOG to move to the Max./Min. positions or input a numeric value

JOG speed[r/min] 60

JOG acceleration...[ms/JOG speed] 50

Servo-on ☐ Operates only while the button is pressed.

- direction Go to 0 + direction

Current position [command unit] 0

Minimum position [command unit] -400000000

Maximum position [command unit] 400000000

Advanced settings

To perform tuning using operation command settings and operation commands from the host device, or to change the required performance, perform setup using "Advanced settings".

> Detailed protection function

> Required performance

> Tuning conditions

> Command condition

Next

■ Detailed Protection Function

This setup value is enabled only during One Minute TUNING execution.

▼ Detailed protection function

Tuning vibration automatic suppression effective level[%] 15

Tuning over-speed level setup[r/min] 0

Tuning torque limit[%] 0

Tuning JOG test run command speed[r/min] 60

Tuning JOG test run acceleration and decel...[ms/Max speed] 50

Item	Description
Tuning vibration automatic suppression effective level	<p>If oscillation does not subside when auto tuning is in progress, the gain is automatically lowered to stabilize.</p> <p>Set the vibration level of the torque to be considered as oscillation by half amplitude value (half of the peak-to-peak value) with the rated torque as 100%.</p>
Tuning overspeed level setting	<p>Stops the motor if the motor speed becomes excessive when auto tuning is in progress.</p> <p>Sets the speed in units of [r/min] at which the speed is judged to be excessive.</p> <p>If 0, Pr5.13 "Over-speed level setup" set values are used.</p> <p>— Precautions —</p> <ul style="list-style-type: none"> If the set value is less than 1.11 times the rated speed, the device characteristics measuring accuracy may drop and it may not be possible to perform tuning correctly. If the value has not been changed from the initial value, there is no problem.

Item	Description
Tuning torque limit	<p>Sets the value for determining torque saturation when auto tuning is in progress. Sets the ratio when the rated torque is 100% in units of [%].</p> <p>If 0, setup values enabled by Pr5.21 "Selection of torque limit" are used. For details, see Operating Instructions (Overall) "8.1 Torque Limit Switching Function".</p> <p>— Precautions —</p> <ul style="list-style-type: none"> If the set value is less than 111% the rated speed, the device characteristics measuring accuracy may drop and it may not be possible to perform tuning correctly. If the value has not been changed from the initial value, there is no problem.
Tuning JOG test run command speed	Sets the motor speed in [r/min] units when checking the movable range.
Tuning JOG test run acceleration and deceleration time	Sets the time for acceleration and deceleration of the motor speed when checking the movable range (time from 0 to JOG speed or from JOG speed to 0).

Required performance

?

Positioning complete (In-position) range[Command unit]

8400

Target settling time[ms]

0


Settling time count condition

☒ After completion of command transfer judgment
☐ At start of command transfer judgment

Allowable overshoot amount[%]

100

Example of positioning waveform



Item	Description
Positioning complete (In-position) range	Sets the position deviation (difference between command position and actual position) that determines that positioning is complete.
Target settling time	<p>Sets the target time in [ms] units from the timing of the following settling time count condition until convergence to the positioning complete (in-position) range.</p> <p>If the setup value is 0, the settling time is tuned to be the shortest it can be.</p>
Settling time count condition	Selects the timing to be time 0 when calculating the settling time.

— Precautions —

- For details, see Operating Instructions (Overall) “3.2.8 Wiring to Connector X7 (Connecting to External Monitor)” .

Tuning conditions

RTAT machine stiffness setting at the start of the tuning

☒ Set automatically

12

Stability margin[%]

Emphasis on balance

80

Tuning step

Advance operation

OFF

Homing operation

ON

Tuning target

Inertia ratio

ON

Unbalanced load compensation

OFF

Dynamic friction compensation

OFF

Viscous friction compensation

OFF

RTAT machine stiffness setting

ON

RTAT FF stiffness setting

ON

Load fluctuation suppression (disturban...

ON

Notch filter

ON

1st damping filter

OFF

2nd damping filter

OFF

Control tolerance

Tolerance for changes to the characteristics of machine axes that can be driven stably
You can choose from the following four items.

- Emphasis on responsiveness: 60%
- Emphasis on balance: 80%
- Emphasis on stability: 100%
- Manual: The lower slide bar can be used to set any value.

The higher the value, the higher the control stability against changes in characteristics, but the lower the suppression against disturbance. When the two-degree-of-freedom control mode is disabled, not only is the suppression of disturbance reduced, but also the command responsiveness. If the set value is 0, the setting is the same as for "Emphasis on balance".

Item	Description
Tuning step	Select whether to perform advance operation and homing operation. If performing these operations, set to "ON". Advance operation: Operation to check the operating range Homing operation: Operation for moving to the initial position after completion of auto tuning
Tuning target	The tuning target can be selected arbitrarily. When switched to "ON", the item is subject to tuning. When tuning for the first time, do not change the setting before use. <div style="background-color: black; color: white; padding: 2px; text-align: center;">— Precautions —</div> <ul style="list-style-type: none"> When setting the "Inertia ratio" to "OFF", make sure the appropriate inertia ratio for the device being tuned is set in Pr0.04 "Inertia ratio". If the appropriate inertia ratio is not set in Pr0.04 "Inertia ratio" with inertia ratio excluded from tuning, the correct tuning results may not be obtained. When two-degree-of-freedom control mode is disabled, "Viscous friction compensation" is set to "OFF".

■ Command conditions

▼ Command condition

?

Is there an upper command? ☒ No ☐ Yes


Tuning amount of movement[Command unit]

Tuning max speed[r/min]

Tuning acceleration and deceleration time[ms/Max speed]

Tuning wait time[ms]

Image of the motor operation pattern



Item	Description
Is there an upper command?	Select whether to use an upper command as an operation command during command response measurement. The current version of Set-up Support Software (PANATERM ver.7) does not support the "Yes" for upper commands. Only "No" can be selected.
Tuning amount of movement	Sets the amount of movement when the motor operation pattern for command response measurement in the automatic adjustment process is generated inside the driver. If the set value is 0, the servo driver automatically sets the value within the operating range set by "Step 5". <div style="background-color: black; color: white; padding: 2px; text-align: center;">— Precautions —</div> <ul style="list-style-type: none"> Set a value larger than the positioning complete (In-position) range. If it is smaller, an error occurs. The upper-limit value that can be set is 1073741823.

Item	Description
Tuning max speed	<p>Sets the maximum speed when the motor operation pattern for command response measurement in the automatic adjustment process is generated inside the driver.</p> <p>If the set value is 0, the servo driver automatically sets the value within the tuning overspeed level setting set in detailed protection function.</p> <p>— Precautions —</p> <ul style="list-style-type: none"> Set a value smaller than the over-speed level setup. If it is larger, an error occurs.
Tuning acceleration and deceleration time	<p>Sets the acceleration and deceleration time (from 0 to maximum speed or from maximum speed to 0) when the motor operation pattern for command response measurement in the automatic adjustment process is generated inside the driver.</p> <p>If the set value is 0, the servo driver automatically sets the value within the range below the tuning torque limit set in detailed protection function.</p>
Tuning wait time	<p>Sets the waiting time between operations when the motor operation pattern for command response measurement in the automatic adjustment process is generated inside the driver.</p> <p>— Precautions —</p> <ul style="list-style-type: none"> Set a sufficiently large value for the waiting time so that the previous positioning operation does not affect measurement, and so that measurement can be performed correctly even if settling time during tuning is long. The time that can be set is limited to between 501 and 9000 ms.

After configuring the settings, go to [“3.1.2.4.3 Adjustment Operation”](#) .

3.1.2.4.3 Adjustment Operation

<< Procedure >>


1. After finishing configuring the “initial settings”, click the [Next] button. This displays the Execute Tuning screen.

— Precautions —

- If “Step 5” of “3.1.2.4.2 Initial Settings” is not set for the operating range, the [Next] button cannot be clicked.

- Click the [Start] button to start auto tuning and the motor starts moving.
Click the [Back] button to return to the settings screen.


One Minute TUNING Execute Tuning Screen



3. Once auto tuning is started, the parameters are tuned based on the “[Step 2](#)” to “[Step 6](#)” settings of “[3.1.2.4.2 Initial Settings](#)” while the motor is running.

If you wish to stop the auto tuning process midway, click the [Stop] button. Clicking the [Stop] button discards all values of parameters being tuned and returns them to the values before tuning started.

One Minute TUNING In Progress Screen



— Precautions —

- If an error occurs during operation, resolve according to the message. For details on error content, see “[7.6 List of Errors Related to One Minute TUNING](#)”.
- Error no. 1537 “Device characteristics measuring error 1” may occur, and the error may not be resolved even after action is taken. In such cases, perform manual tuning. For details on manual tuning, See “[3.2 Manual Tuning](#)”.
- If an error occurs during tuning and the machine stops, there is no homing operation for the initial position.
- If power is interrupted when tuning is in progress, the servo driver parameters must be initialized manually.


4. Tuning is complete when all steps are checked with a check mark.

Click the [Next] button.

One Minute TUNING Completion Screen



The tuning results screen is displayed.



3.1.2.4.4 Confirming Tuning Results, Ending One Minute TUNING

The left side of the tuning results screen displays the parameters before and after tuning. A summary is displayed in the upper right-hand corner of the tuning results screen.

One Minute TUNING Results Screen

Name	Unit	Before tuning	After tuning
Pr0.02 Real-time auto-gain tunin...		1	0
Pr0.04 Inertia ratio	%	250	0
Pr0.27 Selection of machine stiffn...		16	29
Pr0.28 Selection of feed forward...		16	31
Pr1.00 1st gain of position loop	0.1/s	480	1850
Pr1.01 1st velocity loop gain	0.1Hz	270	1025
Pr1.02 1st velocity loop integrati...	0.1ms	210	70
Pr1.03 1st filter of velocity detect...		0	0
Pr1.04 1st torque filter time cons...	0.01ms	10	10
Pr1.05 2nd gain of position loop	0.1/s	480	1850
Pr1.06 2nd velocity loop gain	0.1Hz	270	1025
Pr1.07 2nd velocity loop integrati...	0.1ms	210	70
Pr1.08 2nd filter of velocity detec...		0	0
Pr1.09 2nd torque filter time con...	0.01ms	10	10
Pr1.10 Velocity feed forward gain	0.1%	1000	1000
Pr1.11 Velocity feed forward filter	0.01ms	0	0
Pr1.12 Torque feed forward gain	0.1%	1000	1000

■ Load characteristic: Inertia ratio: 0 [%]
 ■ Operation command during tuning: Amount of movement: 33,554,432 [Command unit] Maximum speed: 1,959 [rpm]
 Acceleration and deceleration time 122 [ms]
 ■ Tuning performance: Positioning complete (In-position) range: 8400 [Command unit] Settling time: 0 [ms]
 Overshoot amount: 724 [Command unit]

> Detailed measurement results
 > Graph

Save results Complete

<< Procedure >>

1. To see details of the tuning results, click “>” in “> Detailed measurement results” to expand details of the measurement results.

Name	Unit	Before tuning	After tuning
Pr0.02 Real-time auto-gain tunin...		1	0
Pr0.04 Inertia ratio	%	250	0
Pr0.27 Selection of machine stiffn...		16	29
Pr0.28 Selection of feed forward...		16	31
Pr1.00 1st gain of position loop	0.1/s	480	1850
Pr1.01 1st velocity loop gain	0.1Hz	270	1025
Pr1.02 1st velocity loop integrati...	0.1ms	210	70
Pr1.03 1st filter of velocity detect...		0	0
Pr1.04 1st torque filter time cons...	0.01ms	10	10
Pr1.05 2nd gain of position loop	0.1/s	480	1850
Pr1.06 2nd velocity loop gain	0.1Hz	270	1025
Pr1.07 2nd velocity loop integrati...	0.1ms	210	70
Pr1.08 2nd filter of velocity detec...		0	0
Pr1.09 2nd torque filter time con...	0.01ms	10	10
Pr1.10 Velocity feed forward gain	0.1%	1000	1000
Pr1.11 Velocity feed forward filter	0.01ms	0	0
Pr1.12 Torque feed forward gain	0.1%	1000	1000

■ Load characteristic: Inertia ratio: 0 [%]
 ■ Operation command during tuning: Amount of movement: 33,554,432 [Command unit] Maximum speed: 1,959 [rpm]
 Acceleration and deceleration time 122 [ms]
 ■ Tuning performance: Positioning complete (In-position) range: 8400 [Command unit] Settling time: 0 [ms]
 Overshoot amount: 724 [Command unit]

> Detailed measurement results
 > Basic information
 > Tuning conditions
 > Load characteristic
 > Operation command
 > Tuning performance
 > Protection Functions

> Graph

Save results Complete


Click “>” by each item displayed to expand it, allowing you to check detailed information on tuning conditions and tuning performance.

Item	Check item
Basic information	<ul style="list-style-type: none"> • Date and time of measurement • Driver information (Model No., Serial No.) • Motor information (Model No., Serial No.)
Tuning conditions	Set in initial setting. <ul style="list-style-type: none"> • Application • Positioning complete (In-position) range • Target settling time • Settling time count condition • Allowable overshoot amount • Stability margin • RTAT machine stiffness setting at the start of the tuning • Tuning step (advance operation, homing operation) • Tuning target (inertia ratio, etc.)
Load characteristics	Calculated during the adjustment process. <ul style="list-style-type: none"> • Inertia ratio • Unbalanced load • Dynamic friction torque • Viscous friction torque • Resonance frequency • Vibration frequency
Operation command	Set in initial setting. <ul style="list-style-type: none"> • Tuning Amount of movement • Tuning Max speed • Tuning Acceleration and deceleration time • Tuning Wait time • Command time • Command speed (maximum) • Command speed (minimum) • Command amount of movement
Tuning performance	Measured during the adjustment process. <ul style="list-style-type: none"> • Settling time • Overshoot amount • INP change count • Vibration level • Effective load factor • Takt • Velocity zero cross count • Motor speed (maximum) • Motor speed (minimum) • Torque command (maximum) • Torque command (minimum) • Position deviation (maximum) • Position deviation (minimum) • Fine vibration count • INP change count at settling time • Regenerative load factor

Item	Check item
Protection functions	Set in initial setting. <ul style="list-style-type: none"> • Tuning vibration automatic suppression effective level • Tuning operating range upper limit • Tuning operating range lower limit • Tuning over-speed level setup • Tuning torque limit


2. To save the settings and information on the adjustment process (“3.1.2.4.2 Initial Settings” to “3.1.2.4.3 Adjustment Operation”) to a file, click the [Save results] button. A save file dialog box opens. Set the folder to save to and the file name, and save the file.

To end One Minute TUNING, click the [Complete] button.



A confirmation dialog box is displayed asking if you want to write the parameters from the tuning results to EEPROM.

- Click the [Yes] button to end One Minute TUNING with parameters written to EEPROM.
- Click the [No] button to end One Minute TUNING without parameters written to EEPROM.
- Click the [Cancel] button to close the confirmation dialog box and return to the tuning results screen.



3.1.2.5 Use Cases in Re-adjustment

With One Minute TUNING, if there is a change in the device workpiece or position, only specific items can be auto tuned again.

Read out a previously saved configuration file, configure the appropriate settings for the tuning target in “Advanced settings” (“3.1.2.4.2 Initial Settings” “Step 6” onward), and execute One Minute TUNING.

The table below shows reasons for re-adjustment and examples of setting items to be turned ON for tuning at that time.

Reason for re-adjustment	Re-adjustment method	ON setting items to be tuned
A component of the device moving part was changed.	Settings such as inertia ratio and machine stiffness require re-adjusting due to inertia fluctuations.	<ul style="list-style-type: none"> • Inertia ratio • RTAT machine stiffness setting • RTAT FF stiffness setting • Load fluctuation suppression • Notch filter
Vibration as a result of a change in position.	Re-adjust damping control (damping filter) to suppress vibration.	<ul style="list-style-type: none"> • RTAT FF stiffness setting • Load fluctuation suppression • 1st damping filter • 2nd damping filter
Abnormal noise occurred due to aging.	Re-adjust the notch filter to suppress mechanical resonance.	<ul style="list-style-type: none"> • Load fluctuation suppression • Notch filter

3.1.3 precAlse TUNING

3.1.3.1 Function Overview

This function automatically tunes various parameters while the motor is running, with AI determining the motor response.

It is effective for tuning devices that are difficult to tune and require tuning by skilled operators. The tuning results are expected to exceed those of skilled operators.

This is also effective for reducing operator labor hours, because it performs automatic operation using Set-up Support Software (PANATERM ver.7) after initial setting of target performance and multiple operation patterns, etc.

3.1.3.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Position control and two-degree-of-freedom control mode enabled
Real-time auto tuning control type	<ul style="list-style-type: none"> Two-degree-of-freedom Control Mode for Standard Type
Load fluctuation control function	<ul style="list-style-type: none"> The load fluctuation control function is enabled and load fluctuation compensation gain is 90 % or more Load fluctuation control function disabled
Other	<ul style="list-style-type: none"> Set-up Support Software (PANATERM ver.7) is required.

— Precautions —

- The motor rotates during execution of this function. Be careful not to contact moving parts.
- Tuning results that satisfy the required performance may not be obtained. In such cases the tuning results judged to be the best are displayed.
- This tuning changes the values of many parameters. If you need the values before tuning, save the data beforehand.
- Depending on the initial parameter settings, the following may occur when tuning is in progress. Initial settings must be configured to ensure the motor operates properly.
 - The motor operates in an unintended position, direction, or amount of movement (for example, when the rotational direction setup is incorrect)
 - The motor oscillates (for example, when the maximum value of the tuning range for the parameter to be tuned is too large)
 - AI set values are not reflected (for example, when the mode is one in which the parameter to be tuned is automatically set)
 - An alarm is triggered and tuning is aborted (For example, when the detection level of the protection function is set too low. If an alarm is triggered and the response in the initial settings is unclear, please contact us.)
- Depending on what the parameters are when the tuning is initiated, oscillation may occur while the tuning is in progress. Please use OneMinuteTUNING or similar software to perform tuning beforehand to ensure that no oscillation occurs with all the operation patterns that will be set and that they all operate normally.

3.1.3.3 Parameters That Are Automatically Set and Automatically Tuned

Parameters selected in *“Initial settings”* (“Step 2”) in the usage instructions

3.1.3.4 Usage


Instructions for use are described according to the following steps.

- 1 *“Starting the Tuning Function”*
- 2 *“Initial Settings”*
- 3 *“Adjustment Operation”*
- 4 *“Confirming Tuning Results, Ending precAIse TUNING”*


3.1.3.4.1 Starting the Tuning Function

<< Procedure >>

1. Check that Pr0.01 “Control mode setup” is set to position control mode for operational conditions.
2. Activate Set-up Support Software (PANATERM ver.7) .
3. Select one device that you want to tune in the device tree and click the “Tuning” tab.



4. In the “Tuning” tab screen, select “precAIsE TUNING”, and click the [Go to the Tuning screen] button.



The “precAIsE TUNING” settings screen is displayed.

precAIsE TUNING

Setting Execute tuning Tuning results

Load tuning conditions Check past results Tuning based on past history Save tuning conditions

Evaluation method setting

Evaluation target: Servo data Advanced sensor settings: []

Evaluation data compensation: Offset amount: 0 [%] Average number of points moved: 1

Evaluation metric: Setting width: 8400 Command unit: [] Settling time: 0.000 [ms]

Evaluation time/operation count: ☐ Evaluation time ☒ Operation count 10 [min] 1000 [times]

Condition setting

Command input mode: ☐ Host device ☒ PANATERM trial run Trial run pattern settings: []

Waveform measurement conditions

Measurement item: ☒ Evaluation target Edit Sampling cycle [ms]: 0.7500 Measurement time [ms]: 767.25

Position command speed [r/min] Torque command [%] Command position deviation [Command unit] Analog input [V] Encoder position deviation [Encoder unit]

Trigger condition: 1 or 2 Trigger position: 1/8

Trigger	Target	Level	Slope	Filter
Trigger 1	Position command speed [r/min]	50	Rising up	No use
Trigger 2	Position command speed [r/min]	-50	Falling down	No use

Parameter setup

Parameter class: All parameters *Depending on parameter settings, AI set values may not be reflected or the motor may oscillate. See the Technical Reference to ensure that each control function operates correctly.*

Tuning target	Class	No.	Name	Unit	Initial Value	Tuning range	Tuning step width
<input checked="" type="checkbox"/>	0	27	Selection of machine stiffness at real-time auto-gain tuning 2		29	0 ~ 44	1

Pr0.27 Selection of machine stiffness at real-time auto-gain tuning 2
Input range: 0 - 44
When Pr2.45 "Function expansion setup 10" bit 5 = 1,

Go to tuning

3.1.3.4.2 Initial Settings

<< Procedure >>

1. Starts configuration of initial settings.

- To set new initial settings

Go to “Step 2”.

- To use the contents of a previously saved configuration file

Perform one of the following operations before proceeding to “Step 3”.

- To use the contents of a previously saved tuning condition setup file

Click on the [Load tuning conditions] button to load that file.

- To check previously saved tuning results

Click on the [Check past results] button to load that file.

- To start tuning based on previously saved tuning results

Click on the [Tuning based on past history] button to load that file. If tuning is aborted due to a problem, tuning can be resumed using past history files saved up to that point.

precAlse TUNING Settings Screen

precAlse TUNING

1 Setting 2 Execute tuning 3 Tuning results

Load tuning conditions Check past results Tuning based on past history Save tuning conditions

▼ Evaluation method setting

Evaluation target: Servo data

Evaluation data compensation: Offset amount: 0 [%]

Average number of points moved: 1

Evaluation metric: Settling width: 8400 Command unit

Settling time: 0.000 [ms]

Evaluation time/operation count: ☐ Evaluation time: 10 [min]

☒ Operation count: 1000 [times]

▼ Condition setting

Command input mode: ☐ Host device

☒ PANATERM trial run Trial run pattern settings

▼ Waveform measurement conditions

Measurement item: ☒ Evaluation target Edit

Sampling cycle [ms]: 0.7500 Measurement time [ms]: 767.25

Position command speed[r/min]

Torque command[%]

Command position deviation[Command unit]

Analog input[V]

Encoder position deviation[Encoder unit]

Trigger condition: 1 or 2 Trigger position: 1/8

Target Level Slope Filter

Trigger 1: Position command speed[r/min] 50 Rising up No use

Trigger 2: Position command speed[r/min] -50 Falling down No use

▼ Parameter setup

Parameter class: All parameters

Depending on parameter settings, AI set values may not be reflected or the motor may oscillate. See the Technical Reference to ensure that each control function operates correctly.

Tuning target	Class	No.	Name	Unit	Initial Value	Tuning range	Tuning step width
<input checked="" type="checkbox"/>	0	27	Selection of machine stiffness at real-time auto-gain tuning 2		29	0 ~ 44	1

Pr0.27 Selection of machine stiffness at real-time auto-gain tuning 2

Input range: 0 - 44

When Pr2.45 "Function expansion setup 10" bit 5 = 1.

Go to tuning

2. To set new tuning conditions, set the following. After completing the settings, go to “Step 3”.

Evaluation method setting

▼ Evaluation method setting

Evaluation target: Servo data Advanced sensor settings:

Evaluation data compensation: Offset amount: 0 [%]

Average number of points moved: 1

Evaluation metric: Settling width: 8400 Command unit

Settling time: 0.000 [ms]

Evaluation time/operation count: ☐ Evaluation time: 10 [min]

☒ Operation count: 1000 [times]

Item	Description
Evaluation target	<p>Select data to be used for performance evaluation (servo data, analog sensors).</p> <ul style="list-style-type: none">is automatically assigned to the evaluation target in [Waveform measurement conditions] - [Measurement items]. <p>When “Servo data” is selected, the target data is command position deviation.</p> <p>When “Analog sensor” is selected, the target data is the analog input. When “Analog sensor” is selected, click the [Advanced sensor settings] button and enter specifications from the “Advanced sensor settings” screen.</p> <div><div><div>▼ Evaluation method setting</div><div><div>Evaluation target</div><div>Analogue sensor</div><div>Advanced sensor settings:</div></div><div><div>Evaluation data compensation</div><div>Offset amount</div><div>10</div><div>[%]</div></div><div><div>Average number of points moved</div><div>9</div></div><div><div>Evaluation metric</div><div>Settling width</div><div>0.000</div><div>[V]</div></div><div><div>Settling time</div><div>0.000</div><div>[ms]</div></div><div><div>Evaluation time/operation count</div><div><div><div></div><div>Evaluation time</div></div><div>10</div><div>[min]</div></div><div><div><div><div></div><div>Operation count</div></div><div>1000</div><div>[times]</div></div></div></div></div></div> <p>“Advanced Sensor Settings” Screen</p> <p>Register the correspondence between the analog output voltage of the sensor and the measured value and input the settling width in μm to calculate the settling width with the analog sensor. Click the [Apply] button to apply the settling width on the settings screen.</p> <div><div>Advanced sensor settings</div><div><div>It register the correspondence between the analog output voltage of the sensor and the measured value, and calculate the tuning range for the analog input value [V] conversion.</div><div><div>Sensor specifications</div><div><div><div>Measured value [mm]</div><div>1.0000</div></div><div><div>Analog output voltage [V]</div><div>10.500</div></div></div><div><div>Maximum value</div><div>-1.0000</div><div>0.000</div></div><div><div>Minimum value</div></div></div><div><div>Evaluation metric</div><div><div>Settling width[μm]</div><div>50.0</div></div><div><div>Settling width[V]</div><div>0.262</div></div></div><div><div>Apply</div><div>Cancel</div></div></div></div> <div><div>— Precautions —</div><div><ul style="list-style-type: none">When using analog sensors, configure Pr4.22, Pr4.23, Pr4.24, and Pr4.65 settings appropriately for normal waveform measurement.</div></div>

Item	Description
Evaluation data compensation	<p>This item can be set when “Analog sensor” is selected, and it sets the measurement data compensation value.</p> <ul style="list-style-type: none"> Offset amount [%] Sets the percentage of data used for offset calculation relative to the entire measured settling time waveform data (for automatic calibration of analog sensor data). Average number of points moved Sets the number of movement averaging data points for measured waveform data.
Evaluation metric	Sets the target values for settling width and settling time.
Evaluation time/operation count	<p>Sets the upper limit for the operation count or evaluation time.</p> <p>— Precautions —</p> <ul style="list-style-type: none"> In the current version of Set-up Support Software (PANATERM ver.7) , only “operation count” can be selected. The actual operation count will be less than the set operation count due to the adjustment algorithm. The set upper limit value is displayed in the operation count [times] denominator on the Execute Tuning screen.

Waveform measurement conditions

Waveform measurement conditions

Measurement item: ☒ Evaluation target ☐ Edit

Sampling cycle [ms]: 0.25 Measurement time [ms]: 255.75

Position command speed[r/min]
Torque command[%]
Command position deviation[Command unit]
Analog input[V]
Encoder position deviation[Encoder unit]

Trigger condition: 1 or 2 Trigger position: 1/8

	Target	Level	Slope	Filter
Trigger 1	Position command speed[r/min]	50	Rising up	No use
Trigger 2	Position command speed[r/min]	-50	Falling down	No use

Item	Description
Measurement item	This displays the measurement items. Measurement items can be added or deleted in the “Edit measurement items” dialog box that is displayed when the [Edit] button is clicked. For the editing method, see Set-up Support Software (PANATERM ver.7) Operating Manual. Default items cannot be deleted.
Sampling cycle, trigger-related setting items	<p>See Set-up Support Software (PANATERM ver.7) Operating Manual.</p> <p>— Precautions —</p> <ul style="list-style-type: none"> Set the sampling cycle so that the evaluation metric (settling time) can be determined within the measurement time.

Parameter setup

Parameter setup

Parameter class: All parameters Depending on parameter settings, AI set values may not be reflected or the motor may oscillate. See the Technical Reference to ensure that each control function operates correctly.

Tuning target	Class	No.	Name	Unit	Initial Value	Tuning range	Tuning step width
<input checked="" type="checkbox"/>	0	28	Selection of feed forward stiffness at real-time auto-gain tuning		31	0 ~ 44	1
<input type="checkbox"/>	1	00	1st gain of position loop	0.1/s	1850	0 ~ 30000	1
<input type="checkbox"/>	4	04	Feed forward stiffness	0.1/s	1000	0 ~ 33333	1

Pr0.28 Selection of feed forward stiffness at real-time auto-gain tuning
Input range: 0 - 44
When Pr2.45 “Function expansion setup 10”:bits 5 and 4 = 11b, the feedforward stiffness is set when real-time auto tuning is executed.

Item	Description
Parameter setup	<p>Select the parameters to be tuned.</p> <p>The “Parameter class” drop-down list allows only “All parameters” to be selected.</p> <p>A list of parameters is displayed at the bottom of the screen.</p> <p>Select the parameter to be tuned by checking the “Tuning target” check box, and enter the “Initial value”, “Tuning range” and “Tuning step width” in the text boxes.</p> <p>— Precautions —</p> <ul style="list-style-type: none"> At least one parameter should be set as a tuning target. Tuning can be performed without changing the setting values. Changing the tuning range, tuning target, or initial value may cause the motor to oscillate.

Condition setting

▼ Condition setting

Command input mode ☐ Host device ☒ PANATERM trial run Trial run pattern settings

Item	Description
Command input mode	<p>Set the command generation means.</p> <p>— Precautions —</p> <ul style="list-style-type: none"> In the current version of Set-up Support Software (PANATERM ver.7) , only “PANATERM trial run” can be selected. <p>Configure the advanced settings from the [Trial run pattern settings] button.</p>

Condition setting - Trial run pattern settings screen

Trial run pattern settings

1 — 2
Tuning settings — Operation settings

(1) Protection Functions

Pr5.12 Overload level[%]

Pr5.13 Overspeed level[r/min]

☒ Automatic setting (overspeed lev...)

Pr5.14 Motor movable...[0.1 rotation]

Operation limit

Pr5.04 Over-travel inhibit input setup

Operating range

Use JOG to move to the Max./Min. positions or input a numeric value

JOG speed[r/min]

JOG acceleration a...[ms/JOG speed]

(2) Operation settings

Operation No.	Start position [Command unit]	End position [Command unit]	Amount of movement [Command unit]	Target speed [r/min]	Acceleration and deceleration time [ms]	Operation time [s]
1	0	0	0	1	1	

(1) Servo-on ☐ **Operates only while the button is pressed.**

Current position [command unit]

Minimum position [command unit] Maximum position [command unit]

(1)	Set the protective function and operable range for trial run.
(2)	<p>The parameters of the operation command for which the response is to be evaluated are displayed.</p> <p>To edit, click the [To trial run pattern settings] button at the bottom, which becomes active when the operating range is set in (1), and then click the button to display the screen (next figure).</p>

Trial run pattern settings

Tuning settings Operation settings

Protection Functions

P5.12 Overload level[%] 0

P5.13 Overspeed level[r/min] 0

P5.14 Motor movable...[0.1 rotation] 10

Servo-on ☐ Operates according to the operation pattern

▶ Operation... ▶ Go to 0

⏸ Temporary ⏹ Stop

Current position [command unit] 0

Minimum position [command unit] -400,000

Maximum position [command unit] 400,000

Troubleshooting

Back

End

Operation No.	Start position [Command unit]	End position [Command unit]	Amount of movement [Command unit]	Target speed [r/min]	Acceleration and deceleration time [ms]	Operating wait time [ms]	Preliminary speed [r/min]	Preliminary acceleration and deceleration time [ms]
1	0	1000	1000	3000	100	2000	200	100
2	0	2000	2000	3000	100	2000	200	100
3	0	5000	5000	3000	100	2000	200	100
4	0	10000	10000	3000	100	2000	200	100
5	0	20000	20000	3000	100	2000	200	100
6	0	50000	50000	3000	100	2000	200	100

Add Delete


Different trial run patterns can be added or deleted by clicking the [Add] and [Delete] buttons. Please refer to the following example of a trial run pattern when setting.

The maximum number of trial run patterns that can be set is 100. The amount of movement can be automatically calculated by entering the start and end positions. When finishing configuring the settings, click the [End] button.

— Precautions —

- In all trial run patterns, the amount of movement must be greater than or equal to 1.

Example trial run pattern



Once finished configuring the settings for tuning conditions, go to “Step 3”.

3. To save the settings configured in “Step 1” or “Step 2”, click the [Save tuning conditions] button. A save file dialog box opens. Set the folder to save to and the file name, and save the file.

After finishing the tuning condition setup, click the [Go to tuning] button in the lower right-hand corner of the screen.

The screenshot shows the 'precAise TUNING' window with three steps: 1. Setting, 2. Execute tuning, and 3. Tuning results. Step 1 is active. The 'Save tuning conditions' button is highlighted in red. The 'Go to tuning' button is also highlighted in red at the bottom right.

Evaluation method setting

- Evaluation target: Servo data
- Evaluation data compensation: Offset amount: 0 [Hz], Average number of points moved: 1
- Evaluation metric: Settling width: 8400 [ms], Command unit
- Evaluation time/operation count: Evaluation time: 10 [min], Operation count: 1000 [times]

Condition setting

- Command input mode: Host device, PANATERM trial run
- Trial run pattern settings

Waveform measurement conditions

- Measurement item: Evaluation target
- Sampling cycle [ms]: 0.7500, Measurement time [ms]: 767.25
- Position command speed [r/min]: 50, Torque command [%]: 10, Command position deviation [Command unit]: 1, Analog input [V]: 1, Encoder position deviation [Encoder unit]: 1
- Trigger condition: 1 or 2, Trigger position: 1/8
- Target: Position command speed [r/min], Level: 50, Slope: Rising up, Filter: No use
- Trigger 2: Position command speed [r/min], Level: -50, Slope: Falling down, Filter: No use


Parameter setup

- Parameter class: All parameters
- Parameter settings table:

Tuning target	Class	No.	Name	Unit	Initial Value	Tuning range	Tuning step width
<input checked="" type="checkbox"/>	0	28	Selection of feed forward stiffness at real-time auto-gain tuning		16	0 ~ 44	1
<input type="checkbox"/>	1	100	1st gain of position loop	0.1/s	270	0 ~ 30000	1

Pr0.28 Selection of feed forward stiffness at real-time auto-gain tuning
Input range: 0 - 44

The screen switches to the Execute Tuning screen.




Go to “3.1.3.4.3 Adjustment Operation”.

3.1.3.4.3 Adjustment Operation

<< Procedure >>

1. Click the [Start] button on the Execute Tuning screen.



The “Tuning start preparation dialog” dialog box is displayed.

2. Perform servo-on, set the operating range of the device, and click the [Start] button.

Once clicked, the “Tuning start preparation dialog” dialog box automatically closes and AI evaluates the motor command response and starts tuning the parameters.

- If you are tuning repeatedly under the same conditions, please use PANATERM to align the motor position as much as possible when setting the servo to servo-on status.

The precAiSe TUNING function uses PANATERM and operates with the reference position (zero position) set as the motor position when the servo is set to servo-on status.

If the reference position (zero position) deviates significantly in comparison to past tunings, an error may occur when tuning is in progress or the expected performance may not be achieved.

Tuning start preparation dialog

Protection Functions

Pr5.12 Overload level[%]

Pr5.13 Overspeed level[r/min]

☒ Automatic setting (overspeed level)

Pr5.14 Motor movable range[0.1 rotation]

Operation limit

Pr5.04 Over-travel inhibit input setup

Operating range

Use JOG to move to the Max./Min. positions or input a numeric value

JOG speed[r/min]

JOG acceleration and dece...[ms/JOG speed]

Servo-on ☒ Operates only while the button is pressed.


- direction + direction

Current position [command unit]

Minimum position [command unit]

Maximum position [command unit]


3. If you wish to end parameter tuning, for example in an emergency, click the [Stop] button.



You can check progress with “Progress status” and “Current operating conditions”. In addition, detailed data is displayed on three central images on the screen.

(1)	Settling time measurement data	The settling time transition in the adjustment process is displayed.
(2)	Parameters	The current parameters in the adjustment process and the parameters with the best results at that time are displayed.
(3)	Waveform graph	The current measurement data (time-series data) is displayed.

4. When the progress status displays “Complete”, click the [Go to result] button in the lower right-hand corner.




The tuning results screen is displayed.

3.1.3.4.4 Confirming Tuning Results, Ending precAlse TUNING

To check the tuning results and end precAlse TUNING, use the respective buttons listed in the table below.

precAlse TUNING Results Screen



(1)	Settling time measurement data	<p>The settling time transition in the adjustment process is displayed.</p> <p>Each dot represents an evaluation value (data result) measured after changing the parameter setup values.</p> <p>Red dot: Best evaluation value</p> <p>Blue dots: Other evaluation values</p> <p>Green dot: Selected evaluation value (displayed in [Current evaluation value] at the top of the screen)</p>
(2)	Parameters	The parameters from the settling time measurement data determined to be the best in the adjustment process and the parameters for the selected settling time measurement data are displayed.
(3)	Waveform graph of selected data	<p>The measurement data (time-series data) for the selected trial is displayed.</p> <p>When multiple operation commands are set in the operational conditions settings, measurement data (time-series data) for each operation command can be selected and superimposed on top of each other.</p>
(4)	[Send parameters] button	Sets the parameters for the selected trial to the servo driver.
(5)	[Additional tuning] button	Click this button to continue tuning. Click the button to go to the settings screen.
(6)	[End] button	Save all results of the adjustment process and end precAlse TUNING.

3.2 Manual Tuning

Manual tuning is possible if gain adjustment has not be adequately performed using an automatic tuning function such as One Minute TUNING, or to ensure the best responsiveness and stability for individual loads. The user determines the response results when the parameters are changed, and performs tuning.

3.2.1 Manual TUNING

3.2.1.1 Function Overview

Use to further improve responsiveness and stability after auto tuning, for example. Make sure you have a thorough understanding of the characteristics of each control function before use.

Set-up Support Software (PANATERM ver.7) has a user interface that groups related parameters by control function for easy tuning.

3.2.1.2 Operational Conditions

Set-up Support Software (PANATERM ver.7) is used.

Depending on the parameters to be changed, power may need to be restored. If the power needs to be restored, a message is displayed. Follow the instructions in the message to restore the power.

3.2.1.3 Tuning Method

The tuning method with Manual TUNING for each control mode is described in this section.

- [“3.2.1.3.1 Tuning in Position Control Mode”](#)
- [“3.2.1.3.2 Tuning in Speed Control Mode”](#)
- [“3.2.1.3.3 Tuning in Torque Control Mode”](#)
- [“3.2.1.3.4 Tuning in Full-closed Control Mode”](#)

3.2.1.3.1 Tuning in Position Control Mode

This section describes the basic gain adjustment procedure when the gain switching function is not used in position control mode.

This section describes the adjustment procedure aimed at position control with high responsiveness and that uses the basic parameters of position loop gain, speed loop gain, speed integral time constant, and torque filter and notch filter parameters to suppress vibration.

For a block diagram on position control, see [“7.2.1 Position Control Mode Block Diagram”](#).

Refer to the following procedure for reference when tuning.

<< Procedure >>

1. After tuning using an automatic tuning function, go to [“Step 3”](#). When starting new tuning, configure initial settings for the parameters.

Reset the following parameters to the initial values. For initial values, see [“7.1 List of Parameters”](#).

- Pr0.02 “Real-time auto-gain tuning setup”
- Pr0.04 “Inertia ratio”
- Pr1.00 “1st gain of position loop”
- Pr1.01 “1st velocity loop gain”
- Pr1.02 “1st velocity loop integration time constant”
- Pr1.03 “1st filter of velocity detection”

- Pr1.04 “1st torque filter time constant”
- Pr1.14 “2nd gain setup”
- Pr2.00 “Adaptive filter mode setup”
- Pr2.01 “1st notch frequency”
- Pr2.02 “1st notch width selection”
- Pr2.03 “1st notch depth selection”
- Pr2.04 “2nd notch frequency”
- Pr2.05 “2nd notch width selection”
- Pr2.06 “2nd notch depth selection”
- Pr2.07 “3rd notch frequency”
- Pr2.08 “3rd notch width selection”
- Pr2.09 “3rd notch depth selection”
- Pr2.10 “4th notch frequency”
- Pr2.11 “4th notch width selection”
- Pr2.12 “4th notch depth selection”

2. Set the inertia ratio.

Set Pr0.04 “Inertia ratio” .

If the Pr0.04 “Inertia ratio” value is found with the real-time auto tuning function, use the Pr0.04 “Inertia ratio” set value as it is.

If the inertia ratio is found by load calculation or other means, enter the calculated value.

3. Check the motor operation.

Run the motor with Set-up Support Software (PANATERM ver.7) , etc., and check for any abnormalities in operation.

If no vibration or oscillation occurs at stop (servo lock) or during operation, go to “Step 4”.

If vibration or oscillation occurs, lower Pr1.01 “1st velocity loop gain” and Pr1.00 “1st gain of position loop” by about 50 [0.1 Hz] until vibration or oscillation no longer occurs.

4. Adjust the speed loop gain.

Raise Pr1.01 “1st velocity loop gain” by about 100 [0.1 Hz], and then raise Pr1.00 “1st gain of position loop” by the same amount.

Run the motor to check for vibration or oscillation, and if vibration or oscillation does not occur, proceed to “Step 5”.

If vibration or oscillation occurs, lower Pr1.01 “1st velocity loop gain” to about 80% of the current value and then lower Pr1.00 “1st gain of position loop” to the same value and proceed to “Step 5”.

— Precautions —

- Parameters should be changed when the motor is stopped.

5. Set the time constant of the torque filter.

- Refer to the following formula when setting Pr1.04 “1st torque filter time constant” .

Torque filter cut-off frequency [Hz] $\times 4 \geq$ speed loop gain [Hz]

- The torque filter cut-off frequency can be obtained using the following formula.

Cut-off frequency [Hz] = $1/(2 \pi \times \text{Pr1.04 “1st torque filter time constant” [0.01 ms]} \times 0.00001)$

If the operation sound is noticeable, increase Pr1.04 “1st torque filter time constant” by about 10 [0.01 ms].

To speed up the response, decrease Pr1.04 “1st torque filter time constant” by about 10 [0.01 ms] and increase Pr1.01 “1st velocity loop gain”.

If Pr0.04 “Inertia ratio” is set correctly, the value of Pr1.01 “1st velocity loop gain” is the speed loop gain [Hz].

6. Set 1st filter of velocity detection.

To speed up the response, decrease Pr1.03 “1st filter of velocity detection” and increase Pr1.01 “1st velocity loop gain”.

Normally use with Pr1.03 “1st filter of velocity detection” set to 0.

7. Set 1st gain of position loop.

Set Pr1.00 “1st gain of position loop” to a value of about Pr1.01 “1st velocity loop gain” $\times 1.5$.

Run the motor and fine tune while checking the positioning settling time by Set-up Support Software (PANATERM ver.7) waveform measurement or other means.

To shorten the positioning settling time, go to “[Step 8](#)”, and if not, go to “[Step 9](#)”.

— Precautions —

- Increasing the value shortens the positioning settling time, but too large a value may cause vibration or oscillation. Take due care.

If vibration or oscillation occurs, lower Pr1.00 “1st gain of position loop” to about 80% of the current level.

- Parameters should be changed when the motor is stopped.

8. Set the 1st velocity loop integration time constant.

Lower Pr1.02 “1st velocity loop integration time constant” from the initial value below according to the conditions.

The extent of lowering depends on the value of Pr1.02 “1st velocity loop integration time constant” [0.1 ms]. Refer to the conditions in the table below when lowering the value.

Initial value

$1,500,000 / (2 \pi \times \text{Pr1.01 “1st velocity loop gain” [0.1 Hz]})$

Extent of lowering

Pr1.02 “1st velocity loop integration time constant” [0.1 ms] value	Extent of lowering
300 or more	100 at a time
150 to 299	50 at a time
Less than 150	10 at a time

To further shorten the positioning settling time, go back to “[Step 4](#)” and tune Pr1.01 “1st velocity loop gain”.

If vibration or oscillation occurs when Pr1.01 “1st velocity loop gain” is raised, configure the notch filter settings in “[Step 9](#)”, and then go back to “[Step 4](#)” and tune Pr1.01 “1st velocity loop gain”.

A smaller Pr1.02 “1st velocity loop integration time constant” value will bring the deviation during positioning settling time closer to 0 sooner, but may delay the time to first reach the settling width. In this case, the settling time may be improved by setting Pr1.07 “2nd velocity loop integration time constant” to 10,000 (disabled) during operation using the gain switching function.

9. Set the notch filter settings.

Measure the vibration frequency of the torque command using Set-up Support Software (PANATERM ver.7) waveform measurement, frequency response measurement, etc.

Take the following measures according to the measured vibration frequency.

Compare before and after the measures and continue to tune settings to raise Pr1.01 “1st velocity loop gain” more.

After the measures, vibration and oscillation, etc. may subside even if Pr1.01 “1st velocity loop gain” is raised. Go back to [“Step 4”](#) again to check.

Vibration frequency	Details of measures
1.5 kHz or more	Increase the set value for Pr1.04 “1st torque filter time constant” until the vibration is within the allowable range. The set value should be changed by increasing by 10% at a time. If Pr1.04 “1st torque filter time constant” is set too large, vibration at low frequencies may increase. In this case, lower Pr1.01 “1st velocity loop gain” .
600 Hz to 1.5 kHz	Set the vibration frequency to Pr2.01 “1st notch frequency” . Set a notch filter to suppress resonance peaks. If vibration is not reduced, fine tune the Pr2.01 “1st notch frequency” value. Resonance peaks can be measured using Set-up Support Software (PANATERM ver.7) frequency response measurement. If there are multiple resonance peaks, set the vibration frequency to Pr2.04 “2nd notch frequency” to Pr2.10 “4th notch frequency” . If the vibration is still 600 Hz or more, increase the set value for Pr1.04 “1st torque filter time constant” . The set value should be changed by increasing by 10% at a time.
400 to 600 Hz	Measure the resonance frequency using the frequency response measurement in Set-up Support Software (PANATERM ver.7) and set the resonance frequency in Pr2.01 “1st notch frequency” . After setting Pr2.01 “1st notch frequency” , measure the frequency response again and confirm that the resonance peak is reduced. If the resonance peak is not reduced, tune Pr2.01 “1st notch frequency” , Pr2.02 “1st notch width selection” , and Pr2.03 “1st notch depth selection” to lower the resonance peak. For vibrations with resonance peaks at low frequencies and frequencies lower than the anti-resonance frequency, make Pr1.01 “1st velocity loop gain” smaller. When the resonance frequency is within the range of about 350 to 450 Hz, raise Pr1.01 “1st velocity loop gain” and set a notch filter when vibration occurs. Vibration may be reduced.

If the vibration is not reduced by the measures taken, no further tuning is available. Disable the notch filter used for the measures taken and end tuning.

3.2.1.3.2 Tuning in Speed Control Mode

Tuning in speed control is almost the same as in [“3.2.1.3.1 Tuning in Position Control Mode”](#) . Tune parameters excluding the Pr1.00 “1st gain of position loop” setting in accordance with the [“3.2.1.3.1 Tuning in Position Control Mode”](#) procedure.

For speed control mode block diagram, see [“7.2.2 Speed Control Mode Block Diagram”](#) .

3.2.1.3.3 Tuning in Torque Control Mode

In torque control, Pr3.21 “Velocity limit value 1” and Pr3.22 “Velocity limit value 2” act as speed limits to control the rotational velocity of the motor so that it does not exceed the speed limit value.

For a block diagram on torque control, see [“7.2.3 Torque Control Mode Block Diagram”](#) .

Details on setting speed limit values are provided below.

- Setting speed limit values

The setup method differs with Pr3.17 “Selection of speed limit” .

Pr3.17 “Selection of speed limit”	Setup method
0	Pr3.21 “Velocity limit value 1”
1	SL_SW = 0:Pr3.21 “Velocity limit value 1” SL_SW = 1:Pr3.22 “Velocity limit value 2”

For details on RTEX communication command SL_SW (speed limit switching command), see Technical Reference Communication Specification.

When the motor speed reaches the speed limit value, it switches from torque control via torque commands to speed control via speed limit values in the form of commands.

To ensure stable operation even when there are speed limits, it is necessary to set parameters according to [“3.2.1.3.2 Tuning in Speed Control Mode”](#).

In the following cases, input to torque limit sections may be lower, possibly causing torque output to differ from torque commands.

- The speed limit value is too low.
- Speed loop gain is too low.
- The speed loop integral time constant is set to 1000 (disabled).

3.2.1.3.4 Tuning in Full-closed Control Mode

In full-closed control, the same procedure as for [“3.2.1.3.1 Tuning in Position Control Mode”](#) can be used for tuning, except for the notes in Operating Instructions (Overall) “7.6.1 Full-closed Control Overview” (difference in command units, difference in command division/multiplication, etc.).

For a block diagram on full-closed control, see [“7.2.4 Full-closed Control Mode Block Diagram”](#).

External scale ratio setup and hybrid deviation excess setup in the initial settings for full-closed control are detailed below.

• External scale ratio setup

Use Pr3.24 “Numerator of external scale division” and Pr3.25 “Denominator of external scale division” to set the external scale ratio.

Check the encoder pulse count per motor revolution and the external scale pulse count per motor revolution, and set Pr3.24 “Numerator of external scale division” and Pr3.25 “Denominator of external scale division” so that the following formula holds.

$$\text{External scale ratio} = \frac{\text{Pr3.24 } \boxed{134217728}}{\text{Pr3.25 } \boxed{100000}} = \frac{\text{Encoder pulse count per motor revolution [pulse]}}{\text{External scale pulse count per motor revolution [pulse]}}$$

If this ratio is wrong, the difference between the position calculated based on the encoder pulse and the position calculated based on the external scale pulse becomes large over a long travel distance and Err25.0.0 “Hybrid deviation excess protection” is triggered.

Setting Pr3.24 “Numerator of external scale division” to 0 automatically sets the encoder pulse count as the numerator.

• Hybrid deviation excess setup

Set Pr3.28 “Hybrid deviation excess setup” to the minimum allowable difference between the motor (encoder) position and the load (external scale) position.

In addition to the primary causes above, Err25.0.0 “Hybrid deviation excess protection” can also be caused by reverse connection of the external scale or loose connection between the motor and the load. Also check for these primary causes.

— Precautions —

- Input a command pulse value based on the feedback scale resolution.
- Set Pr3.28 “Hybrid deviation excess setup” to the appropriate value in command units to prevent damage to the machine due to an out-of-control motor caused by improper setting of parameters related to the external scale.
- An external scale ratio of $1/40 \leq \text{External scale ratio} \leq 20480$ is recommended.

Setting the external scale ratio to a smaller value than 50/position loop gain (Pr1.00, Pr1.05) even if the value is within the aforementioned range, may prevent control in single pulse units.

Also, increasing the external scale ratio may increase operation sound.


- For a list scale manufacturers and product numbers that can be used for full-closed control, see the “AC Servo Partner Products” catalog.

3.2.1.4 Manual TUNING Using Set-up Support Software (PANATERM ver.7)


3.2.1.4.1 How to Use

<< Procedure >>


1. Activate Set-up Support Software (PANATERM ver.7) .
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.



3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.



(1)	This is the main screen. This displays the parameter tuning screen.
(2)	This displays the waveform measurement and frequency response measurement screens.
(3)	This displays the trial run operation screen.


Each item on the main screen (left side of the screen) is described below.

The screenshot shows the 'Manual TUNING' interface. At the top, a back arrow and the title 'Manual TUNING' are visible. Below the title, the text 'Selected driver: Axis0_No name set' is displayed. A red box labeled (1) highlights the top navigation bar with three tabs: 'Basic' (selected), 'Load characteristic settings', and 'Notch settings'. Below this, another red box labeled (2) highlights the 'Damping settings' tab. A red box labeled (3) highlights the 'Load characteristic settings' section, which includes 'Automatic setting: OFF' and 'Inertia ratio: 250'. A red box labeled (4) highlights the 'Gain setting' section, which includes 'Feedback gain setting: 16', 'Speed response frequency [Hz]: 27.0', 'Automatic oscillation suppression: OFF', 'FF gain setting: 16', 'Positional command smoothing filter [ms]: 9.2', and 'Overshoot suppression [%]: 100.0'. A red box labeled (5) highlights the 'Notch filter settings' section, which includes '3rd notch frequency [Hz]: 5000' and '4th notch frequency [Hz]: 5000'. A red box labeled (6) highlights the 'Damping filter setup' section, which includes '1st damping frequency [Hz]: 0'. A red box labeled (7) highlights the 'What if I have a problem?' section, which includes a link to 'Tuning Help when problems occur'. A red box labeled (8) highlights the 'Application' tab, and a red box labeled (9) highlights the 'Manual' tab.

For details on each item, see [“3.2.1.4.2 Main Screen Details”](#).

	Reference	Description
(1)	“Category Selection”	Clicking the button toggles the content displayed on the main screen.
(2)	“Mode Setting”	Set Pr0.02 “Real-time auto-gain tuning setup”.
(3)	“Load characteristic settings”	Tune the parameters related to setting and estimating load characteristics.
(4)	“Gain setting”	Tune the parameters related to feedback and feedforward collectively or when overshoot occurs.
(5)	“Notch settings”	Tune the parameters related to the notch filter and torque filter.
(6)	“Damping settings”	Tune the parameters related to damping control, the model-type damping filter and position command filter function.
(7)	“What if I have a problem?”	A PDF file detailing the basics of tuning parameters and typical control challenges is displayed. Use this when issues are known, but corresponding tuning procedures are unknown.
(8)	“Application”	This section summarizes features not listed above.
(9)	“Manual”	Displays the parameters shown in “Basic”, “Load characteristic settings”, “Notch settings”, “Damping settings”, and “Apply” in list format.

4. To end the Manual TUNING function, click the [<] button in the upper left corner.




The “Finish Manual TUNING” dialog box is displayed.

5. Check the tuning results, select “Retained” or “Disabled”, and then click the [End] button.

- To retain parameters related to inertia ratio and friction compensation
“Disabled” automatic inertia ratio setup
- To retain parameters related to notch filter
“Disabled” automatic notch setting


Selecting “Disabled” for both is recommended as this allows parameters to be fixed after tuning.

Enable the “Automatic inertia ratio setup” and “Automatic notch setting” automatic setting functions, and select “Retained” to keep the automatic setting functions enabled after tuning. (If “Retained” is selected after tuning with the automatic setting functions disabled, the parameters are the same as when “Disabled” is selected.)



If there is a change to a parameter, the “Write to EEPROM” dialog box is displayed.

6. Click the [Confirm] button.



Write to EEPROM

Target device: Axis0_No name set

Parameters to be written: User parameters


Target parameter

Parameter number	Parameter name	RAM value	EEPROM value
Pr0.02	Real-time auto-gain tuning setup	0: Conventional co...	1: Conventional co...
Pr6.10	Function expansion setup	16914	528
Pr6.32	Real time auto tuning custom setup	2181	0

Confirm Cancel

A confirmation dialog box is displayed asking if you want to write the parameters to EEPROM.

- To write the parameters to EEPROM, click the [Yes] button.
- To end tuning without writing the parameters to EEPROM, click the [No] button.



Parameters will be written to EEPROM. Is it OK?

Yes No

Clicking the [Cancel] button ends tuning without writing the parameters to EEPROM.

3.2.1.4.2 Main Screen Details

This section describes each item on the main screen of the Manual TUNING screen.

Manual TUNING

Selected driver: Axis0, No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Mode setting ⓘ 0: Disabled Customize settings...

ⓘ When launching for the first time [A7 recommended setting](#) is recommended
 ⓘ When upgrading from A6 [A6 compatibility setting](#) is recommended

Load characteristic settings Automatic setting: OFF

Inertia ratio 250

For more advanced settings [Load characteristic settings](#)

Gain setting

Feedback gain setting - 16 +

Speed response frequency [Hz] 27.0

Automatic oscillation suppression OFF

Safety function...

FF gain setting - 16 +

Positional command smoothing filter [ms] 9.2

Overshoot suppression [%] - 100.0 +

Notch filter settings Automatic setting: OFF

3rd notch frequency [Hz] 5000

4th notch frequency [Hz] 5000

For more advanced settings [Notch settings](#)

Damping filter setup Automatic setting: ON

1st damping frequency [Hz] 0

For more advanced settings [Damping settings](#)

What if I have a problem?
 Refer to Tuning Help [when problems occur](#) such as vibration or abnormal noise

Category Selection

- Clicking the category selection button toggles the display content on the main screen.

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Item	Description
Basic	The first screen displayed is for tuning basic settings.
Load characteristic settings	Fine tune parameter details related to the inertia ratio and friction.
Notch settings	Fine tune the notch filter and torque filter parameters.
Damping settings	Fine tune the damping control, the model-type damping filter and position command filter function parameters.
Application	Tune parameters for functions other than those listed above, such as the gain switching function.
Manual	Tune parameters related to control in list format.

Mode Setting

- Set Pr0.02 “Real-time auto-gain tuning setup”.
- When “A7 recommended setting” is selected, “7 (Customize 2)” is automatically set in “Mode setting”. When “A6 compatibility setting” is selected, the current “Mode setting” set value is retained.

- When “A7 recommended setting” or “A6 compatibility setting” is selected, parameters other than Pr0.02 “Real-time auto-gain tuning setup” are also set. For details, see the table below.

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Mode setting ⓘ 0:Disabled Customize settings...

ⓘ When launching for the first time **A7 recommended setting** is recommended

ⓘ When upgrading from A6 **A6 compatibility setting** is recommended

Load characteristic settings Automatic setting: OFF

Inertia ratio 250

For more advanced settings [Load characteristic settings](#)

Gain setting

Feedback gain setting - 16 +

Speed response frequency [Hz] 27.0

Automatic oscillation suppression OFF

Safety function...

FF gain setting - 16 +

Positional command smoothing filter [ms] 3.7

Overshoot suppression [%] - 100.0 +

Notch filter settings Automatic setting: OFF

3rd notch frequency [Hz] 5000

4th notch frequency [Hz] 5000

For more advanced settings [Notch settings](#)

Damping filter setup Automatic setting: ON

1st damping frequency [Hz] 0

For more advanced settings [Damping settings](#)

What if I have a problem?
Refer to Tuning Help [when problems occur](#) such as vibration or abnormal noise

Item	Description
A7 recommended setting (blue text)	<p>Sets Pr0.02 “Real-time auto-gain tuning setup” to setup value 7 (Customize 2).</p> <p>Sets Pr6.10 “Function expansion setup” and Pr2.45 “Function expansion setup 10” , etc. to A7 series recommended values.</p> <p>Allows finer tuning, such as 45-stage tables for real-time auto-tuning machine stiffness setup. Normally, this item should be selected when launching for the first time, for example. Click the [Yes] button when the dialog box for confirming the parameter change is displayed.</p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p style="text-align: right;">✕</p> <p>Parameters will be changed to A7 recommended settings. Is it OK?</p> <p style="text-align: center;"> <input type="button" value="Yes"/> <input type="button" value="No"/> </p> </div>
A6 compatibility setting (blue text)	<p>The current settings for Pr0.02 “Real-time auto-gain tuning setup” are retained.</p> <p>Sets Pr6.10 “Function expansion setup” and Pr2.45 “Function expansion setup 10” , etc. to settings used for the A6 series.</p> <p>Select this item if you need compatibility with the A6 series.</p> <p>Click the [Yes] button when the dialog box for confirming the parameter change is displayed.</p>

- When “A7 recommended setting” is selected, “7: Customize2 ” is automatically input in “Mode setting” (set Pr0.02 = 7 (Customize2)).

Clicking the [Customize settings...] button allows you to customize settings according to the application.

Mode setting ⓘ 7:Customize2 ▼

Customize settings...

ⓘ When launching for the first time [A7 recommended setting](#) is recommended
 ⓘ When upgrading from A6 [A6 compatibility setting](#) is recommended

Tuning conditions

☒ Positioning/general-purpose
☐ Processing machine
☐ Customize

> Parameters for tuning conditions

Customize Settings Screen

Customize settings

In the auto tuning function customization settings,
Manual setting/automatic setting of each control parameter can be selected.

Load characteristics estimation ☒ ON ☐ OFF

Inertia Ratio Update ☒ ON ☐ OFF

Stiffness Setup ☒ ON ☐ OFF

Fixed Parameter Setup ☐ ON ☒ OFF

Gain Switching Setup 0:Use current settings ▼

Torque compensation setting switching ☒ ON ☐ OFF

Tuning torque command additional value ☐ ON ☒ OFF

Tuning positive direction torque compensation ☐ ON ☒ OFF

Tuning negative direction torque compensation ☐ ON ☒ OFF

Tuning viscous friction compensating gain ☐ ON ☒ OFF

OK Cancel

Item	Description
Load characteristics estimation	Set to enable or disable the load characteristics estimation function. ON: Enabled OFF: Disabled
Inertia ratio update	Set updates in load characteristic estimation results for Pr0.04 “Inertia ratio” . ON: Update with estimated value OFF: Current settings retained
Stiffness setup	Set to enable or disable the basic gain setting using Pr0.03 “Real-time auto-tuning machine stiffness setup” or Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2” . ON: Enabled OFF: Disabled
Fixed parameter setup	Set whether or not to change the parameters that become prescribed fixed values when Pr0.02 “Real-time auto-gain tuning setup” is enabled. ON: Change to fixed value OFF: Current settings retained
Gain switching setup	Select the method for setting parameters related to gain switching when Pr0.02 “Real-time auto-gain tuning setup” is enabled.

Item	Description
Torque compensation setting switching	Select settings for parameters related to friction torque compensation. ON: MINAS A7 Series recommended setting OFF: MINAS A6 Series compatibility setting ON is selected when "A7 recommended setting" is selected in mode setting, and OFF is selected when "A6 compatibility setting" is selected in mode setting.
Torque command additional value tuning	Select the method for setting the torque command additional value (Pr2.52 "Torque command additional value 2" or Pr6.07 "Torque command additional value"). ON: Automatic setting OFF: Manual setting
Positive direction torque compensation tuning	Select the method for settings the positive direction torque compensation value (Pr2.53 "Positive direction torque compensation value 2" or Pr6.08 "Positive direction torque compensation value"). ON: Automatic setting OFF: Manual setting
Negative direction torque compensation tuning	Select the method for setting the negative direction torque compensation value (Pr2.54 "Negative direction torque compensation value 2" or Pr6.09 "Negative direction torque compensation value"). ON: Automatic setting OFF: Manual setting
Viscous friction compensating gain adjustment	Select the method for setting Pr6.50 "Viscous friction compensating gain" . ON: Automatic setting OFF: Manual setting

For details, see Pr6.32 "Real time auto tuning custom setup" below.

- "4.1.1.4 Related Parameters" of "4.1.1 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Standard Type)"
- "4.1.3.4 Related Parameters" of "4.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)"

■ Tuning conditions

- When "7: Customize 2" is selected, "Tuning conditions" are displayed. Normally, select "Positioning/general-purpose".

When "Positioning/general-purpose" is selected, the basic gain parameter setting is used when Pr0.02 "Real-time auto-gain tuning setup" is enabled.

Mode setting ⓘ 7:Customize2 ▼

Customize settings...

ⓘ When launching for the first time [A7 recommended setting](#) is recommended

ⓘ When upgrading from A6 [A6 compatibility setting](#) is recommended

Tuning conditions

☒ Positioning/general-purpose

☐ Processing machine

☐ Customize

➤ Parameters for tuning conditions

- 2 When “Customize” is selected for “Tuning conditions”, “Parameters for tuning conditions” is expanded. In “Parameters for tuning conditions” individual change ratios can be set for each basic gain parameter.
- For basic gain parameter settings, refer to the following.
 - “4.1.1.4 Related Parameters” of “4.1.1 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Standard Type)”
 - “4.1.3.4 Related Parameters” of “4.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)”

Customize Settings Screen

Load characteristic settings

- Parameter values related to setting and estimating load characteristics can be tuned manually.
- When “A7 recommended setting” is selected in “*Mode Setting*”, the inertia ratio is estimated and set automatically (Automatic setting: ON) in this mode.

The current set value is displayed in “Inertia ratio”.


- To fine tune parameters related to load characteristics such as “Inertia ratio”, click “Load characteristics” in blue text, or click the [Load characteristic settings] button at the top. The main screen changes to the “Load characteristic settings” screen. To return to the “Basic” screen, click on the [Basic] button at the top.

“Load Characteristic Settings” Advanced Settings Screen

Item	Description
Estimation speed	Set the speed for load characteristics estimation. Normally, set the value to 3. Higher set values result in faster responses to changes in load characteristics, but they also increase variations in disturbance estimation.
Related parameters	Displays the setup values for each parameter currently set in the driver. Parameters with automatic setting selected are grayed out. Numerical values can be entered directly for parameters that do not have automatic settings selected. The estimated value under the parameter name indicates the load characteristic estimation result. When the estimated value is updated, the value displayed is also updated. When Pr0.02 “Real-time auto-gain tuning setup” is 0 (disabled), no value is displayed. Click the [Reflect the estimated value] button to reflect the estimated value of the target parameter in the set value.

Gain setting

- Tune the parameters related to feedback and feedforward collectively and tune the suppression level for when overshoot occurs.

Item	Description
FB gain setting	<ul style="list-style-type: none"> Used when tuning feedback-related parameters collectively. This setting is linked to Pr0.03 “Real-time auto-tuning machine stiffness setup” or Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2” . To change the set value, click the [+] or [-] buttons, or enter the value directly. The larger the set value, the higher the command responsiveness and servo stiffness also increases, but vibration is more likely to occur. <p>While checking the operation, increase the set value by increments of 1.</p> <p>— Precautions —</p> <ul style="list-style-type: none"> Change the parameters to be used depending on the values set in Pr2.45 “Function expansion setup 10” :bit 5 to 4 “Stiffness setting resolution, individual FB/FF setting switching” . The initial value is Pr2.45: bits 5 to 4 = 11b. <ul style="list-style-type: none"> Pr2.45: bits 5 to 4 = 00b : Pr0.03 Pr2.45: bits 5 to 4 = 10b : Pr0.27 Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28 Even if the same value is set for both Pr0.03 “Real-time auto-tuning machine stiffness setup” and Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2” parameters, the values of the respective related parameters may be different. Refer to the basic gain parameter settings in “4.1 Real-time Auto Tuning Function” for the relationship between the set values and the corresponding related parameters. To set the safety function (for automatically lowering the set value to eliminate oscillation when tuning is in progress), click the [Safety function] button. <p>“Enable (Yes)” or “Disable (No)” can be selected for the safety function. When enabled, the “Oscillation detection level” can be set.</p> <p>“Feedback Gain Setting” - “Safety Function” Advanced Settings Screen</p> 
FF gain setting	<ul style="list-style-type: none"> Used when tuning feedforward-related parameters collectively. This setting is linked to Pr0.28 “Selection of feed forward stiffness at real-time auto-gain tuning” . For details on set values and corresponding parameters, see “4.1 Real-time Auto Tuning Function” “4.1.1.6 Basic Gain Parameter Setup Table” . To change the set value, click the [+] or [-] buttons, or enter the value directly. Although speed responsiveness is higher the larger the set value, overshoot is more likely to occur. <p>While checking the operation, increase the set value by increments of 1.</p>
Overshoot suppression	<ul style="list-style-type: none"> Used when overshoot occurs. To change the set value, click the [+] or [-] buttons, or enter the value directly. To suppress overshoot, adjust the value by decreasing it by about 5% from 100%. <p>A smaller value suppresses overshoot, but delays response.</p> <ul style="list-style-type: none"> This setting is linked to Pr1.10 “Velocity feed forward gain” .

Notch settings

- Tune the parameters related to the notch filter and torque filter.
- When “A7 recommended setting” is selected in “Mode Setting” , the notch filters are set automatically in adaptive filter when the operation command is input in this mode (Pr2.00 = 5) (Automatic setting: ON). In this case, the notch frequencies set automatically are displayed in 3rd notch frequency and 4th notch frequency.

- To fine tune related parameters, click “Notch settings” in blue text, or click the [Notch settings] button at the top. The main screen changes to the “Notch Settings” screen.

To return to the “Basic” screen, click on the [Basic] button at the top.

“Notch Settings” Advanced Settings Screen

Manual TUNING

Selected driver:Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Resonance monitor

Not detected

Resonance frequency [Hz] 5000

“5000” is displayed until resonance is detected.

Tuning based on positioning operation

To perform tuning based on the positioning operation, use the following settings 1 to 5.

Pr2.00 Adaptive filter mode 5: High-precision adaptive filter

Tuning based on frequency characteristics

☐ Display notch filter characteristics in a graph

Offset [dB] 0.0

	Frequency [Hz]	Width	Depth
1th notch	5000	2	0
2th notch	5000	2	0
3th notch	5000	2	0
4th notch	5000	2	0
5th notch	5000	2	0
Custom notch	5000	2	0

The 3rd and 4th notches are automatically set depending on the setting for Pr2.00 Adaptive filter mode.

Torque filter

1st torque filter [0.01 ms] 10

2-stage torque filter time constant [0.01 ms] 0

2-stage torque filter attenuation term 1000

Item	Description
Resonance monitor	When Pr2.00 “Adaptive filter mode setup” is enabled, the resonance frequency is displayed if resonance is detected.
Pr2.00 Adaptive filter mode	When “A7 recommended setting” is selected in “ <i>Mode Setting</i> ”, “5: High-precision adaptive filter” settings are set, and the 3rd notch filter and 4th notch filter are automatically set. Use this setting if you are unfamiliar with notch filter tuning. To manually tune the 3rd notch filter and 4th notch filter, set “0: Disable adaptive filter”. For details on Pr2.00 “Adaptive filter mode setup”, see “ <i>5.4 Adaptive Filter Function</i> ”.
Display notch filter characteristics in a graph	When the check box is checked, the combined filter characteristics of the notch filter and torque filter are displayed when the frequency response graph is displayed on the center screen. Tuning can be performed while comparing with the frequency response measurement results. If the box is not checked, the filter characteristics are not displayed.
Offset	Entering a numerical value in Offset changes the display position of the filter characteristics.

Item	Description
1st notch	Allows advanced settings to be set for notch filter and torque filter parameters. Notch filter parameters set automatically in Pr2.00 “Adaptive filter mode setup” cannot be changed. When real-time auto-gain tuning setup is enabled, the torque filter parameters cannot be changed because the torque filter is set automatically. Custom notch functions the same as other notch filters. It can be used as a 6th notch filter.
2nd notch	
3rd notch	
4th notch	
5th notch	
Custom notch	
1st torque filter	
2-stage torque filter time constant	
2-stage torque filter attenuation term	

For details on functions, see [“5.3 Notch Filter Function”](#), [“5.1 Torque Filter Function”](#) and [“5.2 2-stage Torque Filter Function”](#).

Damping settings

- Parameters related to damping control, the model-type damping filter and position command filter function can be tuned.
- When “A7 recommended setting” is selected in [“Mode Setting”](#), the damping control vibration frequency is estimated and set in damping frequency in this mode. The automatically set damping frequency is displayed.
- To manually tune related parameters, click “Damping settings” in blue text, or click the [Damping settings] button at the top. The main screen changes to the “Damping settings” screen. The screen displays the parameters of the filter used based on the Pr2.13 “Selection of damping filter switching” set value. To return to the “Basic” screen, click on the [Basic] button at the top.

“Damping Settings” Advanced Settings Screen

When Pr2.13 = 0

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Vibration monitor Not detected

Vibration frequency [Hz] ① 0.0

① “0.0” is displayed until vibration is detected

Damping filter setup

Pr2.13 Damping filter switching 0: Use up to two simultaneously

Automatic frequency setting ① 1st damping frequency

① When vibrations are detected, the vibration frequency value is automatically applied to the damping frequency of the target filter.

IN

■ FIR filter Automatic setting

Pr2.23 Positional command FIR filter [0.1 ms] 10

■ Smoothing filter

Pr2.22 Positional command smoothing filter [0.1 ms] 8

Pr6.49 Command response filter attenuation term setup 5: 1

■ Damping filter 1

Pr2.14 1st damping frequency [0.1 Hz] 0

Pr2.15 1st damping filter setup [0.1 Hz] 0

Pr2.27 1st damping width setting 0

Pr6.41 1st damping depth 0

■ Damping filter 2

Pr2.16 2nd damping frequency [0.1 Hz] 0

Pr2.17 2nd damping filter setup [0.1 Hz] 0

Pr2.28 2nd damping width setting 0

Pr6.60 2nd damping depth 0

OUT

■ Tuning filter

Filter function switching A7 mode

Tuning filter time constant 0.01ms 4

Pr6.49 Tuning filter attenuation term setup 1: No attenuation term

When Pr2.13 = 3

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Vibration monitor Not detected

Vibration frequency [Hz] ① 0.0

① “0.0” is displayed until vibration is detected

Damping filter setup

Pr2.13 Damping filter switching 3: Switching by command direction

Automatic frequency setting ① 1st damping frequency

① When vibrations are detected, the vibration frequency value is automatically applied to the damping frequency of the target filter.

IN

■ FIR filter Automatic setting

Pr2.23 Positional command FIR filter [0.1 ms] 10

■ Smoothing filter

Pr2.22 Positional command smoothing filter [0.1 ms] 8

Pr6.49 Command response filter attenuation term setup 5: 1

■ Damping filter 1

[Enabled during positive direction operation]

Pr2.14 1st damping frequency [0.1 Hz] 0

Pr2.15 1st damping filter setup [0.1 Hz] 0

Pr2.27 1st damping width setting 0

Pr6.41 1st damping depth 0

[Enabled during negative direction operation]

Pr2.16 2nd damping frequency [0.1 Hz] 0

Pr2.17 2nd damping filter setup [0.1 Hz] 0

Pr2.28 2nd damping width setting 0

Pr6.60 2nd damping depth 0

OUT

■ Damping filter 2

[Enabled during positive direction operation]

Pr2.18 3rd damping frequency [0.1 Hz] 0

Pr2.19 3rd damping filter setup [0.1 Hz] 0

Pr2.29 3rd damping width setting 0

Pr6.71 3rd damping depth 0

[Enabled during negative direction operation]

Pr2.20 4th damping frequency [0.1 Hz] 0

Pr2.21 4th damping filter setup [0.1 Hz] 0

Pr2.30 4th damping width setting 0

Pr6.72 4th damping depth 0

OUT

■ Tuning filter

Filter function switching A7 mode

Tuning filter time constant 0.01ms 4

Pr6.49 Tuning filter attenuation term setup 1: No attenuation term

When Pr2.13 = 4

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Vibration monitor

Vibration frequency [Hz] ① 0.0

① "0.0" is displayed until vibration is detected

Damping filter setup

Pr2.13 Damping filter switching 4: No switching (model type)

Automatic frequency setting ① Disabled

① When vibrations are detected, the vibration frequency value is automatically applied to the damping frequency of the target filter.

IN

■ FIR filter Automatic setting

Pr2.23 Positional command FIR filter [0.1 ms] 10

■ Smoothing filter

Pr2.22 Positional command smoothing filter [0.1 ms] 8

Pr6.49 Command response filter attenuation term setup 5: 1

■ Model-type damping filter 1

Pr6.61 1st resonance frequency [0.1 Hz] 0

Pr6.62 1st resonance attenuation ratio 0

Pr6.63 1st anti-resonance frequency [0.1 Hz] 0

Pr6.64 1st anti-resonance attenuation ratio 0

Pr6.65 1st response frequency [0.1 Hz] 0

■ Model-type damping filter 2

Pr6.66 2nd resonance frequency [0.1 Hz] 0

Pr6.67 2nd resonance attenuation ratio 0

Pr6.68 2nd anti-resonance frequency [0.1 Hz] 0

Pr6.69 2nd anti-resonance attenuation ratio 0

Pr6.70 2nd response frequency [0.1 Hz] 0

OUT

☐ Display model-type damping filter characteristics in a graph Offset [dB] 0.0

■ Tuning filter

Filter function switching A7 mode

Tuning filter time constant 0.01ms 4

Pr6.49 Tuning filter attenuation term setup 1: No attenuation term

When Pr2.13 = 5

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Vibration monitor

Vibration frequency [Hz] ① 0.0

① "0.0" is displayed until vibration is detected

Damping filter setup

Pr2.13 Damping filter switching 5: Switch by external input (model type)

Automatic frequency setting ① Disabled

① When vibrations are detected, the vibration frequency value is automatically applied to the damping frequency of the target filter.

IN

■ FIR filter Automatic setting

Pr2.23 Positional command FIR filter [0.1 ms] 10

■ Smoothing filter

Pr2.22 Positional command smoothing filter [0.1 ms] 8

Pr6.49 Command response filter attenuation term setup 5: 1

■ Model-type damping filter 1

[Enabled when VS-SEL1 = OFF]

Pr6.61 1st resonance frequency [0.1 Hz] 0

Pr6.62 1st resonance attenuation ratio 0

Pr6.63 1st anti-resonance frequency [0.1 Hz] 0

Pr6.64 1st anti-resonance attenuation ratio 0

Pr6.65 1st response frequency [0.1 Hz] 0

[Enabled when VS-SEL1 = ON]

Pr6.66 2nd resonance frequency [0.1 Hz] 0

Pr6.67 2nd resonance attenuation ratio 0

Pr6.68 2nd anti-resonance frequency [0.1 Hz] 0

Pr6.69 2nd anti-resonance attenuation ratio 0

filtercombination7TextBlock_13Text 0

OUT

☐ Display model-type damping filter characteristics in a graph Offset [dB] 0.0

■ Tuning filter

Filter function switching A7 mode

Tuning filter time constant 0.01ms 4

Pr6.49 Tuning filter attenuation term setup 1: No attenuation term

When Pr2.13 = 6

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Vibration monitor

Vibration frequency [Hz] ① 0.0

① "0.0" is displayed until vibration is detected

Damping filter setup

Pr2.13 Damping filter switching 6: Switch by command direction (model...)

Automatic frequency setting ① Disabled

① When vibrations are detected, the vibration frequency value is automatically applied to the damping frequency of the target filter.

IN

■ FIR filter Automatic setting

Pr2.23 Positional command FIR filter [0.1 ms] 10

■ Smoothing filter

Pr2.22 Positional command smoothing filter [0.1 ms] 8

Pr6.49 Command response filter attenuation term setup 5: 1

■ Model-type damping filter 1

[Enabled during positive direction operation]

Pr6.61 1st resonance frequency [0.1 Hz] 0

Pr6.62 1st resonance attenuation ratio 0

Pr6.63 1st anti-resonance frequency [0.1 Hz] 0

Pr6.64 1st anti-resonance attenuation ratio 0

Pr6.65 1st response frequency [0.1 Hz] 0

[Enabled during negative direction operation]

Pr6.66 2nd resonance frequency [0.1 Hz] 0

Pr6.67 2nd resonance attenuation ratio 0

Pr6.68 2nd anti-resonance frequency [0.1 Hz] 0

Pr6.69 2nd anti-resonance attenuation ratio 0

Pr6.70 2nd response frequency [0.1 Hz] 0

OUT

☐ Display model-type damping filter characteristics in a graph Offset [dB] 0.0

■ Tuning filter

Filter function switching A7 mode

Tuning filter time constant 0.01ms 4

Pr6.49 Tuning filter attenuation term setup 1: No attenuation term

When Pr2.13 = 7

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Vibration monitor

Vibration frequency [Hz] ① 0.0

① "0.0" is displayed until vibration is detected

Damping filter setup

Pr2.13 Damping filter switching 7: Damping 3 stages

Automatic frequency setting ① Disabled

① When vibrations are detected, the vibration frequency value is automatically applied to the damping frequency of the target filter.

IN

■ FIR filter Automatic setting

Pr2.23 Positional command FIR filter [0.1 ms] 10

■ Smoothing filter

Pr2.22 Positional command smoothing filter [0.1 ms] 8

Pr6.49 Command response filter attenuation term setup 5: 1

■ Damping filter 1

Pr2.14 1st damping frequency [0.1 Hz] 0

Pr2.15 1st damping filter setup [0.1 Hz] 0

Pr2.27 1st damping width setting 0

Pr6.41 1st damping depth 0

■ Damping filter 2

Pr2.16 2nd damping frequency [0.1 Hz] 0

Pr2.17 2nd damping filter setup [0.1 Hz] 0

Pr2.28 2nd damping width setting 0

Pr6.60 2nd damping depth 0

■ Damping filter 3

Pr2.18 3rd damping frequency [0.1 Hz] 0

Pr2.19 3rd damping filter setup [0.1 Hz] 0

Pr2.29 3rd damping width setting 0

Pr6.71 3rd damping depth 0

OUT

■ Tuning filter

Filter function switching A7 mode

Tuning filter time constant 0.01ms 4

Pr6.49 Tuning filter attenuation term setup 1: No attenuation term

For details on functions, see [“5.5 Damping Control Function”](#) and [“5.6 Model-type Damping Filter Function”](#).

Item	Description
Vibration monitor	When automatic frequency setting of the damping filter is enabled, the vibration frequency is displayed if vibration is detected.
Pr2.13 Damping filter switching	Set Pr2.13 “Selection of damping filter switching”. The parameters of the filter used based on the set value are displayed. When automatic setting is enabled, the parameters for the damping filter selected for setup are set automatically.
Automatic frequency setting	Select the damping filter for which the damping frequency is automatically set. Each time vibration is detected, the frequency displayed on the vibration monitor is set to the damping frequency.
FIR filter	Sets the value for Pr2.23 “Positional command FIR filter”. Clicking the [Automatic setting] button calculates and automatically sets the appropriate parameters. For details on functions, see “5.7 Position Command Filter Function” .
Smoothing filter	When the two-degree-of-freedom control mode for standard type is set and real-time auto tuning is enabled, the parameters are automatically set to the command response filter settings. Otherwise, parameters can be set manually. If synchronization of multiple axes is required, such as for a processing machine, set Pr2.22 “Positional command smoothing filter” to the same value for all axes. For details on functions, see “5.7 Position Command Filter Function” .

Item	Description
Damping filter 1 Damping filter 2 Damping filter 3 Damping filter 4 Model type damping filter 1 Model type damping filter 2	Parameters for damping filters that are not identified for automatic setting can be set manually. For details on functions, see “5.5 Damping Control Function” and “5.6 Model-type Damping Filter Function” .
Tuning filter	In the case of filter function switching, when “A7 recommended setting” is selected in “Mode Setting” , “A7 mode” is automatically set, and when “A6 compatibility setting” is selected, “Backward compatible” is automatically set. Changes are not required. When the two-degree-of-freedom control mode is enabled and real-time auto tuning is enabled, the tuning filter time constant is automatically set. Otherwise, parameters can be set manually.
Display model-type damping filter characteristics in a graph	This is displayed when Pr2.13 “Selection of damping filter switching” is between 4 and 6, using a model-type damping filter. Use to support tuning of model-type damping filters. When the check box is checked, the model-type damping filter characteristics are displayed on the frequency characteristic screen in the center of the “Manual TUNING” screen. Use with torque speed characteristics displayed. For details of the model-type damping filter function, see “5.6 Model-type Damping Filter Function” .
Offset	Entering a numerical value in Offset changes the display position of the filter characteristics.


What if I have a problem?

- Clicking on “When problems occur” in blue text displays a PDF file detailing the basics of tuning parameters and typical control challenges.
Use this when issues are known, but corresponding tuning procedures are unknown.
The PDF file is displayed in a separate window. Manual TUNING is possible while viewing the displayed contents.

Application

- This section summarizes functions not described previously.

- The main screen changes to the “Application” screen where the names of various functions are displayed. To return to the “Basic” screen, click on the [Basic] button at the top.



Click “>” to the left of each function name to display the related parameters and enable setup.

For details on each function and related parameters, please refer to the relevant items.

- “4.4 Feedforward Function”
- “4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)”
- “4.8 High Response Current Control Function”
- “4.2 Gain Switching Function”
- “4.3 3rd Gain Switching Function”
- “4.9 Quadrant Glitch Suppression Function”
- “5.9 Hybrid Vibration Suppression Function”

Manual

- Displays the parameters shown in “Basic”, “Load characteristic settings”, “Notch settings”, “Damping settings”, and “Apply” in list format.

<
Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Write to EEPROM

Config

Reset

Recall presets

Load presets

Selected preset: All parameters


Name	Unit	Value
Pr0.00		1
Pr0.01		0: Semi-closed control
Pr0.02		7: Conventional control: Customization...
Pr0.03		13
Pr0.04	%	0
Pr0.08		0
Pr0.09		1
Pr0.10		1
Pr0.11	pulse/r	2500
Pr0.12		0: Encoder, positive = B-phase progress...
Pr0.13	%	350
Pr0.14	Command...	83886080
Pr0.15		1: Used in incremental
Pr0.16		2: No regeneration process

3.2.1.4.3 Tuning Procedure When Starting a New Tuning Session


The basic tuning procedure is described when “A7 recommended setting” is selected in the mode setting as an example.

<< Procedure >>


1. Run the motor and check the position deviation response.




- To reduce overshoot, increase the “Feedback gain setting” by increments of 1.




- If the “Feedback gain setting” is set too high, oscillation may occur. In this case, set the filter properly in “Notch filter settings”. For the tuning procedure, see [“5.3 Notch Filter Function”](#).



- Once the overshoot is reduced to a satisfactory level, increase the “FF gain setting” by increments of 1.



- If the position deviation residual vibration is large, set the filter properly in “Damping filter settings”. For the tuning procedure, see [“5.5 Damping Control Function”](#).



- If you experience any trouble during the process, click “When problems occur” in blue text and refer to the tuning advice that is displayed. Check the [“3.2.1.4.4 Tuning Procedure When Control Challenges Are Identified”](#) table for the main contents.

3.2.1.4.4 Tuning Procedure When Control Challenges Are Identified

<< Procedure >>

- Click on “When problems occur” in blue text on the “Basic” screen under “What if I have a problem?”.

2. A PDF file detailing the basics of tuning parameters and typical control challenges is displayed. Use this when issues are known, but corresponding tuning procedures are unknown.

For details on each control function, refer to the relevant sections in this document.

Issues during re-adjustment	Corresponding control function references
Shortening the settling time.	<u>"4.1 Real-time Auto Tuning Function"</u> <u>"5.7 Position Command Filter Function"</u>
Reducing overshoot/undershoot.	<u>"4.1 Real-time Auto Tuning Function"</u> <u>"4.3 3rd Gain Switching Function"</u> <u>"4.4 Feedforward Function"</u> <u>"4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)"</u> <u>"4.8 High Response Current Control Function"</u>
Reducing abnormal noise and oscillation.	<u>"5.3 Notch Filter Function"</u> <u>"5.7 Position Command Filter Function"</u>
Reducing vibration just before stopping.	<u>"5.5 Damping Control Function"</u> <u>"5.6 Model-type Damping Filter Function"</u>
I want to reduce uneven operation and deviation during operation.	<u>"4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)"</u> <u>"4.8 High Response Current Control Function"</u>
Preventing falling on the vertical axis after servo-on.	<u>"4.5 Friction Torque Compensation Function"</u>
Suppressing quadrant glitches when velocity is inverted for processing machines, etc.	<u>"4.9 Quadrant Glitch Suppression Function"</u>
Ensuring own axis is not moved when other axes are moved.	<u>"4.1 Real-time Auto Tuning Function"</u> <u>"4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)"</u> <u>"4.8 High Response Current Control Function"</u>
Reducing vibration when gain is increased in full-closed control.	<u>"5.9 Hybrid Vibration Suppression Function"</u>

3.2.2 Load Fluctuation Suppression Tuning (Stabilizing Load Fluctuation Applications)

3.2.2.1 Function Overview

In devices where load inertia fluctuates, vibration may occur due to the effect of load inertia fluctuations. This function reduces this vibration and improves stability. Set-up Support Software (PANATERM ver.7) has a dedicated screen for tuning the parameters of this function.

3.2.2.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Position control, speed control, and full-closed control

Under the following conditions, the effect of the load fluctuation control function may not be seen.

Item	Conditions that obstruct the effectiveness of the load fluctuation control function
Load	<ul style="list-style-type: none"> Low stiffness (antiresonance points exists in the low frequency range of 10 Hz or less) Looseness, backlash, etc. are present and the load non-linearity is strong

3.2.2.3 Tuning Procedure

For the tuning procedure using Set-up Support Software (PANATERM ver.7) , see “4.7.4.2 When Set-up Support Software (PANATERM ver.7) Is Used” in “4.7 Load Fluctuation Control Function (Load Fluctuation Stabilization Applications)”.

4 Control Functions to Improve Tracking With Respect to Control Commands

4.1 Real-time Auto Tuning Function	95
4.1.1 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Standard Type)	95
4.1.1.1 Function Overview	95
4.1.1.2 Operation Mode	95
4.1.1.3 Operational Conditions.....	96
4.1.1.4 Related Parameters	96
4.1.1.5 How to Use.....	105
4.1.1.6 Basic Gain Parameter Setup Table	107
4.1.2 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Synchronization Type) ..	109
4.1.2.1 Function Overview	109
4.1.2.2 Operation Mode	109
4.1.2.3 Operational Conditions.....	109
4.1.2.4 Related Parameters	110
4.1.2.5 How to Use.....	115
4.1.2.6 Basic Gain Parameter Setup Table	118
4.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)	120
4.1.3.1 Function Overview	120
4.1.3.2 Operation Mode	120
4.1.3.3 Operational Conditions.....	120
4.1.3.4 Related Parameters	121
4.1.3.5 How to Use.....	129
4.1.3.6 Basic Gain Parameter Setup Table	131
4.2 Gain Switching Function	133
4.2.1 Function Overview	133
4.2.2 Operational Conditions.....	133
4.2.3 Related Parameters	133
4.2.4 How to Use.....	138
4.2.4.1 For Manual Setting.....	138
4.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	142
4.3 3rd Gain Switching Function.....	145
4.3.1 Function Overview	145
4.3.2 Operational Conditions.....	145
4.3.3 Related Parameters	145
4.3.4 How to Use.....	146
4.3.4.1 For Manual Setting.....	146
4.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	147
4.4 Feedforward Function.....	148
4.4.1 Function Overview	148
4.4.2 Operational Conditions.....	148
4.4.3 Related Parameters	148
4.4.4 How to Use.....	149
4.4.4.1 For Manual Setting.....	149
4.4.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	150

4.5 Friction Torque Compensation Function	153
4.5.1 Function Overview	153
4.5.2 Operational Conditions	153
4.5.3 Related Parameters	153
4.5.4 How to Use	154
4.5.4.1 When Set-up Support Software (PANATERM ver.7) Is Used	155
4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)	159
4.6.1 Function Overview	159
4.6.2 Operational Conditions	159
4.6.3 Related Parameters	159
4.6.4 How to Use	160
4.6.4.1 For Manual Setting	160
4.6.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	161
4.7 Load Fluctuation Control Function (Load Fluctuation Stabilization Applications)	166
4.7.1 Function Overview	166
4.7.2 Operational Conditions	166
4.7.3 Related Parameters	167
4.7.4 How to Use	168
4.7.4.1 For Manual Setting	168
4.7.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	168
4.8 High Response Current Control Function	173
4.8.1 Function Overview	173
4.8.2 Operational Conditions	173
4.8.3 Related Parameters	173
4.8.4 How to Use	174
4.8.4.1 For Manual Setting	174
4.8.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	174
4.9 Quadrant Glitch Suppression Function	177
4.9.1 Function Overview	177
4.9.2 Operational Conditions	177
4.9.3 Related Parameters	177
4.9.4 How to Use	178
4.9.4.1 For Manual Setting	178
4.9.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	179

4.1 Real-time Auto Tuning Function

This function estimates machine load characteristics in real time and uses those results to automatically perform basic gain setting and load characteristic compensation.

There are the following three types of real-time auto tuning, which can be switched by setting parameters.

Control type	Description
Two-degree-of-freedom control mode for standard type	This mode is suitable for positioning control. Load characteristic measurement, 3rd gain switching and viscous friction compensation can be enabled.
Two-degree-of-freedom control mode for synchronization type	This mode is suitable for controlling multiple loci such as with multijoint robots, etc. This type differs from the two-degree-of-freedom control mode for standard type in that the command response can be set individually and unbalanced load (gravity) compensation can be disabled.
Two-degree-of-freedom control mode disabled type	Two-degree-of-freedom control mode is disabled.

4.1.1 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Standard Type)

4.1.1.1 Function Overview

This control mode is suitable for positioning control where the moving locus is not important. It is effective for individually tuning operation acceleration and disturbance suppression. This is a standard control mode, and normally the two-degree-of-freedom control mode for standard type should be used.

Set Pr6.47 “Function expansion setup 2” :bit 0 “Two-degree-of-freedom control mode” = 1 (enabled) and bit 3 “Two-degree-of-freedom control real-time auto tuning selection” = 0 (standard type) to set this type.

4.1.1.2 Operation Mode

In real-time auto tuning (two-degree-of-freedom control mode for standard type), the operation mode can be changed according to Pr0.02 “Real-time auto-gain tuning setup”. In each operation mode, automatic inertia ratio updates, basic gain setting, unbalanced load compensation, and friction compensation can be enabled or disabled.

In all modes of operation, operation acceleration and disturbance suppression can be tuned individually.

When Pr0.02 = 7, automatic inertia ratio updates, basic gain setting, unbalanced load compensation, and friction compensation can be enabled or disabled individually. Select Pr0.02 = 7 (set value 7) to optimize each function according to device characteristics.

Details on Pr0.02 “Real-time auto-gain tuning setup”

Setup value	Operation mode	Description
0	Disabled	The real-time auto tuning function is disabled.
1	Standard response mode	This is an operation mode with an emphasis on stability. Unbalanced load compensation and friction compensation are not performed, and gain switching is not used.
2	High response mode 1	This is a positioning-focused operation mode. Use for devices such as low-friction ball screw driven devices that do not have unbalanced load on the horizontal axis.
3	High response mode 2	In addition to high response mode 1, this mode suppresses variation in positioning settling times using unbalanced load compensation, such as for a vertical axis, as well as via application of 3rd gain.
4	High response mode 3	In addition to high response mode 2, this mode shortens the positioning settling time with a belt mechanical shaft with high friction, etc. In terms of speed control, this mode is the same as high response mode 2. The Pr2.53 “Positive direction torque compensation value 2”, Pr2.54 “Negative direction torque compensation value 2”, and Pr6.50 “Viscous friction compensating gain” parameter values are updated, but are not reflected in the operation.

Setup value	Operation mode	Description
5	Load characteristic measurement	The basic gain setting and friction compensation setting are not changed, only load characteristic estimation is performed. Used in combination with Set-up Support Software (PANATERM ver.7) .
6	Customize 1	The real-time auto tuning function is disabled in two-degree-of-freedom control mode for standard type.
7	Customize 2	The combination of real-time auto tuning functions can be customized for each application by configuring advanced settings in Pr6.32 "Real time auto tuning custom setup" . A change ratio can be set for the basic gain setting. Therefore, this mode should normally be selected. Some functions are not available depending on the control mode. For details, see " Details on Pr6.32 "Real time auto tuning custom setup" " .

4.1.1.3 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Position control, speed control, and full-closed control Pr6.47:bit 0 = 1 and bit 3 = 0 (standard type)

Real-time auto tuning may not work normally under the following conditions. In such cases, change the load conditions, operation pattern, or manually set the related parameters.

Item	Conditions that obstruct the operation of real-time auto tuning
Load	<ul style="list-style-type: none"> When load inertia is small or large compared to the rotor inertia of the servo motor (less than 3× or 20× or more) When load inertia fluctuates When machine stiffness is extremely low When non-linear characteristics exist, such as looseness due to backlash
Operation patterns	<ul style="list-style-type: none"> When used continuously at low speeds of less than 100 r/min When acceleration and deceleration are gentle, less than 2000 r/min in 1 s When the speed is more than 100 r/min and the acceleration and deceleration condition of more than 2000 r/min in 1 s does not continue for more than 50 ms <p>Example of an operation pattern that obstructs function operation</p> <p>The example shows three scenarios where real-time auto tuning might be obstructed:</p> <ol style="list-style-type: none"> A constant speed profile at 100 r/min. A gradual acceleration profile with a gradient of 2000 (r/min)/s or less. A sharp acceleration profile with a gradient of 2000 (r/min)/s or more, reaching 100 r/min in 50 ms or less. <ul style="list-style-type: none"> When the acceleration and deceleration torque is small compared to the unbalanced load and viscous friction torque

4.1.1.4 Related Parameters

4.1.1.4.1 Parameters That Control the Operation of This Function

—: N/A

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function															
0	02	B	Real-time auto-gain tuning setup	0 to 7	—	Sets the real-time auto tuning operation mode. Normally, select setting value 7.															
0	03	B	Real-time auto-tuning machine stiffness setup	0 to 31	—	Sets responsiveness when real-time auto tuning is enabled. Higher settings result in higher speed responsiveness and servo stiffness, but make it more likely that vibration will occur. Values should be changed from low to high with a close eye on operation. Enabled with Pr2.45 "Function expansion setup 10" : bit 5 = 0 (32 stiffness settings).															
0	27	B	Selection of machine stiffness at real-time auto-gain tuning 2	0 to 44	—	Sets responsiveness when real-time auto tuning is enabled. Higher settings result in higher speed responsiveness and servo stiffness, but make it more likely that vibration will occur. Values should be changed from low to high with a close eye on operation. Allows finer gain adjustment than Pr0.03. Enabled with Pr2.45 "Function expansion setup 10" : bit 5 = 1 (45 stiffness settings).															
0	28	B	Selection of feed forward stiffness at real-time auto-gain tuning	0 to 44	—	Sets responsiveness when real-time auto tuning is enabled. Higher settings result in higher speed responsiveness, but make it more likely that overshoot will occur. Values should be changed from low to high with a close eye on operation. Enabled with Pr2.45 "Function expansion setup 10" : bits 5 to 4 = 11b.															
2	74	A	Tuning auto tuning application selection	-32768 to 32767	—	For Pr0.02 = 7 (Customize 2), any change ratio can be set for the basic gain setting to fit the application when the set value = 3. 0: Positioning 3: Customize															
6	10	B	Function expansion setup	-32768 to 32767	—	bit 14: Load fluctuation suppression function automatic tuning 0: Disabled 1: Enabled															
6	31	B	Real time auto tuning estimation speed	0 to 3	—	Sets load characteristics estimated speed when real-time auto-tuning is enabled. Higher settings result in faster responses to changes in load characteristics, but they also increase variations in disturbance estimation. Estimation results are saved in EEPROM every 30 minutes regardless of the load characteristic estimated speed setting. When automatic vibration detection is enabled from Setup Support Software (PANATERM ver.7) , this setting will be ignored and the setting value will be set to 3.															
<table><tr><td>Setup value</td><td>Mode</td><td>Description</td></tr><tr><td>0</td><td>Does not change</td><td>Stops load characteristics estimation.</td></tr><tr><td>1</td><td>Changes very little</td><td>Estimates changes in load characteristics in minutes.</td></tr><tr><td>2</td><td>Changes slowly</td><td>Estimates changes in load characteristics in seconds.</td></tr><tr><td>3</td><td>Changes precipitously</td><td>Fastest estimation of changes in load characteristics.</td></tr></table>							Setup value	Mode	Description	0	Does not change	Stops load characteristics estimation.	1	Changes very little	Estimates changes in load characteristics in minutes.	2	Changes slowly	Estimates changes in load characteristics in seconds.	3	Changes precipitously	Fastest estimation of changes in load characteristics.
Setup value	Mode	Description																			
0	Does not change	Stops load characteristics estimation.																			
1	Changes very little	Estimates changes in load characteristics in minutes.																			
2	Changes slowly	Estimates changes in load characteristics in seconds.																			
3	Changes precipitously	Fastest estimation of changes in load characteristics.																			

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	32	B	Real time auto tuning custom setup	-32768 to 32767	—	Makes advanced settings for the automatic adjustment function when the Pr0.02 = 7 (Customize 2) is selected as an operation mode for real-time auto tuning.

*1 For attributes, see “7.1 List of Parameters”.

■ Details on Pr6.32 “Real time auto tuning custom setup”

bit	Name	Description																					
1 to 0	Load characteristics estimation	<p>Set to enable or disable the load characteristics estimation function.</p> <p>0: Disabled 1: Enabled</p> <p>— Precautions —</p> <ul style="list-style-type: none"> When this setting is disabled, the target parameters are not updated from the current settings even if bit 3 to 2 “Inertia Ratio Update”, bit 6 to 4 “Torque compensation”, and bit 15 to 12 “Individual torque compensation settings” are set to enable updates. To enable load characteristic estimation, set Pr6.31 “Real time auto tuning estimation speed” to a value other than 0 (no change). 																					
3 to 2	Inertia Ratio Update	<p>Set updates in load characteristic estimation results for Pr0.04 “Inertia ratio”.</p> <p>0: Disabled 1: Enabled</p> <p>— Precautions —</p> <ul style="list-style-type: none"> To enable inertia ratio updates, set bit 1 to 0 “Load characteristics estimation” to 1 (enabled). If both are not enabled, the inertia ratio will not be updated. 																					
6 to 4	Torque compensation (*1)	<p>Set updates in load characteristic estimation results for Pr2.52 “Torque command additional value 2”, Pr2.53 “Positive direction torque compensation value 2”, Pr2.54 “Negative direction torque compensation value 2” and Pr6.50 “Viscous friction compensating gain”.</p> <table border="1"> <thead> <tr> <th>Setup value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Use current settings</td><td>Uses current settings.</td></tr> <tr> <td>1</td><td>Disable torque compensation</td><td>Clear Pr2.52, Pr2.53, Pr2.54, and Pr6.50 to 0.</td></tr> <tr> <td>2</td><td>Vertical axis mode</td><td>Update Pr2.52 and clear Pr2.53, Pr2.54 and Pr6.50 to 0.</td></tr> <tr> <td>3</td><td>Friction compensation (weak)</td><td>Update Pr2.52 and set weak compensation for Pr2.53, Pr2.54, and Pr6.50.</td></tr> <tr> <td>4</td><td>Friction compensation (medium)</td><td>Update Pr2.52 and set medium compensation for Pr2.53, Pr2.54, and Pr6.50.</td></tr> <tr> <td>5</td><td>Friction compensation (strong)</td><td>Update Pr2.52 and set strong compensation for Pr2.53, Pr2.54 and Pr6.50.</td></tr> </tbody> </table> <p>— Precautions —</p> <ul style="list-style-type: none"> Change the parameters to be used depending on the values set in Pr2.45 “Function expansion setup 10”: bit 2 “Friction torque compensation parameter selection”. The initial value is Pr2.45: bit 2 = 1. <ul style="list-style-type: none"> Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09 Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54 	Setup value	Mode	Description	0	Use current settings	Uses current settings.	1	Disable torque compensation	Clear Pr2.52, Pr2.53, Pr2.54, and Pr6.50 to 0.	2	Vertical axis mode	Update Pr2.52 and clear Pr2.53, Pr2.54 and Pr6.50 to 0.	3	Friction compensation (weak)	Update Pr2.52 and set weak compensation for Pr2.53, Pr2.54, and Pr6.50.	4	Friction compensation (medium)	Update Pr2.52 and set medium compensation for Pr2.53, Pr2.54, and Pr6.50.	5	Friction compensation (strong)	Update Pr2.52 and set strong compensation for Pr2.53, Pr2.54 and Pr6.50.
Setup value	Mode	Description																					
0	Use current settings	Uses current settings.																					
1	Disable torque compensation	Clear Pr2.52, Pr2.53, Pr2.54, and Pr6.50 to 0.																					
2	Vertical axis mode	Update Pr2.52 and clear Pr2.53, Pr2.54 and Pr6.50 to 0.																					
3	Friction compensation (weak)	Update Pr2.52 and set weak compensation for Pr2.53, Pr2.54, and Pr6.50.																					
4	Friction compensation (medium)	Update Pr2.52 and set medium compensation for Pr2.53, Pr2.54, and Pr6.50.																					
5	Friction compensation (strong)	Update Pr2.52 and set strong compensation for Pr2.53, Pr2.54 and Pr6.50.																					

bit	Name	Description															
7	Stiffness Setup (*2)	<p>Set to enable or disable the basic gain setting using Pr0.03 “Real-time auto-tuning machine stiffness setup” , Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2” or Pr0.28 “Selection of feed forward stiffness at real-time auto-gain tuning” .</p> <p>0: Disabled 1: Enabled</p> <p>— Precautions —</p> <ul style="list-style-type: none">Change the parameters to be used depending on the values set in Pr2.45 “Function expansion setup 10” :bit 5 to 4 “Stiffness setting resolution, individual FB/FF setting switching” . The initial value is Pr2.45: bits 5 to 4 = 11b.<ul style="list-style-type: none">Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03Pr2.45: bits 5 to 4 = 10b : Pr0.27Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28															
8	Fixed Parameter Setup (*2)	<p>Set whether or not to change parameters that become fixed values when real-time auto tuning is enabled.</p> <p>For details, see the table “<i>Values Set When Real-Time Auto Tuning is Enabled (Pr0.02 = 1 to 4, 7)</i>” in “<i>4.1.1.4.3 Parameters Changed By This Function</i>” .</p> <p>0: Use current settings 1: Set to fixed values</p>															
10 to 9	Gain Switching Setup (*2)	<p>Select the method for setting parameters related to gain switching when real-time auto tuning is enabled.</p> <p>0: Use current settings 1: Gain switching disabled 2: Gain switching enabled</p>															
11	Torque compensation setting switching	<p>Select whether to enable bits 6 to 4 or bits 15 to 12 for torque compensation.</p> <p>0: Enable bits 6 to 4 1: Enable bits 15 to 12</p>															
15 to 12	Individual torque compensation settings (*1)	<p>Select whether to use or update the current setting for the corresponding parameters when bit 11 “Torque compensation setting switching” = 1.</p> <p>0: Use current settings 1: Update</p> <table><tr><td></td><td>bit 15</td><td>bit 14</td><td>bit 13</td><td>bit 12</td></tr><tr><td>When Pr2.45:bit 2 = 1</td><td>Pr6.50</td><td>Pr2.54</td><td>Pr2.53</td><td>Pr2.52</td></tr><tr><td>When Pr2.45:bit 2 = 0</td><td>Pr6.50</td><td>Pr6.09</td><td>Pr6.08</td><td>Pr6.07</td></tr></table>		bit 15	bit 14	bit 13	bit 12	When Pr2.45:bit 2 = 1	Pr6.50	Pr2.54	Pr2.53	Pr2.52	When Pr2.45:bit 2 = 0	Pr6.50	Pr6.09	Pr6.08	Pr6.07
	bit 15	bit 14	bit 13	bit 12													
When Pr2.45:bit 2 = 1	Pr6.50	Pr2.54	Pr2.53	Pr2.52													
When Pr2.45:bit 2 = 0	Pr6.50	Pr6.09	Pr6.08	Pr6.07													

*1 To set to enable updates to torque compensation, set bit 1 to 0 "Load characteristics estimation" and bit 3 to 2 "Inertia Ratio Update" to 1 (enabled). Updates are not applied with update settings for torque compensation only.

*2 To set this set value to a value other than 0, set bit 3 to 2 "Inertia Ratio Update" to 1 (enabled). Whether or not inertia ratio update is enabled at this time can be set with bit 1 to 0 "Load characteristics estimation".

— Precautions —

- These parameters must be set in bit units. Operation cannot be guaranteed with incorrect settings. Using Set-up Support Software (PANATERM ver.7) is recommended for changing parameter setup values.
- Do not change these parameters during motor operation. Actually updating of parameters takes place when the motor stops after the load characteristic measurement results are confirmed.

Notes

- Calculating Pr6.32 set value from values in bit units
When configuring each setting to a value other than 0, use the following procedure to calculate the set value for Pr6.32.
- Confirm the least significant bit for each setting.

(Example) The least significant bit of the torque compensation function is 4

- 2 Multiply 2 to the power of (LSB) by the set value.

(Example) If bit 6 to 4 “Torque compensation” = 3 (friction compensation (weak)), then $2^4 \times 3$.

- 3 For each setting, calculate “1” and “2” and then add them all together to obtain the set value for Pr6.32.

(Example) When load characteristic measurement = enabled, inertia ratio update = enabled, torque compensation = friction compensation (weak), stiffness setting = enabled, fixed parameters = set to fixed values, gain switching setup = enabled

$$2^0 \times 1 + 2^2 \times 1 + 2^4 \times 3 + 2^7 \times 1 + 2^8 \times 1 + 2^9 \times 2 = 1461$$

4.1.1.4.2 Parameters to Switch the Parameters Used by This Function to Minas A6 Series-Compatible Specification

In real-time auto tuning, the parameters used in real-time auto tuning can be switched to MINAS A6 Series-compatible specification parameters by setting Pr2.45 “Function expansion setup 10”.

- Parameters related to stiffness, unbalanced load and friction compensation and tuning filters
- Calculation method when updating torque filter time constant and some parameters for load fluctuation compensation (Pr6.73 “Load estimation filter” and Pr6.76 “Load estimation count”)

Item	Parameters for switching to MINAS A6 Series-compatible specification	Initial value (*1)
Stiffness	Can be changed with Pr2.45 “Function expansion setup 10” :bit 5 to 4 “Stiffness setting resolution, individual FB/FF setting switching”.	bits 5 to 4 = 11b
Unbalanced load/friction compensation	Can be changed with Pr2.45 “Function expansion setup 10” :bit 2 “Friction torque compensation parameter selection”.	bit 2 = 1
Torque filter time constant	Determined by the value of Pr2.45 “Function expansion setup 10” :bit 1 to 0 “Two-degree-of-freedom control function setting”.	bits 1 to 0 = 01b
Load fluctuation compensation	Determined by the value of Pr2.45 “Function expansion setup 10” :bit 3 “Load fluctuation suppression function automatic calculation”.	bit 3 = 1

*1 Normally used with initial values.

—: N/A

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	38	B	Filter function switching	-32768 to 32767	—	Select a tuning filter. Normally, set to bit 1 = 1. bit 1: Tuning filter 2 0: Use Pr6.48 “Tuning filter” (MINAS A6 Series-compatible specification) 1: Use Pr2.46 “Tuning filter 2” (MINAS A7 Series specification)
2	45	B	Function expansion setup 10	-2147483648 to 2147483647	—	Sets various functions. bit 1 to 0: Two-degree-of-freedom control function setting bit 2: Friction torque compensation parameter selection bit 3: Load fluctuation suppression function automatic calculation bit 5 to 4: Stiffness setting resolution, individual FB/FF setting switching bit 31 to 6: Unused

*1 For attributes, see “7.1 List of Parameters”.

■ Details on Pr2.45 “Function expansion setup 10”

—: N/A

bit	Name	Description	Initial value
1 to 0	Two-degree-of-freedom control function setting	00b: Two-degree-of-freedom control (MINAS A6 Series-compatible specification) 01b: Two-degree-of-freedom control (MINAS A7 Series specification) 10b: Manufacturer use 11b: Manufacturer use	01b
2	Friction torque compensation parameter selection	0: MINAS A6 Series-compatible specification settings Unbalanced load compensation value: Use Pr6.07 Dynamic friction compensation value: Use Pr6.08, Pr6.09 1: MINAS A7 Series specification settings Unbalanced load compensation value: Use Pr2.52 Dynamic friction compensation value: Use Pr2.53, Pr2.54	1
3	Load fluctuation suppression function automatic calculation	0: Conventional setting (MINAS A6 Series specification) 1: The following parameters are automatically calculated. Pr6.73 “Load estimation filter” Pr6.76 “Load estimation count”	1
5 to 4	Stiffness setting resolution, individual FB/FF setting switching	00b: 32 stiffness settings, FB/FF common setting (MINAS A6 Series-compatible specification) Use Pr0.03 01b: Same as 00b 10b: 45 stiffness settings, FB/FF common setting (MINAS A7 Series specification) Use Pr0.27 11b: 45 stiffness settings, individual FB/FF settings (MINAS A7 Series specification) Use Pr0.27 and Pr0.28	11b
31 to 6	Not used	—	—

4.1.1.4.3 Parameters Changed By This Function

■ Parameters updated using estimated values for load characteristics

When Pr0.02 “Real-time auto-gain tuning setup” is 1 to 4, real-time auto tuning updates the parameters in the table below using the estimated value for load characteristics.

When Pr0.02 “Real-time auto-gain tuning setup” is 7, the parameters in the table below are updated using the estimated value for load characteristics estimates based on the contents of Pr6.32 “Real time auto tuning custom setup”.

Target parameter (*1)		Conditions for update (*2)
Pr2.45:bit 2 = 1	Pr2.45:bit 2 = 0	
Pr0.04 “Inertia ratio”		When inertia ratio update is enabled (Pr0.02 = 1 to 4, 7)
Pr2.52 “Torque command additional value 2”	Pr6.07 “Torque command additional value”	When vertical axis mode or friction compensation mode is enabled (Pr0.02 = 3, 4, 7)
Pr2.53 “Positive direction torque compensation value 2”	Pr6.08 “Positive direction torque compensation value”	When friction compensation mode is enabled (Pr0.02 = 4, 7)
Pr2.54 “Negative direction torque compensation value 2”	Pr6.09 “Negative direction torque compensation value”	When friction compensation mode is enabled (Pr0.02 = 4, 7)

Target parameter (*1)		Conditions for update (*2)
Pr2.45:bit 2 = 1	Pr2.45:bit 2 = 0	
Pr6.50 "Viscous friction compensating gain"		When viscous friction compensation mode is enabled (Pr0.02 = 4, 7)

*1 Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection". The initial value is Pr2.45: bit 2 = 1.

*2 When Pr0.02 = 7, each parameter update can be set with Pr6.32 "Real time auto tuning custom setup".

■ Basic gain setting parameters updated according to machine stiffness settings

Real-time auto tuning updates the basic gain setting parameters according to the parameter settings below when Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4 or 7. For details, see ["4.1.1.6 Basic Gain Parameter Setup Table"](#).

- Pr0.03 "Real-time auto-tuning machine stiffness setup"
- Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
- Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning"

Notes

- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.
 - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
 - Pr2.45: bits 5 to 4 = 10b : Pr0.27
 - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

Basic gain setting

Target parameter	Conditions for update according to stiffness (*1)
Pr1.00 "1st gain of position loop" Pr1.01 "1st velocity loop gain" Pr1.02 "1st velocity loop integration time constant" Pr1.04 "1st torque filter time constant" Pr1.05 "2nd gain of position loop" Pr1.06 "2nd velocity loop gain" Pr1.07 "2nd velocity loop integration time constant" Pr1.09 "2nd torque filter time constant"	<ul style="list-style-type: none"> • When stiffness setup is enabled (Pr0.02 = 1 to 4, 7)
Pr2.22 "Positional command smoothing filter"	<ul style="list-style-type: none"> • When stiffness setup is enabled (Pr0.02 = 1 to 4, 7) • In speed control, the first order lag filter is fixed.
Pr2.46 "Tuning filter 2"	<ul style="list-style-type: none"> • Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2" = 1 (enabled) When stiffness setup is enabled (Pr0.02 = 1 to 4, 7)
Pr6.48 "Tuning filter"	<ul style="list-style-type: none"> • Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2" = 0 (disabled) When stiffness setup is enabled (Pr0.02 = 1 to 4, 7) • In speed control, the first order lag filter is fixed.
Pr6.49 "Command response/tuning filter attenuation term"	<ul style="list-style-type: none"> • Set to (Pr0.02 = 1 to 4, 7) or 15 when real-time auto tuning is enabled.

*1 When Pr0.02 = 7, each parameter update can be set with Pr6.32 "Real time auto tuning custom setup".

When Pr0.02 = 7 (Customize 2) and Pr2.74 "Tuning auto tuning application selection" = 3, any change ratio can be set for the values in the Basic Gain Parameter Settings Table.

Target parameter	Basic gain parameter setting in stiffness setup values when gain change ratio is enabled
Pr1.106 "1st position loop gain change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.00 "1st gain of position loop" When this setup value is 0, this is set to 100%.
Pr1.107 "1st velocity integration change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.02 "1st velocity loop integration time constant" When this setup value is 0, this is set to 100%.
Pr1.108 "1st torque filter change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.04 "1st torque filter time constant"
Pr1.109 "2nd position loop gain change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.05 "2nd gain of position loop" When this setup value is 0, this is set to 100%.
Pr1.110 "2nd velocity loop gain change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.06 "2nd velocity loop gain" When this setup value is 0, this is set to 100%.
Pr1.111 "2nd velocity integration change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.07 "2nd velocity loop integration time constant" When this setup value is 0, this is set to 100%.
Pr1.112 "2nd torque filter change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.09 "2nd torque filter time constant"
Pr1.113 "Load fluctuation compensation filter change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr6.24 "Load change compensation filter" When this setup value is 0, this is set to 100%.
Pr1.114 "Smoothing filter change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr2.22 "Positional command smoothing filter" (*1)
Pr1.115 "Tuning filter change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr6.48 "Tuning filter"

*1 The "High response modes 1 to 3" column in the Basic Gain Parameter Settings Table is used for Pr2.22 values. For details, see ["4.1.1.6 Basic Gain Parameter Setup Table"](#).

■ Parameters set based on Fixed Parameter Setup

For real-time auto tuning, set the parameters in the table below in any of the following cases.

- When Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4
- When Pr0.02 "Real-time auto-gain tuning setup" is 7 and Pr6.32 "Real time auto tuning custom setup" :bit 8 "Fixed Parameter Setup" is 1

Target parameter	Value to set (Pr0.02 = 1 to 4, 7) when real-time auto tuning is enabled
Pr1.03 "1st filter of velocity detection"	Set to 0
Pr1.08 "2nd filter of velocity detection"	Set to 0
Pr1.10 "Velocity feed forward gain"	Set to 1000
Pr1.11 "Velocity feed forward filter"	Set to 0
Pr1.12 "Torque feed forward gain"	Set to 1000
Pr1.13 "Torque feed forward filter"	Set to 0
Pr6.10 "Function expansion setup"	Set bit 4 "Current response improvement" to 1 (enabled)

■ Parameters set based on Gain Switching Setup

For real-time auto tuning, set the parameters in the table below in any of the following cases.

- When Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4
- When Pr0.02 "Real-time auto-gain tuning setup" is 7 and Pr6.32 "Real time auto tuning custom setup" :bit 10 to 9 "Gain Switching Setup" is 1

Target parameter	Value to be set				
	Pr0.02 = 1	Pr0.02 = 2	Pr0.02 = 3	Pr0.02 = 4	Pr0.02 = 7
Pr1.14 "2nd gain setup"	Set to 1				
Pr1.15 "Mode of position control switching"	Set to 0	Set to 7			

Target parameter	Value to be set				
	Pr0.02 = 1	Pr0.02 = 2	Pr0.02 = 3	Pr0.02 = 4	Pr0.02 = 7
Pr1.16 "Delay time of position control switching"	Set to 10				
Pr1.17 "Level of position control switching"	Set to 0				
Pr1.18 "Hysteresis at position control switching"	Set to 0				
Pr1.19 "Position gain switching time"	Set to 10				
Pr1.20 "Mode of velocity control switching"	Set to 0				
Pr1.21 "Delay time of velocity control switching"	Set to 0				
Pr1.22 "Level of velocity control switching"	Set to 0				
Pr1.23 "Hysteresis at velocity control switching"	Set to 0				
Pr1.24 "Mode of torque control switching"	Set to 0				
Pr1.25 "Delay time of torque control switching"	Set to 0				
Pr1.26 "Level of torque control switching"	Set to 0				
Pr1.27 "Hysteresis at torque control switching"	Set to 0				
Pr6.05 "Position 3rd gain valid time"	Set to 0 (disabled)		Set to "Pr2.22 × 20" (However, the maximum value is limited to 10000.)		
Pr6.06 "Position 3rd gain scale factor"	Set to 100 (100%)		Set to 200 (200%)		

■ Parameters set based on Load fluctuation suppression function automatic tuning

When Pr0.02 "Real-time auto-gain tuning setup" is between 1 to 4 or 7, set the following parameters according to Pr6.10 "Function expansion setup" :bit 14 "Load fluctuation suppression function automatic tuning".

Target parameter	Condition	Value to be set	
		Pr6.10:bit 14 = 1	Pr6.10:bit 14 = 0
Pr6.10 “Function expansion setup”	When stiffness setup is enabled	bit 1 “Load fluctuation control function” = 1 (enabled)	bit 1 “Load fluctuation control function” = 0 (disabled)
Pr6.23 “Load change compensation gain”	When stiffness setup is enabled	Set to 90 (90%)	Set to 0
Pr6.24 “Load change compensation filter”	When stiffness setup is enabled	Updates to set value according to stiffness	Retain value
Pr6.73 “Load estimation filter”	When stiffness setup is enabled and Pr2.45 “Function expansion setup 10” :bit 3 = 0	Set to 13	Set to 0
	When stiffness setup is enabled and Pr2.45 “Function expansion setup 10” :bit 3 = 1	Set automatically	
Pr6.74 “Torque compensation frequency 1”	Set to 0 regardless of the value of Pr6.10:bit 14.		
Pr6.75 “Torque compensation frequency 2”	Set to 0 regardless of the value of Pr6.10:bit 14.		
Pr6.76 “Load estimation count”	When stiffness setup is enabled and Pr2.45 “Function expansion setup 10” :bit 3 = 0	Set to 4	Set to 0
	When stiffness setup is enabled and Pr2.45 “Function expansion setup 10” :bit 3 = 1	Automatically set according to stiffness	

4.1.1.5 How to Use

- When Pr0.02 “Real-time auto-gain tuning setup” is set to 1 to 4 or 7, real-time auto tuning is enabled. The parameter values used for tuning are automatically set according to the parameter settings below.
 - Pr0.03 “Real-time auto-tuning machine stiffness setup”
 - Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2”
 - Pr0.28 “Selection of feed forward stiffness at real-time auto-gain tuning”
 - Pr6.10 “Function expansion setup” :bit 14 “Load fluctuation suppression function automatic tuning”
- Input the operation command after approximately 100 ms have elapsed since servo-on.
- Pr0.04 “Inertia ratio” changes when load characteristics estimation is complete. Pr2.52 “Torque command additional value 2” , Pr2.53 “Positive direction torque compensation value 2” , and Pr2.54 “Negative direction torque compensation value 2” also change depending on the mode setting (see [“Supplement”](#)).
- Increasing the setup values of the following parameters will increase the responsiveness of the motor. While checking the positioning settling time and vibration state, increase the setup values by increments of 1 and tune to the optimal values.
 - Pr0.03 “Real-time auto-tuning machine stiffness setup”
 - Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2”
 - Pr0.28 “Selection of feed forward stiffness at real-time auto-gain tuning”
- Setting Pr0.02 “Real-time auto-gain tuning setup” to 0 disables real-time auto tuning. Automatic estimation of Pr0.04 “Inertia ratio” stops, but the inertia ratio value at the time of estimation stopping is retained. If the value of the inertia ratio is clearly abnormal, set a reasonable value manually.

Notes

- Pr2.52, Pr2.53 and Pr2.54
Change the parameters to be used depending on the values set in Pr2.45 “Function expansion setup 10” :bit 2 “Friction torque compensation parameter selection” . The initial value is Pr2.45: bit 2 = 1.
 - Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
 - Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
- Change the parameters to be used depending on the values set in Pr2.45 “Function expansion setup 10” :bit 5 to 4 “Stiffness setting resolution, individual FB/FF setting switching” . The initial value is Pr2.45: bits 5 to 4 = 11b.
 - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
 - Pr2.45: bits 5 to 4 = 10b : Pr0.27
 - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

— Precautions —

- When real-time auto tuning is enabled, the response to estimated values after power-up to completion of load characteristic estimation may be faster regardless of the set value for Pr6.31 “Real time auto tuning estimation speed” .
- Immediately after power-up, there is not enough operation data effective for load characteristic estimation, meaning estimated values may be abnormal and operation instable due to disturbance, etc. Once tuning is finished, we recommended that real-time auto tuning is set to disabled (Pr0.02 “Real-time auto-gain tuning setup” = 0).
- Until load characteristic estimation results stabilize, abnormal noise or oscillation may occur.
For example, if abnormal noise or oscillation occurs immediately after the first servo-on after activation or when the Pr0.03 “Real-time auto-tuning machine stiffness setup” set value is increased, it is not abnormal for the operation to stabilize immediately. After abnormal noise or oscillation occurs ,Pr0.04

"Inertia ratio" , Pr2.52 "Torque command additional value 2" , Pr2.53 "Positive direction torque compensation value 2" , or Pr2.54 "Negative direction torque compensation value 2" may change to extreme values. Take the following measures. The following measures should also be taken if abnormal noise or oscillation occurs frequently.

- 1 Lower the set value for Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2" .
 - 2 Set Pr0.02 "Real-time auto-gain tuning setup" to 0 to disable real-time auto tuning.
 - 3 Set Pr0.04 "Inertia ratio" to the value calculated on the device and set Pr2.52 "Torque command additional value 2" , Pr2.53 "Positive direction torque compensation value 2" , and Pr2.54 "Negative direction torque compensation value 2" to 0 (see "Supplement").
 - 4 After setting Pr6.10 "Function expansion setup" :bit 14 = 0, set bit 1 = 0 to disable the load fluctuation control function.
- The Pr0.04 "Inertia ratio" , Pr2.52 "Torque command additional value 2" , Pr2.53 "Positive direction torque compensation value 2" , and Pr2.54 "Negative direction torque compensation value 2" (see "Supplement") values, which are the results of real-time auto gain tuning, are automatically written to and saved in EEPROM every 30 minutes. When power is restored, auto tuning is performed using the saved EEPROM values as the initial values. If turning OFF the power without 30 minutes having elapsed since values were automatically saved in EEPROM, manually write the latest real-time auto gain tuning results to EEPROM before turning OFF the power.
 - Since control gain is updated when the motor stops, changes to Pr0.03 "Real-time auto-tuning machine stiffness setup" , Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2" , and Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning" settings are not reflected if the motor does not stop (if the gain is extremely low or if a command is continuously given in one direction).
- Before changing any of the above three parameters related to stiffness setup, stop the motor once to make sure that the stiffness setup has been reflected. Depending on the stiffness setup reflected after the motor is stopped, abnormal noise or oscillation may occur.
- In torque control of two-degree-of-freedom control mode, when real-time auto tuning is enabled, torque feedforward is disabled (equivalent to Pr1.12 = 0) regardless of the Pr1.12 "Torque feed forward gain" set value. Operation continues with torque feedforward disabled until the next operation is performed.
 - Set Pr1.12 "Torque feed forward gain" to a value other than the current parameter (1000) after switching real-time auto tuning from enabled to disabled.
 - The following are linked in the Set-up Support Software (PANATERM ver.7) Manual TUNING screen.
 - Feedback gain setting: Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
 - FF gain setting: Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning"

Notes

- Pr2.52, Pr2.53 and Pr2.54
Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection" . The initial value is Pr2.45: bit 2 = 1.
 - Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
 - Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching" . The initial value is Pr2.45: bits 5 to 4 = 11b.
 - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03

- Pr2.45: bits 5 to 4 = 10b : Pr0.27
- Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

4.1.1.6 Basic Gain Parameter Setup Table

—: None

Stiffness (*1)		1st gain/2nd gain				Command response		Tuning fil- ter	Load fluctuation suppression
Pr0.03 (*1)	Pr0.27 Pr0.28 (*1)	Pr1.00 Pr1.05	Pr1.01 Pr1.06	Pr1.02 Pr1.07	Pr1.04 Pr1.09 (*2)	Pr2.22		Pr6.48 (*3)	Pr6.24
		Position [0.1 s ⁻¹]	Speed [0.1 Hz]	Speed in- tegration [0.1 ms]	Torque [0.01 ms]	Time constant [0.1 ms]		Time con- stant [0.1 ms]	Load change compensation filter [0.01 ms]
						Standard response mode	High re- sponse modes 1 to 3		
0	0	20	15	3700	1500	1919	764	155	2500
1	1	25	20	2800	1100	1487	595	115	2500
2	2	30	25	2200	900	1214	486	94	2500
3	3	40	30	1900	800	960	384	84	2500
4	4	45	35	1600	600	838	335	64	2500
5	5	55	45	1200	500	668	267	54	2500
6	6	75	60	900	400	496	198	44	2500
7	7	95	75	700	300	394	158	34	2120
8	8	115	90	600	300	327	131	34	1770
9	9	140	110	500	200	268	107	24	1450
10	10	175	140	400	200	212	85	23	1140
—	11	250	160	350	163	170	68	19	1000
11	12	320	180	310	126	139	55	16	880
—	13	355	200	280	114	125	49	14	795
12	14	390	220	250	103	113	45	13	720
—	15	435	245	225	93	101	40	12	650
13	16	480	270	210	84	92	37	11	590
—	17	535	300	190	74	82	33	10	535
14	18	630	350	160	65	71	28	9	450
15	19	720	400	140	57	62	25	8	400
—	20	810	450	125	51	55	22	7	355
16	21	900	500	120	45	50	20	7	320
—	22	990	550	110	41	45	18	6	290
17	23	1080	600	110	38	41	17	6	270
—	24	1170	650	105	35	37	15	5	250
—	25	1260	700	100	32	35	14	5	235
18	26	1350	750	90	30	33	13	5	210
—	27	1490	825	85	27	30	12	5	190
19	28	1620	900	80	25	28	11	5	180
—	29	1850	1025	70	22	24	10	4	160

Stiffness (*1)		1st gain/2nd gain				Command response		Tuning fil- ter	Load fluctuation suppression
Pr0.03 (*1)	Pr0.27 Pr0.28 (*1)	Pr1.00 Pr1.05	Pr1.01 Pr1.06	Pr1.02 Pr1.07	Pr1.04 Pr1.09 (*2)	Pr2.22		Pr6.48 (*3)	Pr6.24
		Position [0.1 s ⁻¹]	Speed [0.1 Hz]	Speed in- tegration [0.1 ms]	Torque [0.01 ms]	Time constant [0.1 ms]		Time con- stant [0.1 ms]	Load change compensation filter [0.01 ms]
						Standard response mode	High re- sponse modes 1 to 3		
20	30	2060	1150	70	20	22	9	4	140
—	31	2260	1260	65	18	20	8	4	130
21	32	2510	1400	60	16	18	7	4	110
—	33	2780	1550	55	14	16	6	3	100
22	34	3050	1700	50	13	15	6	3	90
—	35	3410	1900	45	12	13	5	3	80
23	36	3770	2100	40	11	12	5	3	80
24	37	4490	2500	40	9	10	4	3	60
25	38	5000	2800	35	8	9	4	2	60
26	39	5600	3100	30	7	8	3	2	50
27	40	6100	3400	30	7	7	3	2	50
28	41	6600	3700	25	6	7	3	2	40
29	42	7200	4000	25	6	6	2	2	40
30	43	8100	4500	20	5	6	2	2	40
31	44	9000	5000	20	5	5	2	2	40

*1 Change the parameters to be used depending on the values set in Pr2.45 “Function expansion setup 10” :bit 5 to 4 “Stiffness setting resolution, individual FB/FF setting switching” . The initial value is Pr2.45: bits 5 to 4 = 11b.

- Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
- Pr2.45: bits 5 to 4 = 10b : Pr0.27
- Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

In the initial settings, only Pr2.22 is set according to Pr0.28 in the basic gain parameter setup table.

*2 The values in the table are used only when Pr2.45 “Function expansion setup 10” :bit 1 to 0 = 0.

*3 Pr6.48 “Tuning filter” may be +1 depending on the combination of servo driver and motor. Also, Pr6.48 is not used because Pr2.38 “Filter function switching” :bit 1 “Tuning filter 2” =1 (enabled) in the initial settings. The Pr2.46 “Tuning filter 2” value is set automatically when real-time auto tuning is enabled.

4.1.2 Real-time Auto Tuning (Two-degree-of-freedom Control Mode for Synchronization Type)

4.1.2.1 Function Overview

The two-degree-of-freedom control mode for synchronization type is suitable for controlling multiple loci such as with multijoint robots, because the command response setting for each axis can be set to the same value.

Set Pr6.47 “Function expansion setup 2” :bit 0 “Two-degree-of-freedom control mode” = 1 (enabled) and bit 3 “Two-degree-of-freedom control real-time auto tuning selection” = 1 (synchronization type) to set this type.

4.1.2.2 Operation Mode

In real-time auto tuning (two-degree-of-freedom control mode for synchronization type), the operation mode can be changed according to Pr0.02 “Real-time auto-gain tuning setup”. In each operation mode, automatic inertia ratio updates, basic gain setting, dynamic friction compensation, and viscous friction compensation can be enabled or disabled. An operation mode (Pr0.02 = 6) is also available for applications where load inertia fluctuates, such as multijoint robots.

Details on Pr0.02 “Real-time auto-gain tuning setup”

Setup value	Operation mode	Description
0	Disabled	The real-time auto tuning function is disabled.
1	Synchronization	This mode is for synchronous control. The settings for unbalanced load compensation and friction compensation are not changed. The command response filter is retained. Use this mode first. If you have any issues, try a different mode.
2	Synchronous friction compensation	In addition to synchronous mode, dynamic friction compensation and viscous friction compensation are applied. Use this mode for loads with high friction.
3	Stiffness setup	Only the gain and filter settings corresponding to the stiffness table are updated without changing the settings for inertia ratio estimation, unbalanced load compensation or friction compensation. For loads with significant inertia change, use this mode after inertia ratio estimation in the synchronous mode, etc.
4	Load characteristics update	Of the load characteristics, only the inertia ratio, dynamic friction compensation and viscous friction compensation are updated. Gain and filter settings retain their current values.
5	Load characteristic measurement	The basic gain setting and friction compensation setting are not changed, only load characteristic estimation is performed. Used in combination with Set-up Support Software (PANATERM ver.7) .
6	Load fluctuation support mode	Use this mode for robust tuning against load fluctuations.
7	Disabled	The real-time auto tuning function is disabled for the two-degree-of-freedom control mode for synchronization type.

4.1.2.3 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Position control Pr6.47:bit 0 = 1 and bit 3 = 1 (synchronization type)

Real-time auto tuning may not work normally under the following conditions. In such cases, change the load conditions, operation pattern, or refer to the manual TUNING function description and manually set the related parameters.

Item	Conditions that obstruct the operation of real-time auto tuning
Load	<ul style="list-style-type: none"> When load inertia is small or large compared to the rotor inertia of the servo motor (less than 3× or 20× or more) When load inertia fluctuates When machine stiffness is extremely low When non-linear characteristics exist, such as looseness due to backlash
Operation patterns	<ul style="list-style-type: none"> When used continuously at low speeds of less than 100 r/min When acceleration and deceleration are gentle, less than 2000 r/min in 1 s When the speed is more than 100 r/min and the acceleration and deceleration condition of more than 2000 r/min in 1 s does not continue for more than 50 ms <p>Example of an operation pattern that obstructs function operation</p> <p>When the acceleration and deceleration torque is small compared to the unbalanced load and viscous friction torque</p>

4.1.2.4 Related Parameters

4.1.2.4.1 Parameters That Control the Operation of This Function

—: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
0	02	B	Real-time auto-gain tuning setup	0 to 7	—	Sets the real-time auto tuning operation mode.
0	03	B	Real-time auto-tuning machine stiffness setup	0 to 31	—	<p>Sets responsiveness when real-time auto tuning is enabled. Higher settings result in higher speed responsiveness and servo stiffness, but make it more likely that vibration will occur. Values should be changed from low to high with a close eye on operation.</p> <p>Enabled with Pr2.45 "Function expansion setup 10" : bit 5 = 0 (32 stiffness settings).</p>
0	27	B	Selection of machine stiffness at real-time auto-gain tuning 2	0 to 44	—	<p>Sets responsiveness when real-time auto tuning is enabled. Higher settings result in higher speed responsiveness and servo stiffness, but make it more likely that vibration will occur. Values should be changed from low to high with a close eye on operation.</p> <p>Allows finer gain adjustment than Pr0.03.</p> <p>Enabled with Pr2.45 "Function expansion setup 10" : bit 5 = 1 (45 stiffness settings).</p>
0	28	B	Selection of feed forward stiffness at real-time auto-gain tuning	0 to 44	—	Cannot be used with two-degree-of-freedom control mode for synchronization type.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function															
2	74	A	Tuning auto tuning application selection	-32768 to 32767	—	Cannot be used with two-degree-of-freedom control mode for synchronization type.															
6	10	B	Function expansion setup	-32768 to 32767	—	bit 14: Load fluctuation suppression function automatic tuning 0: Disabled 1: Enabled															
6	31	B	Real time auto tuning estimation speed	0 to 3	—	Sets load characteristics estimated speed when real-time auto-tuning is enabled. Higher settings result in faster responses to changes in load characteristics, but they also increase variations in disturbance estimation. Estimation results are saved in EEPROM every 30 minutes regardless of the load characteristic estimated speed setting. When automatic vibration detection is enabled from Set-up Support Software (PANATERM ver.7) , this setting will be ignored and the setting value will be set to 3.															
<table><tr><th>Setup value</th><th>Mode</th><th>Description</th></tr><tr><td>0</td><td>Does not change</td><td>Stops load characteristics estimation.</td></tr><tr><td>1</td><td>Changes very little</td><td>Estimates changes in load characteristics in minutes.</td></tr><tr><td>2</td><td>Changes slowly</td><td>Estimates changes in load characteristics in seconds.</td></tr><tr><td>3</td><td>Changes precipitously</td><td>Fastest estimation of changes in load characteristics.</td></tr></table>							Setup value	Mode	Description	0	Does not change	Stops load characteristics estimation.	1	Changes very little	Estimates changes in load characteristics in minutes.	2	Changes slowly	Estimates changes in load characteristics in seconds.	3	Changes precipitously	Fastest estimation of changes in load characteristics.
Setup value	Mode	Description																			
0	Does not change	Stops load characteristics estimation.																			
1	Changes very little	Estimates changes in load characteristics in minutes.																			
2	Changes slowly	Estimates changes in load characteristics in seconds.																			
3	Changes precipitously	Fastest estimation of changes in load characteristics.																			
6	32	B	Real time auto tuning custom setup	-32768 to 32767	—	Cannot be used with two-degree-of-freedom control mode for synchronization type. Use with the setup value at 0.															

*1 For attributes, see [“7.1 List of Parameters”](#) .

4.1.2.4.2 Parameters to Switch the Parameters Used by This Function to Minas A6 Series-Compatible Specification

In real-time auto tuning, the parameters used in real-time auto tuning can be switched to MINAS A6 Series-compatible specification parameters by setting Pr2.45 “Function expansion setup 10” .

- Parameters related to stiffness, unbalanced load and friction compensation and tuning filters
- Calculation method when updating torque filter time constant and some parameters for load fluctuation compensation (Pr6.73 “Load estimation filter” and Pr6.76 “Load estimation count”)

Item	Parameters for switching to MINAS A6 Series-compatible specification	Initial value (*1)
Stiffness	Can be changed with Pr2.45 “Function expansion setup 10” :bit 5 to 4 “Stiffness setting resolution, individual FB/FF setting switching” .	bits 5 to 4 = 11b
Unbalanced load/friction compensation	Can be changed with Pr2.45 “Function expansion setup 10” :bit 2 “Friction torque compensation parameter selection” .	bit 2 = 1
Tuning filter	Can be changed with Pr2.38 “Filter function switching” :bit 1 “Tuning filter 2” .	bit 1 = 1
Torque filter time constant	Determined by the value of Pr2.45 “Function expansion setup 10” :bit 1 to 0 “Two-degree-of-freedom control function setting” .	bits 1 to 0 = 01b
Load fluctuation compensation	Determined by the value of Pr2.45 “Function expansion setup 10” :bit 3 “Load fluctuation suppression function automatic calculation” .	bit 3 = 1

*1 Normally used with initial values.

—: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	38	B	Filter function switching	-32768 to 32767	—	Select a tuning filter. Normally, set to bit 1 = 1. bit 1: Tuning filter 2 0: Use Pr6.48 "Tuning filter" (MINAS A6 Series-compatible specification) 1: Use Pr2.46 "Tuning filter 2" (MINAS A7 Series specification)
2	45	B	Function expansion setup 10	-2147483648 to 2147483647	—	Sets various functions. bit 1 to 0: Two-degree-of-freedom control function setting bit 2: Friction torque compensation parameter selection bit 3: Load fluctuation suppression function automatic calculation bit 5 to 4: Stiffness setting resolution, individual FB/FF setting switching bit 31 to 6: Unused

*1 For attributes, see "7.1 List of Parameters".

■ Details on Pr2.45 "Function expansion setup 10"

—: N/A

bit	Name	Description	Initial value
1 to 0	Two-degree-of-freedom control function setting	00b: Two-degree-of-freedom control (MINAS A6 Series-compatible specification) 01b: Two-degree-of-freedom control (MINAS A7 Series specification) 10b: Manufacturer use 11b: Manufacturer use	01b
2	Friction torque compensation parameter selection	0: MINAS A6 Series-compatible specification settings Unbalanced load compensation value: Use Pr6.07 Dynamic friction compensation value: Use Pr6.08, Pr6.09 1: MINAS A7 Series specification settings Unbalanced load compensation value: Use Pr2.52 Dynamic friction compensation value: Use Pr2.53, Pr2.54	1
3	Load fluctuation suppression function automatic calculation	0: Conventional setting (MINAS A6 Series specification) 1: The following parameters are automatically calculated. Pr6.73 "Load estimation filter" Pr6.76 "Load estimation count"	1
5 to 4	Stiffness setting resolution, individual FB/FF setting switching	00b: 32 stiffness settings, FB/FF common setting (MINAS A6 Series-compatible specification) Use Pr0.03 01b: Same as 00b 10b: 45 stiffness settings, FB/FF common setting (MINAS A7 Series specification) Use Pr0.27 11b: 45 stiffness settings, individual FB/FF settings (MINAS A7 Series specification) Use Pr0.27 and Pr0.28	11b
31 to 6	Not used	—	—

4.1.2.4.3 Parameters Changed By This Function

■ Parameters updated using estimated values for load characteristics

Real-time auto tuning updates the parameters in the table below using the estimated value for load characteristics based on the Pr0.02 “Real-time auto-gain tuning setup” setting.

Target parameter (*1)		Conditions for update
Pr2.45:bit 2 = 1	Pr2.45:bit 2 = 0	
Pr0.04 “Inertia ratio”		When in synchronous mode (Pr0.02 = 1), synchronous friction compensation mode (Pr0.02 = 2), or load characteristics update mode (Pr0.02 = 4). However, in load fluctuation support mode (Pr0.02 = 6), the value is fixed at 100.
Pr2.52 “Torque command additional value 2”	Pr6.07 “Torque command additional value”	When in synchronous friction compensation mode (Pr0.02 = 2) or load characteristics update mode (Pr0.02 = 4)
Pr2.53 “Positive direction torque compensation value 2”	Pr6.08 “Positive direction torque compensation value”	
Pr2.54 “Negative direction torque compensation value 2”	Pr6.09 “Negative direction torque compensation value”	
Pr6.50 “Viscous friction compensating gain”		

*1 Change the parameters to be used depending on Pr2.45 “Function expansion setup 10” and bit 2 “Friction torque compensation parameter selection” set values. The initial setting is Pr2.45:bit 2 = 1.

■ Basic gain setting parameters updated according to machine stiffness settings

Real-time auto tuning updates the basic gain setting parameters according to the parameter settings below. For details, see [“4.1.2.6 Basic Gain Parameter Setup Table”](#).

- Pr0.03 “Real-time auto-tuning machine stiffness setup”
- Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2”

Notes

- Change the parameters to be used depending on the values set in Pr2.45 “Function expansion setup 10” :bit 5 to 4 “Stiffness setting resolution, individual FB/FF setting switching”. The initial value is Pr2.45: bits 5 to 4 = 11b.
 - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
 - Pr2.45: bits 5 to 4 = 10b : Pr0.27
 - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28
 Pr0.28 is disabled.

Basic gain setting

Target parameter	Conditions for update according to stiffness
Pr1.00 “1st gain of position loop” Pr1.01 “1st velocity loop gain” Pr1.02 “1st velocity loop integration time constant” Pr1.04 “1st torque filter time constant” Pr1.05 “2nd gain of position loop” Pr1.06 “2nd velocity loop gain” Pr1.07 “2nd velocity loop integration time constant” Pr1.09 “2nd torque filter time constant”	<ul style="list-style-type: none"> • When in synchronous mode, synchronous friction compensation mode, stiffness setting mode, or load fluctuation support mode (Pr0.02 = 1 to 3, or 6)

Target parameter	Conditions for update according to stiffness
Pr2.46 "Tuning filter 2"	<ul style="list-style-type: none"> Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2" = 1 (enabled) When in synchronous mode, synchronous friction compensation mode, stiffness setting mode, or load fluctuation support mode (Pr0.02 = 1 to 3, or 6)
Pr6.48 "Tuning filter"	<ul style="list-style-type: none"> Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2" = 0 (disabled) When in synchronous mode, synchronous friction compensation mode, stiffness setting mode, or load fluctuation support mode (Pr0.02 = 1 to 3, or 6)
Pr6.49 "Command response/tuning filter attenuation term"	<ul style="list-style-type: none"> Set the tens place to 1 and keep the ones place unchanged when in synchronous mode, synchronous friction compensation mode, stiffness setting mode, or load fluctuation support mode (Pr0.02 = 1 to 3, or 6).

■ Parameters set according to Pr0.02 "Real-time auto-gain tuning setup" settings

Real-time auto tuning sets the following parameters according to the Pr0.02 "Real-time auto-gain tuning setup" settings.

Target parameter	Values to set when in synchronous mode, synchronous friction compensation mode, stiffness setting mode, or load fluctuation support mode (Pr0.02 = 1 to 3, or 6)
Pr1.03 "1st filter of velocity detection"	Set to 0
Pr1.08 "2nd filter of velocity detection"	Set to 0
Pr1.10 "Velocity feed forward gain"	Set to 1000 (100%)
Pr1.11 "Velocity feed forward filter"	Set to 0 (disabled)
Pr1.12 "Torque feed forward gain"	Set to 1000 (100%)
Pr1.13 "Torque feed forward filter"	Set to 0 (disabled)
Pr1.14 "2nd gain setup"	Set to 1
Pr1.15 "Mode of position control switching"	Set to 0
Pr1.16 "Delay time of position control switching"	Set to 10 (1.0 ms).
Pr1.17 "Level of position control switching"	Set to 0
Pr1.18 "Hysteresis at position control switching"	Set to 0
Pr1.19 "Position gain switching time"	Set to 10 (1.0 ms).
Pr1.20 "Mode of velocity control switching"	Set to 0
Pr1.21 "Delay time of velocity control switching"	Set to 0
Pr1.22 "Level of velocity control switching"	Set to 0
Pr1.23 "Hysteresis at velocity control switching"	Set to 0
Pr1.24 "Mode of torque control switching"	Set to 0
Pr1.25 "Delay time of torque control switching"	Set to 0
Pr1.26 "Level of torque control switching"	Set to 0
Pr1.27 "Hysteresis at torque control switching"	Set to 0
Pr6.10 "Function expansion setup"	Set bit 4 "Current response improvement" to 1 (enabled)

■ Parameters set based on Load fluctuation suppression function automatic tuning

When Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4, set the following parameters according to Pr6.10 "Function expansion setup" :bit 14 "Load fluctuation suppression function automatic tuning" .

Target parameter	Condition	Value to be set	
		Pr6.10:bit 14 = 1	Pr6.10:bit 14 = 0
Pr6.10 “Function expansion setup”	When stiffness setup is enabled	bit 1 “Load fluctuation control function” = 1 (enabled)	bit 1 “Load fluctuation control function” = 0 (disabled)
Pr6.23 “Load change compensation gain”	When stiffness setup is enabled	Set to 90 (90%)	Set to 0
Pr6.24 “Load change compensation filter”	When stiffness setup is enabled	Updates to set value according to stiffness	Retain value
Pr6.73 “Load estimation filter”	When stiffness setup is enabled and Pr2.45 “Function expansion setup 10” :bit 3 = 0	Set to 13	Set to 0
	When stiffness setup is enabled and Pr2.45 “Function expansion setup 10” :bit 3 = 1	Set automatically	
Pr6.74 “Torque compensation frequency 1”	Set to 0 regardless of the value of Pr6.10:bit 14.		
Pr6.75 “Torque compensation frequency 2”	Set to 0 regardless of the value of Pr6.10:bit 14.		
Pr6.76 “Load estimation count”	When stiffness setup is enabled and Pr2.45 “Function expansion setup 10” :bit 3 = 0	Set to 4	Set to 0
	When stiffness setup is enabled and Pr2.45 “Function expansion setup 10” :bit 3 = 1	Automatically set according to stiffness	

When Pr0.02 "Real-time auto-gain tuning setup" is set to 6 (load fluctuation support mode), the settings change to those shown in the table below.

Target parameter	Value to be set
Pr6.10 "Function expansion setup"	The load fluctuation control function is always enabled (bit 1 = 1, bit 2 = 1)
Pr6.23 "Load change compensation gain"	Set to 100%
Pr6.24 "Load change compensation filter"	Updates to set value according to stiffness
Pr6.73 "Load estimation filter"	Set to 13 (0.13 ms).
Pr6.74 "Torque compensation frequency 1"	Updates to set value according to stiffness
Pr6.75 "Torque compensation frequency 2"	Updates to set value according to stiffness
Pr6.76 "Load estimation count"	Set to 4

4.1.2.5 How to Use

- When Pr0.02 "Real-time auto-gain tuning setup" is set to 1 to 3 or 6, real-time auto tuning is enabled. The parameter values used for tuning are automatically set according to the parameter settings below.
 - Pr0.03 "Real-time auto-tuning machine stiffness setup"
 - Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
 - Pr6.10 "Function expansion setup" :bit 14 "Load fluctuation suppression function automatic tuning"
- Input the operation command after approximately 100 ms have elapsed since servo-on.
- Pr0.04 "Inertia ratio" changes when load characteristics estimation is complete. Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" also change depending on the mode setting (see *"Supplement"*).
- Increasing the set value of either of the following parameters will increase motor responsiveness. While checking the positioning settling time and vibration state, increase the setup values by increments of 1 and tune to the optimal values.
 - Pr0.03 "Real-time auto-tuning machine stiffness setup"

- Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2”
- Setting Pr0.02 “Real-time auto-gain tuning setup” to 0 disables real-time auto tuning. Automatic estimation of Pr0.04 “Inertia ratio” stops, but the inertia ratio value at the time of estimation stopping is retained. If the value of the inertia ratio is clearly abnormal, set a reasonable value manually.

Notes

- Pr2.52, Pr2.53 and Pr2.54

Change the parameters to be used depending on the values set in Pr2.45 “Function expansion setup 10” :bit 2 “Friction torque compensation parameter selection” . The initial value is Pr2.45: bit 2 = 1.

- Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
 - Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
 - Change the parameters to be used depending on the values set in Pr2.45 “Function expansion setup 10” :bit 5 to 4 “Stiffness setting resolution, individual FB/FF setting switching” . The initial value is Pr2.45: bits 5 to 4 = 11b.
 - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
 - Pr2.45: bits 5 to 4 = 10b : Pr0.27
 - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28
- Pr0.28 is disabled.

— Precautions —

- When real-time auto tuning is enabled, the response to estimated values after power-up to completion of load characteristic estimation may be faster regardless of the set value for Pr6.31 “Real time auto tuning estimation speed” .
- Immediately after power-up, there is not enough operation data effective for load characteristic estimation, meaning estimated values may be abnormal and operation instable due to disturbance, etc. Once tuning is finished, we recommended that real-time auto tuning is set to disabled (Pr0.02 “Real-time auto-gain tuning setup” = 0).
- Until load characteristic estimation results stabilize, abnormal noise or oscillation may occur.
For example, if abnormal noise or oscillation occurs immediately after the first servo-on after activation or when the Pr0.03 “Real-time auto-tuning machine stiffness setup” set value is increased, it is not abnormal for the operation to stabilize immediately. After abnormal noise or oscillation occurs ,Pr0.04 “Inertia ratio” , Pr2.52 “Torque command additional value 2” , Pr2.53 “Positive direction torque compensation value 2” , or Pr2.54 “Negative direction torque compensation value 2” may change to extreme values. Take the following measures. The following measures should also be taken if abnormal noise or oscillation occurs frequently.
 - 1 Lower the set value for Pr0.03 “Real-time auto-tuning machine stiffness setup” or Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2” .
 - 2 Set Pr0.02 “Real-time auto-gain tuning setup” to 0 to disable real-time auto tuning.
 - 3 Set Pr0.04 “Inertia ratio” to the value calculated on the device and set Pr2.52 “Torque command additional value 2” , Pr2.53 “Positive direction torque compensation value 2” , and Pr2.54 “Negative direction torque compensation value 2” to 0 (see “Supplement”).
 - 4 After setting Pr6.10 “Function expansion setup” :bit 14 = 0, set bit 1 = 0 to disable the load fluctuation control function.
- The Pr0.04 “Inertia ratio” , Pr2.52 “Torque command additional value 2” , Pr2.53 “Positive direction torque compensation value 2” , and Pr2.54 “Negative direction torque compensation value 2” (see “Supplement”) values, which are the results of real-time auto gain tuning, are automatically written to and saved in EEPROM every 30 minutes. When power is restored, auto tuning is performed using the saved EEPROM values as the initial values. If turning OFF the power without 30 minutes having

elapsed since values were automatically saved in EEPROM, manually write the latest real-time auto gain tuning results to EEPROM before turning OFF the power.

- Since control gain is updated when the motor stops, changes to Pr0.03 “Real-time auto-tuning machine stiffness setup” or Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2” settings are not reflected if the motor does not stop (if the gain is extremely low or if a command is continuously given in one direction).

Before changing any of the above parameters related to stiffness setup, stop the motor once to make sure that the stiffness setup has been reflected. Depending on the stiffness setup reflected after the motor is stopped, abnormal noise or oscillation may occur.

- In torque control of two-degree-of-freedom control mode, when real-time auto tuning is enabled, torque feedforward is disabled (equivalent to Pr1.12 = 0) regardless of the Pr1.12 “Torque feed forward gain” set value. Operation continues with torque feedforward disabled until the next operation is performed.
 - Set Pr1.12 “Torque feed forward gain” to a value other than the current parameter (1000) after switching real-time auto tuning from enabled to disabled.
- The following are linked in the Set-up Support Software (PANATERM ver.7) Manual TUNING screen.
 - Feedback gain setting: Pr0.03 “Real-time auto-tuning machine stiffness setup” or Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2”

Notes

- Pr2.52, Pr2.53 and Pr2.54

Change the parameters to be used depending on the values set in Pr2.45 “Function expansion setup 10” :bit 2 “Friction torque compensation parameter selection” . The initial value is Pr2.45: bit 2 = 1.

- Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
 - Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
 - Change the parameters to be used depending on the values set in Pr2.45 “Function expansion setup 10” :bit 5 to 4 “Stiffness setting resolution, individual FB/FF setting switching” . The initial value is Pr2.45: bits 5 to 4 = 11b.
 - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
 - Pr2.45: bits 5 to 4 = 10b : Pr0.27
 - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28
- Pr0.28 is disabled.

4.1.2.6 Basic Gain Parameter Setup Table

—: None

Stiffness		1st gain/2nd gain				Tuning filter	For load fluctuation control function	Only in load fluctuation support mode (Pr0.02 = 6)			
Pr0.03 (*1)	Pr0.27 (*1)	Pr1.00 Pr1.05	Pr1.01 Pr1.06	Pr1.02 Pr1.07	Pr1.04 Pr1.09 (*2)	Pr6.48 (*3)	Pr6.24	Pr1.00 Pr1.05	Pr6.24	Pr6.74	Pr6.75
		Position [0.1 s ⁻¹]	Speed [0.1 Hz]	Speed integration [0.1 ms]	Torque [0.01 ms]	Time constant [0.1 ms]	Load change compensation filter [0.01 ms]	Load fluctuation position loop gain [0.1 s ⁻¹]	Load change compensation filter [0.01 ms]	Torque compensation frequency L [0.1 Hz]	Torque compensation frequency H [0.1 Hz]
0	0	20	15	3700	1500	155	2500	15	1330	25	10
1	1	25	20	2800	1100	115	2500	20	990	34	10
2	2	30	25	2200	900	94	2500	25	800	42	12
3	3	40	30	1900	800	84	2500	30	660	51	15
4	4	45	35	1600	600	64	2500	35	570	59	17
5	5	55	45	1200	500	54	2500	45	440	76	22
6	6	75	60	900	400	44	2500	60	330	104	30
7	7	95	75	700	300	34	2120	75	270	129	37
8	8	115	90	600	300	34	1770	90	220	153	44
9	9	140	110	500	200	24	1450	110	180	184	53
10	10	175	140	400	200	23	1140	140	140	231	66
—	11	250	160	350	163	19	1000	160	120	264	75
11	12	320	180	310	126	16	880	180	110	290	83
—	13	355	200	280	114	14	795	200	100	322	92
12	14	390	220	250	103	13	720	220	90	346	99
—	15	435	245	225	93	12	650	245	80	385	110
13	16	480	270	210	84	11	590	270	70	413	118
—	17	535	300	190	74	10	535	300	65	458	131
14	18	630	350	160	65	9	450	350	60	512	146
15	19	720	400	140	57	8	400	400	50	570	163
—	20	810	450	125	51	7	355	450	45	641	183
16	21	900	500	120	45	7	320	500	40	678	194
—	22	990	550	110	41	6	290	550	40	678	194
17	23	1080	600	110	38	6	270	600	40	678	194
—	24	1170	650	105	35	5	250	650	40	678	194
—	25	1260	700	100	32	5	235	700	40	678	194
18	26	1350	750	90	30	5	210	750	40	678	194
—	27	1490	825	85	27	5	190	825	40	678	194
19	28	1620	900	80	25	5	180	900	40	678	194
—	29	1850	1025	70	22	4	160	1025	40	678	194
20	30	2060	1150	70	20	4	140	1150	40	678	194

Stiffness		1st gain/2nd gain				Tuning filter	For load fluctuation control function	Only in load fluctuation support mode (Pr0.02 = 6)			
Pr0.03 (*1)	Pr0.27 (*1)	Pr1.00 Pr1.05	Pr1.01 Pr1.06	Pr1.02 Pr1.07	Pr1.04 Pr1.09 (*2)	Pr6.48 (*3)	Pr6.24	Pr1.00 Pr1.05	Pr6.24	Pr6.74	Pr6.75
		Position [0.1 s ⁻¹]	Speed [0.1 Hz]	Speed integration [0.1 ms]	Torque [0.01 ms]	Time constant [0.1 ms]	Load change compensation filter [0.01 ms]	Load fluctuation position loop gain [0.1 s ⁻¹]	Load change compensation filter [0.01 ms]	Torque compensation frequency L [0.1 Hz]	Torque compensation frequency H [0.1 Hz]
—	31	2260	1260	65	18	4	130	1260	40	678	194
21	32	2510	1400	60	16	4	110	1400	40	678	194
—	33	2780	1550	55	14	3	100	1550	40	678	194
22	34	3050	1700	50	13	3	90	1700	40	678	194
—	35	3410	1900	45	12	3	80	1900	40	678	194
23	36	3770	2100	40	11	3	80	2100	40	678	194
24	37	4490	2500	40	9	3	60	2500	40	678	194
25	38	5000	2800	35	8	2	60	2800	40	678	194
26	39	5600	3100	30	7	2	50	3100	40	678	194
27	40	6100	3400	30	7	2	50	3400	40	678	194
28	41	6600	3700	25	6	2	40	3700	40	678	194
29	42	7200	4000	25	6	2	40	4000	40	678	194
30	43	8100	4500	20	5	2	40	4500	40	678	194
31	44	9000	5000	20	5	2	40	5000	40	678	194

*1 Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching" . The initial value is Pr2.45: bits 5 to 4 = 11b.

- Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
- Pr2.45: bits 5 to 4 = 10b : Pr0.27
- Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

Pr0.28 is disabled for synchronization type.

*2 The values in the table are used only when Pr2.45 "Function expansion setup 10" :bit 1 to 0 = 0.

*3 Pr6.48 "Tuning filter" may be +1 depending on the combination of servo driver and motor. Also, Pr6.48 is not used because Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2" =1 (enabled) in the initial settings. The Pr2.46 "Tuning filter 2" value is set automatically when real-time auto tuning is enabled.

4.1.3 Real-time Auto Tuning (Two-degree-of-freedom Control Mode Disabled Type)

4.1.3.1 Function Overview

This is a type of real-time auto tuning function without two-degree-of-freedom control. Set Pr6.47 “Function expansion setup 2” :bit 0 “Two-degree-of-freedom control mode” = 0 (disabled) to set this type.

4.1.3.2 Operation Mode

In real-time auto tuning (two-degree-of-freedom control mode disabled type), the operation mode can be changed according to Pr0.02 “Real-time auto-gain tuning setup” . In each operation mode, automatic inertia ratio updates, basic gain setting, unbalanced load compensation, and friction compensation can be enabled or disabled. Also, when Pr0.02 = 7, automatic inertia ratio updates, basic gain setting, unbalanced load compensation, and friction compensation can be enabled or disabled individually. Select Pr0.02 = 7 (set value 7) to optimize each function according to device characteristics.

Details on Pr0.02 “Real-time auto-gain tuning setup”

Setup value	Operation mode	Description
0	Disabled	The real-time auto tuning function is disabled.
1	Standard	This is a mode with an emphasis on stability. Unbalanced load compensation and friction compensation are not performed, and gain switching is not used.
2	Positioning	This is a positioning-focused mode. Use for devices such as low-friction ball screw driven devices that do not have unbalanced load on the horizontal axis. In terms of speed control and torque control, this mode is the same as standard mode.
3	Vertical axis	In addition to positioning mode, this mode suppresses variation in positioning settling time using unbalanced load compensation, such as a vertical axis. In terms of torque control, this mode is the same as standard mode.
4	Friction compensation	In addition to the vertical axis mode, this mode shortens the positioning settling time with a belt mechanical shaft with high friction, etc. In terms of speed control, this mode is the same as vertical axis mode. In terms of torque control, this mode is the same as standard mode.
5	Load characteristic measurement	The basic gain setting and friction compensation setting are not changed, only load characteristic estimation is performed. Used in combination with Set-up Support Software (PANATERM ver.7) .
6	Customize 1	Although two-degree-of-freedom control mode disabled type has the same function as Customize 2 (Pr0.02 = 7), the change ratio cannot be set for the basic gain setting.
7	Customize 2	The combination of real-time auto tuning functions can be customized for each application by configuring advanced settings in Pr6.32 “Real time auto tuning custom setup” . A change ratio can be set for the basic gain setting. Some functions are not available depending on the control mode. See “Details on Pr6.32 “Real time auto tuning custom setup” ” .

4.1.3.3 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Position control, speed control, and full-closed control Pr6.47:bit 0 = 0 (disabled)

Real-time auto tuning may not work normally under the following conditions. In such cases, change the load conditions, operation pattern, or refer to the manual TUNING function description and manually set the related parameters.

Item	Conditions that obstruct the operation of real-time auto tuning
Load	<ul style="list-style-type: none"> When load inertia is small or large compared to the rotor inertia of the servo motor (less than 3× or 20× or more) When load inertia fluctuates When machine stiffness is extremely low When non-linear characteristics exist, such as looseness due to backlash
Operation patterns	<ul style="list-style-type: none"> When used continuously at low speeds of less than 100 r/min When acceleration and deceleration are gentle, less than 2000 r/min in 1 s When the speed is more than 100 r/min and the acceleration and deceleration condition of more than 2000 r/min in 1 s does not continue for more than 50 ms <p>Example of an operation pattern that obstructs function operation</p> <p>When the acceleration and deceleration torque is small compared to the unbalanced load and viscous friction torque</p>

4.1.3.4 Related Parameters

4.1.3.4.1 Parameters That Control the Operation of This Function

—: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
0	02	B	Real-time auto-gain tuning setup	0 to 7	—	Sets the real-time auto tuning operation mode.
0	03	B	Real-time auto-tuning machine stiffness setup	0 to 31	—	<p>Sets responsiveness when real-time auto tuning is enabled. Higher settings result in higher speed responsiveness and servo stiffness, but make it more likely that vibration will occur. Values should be changed from low to high with a close eye on operation.</p> <p>Enabled with Pr2.45 "Function expansion setup 10" : bit 5 = 0 (32 stiffness settings).</p>
0	27	B	Selection of machine stiffness at real-time auto-gain tuning 2	0 to 44	—	<p>Sets responsiveness when real-time auto tuning is enabled. Higher settings result in higher speed responsiveness and servo stiffness, but make it more likely that vibration will occur. Values should be changed from low to high with a close eye on operation.</p> <p>Allows finer gain adjustment than Pr0.03.</p> <p>Enabled with Pr2.45 "Function expansion setup 10" : bit 5 = 1 (45 stiffness settings).</p>
0	28	B	Selection of feed forward stiffness at real-time auto-gain tuning	0 to 44	—	Cannot be used when two-degree-of-freedom control mode is disabled.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function																																			
2	74	A	Tuning auto tuning application selection	-32768 to 32767	—	For Pr0.02 = 7 (Customize 2), any change ratio can be set for the basic gain setting to fit the application when the set value = 3. 0: Positioning 3: Customize																																			
6	10	B	Function expansion setup	-32768 to 32767	—	bit 14: Load fluctuation suppression function automatic tuning 0: Disabled 1: Enabled																																			
6	31	B	Real time auto tuning estimation speed	0 to 3	—	Sets load characteristics estimated speed when real-time auto-tuning is enabled. Higher settings result in faster responses to changes in load characteristics, but they also increase variations in disturbance estimation. Estimation results are saved in EEPROM every 30 minutes regardless of the load characteristic estimated speed setting. When automatic vibration detection is enabled from Set-up Support Software (PANATERM ver.7) , this setting will be ignored and the setting value will be set to 3.																																			
<table><tr><td></td><td>Setup value</td><td>Mode</td><td colspan="4">Description</td></tr><tr><td></td><td>0</td><td>Does not change</td><td colspan="4">Stops load characteristics estimation.</td></tr><tr><td></td><td>1</td><td>Changes very little</td><td colspan="4">Estimates changes in load characteristics in minutes.</td></tr><tr><td></td><td>2</td><td>Changes slowly</td><td colspan="4">Estimates changes in load characteristics in seconds.</td></tr><tr><td></td><td>3</td><td>Changes precipitously</td><td colspan="4">Fastest estimation of changes in load characteristics.</td></tr></table>								Setup value	Mode	Description					0	Does not change	Stops load characteristics estimation.					1	Changes very little	Estimates changes in load characteristics in minutes.					2	Changes slowly	Estimates changes in load characteristics in seconds.					3	Changes precipitously	Fastest estimation of changes in load characteristics.			
	Setup value	Mode	Description																																						
	0	Does not change	Stops load characteristics estimation.																																						
	1	Changes very little	Estimates changes in load characteristics in minutes.																																						
	2	Changes slowly	Estimates changes in load characteristics in seconds.																																						
	3	Changes precipitously	Fastest estimation of changes in load characteristics.																																						
6	32	B	Real time auto tuning custom setup	-32768 to 32767	—	Makes advanced settings for the automatic adjustment function when the Pr0.02 = 7 (Customize 2) is selected as an operation mode for real-time auto tuning.																																			

*1 For attributes, see “7.1 List of Parameters”.

■ Details on Pr6.32 “Real time auto tuning custom setup”

bit	Mode	Description
1 to 0	Load characteristics estimation	Set to enable or disable the load characteristics estimation function. 0: Disabled 1: Enabled <div> — Precautions — <ul style="list-style-type: none"> When this setting is disabled, the target parameters are not updated from the current settings even if bit 3 to 2 “Inertia Ratio Update” , bit 6 to 4 “Torque compensation” , and bit 15 to 12 “Individual torque compensation settings” are set to enable updates. To enable load characteristic estimation, set Pr6.31 “Real time auto tuning estimation speed” to a value other than 0 (no change). </div>
3 to 2	Inertia ratio update	Set updates in load characteristic estimation results for Pr0.04 “Inertia ratio” . 0: Disabled 1: Enabled <div> — Precautions — <ul style="list-style-type: none"> To enable inertia ratio updates, set bit 1 to 0 “Load characteristics estimation” to 1 (enabled). If both are not enabled, the inertia ratio will not be updated. </div>

bit	Mode	Description																					
6 to 4	Torque compensation (*1)	Set updates in load characteristic estimation results for Pr2.52 "Torque command additional value 2" , Pr2.53 "Positive direction torque compensation value 2" , Pr2.54 "Negative direction torque compensation value 2" and Pr6.50 "Viscous friction compensating gain" .																					
		<table><tr><th>Setup value</th><th>Mode</th><th>Description</th></tr><tr><td>0</td><td>Use current settings</td><td>Uses current settings.</td></tr><tr><td>1</td><td>Disable torque compensation</td><td>Clear Pr2.52, Pr2.53, Pr2.54, and Pr6.50 to 0.</td></tr><tr><td>2</td><td>Vertical axis mode</td><td>Update Pr2.52 and clear Pr2.53, Pr2.54 and Pr6.50 to 0.</td></tr><tr><td>3</td><td>Friction compensation (weak)</td><td>Update Pr2.52 and set weak compensation for Pr2.53, Pr2.54, and Pr6.50.</td></tr><tr><td>4</td><td>Friction compensation (medium)</td><td>Update Pr2.52 and set medium compensation for Pr2.53, Pr2.54, and Pr6.50.</td></tr><tr><td>5</td><td>Friction compensation (strong)</td><td>Update Pr2.52 and set strong compensation for Pr2.53, Pr2.54 and Pr6.50.</td></tr></table>	Setup value	Mode	Description	0	Use current settings	Uses current settings.	1	Disable torque compensation	Clear Pr2.52, Pr2.53, Pr2.54, and Pr6.50 to 0.	2	Vertical axis mode	Update Pr2.52 and clear Pr2.53, Pr2.54 and Pr6.50 to 0.	3	Friction compensation (weak)	Update Pr2.52 and set weak compensation for Pr2.53, Pr2.54, and Pr6.50.	4	Friction compensation (medium)	Update Pr2.52 and set medium compensation for Pr2.53, Pr2.54, and Pr6.50.	5	Friction compensation (strong)	Update Pr2.52 and set strong compensation for Pr2.53, Pr2.54 and Pr6.50.
		Setup value	Mode	Description																			
		0	Use current settings	Uses current settings.																			
		1	Disable torque compensation	Clear Pr2.52, Pr2.53, Pr2.54, and Pr6.50 to 0.																			
		2	Vertical axis mode	Update Pr2.52 and clear Pr2.53, Pr2.54 and Pr6.50 to 0.																			
		3	Friction compensation (weak)	Update Pr2.52 and set weak compensation for Pr2.53, Pr2.54, and Pr6.50.																			
		4	Friction compensation (medium)	Update Pr2.52 and set medium compensation for Pr2.53, Pr2.54, and Pr6.50.																			
5	Friction compensation (strong)	Update Pr2.52 and set strong compensation for Pr2.53, Pr2.54 and Pr6.50.																					
<div>— Precautions —</div> <ul style="list-style-type: none">Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection" . The initial value is Pr2.45: bit 2 = 1 .<ul style="list-style-type: none">Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54																							
7	Stiffness setup (*2)	Set to enable or disable the basic gain setting using Pr0.03 "Real-time auto-tuning machine stiffness setup" , Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2" or Pr0.28 "Selection of feed forward stiffness at real-time auto-gain tuning" .																					
		0: Disabled																					
		1: Enabled																					
		<div>— Precautions —</div> <ul style="list-style-type: none">Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching" . The initial value is Pr2.45: bits 5 to 4 = 11b .<ul style="list-style-type: none">Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03Pr2.45: bits 5 to 4 = 10b : Pr0.27Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28 <p>Pr0.28 is disabled.</p>																					
8	Fixed parameter setup (*2)	Set whether or not to change parameters that become fixed values when real-time auto tuning is enabled. For details, see the table " <u>Values Set When Real-Time Auto Tuning is Enabled (Pr0.02 = 1 to 4, 6, 7)</u> " in " <u>4.1.3.4.3 Parameters Changed By This Function</u> " . 0: Use current settings 1: Set to fixed values																					
10 to 9	Gain switching setup (*2)	Select the method for setting parameters related to gain switching when real-time auto tuning is enabled. 0: Use current settings 1: Gain switching disabled 2: Gain switching enabled																					
11	Torque compensation setting switching	Select whether to enable bits 6 to 4 or bits 15 to 12 for torque compensation. 0: Enable bits 6 to 4 1: Enable bits 15 to 12																					

bit	Mode	Description															
15 to 12	Individual torque compensation settings (*1)	<div>Select whether to use or update the current setting for the corresponding parameters when bit 11 “Torque compensation setting switching” = 1.</div> <div>0: Use current settings</div> <div>1: Update</div> <table><tr><td></td><td>bit 15</td><td>bit 14</td><td>bit 13</td><td>bit 12</td></tr><tr><td>When Pr2.45:bit 2 = 1</td><td>Pr6.50</td><td>Pr2.54</td><td>Pr2.53</td><td>Pr2.52</td></tr><tr><td>When Pr2.45:bit 2 = 0</td><td>Pr6.50</td><td>Pr6.09</td><td>Pr6.08</td><td>Pr6.07</td></tr></table>		bit 15	bit 14	bit 13	bit 12	When Pr2.45:bit 2 = 1	Pr6.50	Pr2.54	Pr2.53	Pr2.52	When Pr2.45:bit 2 = 0	Pr6.50	Pr6.09	Pr6.08	Pr6.07
	bit 15	bit 14	bit 13	bit 12													
When Pr2.45:bit 2 = 1	Pr6.50	Pr2.54	Pr2.53	Pr2.52													
When Pr2.45:bit 2 = 0	Pr6.50	Pr6.09	Pr6.08	Pr6.07													

*1 To set to enable updates to torque compensation, set bit 1 to 0 "Load characteristics estimation" and bit 3 to 2 "Inertia Ratio Update" to 1 (enabled). Updates are not applied with update settings for torque compensation only.

*2 To set this set value to a value other than 0, set bit 3 to 2 "Inertia Ratio Update" to 1 (enabled). Whether or not inertia ratio update is enabled at this time can be set with bit 1 to 0 "Load characteristics estimation".

— Precautions —

- These parameters must be set in bit units. Operation cannot be guaranteed with incorrect settings. Using Set-up Support Software (PANATERM ver.7) is recommended for changing parameter setup values.
- Do not change these parameters during motor operation. Actually updating of parameters takes place when the motor stops after the load characteristic measurement results are confirmed.

Notes

- Calculating Pr6.32 set value from values in bit units

When configuring each setting to a value other than 0, use the following procedure to calculate the set value for Pr6.32.

- 1 Confirm the least significant bit for each setting.

(Example) The least significant bit of the torque compensation function is 4

- 2 Multiply 2 to the power of (LSB) by the set value.

(Example) If bit 6 to 4 "Torque compensation" = 3 (friction compensation (weak)), then $2^4 \times 3$.

- 3 For each setting, calculate "1" and "2" and then add them all together to obtain the set value for Pr6.32.

(Example) When load characteristic measurement = enabled, inertia ratio update = enabled, torque compensation = friction compensation (weak), stiffness setting = enabled, fixed parameters = set to fixed values, gain switching setup = enabled

$$2^0 \times 1 + 2^2 \times 1 + 2^4 \times 3 + 2^7 \times 1 + 2^8 \times 1 + 2^9 \times 2 = 1461$$

4.1.3.4.2 Parameters to Switch the Parameters Used by This Function to MINAS A6 Series-Compatible Specification

In real-time auto tuning, the parameters used in real-time auto tuning can be switched to MINAS A6 Series-compatible specification parameters by setting Pr2.45 "Function expansion setup 10".

- Parameters related to stiffness, unbalanced load and friction compensation and tuning filters
- Calculation method when updating torque filter time constant and some parameters for load fluctuation compensation (Pr6.73 "Load estimation filter" and Pr6.76 "Load estimation count")

Item	Parameters for switching to MINAS A6 Series-compatible specification	Initial value ^{(*)1}
Stiffness	Can be changed with Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching".	bits 5 to 4 = 11b

Item	Parameters for switching to MINAS A6 Series-compatible specification	Initial value (*1)
Unbalanced load/friction compensation	Can be changed with Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection" .	bit 2 = 1
Tuning filter	Can be changed with Pr2.38 "Filter function switching" :bit 1 "Tuning filter 2" .	bit 1 = 1
Torque filter time constant	Determined by the value of Pr2.45 "Function expansion setup 10" :bit 1 to 0 "Two-degree-of-freedom control function setting" .	bits 1 to 0 = 01b
Load fluctuation compensation	Determined by the value of Pr2.45 "Function expansion setup 10" :bit 3 "Load fluctuation suppression function automatic calculation" .	bit 3 = 1

*1 Normally used with initial values.

—: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	38	B	Filter function switching	-32768 to 32767	—	Select a tuning filter. Normally, set to bit 1 = 1. bit 1: Tuning filter 2 0: Use Pr6.48 "Tuning filter" (MINAS A6 Series-compatible specification) 1: Use Pr2.46 "Tuning filter 2" (MINAS A7 Series specification)
2	45	B	Function expansion setup 10	-2147483648 to 2147483647	—	Sets various functions. bit 1 to 0: Two-degree-of-freedom control function setting bit 2: Friction torque compensation parameter selection bit 3: Load fluctuation suppression function automatic calculation bit 5 to 4: Stiffness setting resolution, individual FB/FF setting switching bit 31 to 6: Unused

*1 For attributes, see ["7.1 List of Parameters"](#) .

■ Details on Pr2.45 "Function expansion setup 10"

—: N/A

bit	Name	Description	Initial value
1 to 0	Two-degree-of-freedom control function setting	00b: Two-degree-of-freedom control (MINAS A6 Series-compatible specification) 01b: Two-degree-of-freedom control (MINAS A7 Series specification) 10b: Manufacturer use 11b: Manufacturer use	01b
2	Friction torque compensation parameter selection	0: MINAS A6 Series-compatible specification settings Unbalanced load compensation value: Use Pr6.07 Dynamic friction compensation value: Use Pr6.08, Pr6.09 1: MINAS A7 Series specification settings Unbalanced load compensation value: Use Pr2.52 Dynamic friction compensation value: Use Pr2.53, Pr2.54	1
3	Load fluctuation suppression function automatic calculation	0: Conventional setting (MINAS A6 Series specification) 1: The following parameters are automatically calculated. Pr6.73 "Load estimation filter" Pr6.76 "Load estimation count"	1

bit	Name	Description	Initial value
5 to 4	Stiffness setting resolution, individual FB/FF setting switching	00b: 32 stiffness settings, FB/FF common setting (MINAS A6 Series-compatible specification) Use Pr0.03 01b: Same as 00b 10b: 45 stiffness settings, FB/FF common setting (MINAS A7 Series specification) Use Pr0.27 11b: 45 stiffness settings, individual FB/FF settings (MINAS A7 Series specification) Use Pr0.27 and Pr0.28	11b
31 to 6	Not used	—	—

4.1.3.4.3 Parameters Changed By This Function

■ Parameters updated using estimated values for load characteristics

When Pr0.02 “Real-time auto-gain tuning setup” is 1 to 4, real-time auto tuning updates the parameters in the table below using the estimated value for load characteristics.

When Pr0.02 “Real-time auto-gain tuning setup” is 6 or 7, the parameters in the table below are updated using the estimated value for load characteristics estimates based on the contents of Pr6.32 “Real time auto tuning custom setup” .

Target parameter (*1)		Conditions for update
Pr2.45:bit 2 = 1	Pr2.45:bit 2 = 0	
Pr0.04 “Inertia ratio”		When inertia ratio update is enabled (Pr0.02 = 1 to 4, 6, 7)
Pr2.52 “Torque command additional value 2”	Pr6.07 “Torque command additional value”	When vertical axis mode or friction compensation mode is enabled (Pr0.02 = 3, 4, 6, 7)
Pr2.53 “Positive direction torque compensation value 2”	Pr6.08 “Positive direction torque compensation value”	When friction compensation mode is enabled (Pr0.02 = 4, 6, 7)
Pr2.54 “Negative direction torque compensation value 2”	Pr6.09 “Negative direction torque compensation value”	When friction compensation mode is enabled (Pr0.02 = 4, 6, 7)
Pr6.50 “Viscous friction compensating gain”		When Pr0.02 = 6, 7 (customize mode) with viscous friction compensation enabled

*1 Change the parameters to be used depending on Pr2.45 “Function expansion setup 10” and bit 2 “Friction torque compensation parameter selection” set values. The initial setting is Pr2.45:bit 2 = 1.

■ Basic gain setting parameters updated according to machine stiffness settings

Real-time auto tuning updates the basic gain setting parameters according to the parameter settings below when Pr0.02 “Real-time auto-gain tuning setup” is 1 to 4, 6, or 7. For details, see [“4.1.3.6 Basic Gain Parameter Setup Table”](#) .

- Pr0.03 “Real-time auto-tuning machine stiffness setup”
- Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2”

Notes

- Change the parameters to be used depending on the values set in Pr2.45 “Function expansion setup 10” :bit 5 to 4 “Stiffness setting resolution, individual FB/FF setting switching” . The initial value is Pr2.45: bits 5 to 4 = 11b.
 - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
 - Pr2.45: bits 5 to 4 = 10b : Pr0.27
 - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28
- Pr0.28 is disabled.

Basic gain setting

Target parameter	Conditions for update according to stiffness
Pr1.00 "1st gain of position loop" Pr1.01 "1st velocity loop gain" Pr1.02 "1st velocity loop integration time constant" Pr1.04 "1st torque filter time constant" Pr1.05 "2nd gain of position loop" Pr1.06 "2nd velocity loop gain" Pr1.07 "2nd velocity loop integration time constant" Pr1.09 "2nd torque filter time constant"	<ul style="list-style-type: none"> When stiffness setup is enabled (Pr0.02 = 1 to 4, 7)

When Pr0.02 = 7 (Customize 2) and Pr2.74 "Tuning auto tuning application selection" = 3, any change ratio can be set for the values in the Basic Gain Parameter Settings Table.

Target parameter	Basic gain parameter setting in stiffness setup values when gain change ratio is enabled
Pr1.106 "1st position loop gain change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.00 "1st gain of position loop" When this setup value is 0, this is set to 100 %.
Pr1.107 "1st velocity integration change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.02 "1st velocity loop integration time constant" When this setup value is 0, this is set to 100 %.
Pr1.108 "1st torque filter change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.04 "1st torque filter time constant"
Pr1.109 "2nd position loop gain change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.05 "2nd gain of position loop" When this setup value is 0, this is set to 100 %.
Pr1.110 "2nd velocity loop gain change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.06 "2nd velocity loop gain" When this setup value is 0, this is set to 100 %.
Pr1.111 "2nd velocity integration change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.07 "2nd velocity loop integration time constant" When this setup value is 0, this is set to 100 %.
Pr1.112 "2nd torque filter change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr1.09 "2nd torque filter time constant"
Pr1.113 "Load fluctuation compensation filter change ratio"	<ul style="list-style-type: none"> Sets the change ratio for Pr6.24 "Load change compensation filter" (time constant) When this setup value is 0, this is set to 100 %.
Pr1.114 "Smoothing filter change ratio"	<ul style="list-style-type: none"> Cannot be used with two-degree-of-freedom control mode disabled type.
Pr1.115 "Tuning filter change ratio"	<ul style="list-style-type: none"> Cannot be used with two-degree-of-freedom control mode disabled type.

■ Parameters set based on Fixed Parameter Setup

For real-time auto tuning, set the parameters in the table below in any of the following cases.

- When Pr0.02 "Real-time auto-gain tuning setup" is 1 to 4
- When Pr0.02 "Real-time auto-gain tuning setup" is 6 or 7 and Pr6.32 "Real time auto tuning custom setup" :bit 8 "Fixed Parameter Setup" is 1

Target parameter	Value set to (Pr0.02 = 1 to 4, 6, 7) when real-time auto tuning is enabled
Pr1.03 "1st filter of velocity detection"	Set to 0
Pr1.08 "2nd filter of velocity detection"	Set to 0
Pr1.10 "Velocity feed forward gain"	Set to 300
Pr1.11 "Velocity feed forward filter"	Set to 50
Pr1.12 "Torque feed forward gain"	Set to 0
Pr1.13 "Torque feed forward filter"	Set to 0

■ Parameters set based on Gain Switching Setup

For real-time auto tuning, set the parameters in the table below in any of the following cases.

- When Pr0.02 “Real-time auto-gain tuning setup” is 1 to 4
- When Pr0.02 “Real-time auto-gain tuning setup” is 6 or 7 and Pr6.32 “Real time auto tuning custom setup” :bit 10 to 9 “Gain Switching Setup” is 1

Target parameter	Value to be set					
	Pr0.02 = 1	Pr0.02 = 2	Pr0.02 = 3	Pr0.02 = 4	Pr0.02 = 6	Pr0.02 = 7
Pr1.14 “2nd gain setup”	Set to 1					
Pr1.15 “Mode of position control switching”	Set to 0	Set to 10				
Pr1.16 “Delay time of position control switching”	Set to 50 (5 ms).					
Pr1.17 “Level of position control switching”	Set to 50					
Pr1.18 “Hysteresis at position control switching”	Set to 33					
Pr1.19 “Position gain switching time”	Set to 33 (3.3 ms).					
Pr1.20 “Mode of velocity control switching”	Set to 0					
Pr1.21 “Delay time of velocity control switching”	Set to 0					
Pr1.22 “Level of velocity control switching”	Set to 0					
Pr1.23 “Hysteresis at velocity control switching”	Set to 0					
Pr1.24 “Mode of torque control switching”	Set to 0					
Pr1.25 “Delay time of torque control switching”	Set to 0					
Pr1.26 “Level of torque control switching”	Set to 0					
Pr1.27 “Hysteresis at torque control switching”	Set to 0					

■ Parameters set based on Load fluctuation suppression function automatic tuning

When Pr0.02 “Real-time auto-gain tuning setup” is 1 to 4, 6, or 7, set the following parameters according to Pr6.10 “Function expansion setup” :bit 14 “Load fluctuation suppression function automatic tuning” .

Target parameter	Condition	Value to be set	
		Pr6.10:bit 14 = 1	Pr6.10:bit 14 = 0
Pr6.10 “Function expansion setup”	When stiffness setup is enabled	bit 1 “Load fluctuation control function” = 1 (enabled)	bit 1 “Load fluctuation control function” = 0 (disabled)
Pr6.23 “Load change compensation gain”	When stiffness setup is enabled	Set to 90 (90%)	Set to 0
Pr6.24 “Load change compensation filter”	When stiffness setup is enabled	Updates to set value according to stiffness	Retain value
Pr6.73 “Load estimation filter”	When stiffness setup is enabled and Pr2.45 “Function expansion setup 10” :bit 3 = 0	Set to 13	Set to 0
	When stiffness setup is enabled and Pr2.45 “Function expansion setup 10” :bit 3 = 1	Set automatically	
Pr6.74 “Torque compensation frequency 1”	Set to 0 regardless of the value of Pr6.10:bit 14.		
Pr6.75 “Torque compensation frequency 2”	Set to 0 regardless of the value of Pr6.10:bit 14.		
Pr6.76 “Load estimation count”	When stiffness setup is enabled and Pr2.45 “Function expansion setup 10” :bit 3 = 0	Set to 4	Set to 0

Target parameter	Condition	Value to be set	
		Pr6.10:bit 14 = 1	Pr6.10:bit 14 = 0
Pr6.76 "Load estimation count"	When stiffness setup is enabled and Pr2.45 "Function expansion setup 10" :bit 3 = 1	Automatically set according to stiffness	

4.1.3.5 How to Use

- When Pr0.02 "Real-time auto-gain tuning setup" is set to 1 to 4, 6 or 7, real-time auto tuning is enabled. The parameter values used for tuning are automatically set according to the parameter settings below.
 - Pr0.03 "Real-time auto-tuning machine stiffness setup"
 - Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
 - Pr6.10 "Function expansion setup" :bit 14 "Load fluctuation suppression function automatic tuning"
- Input the operation command after approximately 100 ms have elapsed since servo-on.
- Pr0.04 "Inertia ratio" changes when load characteristics estimation is complete. Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" also change depending on the mode setting (see "[Supplement](#)").
- Increasing the set value of either of the following parameters will increase motor responsiveness. While checking the positioning settling time and vibration state, increase the setup values by increments of 1 and tune to the optimal values.
 - Pr0.03 "Real-time auto-tuning machine stiffness setup"
 - Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"
- Setting Pr0.02 "Real-time auto-gain tuning setup" to 0 disables real-time auto tuning. Automatic estimation of Pr0.04 "Inertia ratio" stops, but the inertia ratio value at the time of estimation stopping is retained. If the value of the inertia ratio is clearly abnormal, set a reasonable value manually.

Notes

- Pr2.52, Pr2.53 and Pr2.54
Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection". The initial value is Pr2.45: bit 2 = 1.
 - Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
 - Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.
 - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
 - Pr2.45: bits 5 to 4 = 10b : Pr0.27
 - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28
 Pr0.28 is disabled.

— Precautions —

- When real-time auto tuning is enabled, the response to estimated values after power-up to completion of load characteristic estimation may be faster regardless of the set value for Pr6.31 "Real time auto tuning estimation speed".
- Immediately after power-up, there is not enough operation data effective for load characteristic estimation, meaning estimated values may be abnormal and operation instable due to disturbance, etc. Once tuning is finished, we recommended that real-time auto tuning is set to disabled (Pr0.02 "Real-time auto-gain tuning setup" = 0).

- Until load characteristic estimation results stabilize, abnormal noise or oscillation may occur. For example, if abnormal noise or oscillation occurs immediately after the first servo-on after activation or when the Pr0.03 "Real-time auto-tuning machine stiffness setup" set value is increased, it is not abnormal for the operation to stabilize immediately. After abnormal noise or oscillation occurs, Pr0.04 "Inertia ratio", Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", or Pr2.54 "Negative direction torque compensation value 2" may change to extreme values. Take the following measures. The following measures should also be taken if abnormal noise or oscillation occurs frequently.
 - 1 Lower the set value for Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2".
 - 2 Set Pr0.02 "Real-time auto-gain tuning setup" to 0 to disable real-time auto tuning.
 - 3 Set Pr0.04 "Inertia ratio" to the value calculated on the device and set Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" to 0 (see "Supplement").
 - 4 After setting Pr6.10 "Function expansion setup": bit 14 = 0, set bit 1 = 0 to disable the load fluctuation control function.
- The Pr0.04 "Inertia ratio", Pr2.52 "Torque command additional value 2", Pr2.53 "Positive direction torque compensation value 2", and Pr2.54 "Negative direction torque compensation value 2" (see "Supplement") values, which are the results of real-time auto gain tuning, are automatically written to and saved in EEPROM every 30 minutes. When power is restored, auto tuning is performed using the saved EEPROM values as the initial values. If turning OFF the power without 30 minutes having elapsed since values were automatically saved in EEPROM, manually write the latest real-time auto gain tuning results to EEPROM before turning OFF the power.
- Since control gain is updated when the motor stops, changes to Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2" settings are not reflected if the motor does not stop (if the gain is extremely low or if a command is continuously given in one direction).
Before changing any of the above parameters related to stiffness setup, stop the motor once to make sure that the stiffness setup has been reflected. Depending on the stiffness setup reflected after the motor is stopped, abnormal noise or oscillation may occur.
- The following are linked in the Set-up Support Software (PANATERM ver.7) Manual TUNING screen.
 - Feedback gain setting: Pr0.03 "Real-time auto-tuning machine stiffness setup" or Pr0.27 "Selection of machine stiffness at real-time auto-gain tuning 2"

Notes

- Pr2.52, Pr2.53 and Pr2.54
Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10": bit 2 "Friction torque compensation parameter selection". The initial value is Pr2.45: bit 2 = 1.
 - Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
 - Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
- Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10": bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching". The initial value is Pr2.45: bits 5 to 4 = 11b.
 - Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
 - Pr2.45: bits 5 to 4 = 10b : Pr0.27
 - Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28
 Pr0.28 is disabled.

4.1.3.6 Basic Gain Parameter Setup Table

—: None

Stiffness		1st gain				2nd gain				For load fluctuation control function
Pr0.03 (*1)	Pr0.27 (*1)	Pr1.00	Pr1.01	Pr1.02	Pr1.04 (*2)	Pr1.05	Pr1.06	Pr1.07 (*3)	Pr1.09 (*2)	Pr6.24
		Position [0.1 s ⁻¹]	Speed [0.1 Hz]	Speed integration [0.1 ms]	Torque [0.01 ms]	Position [0.1 s ⁻¹]	Speed [0.1 Hz]	Speed integration [0.1 ms]	Torque [0.01 ms]	Load change compensation filter [0.01 ms]
0	0	20	15	3700	1500	25	15	10000	1500	2500
1	1	25	20	2800	1100	30	20	10000	1100	2500
2	2	30	25	2200	900	40	25	10000	900	2500
3	3	40	30	1900	800	45	30	10000	800	2500
4	4	45	35	1600	600	55	35	10000	600	2500
5	5	55	45	1200	500	70	45	10000	500	2500
6	6	75	60	900	400	95	60	10000	400	2500
7	7	95	75	700	300	120	75	10000	300	2120
8	8	115	90	600	300	140	90	10000	300	1770
9	9	140	110	500	200	175	110	10000	200	1450
10	10	175	140	400	200	220	140	10000	200	1140
—	11	250	160	350	163	300	160	10000	163	1000
11	12	320	180	310	126	380	180	10000	126	880
—	13	355	200	280	114	425	200	10000	114	795
12	14	390	220	250	103	460	220	10000	103	720
—	15	435	245	225	93	515	245	10000	93	650
13	16	480	270	210	84	570	270	10000	84	590
—	17	535	300	190	74	635	300	10000	74	535
14	18	630	350	160	65	730	350	10000	65	450
15	19	720	400	140	57	840	400	10000	57	400
—	20	810	450	125	51	945	450	10000	51	355
16	21	900	500	120	45	1050	500	10000	45	320
—	22	990	550	110	41	1160	550	10000	41	290
17	23	1080	600	110	38	1260	600	10000	38	270
—	24	1170	650	105	35	1370	650	10000	35	250
—	25	1260	700	100	32	1480	700	10000	32	235
18	26	1350	750	90	30	1570	750	10000	30	210
—	27	1490	825	85	27	1730	825	10000	27	190
19	28	1620	900	80	25	1880	900	10000	25	180
—	29	1850	1025	70	22	2150	1025	10000	22	160
20	30	2060	1150	70	20	2410	1150	10000	20	140
—	31	2260	1260	65	18	2640	1260	10000	18	130
21	32	2510	1400	60	16	2930	1400	10000	16	110
—	33	2780	1550	55	14	3250	1550	10000	14	100
22	34	3050	1700	50	13	3560	1700	10000	13	90

Stiffness		1st gain				2nd gain				For load fluctuation control function
Pr0.03 (*1)	Pr0.27 (*1)	Pr1.00	Pr1.01	Pr1.02	Pr1.04 (*2)	Pr1.05	Pr1.06	Pr1.07 (*3)	Pr1.09 (*2)	Pr6.24
		Position [0.1 s ⁻¹]	Speed [0.1 Hz]	Speed integration [0.1 ms]	Torque [0.01 ms]	Position [0.1 s ⁻¹]	Speed [0.1 Hz]	Speed integration [0.1 ms]	Torque [0.01 ms]	Load change compensation filter [0.01 ms]
—	35	3410	1900	45	12	3980	1900	10000	12	80
23	36	3770	2100	40	11	4400	2100	10000	11	80
24	37	4490	2500	40	9	5240	2500	10000	9	60
25	38	5000	2800	35	8	5900	2800	10000	8	60
26	39	5600	3100	30	7	6500	3100	10000	7	50
27	40	6100	3400	30	7	7100	3400	10000	7	50
28	41	6600	3700	25	6	7700	3700	10000	6	40
29	42	7200	4000	25	6	8400	4000	10000	6	40
30	43	8100	4500	20	5	9400	4500	10000	5	40
31	44	9000	5000	20	5	10500	5000	10000	5	40

*1 Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 5 to 4 "Stiffness setting resolution, individual FB/FF setting switching" . The initial value is Pr2.45: bits 5 to 4 = 11b.

- Pr2.45: bits 5 to 4 = 00b, 01b : Pr0.03
- Pr2.45: bits 5 to 4 = 10b : Pr0.27
- Pr2.45: bits 5 to 4 = 11b : Pr0.27, Pr0.28

Pr0.28 is disabled.

*2 The values in the table are used only when Pr2.45 "Function expansion setup 10" :bit 1 to 0 = 0.

*3 For vertical axis mode or friction compensation mode (Pr0.02 "Real-time auto-gain tuning setup" = 3, 4), Pr1.07 "2nd velocity loop integration time constant" is 9999 (retained) until estimation of load characteristics is complete.

4.2 Gain Switching Function

4.2.1 Function Overview

This function optimizes control based on the operating state of the servo driver by changing settings such as applied gain types and setting conditions based on command inputs such as torque commands and speed commands.

Gain switching is expected to have the following effects:

- Reduce gain when stopped (servo lock) to suppress vibration
- Increase the gain when stopped (settling time) to shorten the settling time
- Increase the gain during operation to improve command tracking
- Switch gain using external signal based on the device status

4.2.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> • All control modes

4.2.3 Related Parameters

The parameters that can be switched vary depending on the control mode.

■ Common

—: N/A

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	14	B	2nd gain setup	0 to 1	—	Set when performing optimum tuning using the gain switching function. 0: Disabled (Fixes 1st gain) 1: Enabled (Enables gain switching between 1st gain and 2nd gain)

*1 For attributes, see [“7.1 List of Parameters”](#).

■ Position control mode, full-closed control mode

—: N/A

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	15	B	Mode of position control switching	0 to 10	—	Sets the trigger condition for gain switching during position control and full-closed control. (Setup value): (switching condition) 0: 1st gain fixed 1: 2nd gain fixed 2: RTEX communication gain switching command (Gain_SW) 3: Torque command 4: Disabled (1st gain fixed) 5: Speed command 6: Position deviation 7: With position command 8: Positioning not completed 9: Actual speed 10: With position command + actual speed
1	16	B	Delay time of position control switching	0 to 10000	0.1 ms	Sets the time from trigger detection to actual gain switching when switching from 2nd gain to 1st gain during position control and full-closed control when Pr1.15 "Mode of position control switching" is 3, or 5 to 10.
1	17	B	Level of position control switching	0 to 20000	Depends on the mode	Sets triggering level during position control and full-closed control when Pr1.15 "Mode of position control switching" is 3, 5, 6, 9, or 10. Units vary with switching mode setting. • Set the level equal to or higher than the hysteresis.
1	18	B	Hysteresis at position control switching	0 to 20000	Depends on the mode	Sets triggering hysteresis during position control and full-closed control when Pr1.15 "Mode of position control switching" is 3, 5, 6, 9, or 10. Units vary with switching mode setting. • When the level is less than the hysteresis, the hysteresis is re-set internally so that it is equal to the level.
1	19	B	Position gain switching time	0 to 10000	0.1 ms	Sudden increases in position loop gain can be suppressed during position control and full-closed control if there is a large difference between Pr1.00 "1st gain of position loop" and Pr1.05 "2nd gain of position loop". If the position loop gain increases, gain will change over the set time.

*1 For attributes, see ["7.1 List of Parameters"](#).

The target parameters referred to in the above description in terms of 1st gain and 2nd gain are as follows.

- 1st gain
 - Pr1.00 "1st gain of position loop"
 - Pr1.01 "1st velocity loop gain"
 - Pr1.02 "1st velocity loop integration time constant"
 - Pr1.03 "1st filter of velocity detection"
 - Pr1.04 "1st torque filter time constant"

- 2nd gain
 - Pr1.05 “2nd gain of position loop”
 - Pr1.06 “2nd velocity loop gain”
 - Pr1.07 “2nd velocity loop integration time constant”
 - Pr1.08 “2nd filter of velocity detection”
 - Pr1.09 “2nd torque filter time constant”

■ Speed control modes

—: N/A

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	20	B	Mode of velocity control switching	0 to 5	—	Sets gain switching trigger conditions during velocity control. (Setup value): (switching condition) 0: 1st gain fixed 1: 2nd gain fixed 2: RTEX communication gain switching command (Gain_SW) 3: Torque command 4: Speed command variation 5: Speed command
1	21	B	Delay time of velocity control switching	0 to 10000	0.1 ms	Sets the time from trigger detection to actual gain switching when switching from 2nd gain to 1st gain during velocity control when Pr1.20 “Mode of velocity control switching” is 3 to 5.
1	22	B	Level of velocity control switching	0 to 20000	Depends on the mode	Sets triggering level during velocity control when Pr1.20 “Mode of velocity control switching” is 3 to 5. Units vary with switching mode setting. ● Set the level equal to or higher than the hysteresis.
1	23	B	Hysteresis at velocity control switching	0 to 20000	Depends on the mode	Sets triggering hysteresis during velocity control when Pr1.20 “Mode of velocity control switching” is 3 to 5. Units vary with switching mode setting. ● When the level is less than the hysteresis, the hysteresis is re-set internally so that it is equal to the level.

*1 For attributes, see “7.1 List of Parameters”.

The target parameters referred to in the above description in terms of 1st gain and 2nd gain are as follows.

- 1st gain
 - Pr1.01 “1st velocity loop gain”
 - Pr1.02 “1st velocity loop integration time constant”
 - Pr1.03 “1st filter of velocity detection”
 - Pr1.04 “1st torque filter time constant”
- 2nd gain
 - Pr1.06 “2nd velocity loop gain”
 - Pr1.07 “2nd velocity loop integration time constant”
 - Pr1.08 “2nd filter of velocity detection”
 - Pr1.09 “2nd torque filter time constant”

■ Torque control modes

—: N/A

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	24	B	Mode of torque control switching	0 to 3	—	Sets gain switching trigger conditions during torque control. (Setup value): (switching condition) 0: 1st gain fixed 1: 2nd gain fixed 2: RTEX communication gain switching command (Gain_SW) 3: Torque command
1	25	B	Delay time of torque control switching	0 to 10000	0.1 ms	Sets the time from trigger detection to actual gain switching when switching from 2nd gain to 1st gain during torque control when Pr1.24 "Mode of torque control switching" is 3.
1	26	B	Level of torque control switching	0 to 20000	Depends on the mode	Sets triggering level during torque control when Pr1.24 "Mode of torque control switching" is 3. Units vary with switching mode setting. • Set the level equal to or higher than the hysteresis.
1	27	B	Hysteresis at torque control switching	0 to 20000	Depends on the mode	Sets triggering hysteresis during torque control when Pr1.24 "Mode of torque control switching" is 3. Units vary with switching mode setting. • When the level is less than the hysteresis, the hysteresis is re-set internally so that it is equal to the level.

*1 For attributes, see "7.1 List of Parameters".

The target parameters referred to in the above description in terms of 1st gain and 2nd gain are as follows.

- 1st gain
 - Pr1.01 "1st velocity loop gain"
 - Pr1.02 "1st velocity loop integration time constant"
 - Pr1.03 "1st filter of velocity detection"
 - Pr1.04 "1st torque filter time constant"
- 2nd gain
 - Pr1.06 "2nd velocity loop gain"
 - Pr1.07 "2nd velocity loop integration time constant"
 - Pr1.08 "2nd filter of velocity detection"
 - Pr1.09 "2nd torque filter time constant"

■ Each control switching mode and gain switching details

The gain switching method differs depending on the set values for Pr1.15 "Mode of position control switching", Pr1.20 "Mode of velocity control switching", and Pr1.24 "Mode of torque control switching". Check 0, 1, 3, 5 to 10 for mode of position control switching, 0, 1, 3 to 5 for mode of velocity control switching, and 0, 1 and 3 for mode of torque control switching.

○: Enabled X: Disabled

Control switching mode setting values	Switching condition	Gain switching details	Control mode			
			Position	Full-closed	Speed	Torque
0	1st gain fixed	Fixed to 1st gain (Pr1.00 to Pr1.04)	○	○	○	○
1	2nd gain fixed	Fixed to 2nd gain (Pr1.05 to Pr1.09)	○	○	○	○
2	RTEX communication gain switching command (Gain_SW)	1st gain when RTEX communication gain switching command (Gain_SW) is 0, and 2nd gain when the command is 1.	○	○	○	○
3	Torque command magnitude	Switches to 2nd gain if previously the absolute value of the torque command exceeded (level + hysteresis) [%] in 1st gain. Returns to 1st gain if previously the absolute value of the torque command remained below (level - hysteresis) [%] for the delay time in 2nd gain.	○	○	○	○
4	Large amount of speed command variation	Switches to 2nd gain if previously the absolute value of speed command variation exceeded (level + hysteresis) [10 r/min/s] in 1st gain. Returns to 1st gain if previously the absolute value of speed command variation remained below (level - hysteresis) [10 r/min/s] for the delay time in 2nd gain. Notes <ul style="list-style-type: none">Except with speed control, the 1st gain is fixed.	×	×	○	×
5	Speed command magnitude	Switches to 2nd gain if previously the absolute value of the speed command exceeded (level + hysteresis) [r/min] in 1st gain. Returns to 1st gain if previously the absolute value of the speed command remained below (level - hysteresis) [r/min] for the delay time in 2nd gain.	○	○	○	×
6	Position deviation magnitude	Switches to 2nd gain if previously the absolute value of position deviation exceeded (level + hysteresis) [pulse] in 1st gain. Returns to 1st gain if previously the absolute value of position deviation remained below (level - hysteresis) [pulse] for the delay time in 2nd gain. Notes <ul style="list-style-type: none">Level and hysteresis units [pulse] are set by encoder resolution for position control and by feedback scale resolution for full-closed control. The position deviation in this description refers to the deviation between the internal command position after the filter and the actual position, regardless of the set value for Pr7.23 "Communication function extended setup 2" :bit 14.	○	○	×	×
7	With position command	Switches to 2nd gain if previously the position command was not 0 in 1st gain. Returns to 1st gain if previously the position command remained 0 for the delay time in 2nd gain.	○	○	×	×
8	Positioning not completed	Switches to 2nd gain if previously positioning was not completed in 1st gain. Returns to 1st gain if previously the positioning completed state continued for the delay time in 2nd gain.	○	○	×	×

Control switching mode setting values	Switching condition	Gain switching details	Control mode			
			Position	Full-closed	Speed	Torque
9	Actual Speed - Large	Shifts to 2nd gain when the actual speed absolute value exceeds (level + hysteresis) [r/min] in the previous 1st gain. Returns to 1st gain when the actual speed absolute value remains (level - hysteresis) [r/min] or less for the delay time in the previous 2nd gain.	○	○	×	×
10	With Position Command + Actual Speed	Switches to 2nd gain if previously the position command was not 0 in 1st gain. Returns to 1st gain when position command remains at 0 for the delay time and the actual speed absolute value is (level - hysteresis) [r/min] or less in the previous 2nd gain.	○	○	×	×


4.2.4 How to Use

4.2.4.1 For Manual Setting

After setting the gain switching mode for each control mode used, enable the gain switching function (Pr1.14 “2nd gain setup” = 1). Change the related parameters for each control mode.

4.2.4.1.1 Example of Gain Switching Function Use

Assume that when the load moves from position A to position B, the internal state of the servo driver changes as shown in the figure below. This section describes how to set the related parameters when using the gain switching function under such conditions.




<< Procedure >>

1. The following parameters are used to set the conditions for switching gain.

- Pr1.15 “Mode of position control switching”
- Pr1.20 “Mode of velocity control switching”
- Pr1.24 “Mode of torque control switching”

2. Set the switching level and hysteresis according to the gain switching conditions.


When there is a small fluctuation such as noise in the input signal change based on the Pr1.15 “Mode of position control switching”, Pr1.20 “Mode of velocity control switching”, and Pr1.24 “Mode of torque control switching” settings, set the hysteresis to a value greater than the fluctuation range to prevent unnecessary gain switching from occurring continuously and to enable smooth gain switching.



3. Set the switching time.

The switching time sets the delay time from trigger detection to actual gain switching when switching from 2nd gain to 1st gain.

2nd gain switches to 1st gain when the input signal exceeds the set switching level and hysteresis continuously for a set switching time or longer.



4. Set the position gain switching time.

The following parameters are switched instantly during gain switching.

- 1st gain
 - Pr1.00 “1st gain of position loop”
 - Pr1.01 “1st velocity loop gain”
 - Pr1.02 “1st velocity loop integration time constant”
 - Pr1.04 “1st torque filter time constant”
- 2nd gain
 - Pr1.05 “2nd gain of position loop”
 - Pr1.06 “2nd velocity loop gain”
 - Pr1.07 “2nd velocity loop integration time constant”
 - Pr1.09 “2nd torque filter time constant”


Position loop gain can be switched gradually and stepwise to avoid problems caused by sudden changes to high gain.

In this case, the number of steps is “position gain switching time / resolution 62.5 μ s”. If there is a fraction instead of a multiple of 62.5, the number of steps is rounded down.


When Pr1.19 “Position gain switching time” is 2 in the figure below, the set time is 0.2 ms. Therefore, $0.2 \text{ ms} / 62.5 \mu\text{s} = 3.2$, which is a rise of 3 steps. (Actual switching time is $62.5 \mu\text{s} \times 3 = 250 \mu\text{s} = 187.5 \mu\text{s}$)

*The gain switching flag changes at the moment of switching from low gain.

When Pr1.19 “Position gain switching time” is 0



When Pr1.19 “Position gain switching time” is 2




4.2.4.1.2 Example Tuning Procedure for Vibration Suppression

The following is an example tuning procedure for suppressing vibration by lowering the gain after settling due to high position deviation vibration after positioning settling during position control.


<< Procedure >>

1. Set Pr1.15 “Mode of position control switching” to 7 or 10.
2. Set Pr1.16 “Delay time of position control switching” = 50, Pr1.17 “Level of position control switching” = 50, Pr1.18 “Hysteresis at position control switching” = 33, Pr1.19 “Position gain switching time” = 33.
3. Lower Pr1.00 “1st gain of position loop” and Pr1.01 “1st velocity loop gain” by the same ratio.
Raise Pr1.04 “1st torque filter time constant” by the same ratio. Tune Pr1.02 “1st velocity loop integration time constant” so that vibration is suppressed.
4. To change the timing of vibration suppression, tune Pr1.16 “Delay time of position control switching”, Pr1.17 “Level of position control switching”, and Pr1.18 “Hysteresis at position control switching”.
At this time, tune so that Pr1.18 “Hysteresis at position control switching” \leq Pr1.17 “Level of position control switching”.

Example of waveform before tuning




Example of waveform after tuning




4.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

<< Procedure >>


1. Activate Set-up Support Software (PANATERM ver.7) .
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.



3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.



4. Click the [Application] button.

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

> Feedforward function

> Load fluctuation control function

> High response current control function

> Gain switching function

> Quadrant glitch suppression function

> Hybrid vibration suppression function

5. Click on “>” of “> Gain switching function” to expand “Gain switching function”.

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

> Feedforward function

> Load fluctuation control function

> High response current control function

▼ Gain switching function

Enabling this allows gain to be changed during operation or immediately after stopping.

1st gain of position loop: 480

1st velocity loop gain: 270

1st velocity integral time constant: 210

1st torque filter: 10

2nd gain of position loop: 480

2nd velocity loop gain: 270

2nd velocity integral time constant: 210

2nd torque filter: 10

2nd gain setup: 1: Gain switching enabled

Mode of position control switching: 0: 1st gain fixed

Delay time of position control switching [0...]: 10

Level of position control switching [mode...]: 0

Hysteresis at position control switching [m...]: 0

Position gain switching time [0.1 ms]: 10

Position 3rd gain valid time [0.1 ms]: 0

Position 3rd gain scale factor [%]: 100

> Quadrant glitch suppression function

> Hybrid vibration suppression function

6. After setting the “Mode of position control switching”, select “1: Gain switching enabled” from the “2nd gain setup” drop-down list. Change the related parameters.

— Precautions —

- In the current version of Set-up Support Software (PANATERM ver.7) , the parameter setup screen for gain switching supports only position control and full-closed control. To set the gain switching parameters for speed control and torque control, click the [Manual] button.

4.3 3rd Gain Switching Function

4.3.1 Function Overview

In addition to the normal gain switching function (see “[4.2 Gain Switching Function](#)”), this function sets the gain just before stopping as the 3rd gain.

The positioning settling time can be shortened by setting the gain just before stopping higher for a fixed period of time.

4.3.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Position control and full-closed control

4.3.3 Related Parameters

—: N/A

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	14	B	2nd gain setup	0 to 1	—	Set when performing optimum tuning using the gain switching function. 0: Disabled (Fixes 1st gain) 1: Enabled (Enables gain switching between 1st gain and 2nd gain)
1	15	B	Mode of position control switching	0 to 10	—	Sets the trigger condition for gain switching during position control and full-closed control. (Setup value): (switching condition) 0: 1st gain fixed 1: 2nd gain fixed 2: RTEX communication gain switching command (Gain_SW) 3: Torque command 4: Disabled (1st gain fixed) 5: Speed command 6: Position deviation 7: With position command 8: Positioning not completed 9: Actual speed 10: With position command + actual speed
6	05	B	Position 3rd gain valid time	0 to 10000	0.1 ms	Sets time for 3rd gain to be enabled.
6	06	B	Position 3rd gain scale factor	50 to 1000	%	Sets the scale factor of the 3rd gain with respect to the 1st gain. $\text{3rd gain} = \text{1st gain} \times \text{Pr6.06}/100$

*1 For attributes, see “[7.1 List of Parameters](#)”.

4.3.4 How to Use


4.3.4.1 For Manual Setting

Set the time for applying 3rd gain to Pr6.05 “Position 3rd gain valid time” when the normal gain switching function operates normally (Pr1.14 “2nd gain setup” = 1 and Pr1.15 “Mode of position control switching” = 3, with gain switching occurring at 5 to 10). Set the scale factor of the 3rd gain with respect to the 1st gain in Pr6.06 “Position 3rd gain scale factor”.

- If 3rd gain is not used, set Pr6.05 “Position 3rd gain valid time” = 0 and Pr6.06 “Position 3rd gain scale factor” = 100.
- In the 3rd gain section, the position loop gain and speed loop gain become 3rd gain, and 1st gain settings are applied to the speed loop integral time constant, speed detection filter and torque filter time constant parameters.
- If 2nd gain switching conditions are satisfied in the 3rd gain section, the gain is switched to 2nd gain.
- When switching from 2nd gain to 3rd gain, Pr1.19 “Position gain switching time” is applied.

Note that a 3rd gain section is also generated when the gain is switched from 2nd gain to the 1st gain due to a parameter change, etc.

(Example) Gain transition when Pr1.15 “Mode of position control switching” = 7 (with position command)



— Precautions —

- If Pr6.06 “Position 3rd gain scale factor” is raised too high, oscillation may occur.

4.3.4.1.1 Example Tuning Procedure for Overshoot/Undershoot Suppression

The following is an example procedure for suppressing overshoot/undershoot by increasing the gain near settling due to large overshoot/undershoot at positioning settling during position control.

<< Procedure >>

1. Determine the section to be suppressed while observing amounts of overshoot/undershoot.
2. Set the value determined by “Step 1” to Pr6.05 “Position 3rd gain valid time”.
3. Increase Pr6.06 “Position 3rd gain scale factor” by increments of 10 from 100 within the range of oscillation does not occur.
4. If the overshoot/undershoot suppression is ineffective, try tuning Pr6.05 “Position 3rd gain valid time” and Pr6.06 “Position 3rd gain scale factor” to a setting at which overshoot/undershoot is suppressed.

5. If still ineffective after executing “Step 4”, try finding the optimal setting values, including for 1st gain and 2nd gain.

4.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

Refer to “4.2 Gain Switching Function” “4.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used” .

4.4 Feedforward Function

4.4.1 Function Overview

This function performs compensation to minimize the effect of delay caused by feedback control on the command value before the effect is apparent.

- The speed forward function generates a speed feedforward value by adding a speed control command calculated from the internal position command to the speed command from the position control processing part. The use of this speed feedforward value results in less position deviation while operating at a constant speed compared to with feedback control alone, thus increasing the responsiveness of position control.
- The torque forward function generates a torque feedforward value by adding the torque command calculated from the speed control command to the torque command from the speed control processing part. The use of this torque feedforward value results in position deviation of close to 0 at constant acceleration and deceleration, thus increasing the responsiveness of speed control.
- In addition to these functions, some RTEX communication commands can be sent with feedforward values set as command arguments. Feedforward values via RTEX communication are added to internally calculated feedforward values based on the function parameter settings. For details, see Technical Reference Communication Specification.

4.4.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> • Position control, speed control, and full-closed control • In speed control, only the torque feedforward function works

— Precautions —

- If the control mode is switched to torque control mode from any control mode other than torque control mode during motor operation, feedforward may operate even though torque control is in progress.
- Feedforward via RTEX communication should be filtered by the host device.

4.4.3 Related Parameters

—: N/A

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	10	B	Velocity feed forward gain	0 to 4000	0.1%	Multiply the velocity control command calculated according to the internal position command by the ratio of this parameter and add the result to the speed command resulting from the position control process.
1	11	B	Velocity feed forward filter	0 to 6400	0.01 ms	Sets the time constant of first order lag filter which affects the input of velocity feedforward. Disabled when the set value is 0 to 3. Invalid during two-degree-of-freedom control mode.
1	12	B	Torque feed forward gain	0 to 2000	0.1%	Multiply the torque command calculated according to the velocity control command by the ratio of this parameter and add the result to the torque command resulting from the velocity control process.
1	13	B	Torque feed forward filter	0 to 6400	0.01 ms	Set the time constant of first order lag filter which affects the input of torque feedforward. Disabled when the set value is 0 to 3.

*1 For attributes, see [“7.1 List of Parameters”](#).

4.4.4 How to Use

4.4.4.1 For Manual Setting

In the initial setting, two-degree-of-freedom control mode is set to enabled, and both Pr1.10 “Velocity feed forward gain” and Pr1.12 “Torque feed forward gain” are set to 100%.

This setting does not usually require tuning, as this value obtains the highest responsiveness if Pr0.04 “Inertia ratio” is set correctly.


However, the value can be tuned to suppress overshoot during positioning.

Setting Pr1.10 “Velocity feed forward gain” lower suppresses position deviation overshoot during positioning. Reduce the set value by increments of 50 from 1000. Tune to the optimal value, as too small a value may increase the settling time.

On the Manual TUNING screen for Set-up Support Software (PANATERM ver.7), Pr1.10 “Velocity feed forward gain” is linked to “Overshoot Suppression”.

Image of overshoot suppression

Position deviation - Dotted line: before suppression, Solid line: after suppression




If setting Pr1.10 “Velocity feed forward gain” or Pr1.12 “Torque feed forward gain” anything other than 100%, see [“Tuning speed feedforward”](#) and [“Tuning torque feedforward”](#) below.

■ Tuning speed feedforward

With Pr1.11 “Velocity feed forward filter” set to about 50 (0.5 ms), position deviation in the constant speed range can be reduced by gradually increasing Pr1.10 “Velocity feed forward gain”.

If the speed feedforward gain is set to 100%, the calculated position deviation becomes zero, but large overshoot occurs during acceleration and deceleration. Tune the value of Pr1.10 “Velocity feed forward gain” while observing the overshoot response.



Position deviation during operation at a constant speed reduces as the velocity feed forward gain is increased.


If the position command input updating cycle is longer than the servo driver control cycle, or if the input command frequency is not uniform, operation sound may become louder when speed feedforward is enabled.

In this case, apply a position command filter (1st order lag or FIR smoothing) or set a higher value for the speed feedforward filter.

■ Tuning torque feedforward

When using torque feedforward, the inertia ratio must be set correctly. Just use the estimated value from when real-time auto tuning was executed, or set Pr0.04 “Inertia ratio” to the inertia ratio that can be calculated from the mechanical specifications.

Next, with Pr1.13 “Torque feed forward filter” set to about 50 (0.5 ms), position deviation during constant acceleration and deceleration can be brought close to 0 by gradually increasing Pr1.12 “Torque feed forward gain”. Position deviation can be reduced to almost zero over the entire operating range when driving in a trapezoidal speed pattern under ideal conditions in which torque feedforward gain is set to 100% and disturbance torque is not an issue. Tune the value of Pr1.12 “Torque feed forward gain” while observing the position deviation response.




Position deviation during operation at a constant acceleration reduces as the torque feed forward gain is increased.

If the position command input updating cycle is longer than the servo driver control cycle, or if the input command frequency is not uniform, operation sound may become louder when speed feedforward is enabled. In this case, apply a position command filter (1st order lag or FIR smoothing) or set a higher value for the speed feedforward filter. Although operation sound decreases when the torque feedforward filter time constant is increased, the position deviation at the point of acceleration change also increases. Tune Pr1.13 “Torque feed forward filter” while observing the position deviation response.


4.4.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

<< Procedure >>


1. Activate Set-up Support Software (PANATERM ver.7) .
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.



3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.



4. Click the [Application] button.

<

Manual TUNING

Selected driver:Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

>

 Feedforward function

>

 Load fluctuation control function

>

 High response current control function

>

 Gain switching function

>

 Quadrant glitch suppression function

>

 Hybrid vibration suppression function

5. Click on “>” of “> Feedforward function” to expand “Feedforward Function”.

<

Manual TUNING

Selected driver:Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

√

 Feedforward function

Tuning may reduce overshoot/undershoot.

Speed FF gain [0.1%]

1000

Speed FF filter [0.01 ms]

0

Torque FF gain [0.1%]

1000

Torque FF filter [0.01 ms]

0

>

 Load fluctuation control function

>

 High response current control function

>

 Gain switching function

>

 Quadrant glitch suppression function

>

 Hybrid vibration suppression function

6. For details on tuning each parameter, see [“4.4.4.1 For Manual Setting”](#).

4.5 Friction Torque Compensation Function

4.5.1 Function Overview

This function reduces the effect of mechanical system friction and improves responsiveness.

The following three types of friction torque compensation are possible.

Unbalanced load compensation

A constant offset value is always added to the torque command to provide friction compensation.

In situations such as when a constant unbalanced load torque is continuously applied to the motor due to gravity on a vertical axis, a torque command value is added to reduce the variation in the positioning operation caused by the direction of movement.

Dynamic friction compensation

Performs friction compensation by adding a compensation value based on positive-direction and negative-direction position commands to the torque command.

For loads that require high dynamic friction torque due to radial loads, such as a belt mechanical shaft, setting friction torque for each parameter in each rotational direction can reduce positioning settling times that are worsened or varied due to dynamic friction.

Viscous friction compensation

A compensation value proportional to the command speed is added to the torque command to provide friction compensation.

Setting a torque command value for viscous load can reduce response delay during acceleration.

4.5.2 Operational Conditions

Item	Operational Conditions	
Control mode	<ul style="list-style-type: none"> Possible modes of operation depend on the type of friction torque compensation. 	
	Compensation description	Operable modes
	Unbalanced load compensation	Position control mode, speed control mode, full-closed control mode
	Dynamic friction compensation	Position control mode, full-closed control mode
	Viscous friction compensation	When two-degree-of-freedom control mode is enabled in position control mode, speed control mode, or full-close control mode

4.5.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	45	B	Function expansion setup 10	-2147483648 to 2147483647	—	bit 2: Friction torque compensation parameter selection 0: Use Pr6.07, Pr6.08, Pr6.09 1: Use Pr2.52, Pr2.53, Pr2.54
2	52	B	Torque command additional value 2	-1000 to 1000	0.1%	Sets the offset torque to be added to the torque command when Pr2.45: bit 2 "Friction torque compensation parameter selection" = 1.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	53	B	Positive direction torque compensation value 2	-1000 to 1000	0.1%	Sets the value to be added to the torque command during positive direction operation when Pr2.45: bit 2 "Friction torque compensation parameter selection" = 1.
2	54	B	Negative direction torque compensation value 2	-1000 to 1000	0.1%	Sets the value to be added to the torque command during negative direction operation when Pr2.45: bit 2 "Friction torque compensation parameter selection" = 1.
6	07	B	Torque command additional value	-100 to 100	%	Sets the offset torque to be added to the torque command when Pr2.45: bit 2 "Friction torque compensation parameter selection" = 0.
6	08	B	Positive direction torque compensation value	-100 to 100	%	Sets the value to be added to the torque command during positive direction operation when Pr2.45: bit 2 "Friction torque compensation parameter selection" = 0.
6	09	B	Negative direction torque compensation value	-100 to 100	%	Sets the value to be added to the torque command during negative direction operation when Pr2.45: bit 2 "Friction torque compensation parameter selection" = 0.
6	50	B	Viscous friction compensating gain	0 to 10000	0.1 %/ (10000 r/min)	When the two-degree-of-freedom control mode is enabled, the product of the command speed and the setup value is used as the viscous friction torque compensation and the torque command is added to the torque. <ul style="list-style-type: none"> Setting the value of the viscous friction coefficient estimation of real-time auto tuning can improve the encoder position deviation of the settling area.

*1 For attributes, see ["7.1 List of Parameters"](#).


4.5.4 How to Use

Friction torque compensation is added according to the direction and speed of the input position command as shown in the figure below.

Friction torque compensation is the sum of the following three values.

- Unbalanced load compensation value set by the torque command additional value that is always constantly added
- Dynamic friction compensation value set by the positive direction torque compensation value or negative direction torque compensation value, which is added according to the command speed and direction input last
- Viscous friction compensating value added according to command speed

Command speed and direction are reset at power-up and when the motor is not energized.



— Precautions —

- Although it is possible to use both unbalanced load compensation and dynamic friction compensation in combination or individually, note that the following restrictions will apply depending on the control mode switching or servo-on status.
 - Change the parameters to be used depending on the values set in Pr2.45 "Function expansion setup 10" :bit 2 "Friction torque compensation parameter selection" . The initial value is Pr2.45: bit 2 = 1.
 - Pr2.45: bit 2=0 : Pr6.07, Pr6.08, Pr6.09
 - Pr2.45: bit 2=1 : Pr2.52, Pr2.53, Pr2.54
 - During torque control:

Unbalanced load compensation and dynamic friction compensation are set to 0 regardless of the parameter settings.
 - During speed control and servo-off:

Unbalanced load compensation is enabled according to Pr2.52 "Torque command additional value 2" and Pr6.07 "Torque command additional value" . Dynamic friction compensation is set to 0 regardless of the parameter setting.
 - During servo-on in position control or full-closed control:

Until the first position command is received, the previous unbalanced load compensation and dynamic friction compensation values are retained.

Once a position command is received, unbalanced load compensation updates according to the settings for Pr2.52 "Torque command additional value 2" and Pr6.07 "Torque command additional value" .


Depending on the command direction, the dynamic friction compensation value is updated according to the positive direction (Pr2.53 "Positive direction torque compensation value 2" , Pr6.08 "Positive direction torque compensation value") or negative direction (Pr2.54 "Negative direction torque compensation value 2" , Pr6.09 "Negative direction torque compensation value") settings.

4.5.4.1 When Set-up Support Software (PANATERM ver.7) Is Used


<< Procedure >>

1. Activate Set-up Support Software (PANATERM ver.7) .


- Select one device that you want to tune in the device tree and click the “Tuning” tab.



- In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.



4. Select “Mode setting” from the drop-down list. Select “7: Customize 2” and click the [Customize settings] button.

- To set automatically, go to “Step 5”.
- To set manually, go to “Step 6” to “Step 7”.

5. To set automatically, set all of the following items to “ON” (automatic).
- “Torque compensation setting switching” (A7 recommended setting)
 - “Torque command additional value tuning”
 - “Positive direction torque compensation tuning”
 - “Negative direction torque compensation tuning”
 - “Viscous friction compensating gain adjustment”

When setup is complete, close the screen with the [OK] button.

To finish without changing any settings, close the screen with the [Cancel] button.

Once the motor has operated for a while, estimated values for each parameter are calculated and set.

6. To set manually, set all of the following items to “OFF” (manual) and manually set the values calculated from the actual measured data.
- “Tuning torque command additional value”
 - “Tuning positive direction torque compensation”
 - “Tuning negative direction torque compensation”
 - “Viscous friction compensating gain adjustment”

When setup is complete, close the screen with the [OK] button.


To finish without changing any settings, close the screen with the [Cancel] button.

Set values for each parameter. Use the following procedure to calculate the values.

- 6-1** Drive the motor with an operation command that includes constant speed and use the waveform measurement function of Set-up Support Software (PANATERM ver.7) to measure the torque in the constant speed section. Measure the torque multiple times by changing this constant speed value.
- 6-2** Based on these measurement results, create a graph that combines speed and torque and calculate the value of each parameter.

The unit [%] of torque is a percentage of the motor rated torque.

The viscous friction compensation gain is calculated by calculating the inclination of the graph and the torque at 10000 r/min.



- 7.** Click the [Load characteristic settings] button to display the “Load characteristic settings” screen. Set the values calculated by “Step 6”.

4.6 Load Fluctuation Control Function (Disturbance Suppression Applications)


There are the following two types of load fluctuation control functions.

- Disturbance suppression applications
- Load fluctuation stabilization applications

This section describes “Disturbance Suppression Applications”.

4.6.1 Function Overview

In devices with which disturbance torque is applied, velocity change may occur due to the disturbance torque. This function reduces this velocity change and improves stability. An overshoot/undershoot suppression effect may also be obtained during positioning.



4.6.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> • Position control, speed control, and full-closed control

Under the following conditions, the effect of the load fluctuation control function may not be seen.

Item	Conditions that obstruct the effectiveness of the load fluctuation control function
Load	<ul style="list-style-type: none"> • Low stiffness (antiresonance points exists in the low frequency range of 10 Hz or less) • Looseness, backlash, etc. are present and the load non-linearity is strong

4.6.3 Related Parameters

—: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	45	A	Function expansion setup 10	-2147483648 to 2147483647	—	Sets automatic calculation of parameters for load fluctuation suppression. bit 3: Load fluctuation suppression function automatic calculation 0: Conventional setting (MINAS A6 Series specification) 1: The following parameters are automatically calculated Pr6.73 “Load estimation filter” Pr6.76 “Load estimation count”

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	10	B	Function expansion setup	-32768 to 32767	—	<p>Sets the load fluctuation suppression function.</p> <p>bit 1: Load fluctuation control function</p> <p>0: Disabled</p> <p>1: Enabled</p> <p>bit 2: Load fluctuation stabilization setting</p> <p>0: Disabled</p> <p>1: Enabled</p> <p>bit 14: Load fluctuation suppression function automatic tuning</p> <p>0: Disabled</p> <p>1: Enabled</p> <p>Notes</p> <ul style="list-style-type: none"> Depending on the settings for two-degree-of-freedom control and real-time auto tuning, bit 1 may be set automatically according to the setting for bit 14.
6	23	B	Load change compensation gain	-100 to 100	%	Sets compensation gain with respect to load fluctuation.
6	24	B	Load change compensation filter	10 to 2500	0.01 ms	Sets filter time constant with respect to load fluctuation. Disabled when the set value is 0 to 3.
6	73	B	Load estimation filter	0 to 2500	0.01 ms	Sets filter time constant for load estimation. Disabled when the set value is 0 to 3.
6	74	B	Torque compensation frequency 1	0 to 5000	0.1 Hz	<p>Sets filter frequency 1 with respect to velocity control output.</p> <p>Torque compensation is valid when the relationship between Pr6.74 "Torque compensation frequency 1" and Pr6.75 "Torque compensation frequency 2" is within the range of the following formula.</p> $1.0 \text{ Hz} \leq \text{Pr6.75} < \text{Pr6.74} \leq (\text{Pr6.75} \times 32)$
6	75	B	Torque compensation frequency 2	0 to 5000	0.1 Hz	<p>Sets filter frequency 2 with respect to velocity control output.</p> <p>Torque compensation is valid when the relationship between Pr6.74 "Torque compensation frequency 1" and Pr6.75 "Torque compensation frequency 2" is within the range of the following formula.</p> $1.0 \text{ Hz} \leq \text{Pr6.75} < \text{Pr6.74} \leq (\text{Pr6.75} \times 32)$
6	76	B	Load estimation count	0 to 8	—	Sets count relating to load estimation.

*1 For attributes, see ["7.1 List of Parameters"](#).

4.6.4 How to Use

4.6.4.1 For Manual Setting

<< Procedure >>

1. Operate the motor with Pr0.02 “Real-time auto-gain tuning setup” enabled and the load fluctuation control function disabled (Pr6.10 bit 1 = 0). Increase the stiffness settings (Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2”, Pr0.03 “Real-time auto-tuning machine stiffness setup”) by increments of 1 to the largest possible values.
2. After setting the load fluctuation suppression function automatic setting to enable (Pr6.10 “Function expansion setup” :bit 14 = 1), operate the motor to check the disturbance suppression effect.

— Precautions —

- To enable or disable load fluctuation suppression function automatic setting, turn the servo off once.
 - If this change causes the motor to oscillate or make abnormal noises, go back to “Step 1”, reduce the servo stiffness by one or two steps, and repeat the procedure thereafter.
3. If the disturbance suppression effect is insufficient and further tuning is required, perform the following operations.
 - Set Pr0.02 “Real-time auto-gain tuning setup” = 0 (disabled).
 - Set Pr6.10 “Function expansion setup” :bit 14 = 0 to enable load fluctuation suppression function automatic tuning.
 - Reduce the set value for Pr6.24 “Load change compensation filter”. The set value should be changed by decreasing by 10% at a time.


By reducing the filter setting within the range where abnormal noise and torque command fluctuations are not noticeable, disturbance suppression performance is improved, resulting in smaller motor speed fluctuation and encoder position deviation. During positioning, the following effects may be obtained.

 - Overshoot/undershoot suppression
 - Velocity fluctuation suppression during constant speed control
 - Improved disturbance suppression performance
 - If high frequency (1 kHz or higher) abnormal noise is generated, increase Pr6.76 “Load estimation count” by increments of 1. Set an appropriate value as too large a value may result in unstable control.
 - If low frequency (10 Hz or less) vibration is generated, after stopping, for example, decrease Pr6.23 “Load change compensation gain” by increments of 5.
 - Pr6.73 “Load estimation filter” does not normally need to be changed, but may be fine-tuned to an optimal point between 0.00 and 0.20 ms.


4.6.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

<< Procedure >>


1. Activate Set-up Support Software (PANATERM ver.7) .
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.



3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.



4. After changing “Mode setting” to a mode that enables real-time auto tuning, operate the motor. Increase the “Feedback gain setting” by increments of 1 and set as large a value as possible.

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settin...	Notch settings
Damping settings	Application	Manual

Mode setting ⓘ 7:Customize2 ▼

Customize settings...

ⓘ When launching for the first time A7 recommended setting is recommended
 ⓘ When upgrading from A6 A6 compatibility setting is recommended

Tuning conditions

☒ Positioning/general-purpose
☐ Processing machine
☐ Customize

> Parameters for tuning conditions

Load characteristic settings Automatic setting: ON

Inertia ratio 250

For more advanced settings [Load characteristic settings](#)

Gain setting

Feedback gain setting - 16 +

Speed response frequency [Hz] 27.0

Automatic oscillation suppression OFF

Safety function...

FF gain setting - 16 +

Positional command smoothing filter [...] 3.7

Overshoot suppression [%] - 100.0 +

Notch filter settings Automatic setting: ON

3rd notch frequency [Hz] 5000

4th notch frequency [Hz] 5000

For more advanced settings [Notch settings](#)

Damping filter setup Automatic setting: ON

1st damping frequency [Hz] 0

For more advanced settings [Damping settings](#)

What if I have a problem?
 Refer to Tuning Help [when problems occur](#) such as vibration or abnormal noise

5. Click the [Application] button.

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

> Feedforward function

> Load fluctuation control function

> High response current control function

> Gain switching function

> Quadrant glitch suppression function

> Hybrid vibration suppression function

6. Click “>” of “> Load fluctuation control function” to expand “Load fluctuation control function”.

The screenshot shows the 'Manual TUNING' screen for a servo motor. At the top, it says 'Selected driver: Axis0_No name set'. Below this is a tabbed interface with four tabs: 'Basic', 'Load characteristic settin...', 'Notch settings', and 'Application'. The 'Application' tab is currently selected. Under the 'Application' tab, there are several expandable sections. The 'Load fluctuation control function' section is expanded, showing a description: 'Enabling this can more effectively suppress the effects of motion caused by friction or the movement of other axes, etc. Use to suppress overshoot, etc. Be aware that increasing control may cause oscillation to occur.' Below the description are two toggle switches: 'Load fluctuation suppression function en...' (set to ON) and 'Load fluctuation suppression function aut...' (set to ON). There are also several input fields: 'Load change compensation gain [%]' (90), 'Load change compensation filter [0.01 ms]' (590), 'Load estimation filter [0.01 ms]' (4), 'Torque compensation frequency 1 [0.1 Hz]' (0), 'Torque compensation frequency 2 [0.1 Hz]' (0), and 'Load estimation count' (0). Other expandable sections like 'Feedforward function', 'High response current control function', 'Gain switching function', 'Quadrant glitch suppression function', and 'Hybrid vibration suppression function' are visible but not expanded.

7. After setting “Load fluctuation suppression function automatic tuning” to ON, operate the motor to check the disturbance suppression effect.

— Precautions —

- When switching “Load fluctuation suppression function automatic tuning” from OFF to ON, turn the servo off once.
- If the motor oscillates or makes an abnormal noise after this tuning, click the [Basic] button to return to the “Manual TUNING” screen. After lowering the feedback gain setting by one or two steps on the “Manual TUNING” screen, run the motor again to check the disturbance suppression effect.
- Changing the feedback gain setting changes several parameters, including the speed loop gain. Save previous parameters if necessary.

8. If the disturbance suppression effect is insufficient and further tuning is required, perform the following operations.

- Click the [Basic] button and set “Mode setting” to “0: disabled”.

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Mode setting ⓘ 0: Disabled ▼

Customize settings...

ⓘ When launching for the first time [A7 recommended setting](#) is recommended
 ⓘ When upgrading from A6 [A6 compatibility setting](#) is recommended

Load characteristic settings Automatic setting: OFF

Inertia ratio 250

For more advanced settings [Load characteristic settings](#)

Gain setting

Feedback gain setting - 16 +

Speed response frequency [Hz] 27.0

Automatic oscillation suppression OFF

Safety function...

FF gain setting - 16 +

Positional command smoothing filter [ms] 9.2

Overshoot suppression [%] - 100.0 +

Notch filter settings Automatic setting: OFF

3rd notch frequency [Hz] 5000

4th notch frequency [Hz] 5000

For more advanced settings [Notch settings](#)

Damping filter setup Automatic setting: ON

1st damping frequency [Hz] 0

For more advanced settings [Damping settings](#)

What if I have a problem?
 Refer to Tuning Help [when problems occur](#) such as vibration or abnormal noise

- After clicking on the [Application] button, click “>” of “Load fluctuation control function” to expand “Load fluctuation control function”.
- After setting “Load fluctuation suppression function automatic tuning” to OFF, set Load change compensation filter as small as possible. The set value should be changed by decreasing by 10% at a time.
- If high frequency (1 kHz or higher) abnormal noise is generated, increase Load estimation count by increments of 1. Set an appropriate value, as too large a value may result in unstable control.
- If low frequency (10 Hz or less) vibration is generated, after stopping, for example, decrease Load change compensation gain by increments of 5.
- Load estimation filter does not normally need to be changed, but may be fine-tuned to an optimal point between 0.00 and 0.20 ms.

4.7 Load Fluctuation Control Function (Load Fluctuation Stabilization Applications)

There are the following two types of load fluctuation control functions.


- Disturbance suppression applications
- Load fluctuation stabilization applications

This section describes “Load Fluctuation Stabilization Applications”.


4.7.1 Function Overview

In devices where load inertia fluctuates, vibration may occur due to the effect of load inertia fluctuations. This function reduces this vibration and improves stability.

Example of operation before tuning



Example of operation after tuning



4.7.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> • Position control, speed control, and full-closed control

Under the following conditions, the effect of the load fluctuation control function may not be seen.

Item	Conditions that obstruct the effectiveness of the load fluctuation control function
Load	<ul style="list-style-type: none"> • Low stiffness (antiresonance points exists in the low frequency range of 10 Hz or less) • Looseness, backlash, etc. are present and the load non-linearity is strong

4.7.3 Related Parameters

—: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	45	A	Function expansion setup 10	-2147483648 to 2147483647	—	Sets automatic calculation of parameters for load fluctuation suppression. bit 3: Load fluctuation suppression function automatic calculation 0: Conventional setting (MINAS A6 Series specification) 1: The following parameters are automatically calculated Pr6.73 "Load estimation filter" Pr6.76 "Load estimation count"
6	10	B	Function expansion setup	-32768 to 32767	—	Sets the load fluctuation suppression function. bit 1: Load fluctuation control function 0: Disabled 1: Enabled bit 2: Load fluctuation stabilization setting 0: Disabled 1: Enabled bit 14: Load fluctuation suppression function automatic tuning 0: Disabled 1: Enabled Notes <ul style="list-style-type: none">Depending on the settings for two-degree-of-freedom control and real-time auto tuning, bit 1 may be set automatically according to the setting for bit 14.
6	23	B	Load change compensation gain	-100 to 100	%	Sets compensation gain with respect to load fluctuation.
6	24	B	Load change compensation filter	10 to 2500	0.01 ms	Sets filter time constant with respect to load fluctuation. Disabled when the set value is 0 to 3.
6	73	B	Load estimation filter	0 to 2500	0.01 ms	Sets filter time constant for load estimation. Disabled when the set value is 0 to 3.
6	74	B	Torque compensation frequency 1	0 to 5000	0.1 Hz	Sets filter frequency 1 with respect to velocity control output. Torque compensation is valid when the relationship between Pr6.74 "Torque compensation frequency 1" and Pr6.75 "Torque compensation frequency 2" is within the range of the following formula. $1.0 \text{ Hz} \leq \text{Pr6.75} < \text{Pr6.74} \leq (\text{Pr6.75} \times 32)$
6	75	B	Torque compensation frequency 2	0 to 5000	0.1 Hz	Sets filter frequency 2 with respect to velocity control output. Torque compensation is valid when the relationship between Pr6.74 "Torque compensation frequency 1" and Pr6.75 "Torque compensation frequency 2" is within the range of the following formula. $1.0 \text{ Hz} \leq \text{Pr6.75} < \text{Pr6.74} \leq (\text{Pr6.75} \times 32)$

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	76	B	Load estimation count	0 to 8	—	Sets count relating to load estimation.

*1 For attributes, see “7.1 List of Parameters”.

4.7.4 How to Use

4.7.4.1 For Manual Setting

<< Procedure >>


1. Set to two-degree-of-freedom position control mode (synchronization type) (Pr0.01 “Control mode setup” = 0, Pr6.47 “Function expansion setup 2” :bit 0 = 1 bit 3 = 1), and then turn on control power.
2. Set Pr2.22 “Positional command smoothing filter” to 10.0 ms.
3. Set real-time auto tuning to load fluctuation support mode (Pr0.02 “Real-time auto-gain tuning setup” = 6) (this sets Pr6.10 “Function expansion setup” :bit 1 and bit 2 to 1) and operate the motor in a pattern that generates as large a load fluctuation as possible in this state.
4. Increase the stiffness settings (Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2” , Pr0.03 “Real-time auto-tuning machine stiffness setup”) by increments of 1 to the largest possible values.
5. While checking the motor response, change the Pr2.22 “Positional command smoothing filter” value to a small value and set so that the motor response vibration is smaller.

If locus control for multiple axes is required, tune Pr2.22 “Positional command smoothing filter” for all axes, changing them to the same value.


4.7.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

<< Procedure >>

1. Activate Set-up Support Software (PANATERM ver.7) .
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.




3. In the “Tuning” tab screen, select “Load fluctuation suppression tuning (Load fluctuation stabilization applications)”, and click the [Go to the Tuning screen] button.




A dialog box for enabling the load fluctuation control function is displayed.

4. Check the contents, and click the [OK] button or [Cancel] button.




— Precautions —

- If the power needs to be restored, the following dialog box is displayed. Check the contents, and click the [OK] button or [Cancel] button.




The load fluctuation suppression tuning screen is displayed.



(1)	This is the main screen. This displays the parameter tuning screen.
(2)	This displays the waveform measurement and frequency response measurement screens.
(3)	This displays the trial run operation screen.


The following describes tuning with focus on the operations on the main screen (left side of the screen).

- Click the [Basic] button and then select “Easy tuning” for the tuning condition.



- In order to generate as large a load fluctuation as possible, the motor is operated in multiple patterns using the trial run function or via commands from the host device.

7. Check the motor operation by waveform measurement while gradually changing the feedback gain setting to a higher value. Tune so that motor response vibration is reduced in any operation pattern. If “Easy tuning” does not satisfy the response performance, proceed to “Step 8”.



Load fluctuation suppression tuning

Selected driver: Axis0_No name set

Basic Notch settings Damping settings

It is a function to properly adjust even when the load inner fluctuates while driving.

Tuning conditions ☒ Easy tuning ☐ Manual tuning

Feedback gain setting - 16 +

Automatic oscillation suppression OFF

Safety function...

Pr6.23 Load change compensation gain... 0

Pr6.24 Load change compensation filter... 53

Pr6.73 Load estimation filter[0.01ms] 0


Pr6.74 Torque compensation frequency... 0

Pr6.75 Torque compensation frequency... 0

Pr6.76 Load estimation count[] 0

Pr2.22 Positional command smoothing... 92

A safety function (for automatically lowering the set value to eliminate oscillation when tuning is in progress) can be set. To set, click the [Safety function] button. The “Safety function” dialog box is displayed. “Enable (Yes)” or “Disable (No)” can be selected for the safety function. When enabled, the “Oscillation detection level” can be set.



Safety function

Safety functions can be set during gain adjustment.

When this function is enabled, the Feedback gain setting is automatically lowered to immediately suppress vibration if any vibrations occur that exceed the detection level set by the torque command.

Safety function (Automatic oscillation suppression function) ☐ Yes ☒ No

Oscillation detection level 15 %

OK Cancel

8. Select “Manual tuning” for the tuning condition.

The parameters at the bottom of the screen can now be changed. Tune these parameters.

Load fluctuation suppression tuning

Selected driver: Axis0_No name set

Basic Notch settings Damping settings

It is a function to properly adjust even when the load inner fluctuates while driving.

Tuning conditions ☐ Easy tuning ☒ Manual tuning

Feedback gain setting - 16 +

Automatic oscillation suppression OFF

Safety function...

Pr6.23 Load change compensation gain...	0
Pr6.24 Load change compensation filter...	53
Pr6.73 Load estimation filter[0.01ms]	0
Pr6.74 Torque compensation frequency...	0
Pr6.75 Torque compensation frequency...	0
Pr6.76 Load estimation count[]	0
Pr2.22 Positional command smoothing...	92

Lower the set value for Pr2.22 “Positional command smoothing filter” while checking the motor response. The set value should be changed by decreasing by 10% at a time to decrease motor response vibration.

- If locus control for multiple axes is required, tune Pr2.22 “Positional command smoothing filter” for all axes, changing them to the same value.
- If high frequency (1 kHz or higher) abnormal noise is generated, increase Pr6.76 “Load estimation count” by increments of 1.
- If low frequency (10 Hz or less) vibration is generated, after stopping, for example, decrease Pr6.23 “Load change compensation gain” by increments of 5.
- Pr6.73 “Load estimation filter” does not normally need to be changed, but may be fine-tuned to an optimal point between 0.00 and 0.20 ms.

Notes

- If sounds or vibrations of specific frequencies occur in the high frequency range when tuning is in progress, these may be suppressed by tuning the notch filter. Select the [Notch settings] button at the top of the main screen and tune the notch filter parameters. For details, see [“5.3 Notch Filter Function”](#).
- Residual vibration that occurs at the moving part tip or the overall device when tuning is in progress may be suppressed by tuning the damping filter or model-type damping filter. Select the [Damping settings] button at the top of the main screen and tune the damping filter and model-type damping filter parameters. For details, see [“5.5 Damping Control Function”](#) and [“5.6 Model-type Damping Filter Function”](#).

4.8 High Response Current Control Function

4.8.1 Function Overview

This function improves the responsiveness of the current controller by changing the current response setting to a value greater than the initial value in order to improve the current control responsiveness when operating at low current, such as with a processing machine. Improved current response may provide the following effects during positioning

- Overshoot/undershoot suppression
- Velocity fluctuation suppression during constant speed control
- Improved disturbance suppression performance

Changing the current response setting to a value smaller than the initial value enables this to also be used for suppressing fine vibration when stopped.

4.8.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> • All control modes

4.8.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	11	B	Current loop gain response setup	10 to 300	%	Tunes the current response with the current response default as 100%.
6	121	B	Current feed forward response setup	0 to 300	%	Tunes the current feedforward response with the current feedforward response default as 100%.

*1 For attributes, see [“7.1 List of Parameters”](#).

— Precautions —

- Setting Pr6.11 “Current loop gain response setup” and Pr6.121 “Current feed forward response setup” to values greater than 100% of the initial values can cause vibration and noise. As with tuning of the position control part and speed control part, tune to the appropriate values according to the operating status of the applicable device.
- Changing Pr6.11 “Current loop gain response setup” and Pr6.121 “Current feed forward response setup” to values smaller than 100% of the initial values reduces the responsiveness of the current control part.
- Although the maximum value in the setting range for Pr6.11 “Current loop gain response setup” and Pr6.121 “Current feed forward response setup” is 300%, the maximum value capable of being set will depend on the motor and may be less than 300%. The set value is limited by the maximum value that can be set for the motor (Pr6.11 and Pr6.121 are different limit values, even though they are for one motor). Check the parameters after input.
- The parameter name for Pr6.11 is “Current response setting” for the MINAS A6N Series, but was changed to “Current loop gain response setup” from the MINAS A7N Series.

If the value is 100% or higher, the responsiveness is the same as for the MINAS A6N Series. If the value is 99% or less, set Pr6.121 “Current feed forward response setup” to 0% to obtain responsiveness equivalent to the MINAS A6N Series.

4.8.4 How to Use

4.8.4.1 For Manual Setting

- To improve current responsiveness

Set Pr6.11 “Current loop gain response setup” and Pr6.121 “Current feed forward response setup” to values greater than 100% within the range where no noise or vibration is generated, while observing the operating status of the applicable equipment. The set value should be changed by increasing by 30% at a time.


- To suppress fine vibration when stopped

Set Pr6.11 “Current loop gain response setup” to less than 100% while observing the operating status of the applicable device. The set value should be changed by decreasing by 10% at a time. If the value is set too low, control may become unstable. Set the value within the range that does not cause problems in actual operation.


4.8.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

<< Procedure >>


1. Activate Set-up Support Software (PANATERM ver.7) .
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.



3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.



4. Click the [Application] button.

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

> Feedforward function

> Load fluctuation control function

> High response current control function

> Gain switching function

> Quadrant glitch suppression function

> Hybrid vibration suppression function

5. Click on “>” of “> High response current control function” to expand “High response current control function”.

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

> Feedforward function

> Load fluctuation control function

✓ High response current control function

Enabling this can suppress overshoot just before stopping.
Increasing control may cause high-frequency abnormal noise to be generated.

Current loop gain response setup [%]

Current feed forward response setup [%]

> Gain switching function

> Quadrant glitch suppression function

> Hybrid vibration suppression function


6. For details on tuning each parameter, see [“4.8.4.1 For Manual Setting”](#).

4.9 Quadrant Glitch Suppression Function


4.9.1 Function Overview

This function suppresses quadrant glitches that occur when drawing an arc with two or more axes. Although the load fluctuation control function (disturbance suppression applications) can be used to suppress load fluctuations, this function can be used to further suppress fluctuations when levels are still unsatisfactory.

Example of waveform before tuning



Example of waveform after tuning



4.9.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Position control and full-closed control

Under the following conditions, the quadrant glitch suppression function may not be effective.

Item	Conditions that obstruct the effectiveness of the quadrant glitch suppression function
Load	<ul style="list-style-type: none"> Low stiffness (antiresonance points exists in the low frequency range of 10 Hz or less) Looseness, backlash, etc. are present and the load non-linearity is strong When the operation pattern changes

4.9.3 Related Parameters

—: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
5	45	B	Quadrant glitch positive-direction compensation value	-1000 to 1000	0.1%	Sets the compensation value to be added to the torque command when the position command is in positive direction when the quadrant glitch compensation function is enabled.
5	46	B	Quadrant glitch negative-direction compensation value	-1000 to 1000	0.1%	Sets the compensation value to be added to the torque command when the position command is in negative direction when the quadrant glitch compensation function is enabled.
5	47	B	Quadrant glitch compensation delay time	0 to 1000	ms	Sets the delay time until the compensation value is switched when the initial position command is input or after reversing the position command when the quadrant glitch compensation function is enabled.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
5	48	B	Quadrant glitch compensation filter setting L	0 to 6400	0.01 ms	Sets the time constant of the low-pass filter applied to the torque command compensation value when the quadrant glitch compensation function is enabled. Disabled when the set value is 0 to 3.
5	49	B	Quadrant glitch compensation filter setting H	0 to 10000	0.1 ms	Sets the time constant of the high pass filter applied to the torque command compensation value when the quadrant glitch compensation function is enabled.
6	47	R	Function expansion setup 2	-32768 to 32767	—	bit 14: Quadrant glitch compensation function Enables and disables the quadrant glitch compensation function. 0: Disabled 1: Enabled
6	97	B	Function expansion setup 3	-2147483648 to 2147483647	—	bit 0: Quadrant glitch compensation HPF clear Enables and disables expansion of the quadrant glitch compensation function. 0: Disabled 1: Enabled To set the compensation amount of quadrant glitch by inversion direction when the direction of the velocity has changed, set to 1.

*1 For attributes, see “7.1 List of Parameters”.

4.9.4 How to Use

4.9.4.1 For Manual Setting


<< Procedure >>

- Set the quadrant glitch suppression function to enable (Pr6.47:bit 14 = 1), and then turn the control power back on.
- Set the following parameters to their initial settings.
Pr5.47 “Quadrant glitch compensation delay time” = 0
Pr5.48 “Quadrant glitch compensation filter setting L” = Pr1.04 “1st torque filter time constant”
Pr5.49 “Quadrant glitch compensation filter setting H” = 0
- Fine tune Pr5.45 “Quadrant glitch positive-direction compensation value” and Pr5.46 “Quadrant glitch negative-direction compensation value” for each axis while measuring the size of the quadrant glitch.
 - If quadrant glitch occurs later than the movement direction inversion timing, configure the following settings.
 - Change Pr5.47 “Quadrant glitch compensation delay time” and Pr5.48 “Quadrant glitch compensation filter setting L”.
 - Use the following procedure to set the amount of quadrant glitch compensation for each direction when reversing the direction of movement.
 - Set Pr6.97 “Function expansion setup 3” :bit 0 “Quadrant glitch compensation HPF clear” to 1.
 - Set Pr5.45 “Quadrant glitch positive-direction compensation value”, Pr5.46 “Quadrant glitch negative-direction compensation value”.
 - Tune the Pr5.49 “Quadrant glitch compensation filter setting H” value.


4.9.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

<< Procedure >>


1. Activate Set-up Support Software (PANATERM ver.7) .
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.




3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.




The “Manual TUNING” settings screen is displayed.



4. Click the [Application] button.



5. Click on ">" of "> Quadrant glitch suppression function" to expand "Quadrant glitch suppression function".



6. Turn "Enable quadrant glitch compensation function" to ON. Power must be restored. In the message dialog box displayed, click the [OK] button to restore the power.

7. Set related parameters to the following values.

- Quadrant glitch compensation delay time = 0
- Quadrant glitch compensation filter setting L = Pr1.04 "1st torque filter time constant"
- Quadrant glitch compensation filter setting H = 0

8. Fine tune Quadrant glitch positive-direction compensation value and Quadrant glitch negative-direction compensation value for each axis while measuring the size of the quadrant glitch.

- If quadrant glitch occurs later than the movement direction inversion timing, configure the following settings.
 - 1 Set Quadrant glitch compensation delay time, Quadrant glitch compensation filter setting L.
- Use the following procedure to set the amount of quadrant glitch compensation for each direction when reversing the direction of movement.
 - 1 Turn on "Quadrant glitch compensation HPF clear enabled".
 - 2 Set Quadrant glitch positive-direction compensation value, Quadrant glitch negative-direction compensation value.
 - 3 Set Quadrant glitch compensation filter setting H.

5 Details of Control Function to Suppress Abnormal Noise and Vibration

5.1 Torque Filter Function	184
5.1.1 Function Overview	184
5.1.2 Operational Conditions	184
5.1.3 Related Parameters	184
5.1.4 How to Use	184
5.1.4.1 For Manual Setting	184
5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	185
5.2 2-stage Torque Filter Function	188
5.2.1 Function Overview	188
5.2.2 Operational Conditions	188
5.2.3 Related Parameters	188
5.2.4 How to Use	189
5.2.4.1 For Manual Setting	189
5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	189
5.3 Notch Filter Function	192
5.3.1 Function Overview	192
5.3.2 Operational Conditions	192
5.3.3 Related Parameters	192
5.3.4 How to Use	195
5.3.4.1 For Manual Setting	195
5.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	195
5.4 Adaptive Filter Function	199
5.4.1 Function Overview	199
5.4.2 Operational Conditions	199
5.4.3 Related Parameters	200
5.4.4 How to Use	201
5.4.4.1 For Manual Setting	201
5.4.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	202
5.5 Damping Control Function	205
5.5.1 Function Overview	205
5.5.2 Operational Conditions	205
5.5.3 Related Parameters	205
5.5.4 How to Use	209
5.5.4.1 For Manual Setting	209
5.5.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	210
5.5.4.3 Error Troubleshooting	213
5.6 Model-type Damping Filter Function	214
5.6.1 Function Overview	214
5.6.2 Operational Conditions	214
5.6.3 Related Parameters	215
5.6.4 How to Use	217

5.6.4.1 When Set-up Support Software (PANATERM ver.7) Is Used	217
5.6.4.2 Error Troubleshooting	222
5.7 Position Command Filter Function	223
5.7.1 Function Overview	223
5.7.2 Operational Conditions.....	223
5.7.3 Related Parameters	223
5.7.4 How to Use.....	224
5.7.4.1 For Manual Setting.....	226
5.7.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	227
5.7.4.3 Error Troubleshooting	229
5.8 Speed Command Acceleration/Deceleration Setting Function.....	230
5.8.1 Function Overview	230
5.8.2 Operational Conditions.....	230
5.8.3 Related Parameters	230
5.8.4 How to Use.....	230
5.9 Hybrid Vibration Suppression Function	232
5.9.1 Function Overview	232
5.9.2 Operational Conditions.....	232
5.9.3 Related Parameters	232
5.9.4 How to Use.....	232
5.9.4.1 For Manual Setting.....	232
5.9.4.2 When Set-up Support Software (PANATERM ver.7) Is Used	233

5.1 Torque Filter Function

5.1.1 Function Overview

By setting a torque filter, this function suppresses sounds and vibrations in the high frequency range that may occur when gain is increased.

5.1.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> All control modes

5.1.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
1	04	B	1st torque filter time constant	0 to 2500	0.01 ms	Sets the time constant of the 1st torque filter. Disabled when the set value is 0 to 3.
1	09	B	2nd torque filter time constant	0 to 2500	0.01 ms	Sets the time constant of the 2nd torque filter. Disabled when the set value is 0 to 3.

*1 For attributes, see “[7.1 List of Parameters](#)”.


The two types of torque filter are 1st torque filter and 2nd torque filter.

See “[4.2 Gain Switching Function](#)” for details on the use of both torque filters.

The torque filter cut-off frequency can be obtained using the following formula.

Cut-off frequency [Hz] $f_c = 1/(2 \pi \times \text{parameter setup value} \times 0.00001)$

Torque filter frequency response



5.1.4 How to Use

5.1.4.1 For Manual Setting

If there is noticeable noise during operation, increase Pr1.04 “1st torque filter time constant”. The set value should be changed by increasing by 10% at a time. The larger the set value, the stronger the effect of the filter.

However, if set too large, control may become unstable and vibration may occur. Therefore, when increasing the set value, tune it while maintaining balance with other parameters (especially Pr1.01 “1st velocity loop gain”).


— Precautions —

- If Pr0.02 “Real-time auto-gain tuning setup” is not 0 (disabled), the related parameters are set automatically and cannot be set manually. If you want to set the parameters manually, set Pr0.02 “Real-time auto-gain tuning setup” to 0 (disabled) before setting.


5.1.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

<< Procedure >>

1. Activate Set-up Support Software (PANATERM ver.7) .
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.




3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.

4. Click on the [Notch settings] button or “Notch settings” in blue text.



The advanced notch settings screen is displayed.

5. Tune the “1st torque filter”. For details on parameter tuning, see “5.1.4.1 For Manual Setting” .

When the “Display notch filter characteristics in a graph” check box is checked, the frequency response of the torque filter set here and the frequency response of the notch filter set separately as parameters are displayed on the frequency response graph.

Manual TUNING

Selected driver:Axis0_No name set

Basic

Load characteristic settings

Notch settings

Damping settings

Application

Manual

Resonance monitor

Not detected

Resonance frequency [Hz] 5000

"5000" is displayed until resonance is detected.

Tuning based on positioning operation

To perform tuning based on the positioning operation, use the following settings 1 to 5.

Pr2.00 Adaptive filter mode5: High-precision adaptive fl...

Tuning based on frequency characteristics

Display notch filter characteristics in a...

Offset [dB]0.0

	Frequency [Hz]	Width	Depth
1th notch	5000	2	0
2th notch	5000	2	0
3th notch	5000	2	0
4th notch	5000	2	0
5th notch	5000	2	0
Costom notch	5000	2	0

The 3rd and 4th notches are automatically set depending on the setting for Pr2.00 Adaptive filter mode.

Torque filter

1st torque filter [0.01 ms]10

2-stage torque filter time constant [0.01 ms]0

2-stage torque filter attenuation term1000

Mode setting7:Customize2

Gain setting

Feedback gain setting-16+

1st velocity loop gain [0.1 Hz]270

1st velocityintegral time constant [0.01 ms]210

Load fluctuation control function

Enabling this can more effectively suppress the effects of motion caused by friction or the movement of other axes, etc.

Use to suppress overshoot, etc. Be aware that increasing control may cause oscillation to occur.

Load fluctuation suppression function enabledON

Load fluctuation suppression function automatic t...ON

Load change compensation gain [%]90

Load change compensation filter [0.01 ms]590

Load estimation filter [0.01 ms]4

Torque compensation frequency 1 [0.1 Hz]0

Torque compensation frequency 2 [0.1 Hz]0

Load estimation count0

5.2 2-stage Torque Filter Function

5.2.1 Function Overview

This function sets a 2-stage torque filter to suppress high-frequency vibration components that cannot be suppressed by the “[5.1 Torque Filter Function](#)” torque filter alone.

5.2.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> All control modes

5.2.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	42	B	2-stage torque filter time constant	0 to 2500	0.01 ms	Sets the 2-stage torque filter time constant. <ul style="list-style-type: none"> When Pr6.43 = 0 to 49 0 to 3: 2-stage torque filter disabled 4 to 2500: Setting value [$\times 0.01$ ms] When Pr6.43 = 50 to 1000 0: 2-stage torque filter disabled 1 to 3: 4 [$\times 0.01$ ms] 4 to 159: Setting value [$\times 0.01$ ms] 159 to 2500: 159 [$\times 0.01$ ms]
6	43	B	2-stage torque filter attenuation term	0 to 1000	—	Sets the 2-stage torque filter attenuation term. <ul style="list-style-type: none"> 0 to 49: Operates as the first order lag filter. 50 to 1000: Operates as the second order lag filter. With a setting value of 1000, becomes a second order lag filter with $\zeta = 1.0$. The smaller the setting value, the more it vibrates. Normally use with a setting value of 1000.


*1 For attributes, see “[7.1 List of Parameters](#)”.

The torque filter cut-off frequency of the 2-stage torque filter can be obtained using the following formula.


Cut-off frequency [Hz] $f_c = 1/(2 \pi \times \text{parameter setup value} \times 0.00001)$

2-stage torque filter characteristics figure

Frequency responses when first order lag filter



Frequency responses when second order lag filter



5.2.4 How to Use

5.2.4.1 For Manual Setting

If there is noticeable noise during operation, increase Pr6.42 “2-stage torque filter time constant”. The set value should be changed by increasing by 10% at a time. The larger the set value, the stronger the effect of the filter.

If set too large, control may become unstable and vibration may occur. Therefore, when increasing the set value, tune it while maintaining balance with other parameters (especially Pr1.01 “1st velocity loop gain”).

Pr6.43 “2-stage torque filter attenuation term” is normally used with a set value of 1000.


— Precautions —

- If Pr6.42 “2-stage torque filter time constant” is set too large, control may become unstable and vibration may occur.
- Changing Pr6.43 “2-stage torque filter attenuation term” during operation may cause vibration. Stop operation before making changes.


5.2.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

<< Procedure >>

1. Activate Set-up Support Software (PANATERM ver.7) .
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.




3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.

4. Click on the [Notch settings] button or “Notch settings” in blue text.



The advanced notch settings screen is displayed.

5. Tune the “2-stage torque filter time constant”. For details on parameter tuning, see [“5.2.4.1 For Manual Setting”](#).

When the “Display notch filter characteristics in a graph” check box is checked, the frequency response of the torque filter set here and the frequency response of the notch filter set separately as parameters are displayed on the frequency response graph.

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Resonance monitor Not detected

Resonance frequency [Hz] ① 5000

① "5000" is displayed until resonance is detected.

Tuning based on positioning operation

① To perform tuning based on the positioning operation, use the following settings 1 to 5.

Pr2.00 Adaptive filter mode 5: High-precision adaptive fl...

Tuning based on frequency characteristics ☐ Display notch filter characteristics in a...

Offset [dB] 0.0

	Frequency [Hz]	Width	Depth
1th notch	5000	2	0
2th notch	5000	2	0
3th notch ①	5000	2	0
4th notch ①	5000	2	0
5th notch	5000	2	0
Custom notch	5000	2	0

① The 3rd and 4th notches are automatically set depending on the setting for Pr2.00 Adaptive filter mode.

Torque filter

1st torque filter [0.01 ms]	10
2-stage torque filter time constant [0.01 ms]	0
2-stage torque filter attenuation term	1000

Mode setting 7:Customize2

Gain setting

Feedback gain setting - 16 +

1st velocity loop gain [0.1 Hz] 270

1st velocity integral time constant [0.01 ms] 210

Load fluctuation control function

Enabling this can more effectively suppress the effects of motion caused by friction or the movement of other axes, etc.
Use to suppress overshoot, etc. Be aware that increasing control may cause oscillation to occur.

Load fluctuation suppression function enabled ON

Load fluctuation suppression function automatic t... ON

Load change compensation gain [%] 90

Load change compensation filter [0.01 ms] 590

Load estimation filter [0.01 ms] 4

Torque compensation frequency 1 [0.1 Hz] 0

Torque compensation frequency 2 [0.1 Hz] 0

Load estimation count 0

5.3 Notch Filter Function

5.3.1 Function Overview

When the gain is increased, sounds and vibrations of specific frequencies in the high frequency range may occur. This function suppresses sound and vibration at specific frequencies in the high frequency range by setting a notch filter. Up to six notch filters (1st to 5th notch filters and a custom notch filter) can be set simultaneously for different vibration frequencies.

5.3.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> All control modes

5.3.3 Related Parameters


Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	01	B	1st notch frequency	10 to 5000	Hz	Sets 1st notch filter center frequency. A setup value of 5000 disables the notch filter.
2	02	B	1st notch width selection	0 to 20	—	Sets 1st notch filter frequency width.
2	03	B	1st notch depth selection	0 to 99	—	Sets depth in 1st notch filter center frequency.
2	04	B	2nd notch frequency	10 to 5000	Hz	Sets 2nd notch filter center frequency. A setup value of 5000 disables the notch filter.
2	05	B	2nd notch width selection	0 to 20	—	Sets 2nd notch filter frequency width.
2	06	B	2nd notch depth selection	0 to 99	—	Sets depth in 2nd notch filter center frequency.
2	07	B	3rd notch frequency	10 to 5000	Hz	Sets 3rd notch filter center frequency. A setup value of 5000 disables the notch filter. The parameter value is set automatically when the adaptive filter function is used.
2	08	B	3rd notch width selection	0 to 20	—	Sets 3rd notch filter frequency width. The parameter value is set automatically when the adaptive filter function is used.
2	09	B	3rd notch depth selection	0 to 99	—	Sets depth in 3rd notch filter center frequency. The parameter value is set automatically when the adaptive filter function is used.
2	10	B	4th notch frequency	10 to 5000	Hz	Sets 4th notch filter center frequency. A setup value of 5000 disables the notch filter. The parameter value is set automatically when the adaptive filter function is used.
2	11	B	4th notch width selection	0 to 20	—	Sets 4th notch filter frequency width. The parameter value is set automatically when the adaptive filter function is used.
2	12	B	4th notch depth selection	0 to 99	—	Sets depth in 4th notch filter center frequency. The parameter value is set automatically when the adaptive filter function is used.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	24	B	5th notch frequency	10 to 5000	Hz	Sets 5th notch filter center frequency. A setup value of 5000 disables the notch filter.
2	25	B	5th notch width selection	0 to 20	—	Sets 5th notch filter frequency width.
2	26	B	5th notch depth selection	0 to 99	—	Sets depth in 5th notch filter center frequency.
2	39	B	Custom notch compensation coefficient	0 to 1000	0.01	Sets the custom notch compensation coefficient. A set value of 100 or less disables compensation. Normally, leave it at the initial value.
2	40	B	Custom notch compensation frequency 1	0 to 10000	0.1 Hz	Sets custom notch compensation frequency 1. A setup value of 0 disables compensation. Normally, leave it at the initial value.
2	41	B	Custom notch compensation frequency 2	0 to 10000	0.1 Hz	Sets custom notch compensation frequency 2. A setup value of 0 disables compensation. Normally, leave it at the initial value.
2	42	B	Custom notch frequency	10 to 5000	Hz	Sets the notch frequency of the custom notch filter. A setup value of 5000 disables the custom notch filter.
2	43	B	Custom notch width	0 to 20	—	Sets the notch width of the custom notch filter.
2	44	B	Custom notch depth	0 to 99	—	Sets the notch depth of the custom notch filter.

*1 For attributes, see “7.1 List of Parameters”.

■ Notch filter set values

Notch filter frequency response



Notch frequency

The frequency at which the most gain is attenuated.

Notch depth

The input/output ratio (attenuation rate) for the notch frequency.

The notch depth values corresponding to the set values are shown in the table below.

For the input in notch frequency, a set value of 0 is complete cutoff and a set value of 100 is complete pass.

Notch width

The frequency bandwidth in which the attenuation ratio is -3 dB when the notch depth set value is 0 (complete cutoff).

This is expressed as a ratio to the notch frequency.

The notch width values for the set values are shown in the table below.

Relation between notch depth set value and notch depth

Notch depth set value Pr2.03, Pr2.06, Pr2.09, Pr2.12, Pr2.26, Pr2.44	Notch depth (ratio)	Notch depth ([dB] display)
0	0.00	-∞
1	0.01	-40.0
2	0.02	-34.0
3	0.03	-30.5
4	0.04	-28.0
5	0.05	-26.0
6	0.06	-24.4
7	0.07	-23.1
8	0.08	-21.9
9	0.09	-20.9
10	0.10	-20.0
15	0.15	-16.5
20	0.20	-14.0
25	0.25	-12.0
30	0.30	-10.5
35	0.35	-9.1
40	0.40	-8.0
45	0.45	-6.9
50	0.50	-6.0
60	0.60	-4.4
70	0.70	-3.1
80	0.80	-1.9
90	0.90	-0.9
100	1.00	0.0


Relation between notch width set value and notch width

Notch width set value Pr2.02, Pr2.05, Pr2.08, Pr2.11, Pr2.25, Pr2.43	Notch width
0	0.25
1	0.3
2	0.35
3	0.42
4	0.5
5	0.59
6	0.71
7	0.84
8	1.00
9	1.19
10	1.41
11	1.68
12	2.00
13	2.38
14	2.83
15	3.36
16	4.00
17	4.76
18	5.66
19	6.73
20	8.00

Example of notch filter characteristics

The following is an example of the change in characteristics when the notch frequency setting is fixed and the notch depth and notch width settings are changed.

(Example) For a notch frequency of 100 Hz



— Precautions —

- If the notch filter parameters are not set normally, noise and vibration may increase.
- Using more notch filters may cause unstable control and vibration.
- If the notch filter frequency is too low, control may become unstable and vibration may occur.
- Note that when adaptive filter is enabled, parameters of either or both the 3rd notch filter and 4th notch filter cannot be set manually, but are automatically set (overwritten) by adaptive operation. For details, see [“5.4 Adaptive Filter Function”](#).

5.3.4 How to Use


5.3.4.1 For Manual Setting

Tune using an adaptive filter. For details, see [“5.4 Adaptive Filter Function”](#).


5.3.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

<< Procedure >>

1. Activate Set-up Support Software (PANATERM ver.7).
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.




3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.

4. Click on the [Notch settings] button or “Notch settings” in blue text.



The advanced notch settings screen is displayed.

5. Set “Tuning based on positioning operation” or “Tuning based on frequency characteristics”.

Settings can be configured from either menu, but usually settings are configured using “Tuning based on positioning operation”.

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Resonance monitor Not detected

Resonance frequency [Hz] ① 5000

① "5000" is displayed until resonance is detected.

Tuning based on positioning operation

① To perform tuning based on the positioning operation, use the following settings 1 to 5.

Pr2.00 Adaptive filter mode 5: High-precision adaptive fl...

Tuning based on frequency characteristics ☐ Display notch filter characteristics in a...

Offset [dB] 0.0

	Frequency [Hz]	Width	Depth
1th notch	5000	2	0
2th notch	5000	2	0
3th notch ①	5000	2	0
4th notch ①	5000	2	0
5th notch	5000	2	0
Custom notch	5000	2	0

① The 3rd and 4th notches are automatically set depending on the setting for Pr2.00 Adaptive filter mode.

Torque filter

1st torque filter [0.01 ms] 10

2-stage torque filter time constant [0.01 ms] 0

2-stage torque filter attenuation term 1000

Mode setting 7:Customize2

Gain setting

Feedback gain setting - 16 +

1st velocity loop gain [0.1 Hz] 270

1st velocity integral time constant [0.01 ms] 210

Load fluctuation control function

Enabling this can more effectively suppress the effects of motion caused by friction or the movement of other axes, etc.
Use to suppress overshoot, etc. Be aware that increasing control may cause oscillation to occur.

Load fluctuation suppression function enabled ON

Load fluctuation suppression function automatic t... ON

Load change compensation gain [%] 90

Load change compensation filter [0.01 ms] 590

Load estimation filter [0.01 ms] 4

Torque compensation frequency 1 [0.1 Hz] 0

Torque compensation frequency 2 [0.1 Hz] 0

Load estimation count 0

- To set with “Tuning based on positioning operation”

Up to two adaptive filters can be used for auto tuning.

For details, see [“5.4 Adaptive Filter Function”](#).

- To set with “Tuning based on frequency characteristics”

Make the following preparations.

- Measure frequency response. For details, see [“6.2 Frequency Response Measurement”](#).
- Turn the servo off.

Set according to the following procedure.

- 1 Read the resonance frequency (the frequency with the highest gain peak) from the measurement results and set that frequency as the notch frequency.
- 2 Check the “Display notch filter characteristics in a graph” check box. The notch filter characteristics configured are displayed on the graph screen (frequency response).
- 3 Tune the notch width and notch depth settings so that the resonance shape in the measurement results is inverted vertically compared to the shape of the notch filter.

— Precautions —

- Noise and vibration may not be suppressed if the lowest notch frequency is lower than the Pr1.01 “1st velocity loop gain” setting frequency or close to the Pr1.01 “1st velocity loop gain” setting frequency.


When this happens, click the [Basic] button to return to the “Manual TUNING” screen, lower the feedback gain setting, and then tune the notch filter.

5.4 Adaptive Filter Function

5.4.1 Function Overview

This function auto tunes parameters related to notch filters by estimating the resonance frequency from vibration components that appear due to motor speed during actual operation. Up to two notch filters (3rd notch filter and 4th notch filter) can be tuned automatically.

Adaptive filter operation image



5.4.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Position control, speed control, and full-closed control

Under the following conditions, adaptive filters may not work normally. In such cases, set the notch filters manually to suppress resonance.

Item	Conditions that obstruct the operation of adaptive filters
Resonance	<ul style="list-style-type: none"> Resonance frequency is less than three times the speed response frequency [Hz] When the resonance peak is low or the control gain is low and the effect is not apparent in the motor speed When there are three or more resonance points
Load	<ul style="list-style-type: none"> When motor speed fluctuations with high-frequency components occur due to non-linear characteristics such as backlash
Command pattern	<ul style="list-style-type: none"> When acceleration and deceleration are 30000 r/min or more every second
Other	<ul style="list-style-type: none"> In the event of sudden disturbances such as a collision

5.4.3 Related Parameters

—: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	00	B	Adaptive filter mode setup	0 to 6	—	<p>Sets adaptive filter operation mode.</p> <p>When changing modes, temporarily set this parameter to 0 (adaptive filter disabled) or 4 (adaptation results cleared). Then set this parameter to the next value to be changed.</p> <p>0: Disable adaptive filter Adaptive filter is disabled. Maintains current values of parameters related to 3rd and 4th notch filters.</p> <p>1: Enable one adaptive filter One adaptive filter is enabled. Updates parameters related to 3rd notch filter according to adaptation results.</p> <p>2: Enable two adaptive filters Two adaptive filters are enabled. Updates parameter related to 3rd and 4th notch filters according to adaptation results.</p> <p>3: Resonance frequency measurement mode Measures resonance frequency. Measurement results can be checked using the Set-up Support Software (PANATERM ver.7) . Retains current values of parameters related to 3rd and 4th notch filters.</p> <p>4: Clear adaptation results Clears adaptation results by disabling parameters related to 3rd and 4th notch filters.</p> <p>5: High-precision adaptive filter Two adaptive filters are enabled. Updates parameter related to 3rd and 4th notch filters according to adaptation results.</p> <p>Adaption performance is improved using setting value 2. Set this setting value when two adaptive filters are used.</p> <p>6: Manufacturer use (setting is prohibited) Do not use this setting value.</p>

*1 For attributes, see “7.1 List of Parameters” .

The following parameters are set automatically when adaptive filter is enabled.

—: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	07	B	3rd notch frequency	10 to 5000	Hz	<p>The 1st resonance frequency estimated by the adaptive filter is automatically set.</p> <p>Is set to 5000 when the resonance point cannot be found.</p>
2	08	B	3rd notch width selection	0 to 20	—	Set automatically when adaptive filter is enabled.
2	09	B	3rd notch depth selection	0 to 99	—	Set automatically when adaptive filter is enabled.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	10	B	4th notch frequency	10 to 5000	Hz	The 2nd resonance frequency estimated by the adaptive filter is automatically set. Is set to 5000 when the resonance point cannot be found.
2	11	B	4th notch width selection	0 to 20	—	Set automatically when two adaptive filters are enabled or a high-precision adaptive filter is used.
2	12	B	4th notch depth selection	0 to 99	—	Set automatically when two adaptive filters are enabled or a high-precision adaptive filter is used.

*1 For attributes, see [“7.1 List of Parameters”](#).

5.4.4 How to Use

5.4.4.1 For Manual Setting

<< Procedure >>

1. When Pr2.07 “3rd notch frequency” and Pr2.10 “4th notch frequency” are set to a value other than 5000 (disabled), set Pr2.00 “Adaptive filter mode setup” = 4 and initialize 3rd notch frequency and 4th notch frequency. Then, set Pr2.00 “Adaptive filter mode setup” to 1, 2, or 5 to enable the adaptive filter (5 is recommended).
2. Run the motor in actual operation. When the effect of the resonance point is apparent in the motor speed, the parameters of one or both of the 3rd notch filter and 4th notch filter are automatically set, depending on the number of adaptive filters.


— Precautions —

- Abnormal noise or oscillation may occur until the adaptive filter stabilizes, such as immediately after the first servo-on after activating the motor, or when the stiffness setting is increased when real-time auto tuning is enabled. However, if oscillation or continuous abnormal noise for three or more reciprocating operations occur frequently, take the following measures.
 - 1 Write the parameters to EEPROM once in normal operation.
 - 2 Lower the set value for Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2” or Pr0.03 “Real-time auto-tuning machine stiffness setup”.
 - 3 Set Pr2.00 “Adaptive filter mode setup” to 0 to disable the adaptive filter.
 - 4 Manually set the notch filter.
- After an abnormal noise or oscillation occurs, the 3rd notch filter and 4th notch filter settings may have changed to extreme values. When this happens, disable the adaptive filter once using the procedure “1” to “3” above. Then, enable the adaptive filter again (set Pr2.00 “Adaptive filter mode setup” to either 1, 2, or 5 (5 is recommended)).
- Pr2.07 “3rd notch frequency” and Pr2.10 “4th notch frequency” are written to EEPROM every 30 minutes. When power is restored, the adaptive filter starts processing with this data as the initial values.
- Depending on the Pr2.00 “Adaptive filter mode setup” set value, parameters of one or both of the 3rd notch filter and 4th notch filter are automatically set. Note that these parameters are automatically updated.


5.4.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

<< Procedure >>

1. Activate Set-up Support Software (PANATERM ver.7) .
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.




3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.

4. Click on the [Notch settings] button or “Notch settings” in blue text.



The advanced notch settings screen is displayed.

5. In “Pr2.00 Adaptive filter mode” select “4: Clear adaptive results” from the drop-down list to initialize the 3rd notch and 4th notch.

Next, select either “1: One adaptive filter enabled”, “2: Two adaptive filters enabled” or “5: High-precision adaptive filter” to enable the adaptive filter (“5: High-precision adaptive filter” is recommended).

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Resonance monitor Not detected

Resonance frequency [Hz] ⓘ 5000

ⓘ "5000" is displayed until resonance is detected.

Tuning based on positioning operation

ⓘ To perform tuning based on the positioning operation, use the following settings 1 to 5.

Pr2.00 Adaptive filter mode 5: High-precision adaptive fi...

Tuning based on frequency characteristics ☐ Display notch filter characteristics in a...

Offset [dB] 0.0

	Frequency [Hz]	Width	Depth
1st notch	5000	2	0
2nd notch	5000	2	0
3rd notch ⓘ	5000	2	0
4th notch ⓘ	5000	2	0
5th notch	5000	2	0
Custom notch	5000	2	0

ⓘ The 3rd and 4th notches are automatically set depending on the setting for Pr2.00 Adaptive filter mode.

Torque filter

1st torque filter [0.01 ms] 10

2-stage torque filter time constant [0.01 ms] 0

2-stage torque filter attenuation term 1000

Mode setting 7:Customize2

Gain setting

Feedback gain setting - 16 +

1st velocity loop gain [0.1 Hz] 270

1st velocity integral time constant [0.01 ms] 210

Load fluctuation control function

Enabling this can more effectively suppress the effects of motion caused by friction or the movement of other axes, etc.
Use to suppress overshoot, etc. Be aware that increasing control may cause oscillation to occur.

Load fluctuation suppression function enabled ☒

Load fluctuation suppression function automatic t... ☒

Load change compensation gain [%] 90

Load change compensation filter [0.01 ms] 590

Load estimation filter [0.01 ms] 4

Torque compensation frequency 1 [0.1 Hz] 0

Torque compensation frequency 2 [0.1 Hz] 0


Load estimation count 0

6. Click the [Basic] button to return to the “Manual TUNING” screen. Check that automatic setting is turned ON for the notch filter.
7. Operate the motor. When the effect of the resonance point is apparent in the motor speed, the parameters of one or both of the 3rd notch filter and 4th notch filter are automatically set, depending on the number of adaptive filters.

5.5 Damping Control Function

5.5.1 Function Overview

This function reduces residual vibration of approximately 100 Hz or less that occurs at the moving part tip or the overall device during positioning operation by setting a damping filter. Positioning settling time can be shortened by reducing residual vibration. Up to three of the four damping filters can be used simultaneously.



5.5.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Position control and full-closed control

Under the following conditions, damping control may not work normally, and its effects may not be seen.

Item	Conditions that obstruct the operation of damping control
Load conditions	<ul style="list-style-type: none"> When vibration is excited by primary causes other than commands (external forces, etc.) When the ratio of resonance frequency to antiresonance frequency is large When the vibration frequency is outside the range of 0.5 to 300.0 Hz

5.5.3 Related Parameters

—: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	13	B	Selection of damping filter switching	0 to 7	—	Sets the switching method of the four filters used for damping control. For details, see "Pr2.13 "Selection of damping filter switching" details" below.
2	14	B	1st damping frequency	0 to 3000	0.1 Hz	<p>Sets the 1st control frequency of damping control that suppresses the vibration at load edge. Measure the frequency of vibration at load edge and set it in units of 0.1 Hz.</p> <p>The valid frequency range for the setting is 0.5 to 300.0 Hz. Disabled if the setting value is set to 0 to 4.</p>

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	15	B	1st damping filter setup	0 to 1500	0.1 Hz	When the 1st damping frequency is set to enabled, set it smaller if torque saturation occurs, and set it larger to speed up operation. Use 0 under normal conditions. The setting value is capped by the corresponding damping frequency, or (3000-damping frequency), whichever is smaller.
6	41	B	1st damping depth	0 to 1000	—	Sets the depth for the 1st damping frequency. Setting value 0 is the deepest, and the larger the setting value, the shallower the depth. The deeper the depth, the better the damping effect, but the greater the delay. As the depth decreases, the delay decreases, but the damping effect also decreases. Use the parameter to make fine adjustments to the damping effect and delay.
2	27	B	1st damping width setting	0 to 1000	—	Sets width for the 1st control frequency. The valid range of setting is 10 to 1000, and 0 to 9 works as setup value 100. Within the effective range, the larger the value, the wider the width, improving the robustness against changes in vibration.
2	16	B	2nd damping frequency	0 to 3000	0.1 Hz	Sets the 2nd control frequency of damping control that suppresses the vibration at load edge. Measure the frequency of vibration at load edge and set it in units of 0.1 Hz. The valid frequency range for the setting is 0.5 to 300.0 Hz. Disabled if the setting value is set to 0 to 4.
2	17	B	2nd damping filter setup	0 to 1500	0.1 Hz	When the 2nd damping frequency is set to enabled, set it smaller if torque saturation occurs, and set it larger to speed up operation. Use 0 under normal conditions. The setting value is capped by the corresponding damping frequency, or (3000-damping frequency), whichever is smaller.
6	60	B	2nd damping depth	0 to 1000	—	Sets the depth for the 2nd damping frequency. Setting value 0 is the deepest, and the larger the setting value, the shallower the depth. The deeper the depth, the better the damping effect, but the greater the delay. As the depth decreases, the delay decreases, but the damping effect also decreases. Use the parameter to make fine adjustments to the damping effect and delay.
2	28	B	2nd damping width setting	0 to 1000	—	Sets width for the 2nd control frequency. The valid range of setting is 10 to 1000, and 0 to 9 works as setup value 100. Within the effective range, the larger the value, the wider the width, improving the robustness against changes in vibration.
2	18	B	3rd damping frequency	0 to 3000	0.1 Hz	Sets the 3rd control frequency of damping control that suppresses the vibration at load edge. Measure the frequency of vibration at load edge and set it in units of 0.1 Hz. The valid frequency range for the setting is 0.5 to 300.0 Hz. Disabled if the setting value is set to 0 to 4.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	19	B	3rd damping filter setup	0 to 1500	0.1 Hz	When the 3rd damping frequency is set to enabled, set it smaller if torque saturation occurs, and set it larger to speed up operation. Use 0 under normal conditions. The setting value is capped by the corresponding damping frequency, or (3000-damping frequency), whichever is smaller.
6	71	B	3rd damping depth	0 to 1000	—	Sets the depth for the 3rd damping frequency. Setting value 0 is the deepest, and the larger the setting value, the shallower the depth. The deeper the depth, the better the damping effect, but the greater the delay. As the depth decreases, the delay decreases, but the damping effect also decreases. Use the parameter to make fine adjustments to the damping effect and delay.
2	29	B	3rd damping width setting	0 to 1000	—	Sets width for the 3rd control frequency. The valid range of setting is 10 to 1000, and 0 to 9 works as setup value 100. Within the effective range, the larger the value, the wider the width, improving the robustness against changes in vibration.
2	20	B	4th damping frequency	0 to 3000	0.1 Hz	Sets the 4th control frequency of damping control that suppresses the vibration at load edge. Measure the frequency of vibration at load edge and set it in units of 0.1 Hz. The valid frequency range for the setting is 0.5 to 300.0 Hz. Disabled if the setting value is set to 0 to 4.
2	21	B	4th damping filter setup	0 to 1500	0.1 Hz	When the 4th damping frequency is set to enabled, set it smaller if torque saturation occurs, and set it larger to speed up operation. Use 0 under normal conditions. The setting value is capped by the corresponding damping frequency, or (3000-damping frequency), whichever is smaller.
6	72	B	4th damping depth	0 to 1000	—	Sets the depth for the 4th damping frequency. Setting value 0 is the deepest, and the larger the setting value, the shallower the depth. The deeper the depth, the better the damping effect, but the greater the delay. As the depth decreases, the delay decreases, but the damping effect also decreases. Use the parameter to make fine adjustments to the damping effect and delay.
2	30	B	4th damping width setting	0 to 1000	—	Sets width for the 4th control frequency. The valid range of setting is 10 to 1000, and 0 to 9 works as setup value 100. Within the effective range, the larger the value, the wider the width, improving the robustness against changes in vibration.
2	50	B	Detection start vibration count	0 to 100	—	This parameter is related to automatic frequency settings for damping control, and sets the number of vibrations for the position deviation that starts the vibration frequency detection process after the command is completed.
2	51	B	Detected vibration amplitude	0 to 134217728	Command unit	This parameter is related to automatic frequency settings for damping control, and sets the vibration amplitude for the position deviation detected as vibrations after the command is completed. If 0, the parameters are set automatically inside the driver.

*1 For attributes, see [“7.1 List of Parameters”](#).

■ Pr2.13 “Selection of damping filter switching” details

Setup value	Description					
0	Each damping control filter can be enabled or disabled as follows.					
	Setup value	1st damping	2nd damping	3rd damping	4th damping	
	0	Enabled	Enabled	Disabled	Disabled	
1 to 2	Manufacturer use (setting is prohibited)					
3	Depending on the direction of the position command, each damping control filter is switched between enabled and disabled as follows.					
	Setup value	Position command direction	1st damping	2nd damping	3rd damping	4th damping
	3	Positive direction	Enabled	Disabled	Enabled	Disabled
		Negative direction	Disabled	Enabled	Disabled	Enabled
4 to 6	Depending on the control mode, each damping control filter is switched between enabled and disabled as follows.					
	Position Control (Two-degree-of-freedom Control Mode Enabled)					
	Setup value	Position command direction	1st model-type damping control		2nd model-type damping control	
	4	—	Enabled		Enabled	
	5	—	Manufacturer use (setting is prohibited)			
	6	Positive direction	Enabled		Disabled	
		Negative direction	Disabled		Enabled	
	Position Control (Two-degree-of-freedom Control Mode Disabled)					
	Setup value	1st damping	2nd damping	3rd damping	4th damping	
	4	Enabled	Enabled	Enabled	Disabled	
	5, 6	Enabled	Enabled	Disabled	Disabled	
	Full-closed Control					
	Setup value	1st damping	2nd damping	3rd damping	4th damping	
	4 to 6	Enabled	Enabled	Disabled	Disabled	
7	Depending on the control mode, each damping control filter is switched between enabled and disabled as follows.					
	Position Control (Two-degree-of-freedom Control Mode Enabled), Full-closed Control					
	Setup value	1st damping	2nd damping	3rd damping	4th damping	
	7	Enabled	Enabled	Enabled	Disabled	
	Position Control (Two-degree-of-freedom Control Mode Disabled)					
	Setup value	1st damping	2nd damping	3rd damping	4th damping	
	7	Enabled	Enabled	Disabled	Disabled	

5.5.4 How to Use

5.5.4.1 For Manual Setting


Depending on the Pr2.13 “Selection of damping filter switching” setting, the damping filters that can be used may be limited. Check before tuning.

<< Procedure >>

1. Tune the damping frequency (Pr2.14, Pr2.16, Pr2.18, Pr2.20).

Measure the vibration frequency at the tip of the device. If the tip vibration can be measured directly with a laser displacement meter or similar instrument, the vibration frequency is read from the measured waveform in 0.1 Hz increments and set for each parameter.

If there is no measuring instrument, the frequency is read from the residual vibration of the position deviation measured by the vibration frequency monitor using Set-up Support Software (PANATERM ver.7) or the waveform measurement function, and then set for each parameter.




2. Tune the damping filter settings (Pr2.15, Pr2.17, Pr2.19, Pr2.21).

Initially, set each parameter to 0 to check the position deviation waveform and torque waveform during operation.

To shorten the settling time, gradually increase the damping filter setting from 0. The amount of change in the set value per change is approximately 10% of the damping frequency. If increased too much, torque saturation (hitting the torque limit) occurs as shown in the figure below, causing vibration suppression to be ineffective. Tune within the range where torque saturation does not occur under actual operating conditions.

Note that the damping filter setting is limited by the following equation.

$$10.0 \text{ Hz} - \text{Damping frequency} \leq \text{Damping filter setting} \leq \text{Damping frequency}$$



3. Tune the damping depth settings (Pr6.41, Pr6.60, Pr6.71, Pr6.72) and damping width settings (Pr2.27, Pr2.28, Pr2.29, Pr2.30).


Initially, set each parameter to 0 to check for tip vibration or residual vibration in the position deviation waveform.

To further increase the effectiveness of vibration suppression, gradually increase the damping depth setting from 0 (make it shallower). The amount of change in the set value per change is approximately 50.

To reduce delays in command responses, set a smaller (narrower) damping width setting. To track fluctuations in vibration frequency, increase (widen) the damping width setting. The amount of change in the set value per change is approximately 20 for each.

— Precautions —

- Parameter switching when changing damping filter-related parameter settings




- If damping filter-related parameters (damping frequency, damping filter setup, damping depth and damping width settings) are changed during command input, parameter switching occurs at the rising up of the command (before position command filter) from 0 during positioning complete (In-position) output.
- When the positioning complete (in-position) range is set to a large value, a large accumulated pulse (the area obtained by integrating the difference between the position command before the filter and the position command after the filter over time) may remain in the filter during parameter switching. In particular, if the setting is changed to increase damping frequency or disable the filter, the motor may temporarily run at a higher speed than the original command speed because the accumulated pulses are transferred rapidly when switching occurs. Take due care.
- After changing the parameter settings of the filter during velocity control or torque control, the setting will not change even if the control mode is changed to position control.

5.5.4.2 When Set-up Support Software (PANATERM ver.7) Is Used


<< Procedure >>

1. Activate Set-up Support Software (PANATERM ver.7) .

2. Select one device that you want to tune in the device tree and click the “Tuning” tab.




3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.

4. Click on the [Damping settings] button or “Damping settings” in blue text.



The advanced damping settings screen is displayed.

Manual TUNING

Selected driver:Axis0_No name set

Basic

Load characteristic settings

Notch settings

Damping settings

Application

Manual

Vibration monitor

Not detected

Vibration frequency [Hz]

0.0

0.0 is displayed until vibration is detected

Damping filter setup

Pr2.13 Damping filter switching

0: Use up to two simultaneo...

Automatic frequency setting

1st damping frequency

When vibrations are detected, the vibration frequency value is automatically applied to the damping frequency of the target filter.

IN

FIR filter

Automatic setting

Pr2.23 Positional command FIR filter [0.1 ms]

10

Smoothing filter

Pr2.22 Positional command smoothing filter...

37

Pr6.49 Command response filter attenuation...

5: 1

Damping filter 1

Pr2.14 1st damping frequency [0.1 Hz]

0

Pr2.15 1st damping filter setup [0.1 Hz]

0

Pr2.27 1st damping width setting

0

Pr6.41 1st damping depth

0

Damping filter 2

Pr2.16 2nd damping frequency [0.1 Hz]

0

Pr2.17 2nd damping filter setup [0.1 Hz]

0

Pr2.28 2nd damping width setting

0

Pr6.60 2nd damping depth

0

OUT

Tuning filter

Filter function switching

A7 mode

Tuning filter time constant[0.01ms]

4

Pr6.49 Tuning filter attenuation term setup

1: No attenuation term

— Precautions —

- The parameters displayed vary depending on the set value for “Pr2.13 Damping filter switching”.

5. Select “Pr2.13 Damping filter switching” from the drop-down list. For details, see [“5.5.3 Related Parameters”](#) .

— Precautions —

- Only damping filter parameters that can be used are displayed.

6. Select “Automatic frequency setting” from the drop-down list.

The choices displayed depend on the “Pr2.13 Damping filter switching” setting.

Automatic frequency setting	Description
Disabled	None of the damping frequencies are set automatically.
1st damping frequency	When vibrations are detected, the vibration frequency value is automatically applied to the damping frequency of the target filter.
2nd damping frequency	
3rd damping frequency	
4th damping frequency	

7. If not setting the damping frequency automatically with “Automatic frequency setting”, set “Automatic frequency setting” to “Disabled” and set manually.

For details on parameter settings, see [*“5.5.4.1 For Manual Setting”*](#) .

5.5.4.3 Error Troubleshooting

- When Err24.0.0 “Position deviation excess protection” occurs

Tuning related parameters may cause the position deviation excess setup value to deviate from the appropriate value.

Review the set value using the formula for calculating the position deviation excess setup value shown in Operating Instructions (Overall) “7.2.9 Before Gain Tuning Protection Function Setup” .

5.6 Model-type Damping Filter Function


5.6.1 Function Overview

This function reduces residual vibration of approximately 100 Hz or less that occurs at the moving part tip of the device during positioning operation by setting a model-type damping filter. Positioning settling time can be shortened by reducing residual vibration.

The model-type damping filter eliminates both resonance frequency components and antiresonance frequency components while increasing the effectiveness of conventional damping filters to achieve smooth torque commands and improve the damping effect.

By removing the antiresonance frequency components and resonance frequency components, the responsiveness of the command response filter can be increased and the settling time can be reduced.

However, to measure antiresonance frequency components and resonance frequency components, it is necessary to perform frequency characteristics analysis to set optimal parameter values, since vibration components cannot be acquired from position sensors, as is the case with conventional damping filters. (For details of conventional damping filters, see [“5.5 Damping Control Function”](#).)



5.6.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Position control and two-degree-of-freedom control mode enabled
Other	<ul style="list-style-type: none"> Set-up Support Software (PANATERM ver.7) is required.

Under the following conditions, the model-type damping filter may not work normally, and its effects may not be seen.

Item	Conditions that obstruct the operation of model-type damping filters
Load conditions	<ul style="list-style-type: none"> When vibration is excited by primary causes other than commands (external forces, etc.) When the resonance frequency and antiresonance frequency are not between 5.0 and 300.0 Hz

If the parameter settings are as follows, the filter operates as a conventional damping filter (see [“5.5 Damping Control Function”](#)).

Item	Conditions for operating as a conventional damping filter
Parameter set-up	<ul style="list-style-type: none"> When the resonance frequency and antiresonance frequency do not have the following relationship $5.0 \text{ Hz} \leq \text{antiresonance frequency} < \text{resonance frequency} \leq 300.0 \text{ Hz}$ When the response frequency and antiresonance frequency do not have the following relationship $5.0 \text{ Hz} \leq \text{antiresonance frequency} \leq \text{response frequency} \leq \text{antiresonance frequency} \times 4 \leq 300.0 \text{ Hz}$ When Pr2.13 “Selection of damping filter switching” is set to 4, both the 1st and 2nd model-type damping filters are enabled, and the ratio of the 1st and 2nd response frequencies and antiresonance frequencies multiplied exceeds 8 (in this case, only the 2nd model-type damping filter is a conventional type damping filter)

When operating as a conventional damping filter, the following three types of parameters of antiresonance frequency, anti-resonance damping ratio, and response frequency, are used as the damping frequency, damping depth and damping filter setting, respectively.

To completely disable this function, all five parameters (resonance frequency, resonance damping ratio, antiresonance frequency, anti-resonance damping ratio, response frequency) must be set to 0.

Pr6.61 “1st resonance frequency”, Pr6.66 “2nd resonance frequency”

Pr6.62 “1st resonance attenuation ratio”, Pr6.67 “2nd resonance attenuation ratio”

Pr6.63 “1st anti-resonance frequency”, Pr6.68 “2nd anti-resonance frequency”

Pr6.64 “1st anti-resonance attenuation ratio”, Pr6.69 “2nd anti-resonance attenuation ratio”

Pr6.65 “1st response frequency”, Pr6.70 “2nd response frequency”

5.6.3 Related Parameters

—: None

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	13	B	Selection of damping filter switching	0 to 7	—	Sets the switching method of the four filters used for damping control. For details, see “Pr2.13 “Selection of damping filter switching” details” below.
6	61	B	1st resonance frequency	0 to 3000	0.1 Hz	Sets model-type damping filter load resonance frequency.
6	62	B	1st resonance attenuation ratio	0 to 1000	—	Sets the model-type damping filter load resonance damping ratio. The damping ratio can be set as the setup value multiplied by 0.001. A setting value of 1000 results in an attenuation of 1 (no peak). The smaller the setting value, the smaller the damping ratio (higher resonance peak).
6	63	B	1st anti-resonance frequency	0 to 3000	0.1 Hz	Sets the model-type damping filter load anti-resonance frequency.
6	64	B	1st anti-resonance attenuation ratio	0 to 1000	—	Sets the model-type damping filter load anti-resonance damping ratio. The damping ratio can be set as the setup value multiplied by 0.001. A setting value of 1000 results in an attenuation of 1 (no peak). The smaller the setting value, the smaller the damping ratio (higher resonance peak).
6	65	B	1st response frequency	0 to 3000	0.1 Hz	Sets the model-type damping filter load response frequency.
6	66	B	2nd resonance frequency	0 to 3000	0.1 Hz	Sets the model-type damping filter load 2nd resonance frequency.
6	67	B	2nd resonance attenuation ratio	0 to 1000	—	Sets the model-type damping filter load 2nd resonance attenuation ratio. The damping ratio can be set as the setup value multiplied by 0.001. A setting value of 1000 results in an attenuation of 1 (no peak). The smaller the setting value, the smaller the damping ratio (higher resonance peak).
6	68	B	2nd anti-resonance frequency	0 to 3000	0.1 Hz	Sets the model-type damping filter load 2nd anti-resonance frequency.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	69	B	2nd anti-resonance attenuation ratio	0 to 1000	—	Sets the model-type damping filter load 2nd anti-resonance attenuation ratio The damping ratio can be set as the setup value multiplied by 0.001. A setting value of 1000 results in an attenuation of 1 (no peak). The smaller the setting value, the smaller the damping ratio (higher resonance peak).
6	70	B	2nd response frequency	0 to 3000	0.1 Hz	Sets the model-type damping filter load 2nd response frequency. The unit is 0.1 Hz.

*1 For attributes, see “7.1 List of Parameters”.

■ Pr2.13 “Selection of damping filter switching” details

Setup value	Description					
0	Each damping control filter can be enabled or disabled as follows.					
	Setup value	1st damping	2nd damping	3rd damping	4th damping	
	0	Enabled	Enabled	Disabled	Disabled	
1 to 2	Manufacturer use (setting is prohibited)					
3	Depending on the direction of the position command, each damping control filter is switched between enabled and disabled as follows.					
	Setup value	Position command direction	1st damping	2nd damping	3rd damping	4th damping
	3	Positive direction	Enabled	Disabled	Enabled	Disabled
		Negative direction	Disabled	Enabled	Disabled	Enabled
4 to 6	Depending on the control mode, each damping control filter is switched between enabled and disabled as follows.					
	Position Control (Two-degree-of-freedom Control Mode Enabled)					
	Setup value	Position command direction	1st model-type damping control		2nd model-type damping control	
	4	—	Enabled		Enabled	
	5	—	Manufacturer use (setting is prohibited)			
	6	Positive direction	Enabled		Disabled	
		Negative direction	Disabled		Enabled	
	Position Control (Two-degree-of-freedom Control Mode Disabled)					
	Setup value	1st damping	2nd damping	3rd damping	4th damping	
	4	Enabled	Enabled	Enabled	Disabled	
5, 6	Enabled	Enabled	Disabled	Disabled		
Full-closed Control						
Setup value	1st damping	2nd damping	3rd damping	4th damping		
4 to 6	Enabled	Enabled	Disabled	Disabled		

Setup value	Description				
7	Depending on the control mode, each damping control filter is switched between enabled and disabled as follows.				
	Position Control (Two-degree-of-freedom Control Mode Enabled), Full-closed Control				
	Setup value	1st damping	2nd damping	3rd damping	4th damping
	7	Enabled	Enabled	Enabled	Disabled
	Position Control (Two-degree-of-freedom Control Mode Disabled)				
	Setup value	1st damping	2nd damping	3rd damping	4th damping
	7	Enabled	Enabled	Disabled	Disabled


5.6.4 How to Use

Manual setting is not possible. Use Set-up Support Software (PANATERM ver.7) .


5.6.4.1 When Set-up Support Software (PANATERM ver.7) Is Used

<< Procedure >>

- 1. Activate Set-up Support Software (PANATERM ver.7) .
- 2. Select one device that you want to tune in the device tree and click the “Tuning” tab.




3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.

4. Click on the [Damping settings] button or “Damping settings” in blue text.



The advanced damping settings screen is displayed.

Manual TUNING

Selected driver:Axis0_No name set

Basic

Load characteristic settings

Notch settings

Damping settings

Application

Manual

Vibration monitor

Not detected

Vibration frequency [Hz]0.0

0.0

 is displayed until vibration is detected

Damping filter setup

Pr2.13 Damping filter switching4: No switching (model type)

Automatic frequency settingDisabled

When vibrations are detected, the vibration frequency value is automatically applied to the damping frequency of the target filter.

IN

FIR filter

Automatic setting

Pr2.23 Positional command FIR filter [0.1 ms]

10

Smoothing filter

Pr2.22 Positional command smoothing filter...

37

Pr6.49 Command response filter attenuation...

5: 1

Model-type damping filter 1

Pr6.61 1st resonance frequency [0.1 Hz]

0

Pr6.62 1st resonance attenuation ratio

0

Pr6.63 1st anti-resonance frequency [0.1 Hz]

0

Pr6.64 1st anti-resonance attenuation ratio

0

Pr6.65 1st response frequency [0.1 Hz]

0

Model-type damping filter 2

Pr6.66 2nd resonance frequency [0.1 Hz]

0

Pr6.67 2nd resonance attenuation ratio

0

Pr6.68 2nd anti-resonance frequency [0.1 Hz]

0

Pr6.69 2nd anti-resonance attenuation ratio

0

Pr6.70 2nd response frequency [0.1 Hz]

0

OUT

Display model-type damping filter characteristics in a graph

Offset [dB]

0.0

Tuning filter

Filter function switching

A7 mode

Tuning filter time constant0.01ms]

4

Pr6.49 Tuning filter attenuation term setup

1: No attenuation term

— Precautions —

- The parameters displayed vary depending on the set value for “Pr2.13 Damping filter switching”.

5. Select “Pr2.13 Damping filter switching” from the drop-down list. For details, see [“5.6.3 Related Parameters”](#).

— Precautions —

- Only parameters for model-type damping filter that can be used are displayed.

6. Frequency response is measured using the torque speed mode of the frequency response measurement function. For details, see [“6.2 Frequency Response Measurement”](#).

7. Read a maximum of two each of large peaks and troughs for gain from the measurement results, and set Pr6.61 “1st resonance frequency”, Pr6.63 “1st anti-resonance frequency”, Pr6.66 “2nd resonance frequency”, and Pr6.68 “2nd anti-resonance frequency”.

An example of measurement with a belt device is shown below. Ignoring small resonances, the resonance frequencies that are peaks of the gain, as well as the antiresonance frequencies that are troughs of the gain, are as follows.

1st resonance frequency = 130 Hz ((2) in the figure below), 1st anti-resonance frequency = 44 Hz ((1) in the figure below)

2nd resonance frequency = 285 Hz ((4) in the figure below), 2nd anti-resonance frequency = 180 Hz ((3) in the figure below)

Example of frequency response measurement results



8. For the 1st and 2nd resonance damping ratios and anti-resonance damping ratios, set the initial value to 50 (0.050).

Check the “Display model-type damping filter characteristics in a graph” check box to display the model-type damping filter characteristics based on the set parameter.


The validity of the set parameters can be checked by comparing them with the measurement results for frequency response.

9. Set response frequency to the same value as antiresonance frequency.

- 10.** Run the motor to check for tip vibration or residual vibration in the position deviation waveform. Then, fine tune the parameters in the following order to reduce vibration components.
- Pr6.63 “1st anti-resonance frequency” > Pr6.64 “1st anti-resonance attenuation ratio” > Pr6.61 “1st resonance frequency” > Pr6.62 “1st resonance attenuation ratio”
 - Pr6.68 “2nd anti-resonance frequency” > Pr6.69 “2nd anti-resonance attenuation ratio” > Pr6.66 “2nd resonance frequency” > Pr6.67 “2nd resonance attenuation ratio”
- 11.** Find the setting with the lowest vibration and increase the response frequency setting. Although higher frequencies result in less control delay caused by the model-type damping filter, they also result in gradual decreases in damping effectiveness. This makes it important to find a balanced setting. Note that, according to the specifications of the model-type damping filter, the response frequency setting should be less than four times the antiresonance frequency.

— Precautions —

- Parameter switching when changing model-type damping filter-related parameter settings



- If the model-type damping filter-related parameters (resonance frequency, resonance damping ratio, antiresonance frequency, anti-resonance damping ratio, and response frequency) are changed during command input, parameter switching occurs at the rising up of the command (before position command filter) from 0 during positioning complete (in-position) output.
- When the positioning complete (in-position) range is set to a large value, a large accumulated pulse (the area obtained by integrating the difference between the position command before the filter and the position command after the filter over time) may remain in the filter during parameter switching. In particular, if the setting is changed to increase the antiresonance frequency or disable the filter, the motor may temporarily run at a higher speed than the original command speed because the accumulated pulses are transferred rapidly when switching occurs. Take due care.
- After changing the parameter settings of the filter during velocity control or torque control, the setting will not change even if the control mode is changed to position control.

5.6.4.2 Error Troubleshooting

- When Err24.0.0 “Position deviation excess protection” occurs

Tuning related parameters may cause the position deviation excess setup value to deviate from the appropriate value.

Review the set value using the formula for calculating the position deviation excess setup value shown in Operating Instructions (Overall) “7.2.9 Before Gain Tuning Protection Function Setup” .

5.7 Position Command Filter Function

5.7.1 Function Overview

A function that applies a positional command smoothing filter to a position command to gently accelerate or decelerate the motor. This is expected to suppress vibration and velocity change caused by the command resolution and command updating cycle roughness.

5.7.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Position control, speed control, and full-closed control

5.7.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	22	B	Positional command smoothing filter	0 to 10000	0.1 ms	<p>When two-degree-of-freedom control mode is enabled: Functions as a command response filter and sets the filter time constant.</p> <p>When two-degree-of-freedom control mode is disabled: Sets the time constant of the first order lag filter for the position command.</p>
2	23	B	Positional command FIR filter	0 to 10000	0.1 ms	Sets the average movement time for the position command.
6	49	B	Command response/tuning filter attenuation term	0 to 99	—	<p>Sets the “command response filter” and “tuning filter” attenuation terms in the two-degree-of-freedom control.</p> <ul style="list-style-type: none"> Sets each filter in decimal notation. <ul style="list-style-type: none"> Ones: Command response filter Tens: Tuning filter <p><Target digit setting values></p> <p>0 to 4: No attenuation terms (operates as first order lag filter)</p> <p>5 to 9: Attenuation term ζ is 1.0, 0.86, 0.71, 0.50, 0.35, in that order (operates as second order lag filter)</p> <p>< Example of this parameter setup ></p> <p>To set the command response filter to $\zeta = 1.0$ and the tuning filter to $\zeta = 0.71$, set the setting value to 75 (ones = 5 ($\zeta = 1.0$), tens = 7 ($\zeta = 0.71$)).</p> <p>Note that Pr2.22 “Positional command smoothing filter” is applied to the command response filter time constant.</p>

*1 For attributes, see “7.1 List of Parameters”.

— Precautions —

- Changing the damping control-related parameters changes the recommended setting value for position deviation excess protection.

As a result, the set value for position deviation may be too small to cause an unexpected error, or the set value may be too large to detect. Review the set values.

5.7.4 How to Use

■ Details on Pr2.22 “Positional command smoothing filter”

Setting the time constant of the command response filter


Set the time constant of the “command response filter” when two-degree-of-freedom control mode is enabled.

In the following cases, set the time constant of the first order lag filter or the second order lag filter based on the set value for the ones place of Pr6.49, “Command response filter attenuation term setup”.

- When two-degree-of-freedom control mode is enabled, and the set value for the ones place of Pr6.49, “Command response filter attenuation term setup”, is 5 to 9

Normally, the ones place of Pr6.49, “Command response filter attenuation term setup”, should be set to 5.

The figure below shows a waveform after filtering for the target speed V_c square wave command using a second-order lag filter.




Ones place of Pr6.49	Attenuation term value	K1	K2
5	1.0	4.7	1.00
6	0.86	3.8	1.01
7	0.71	2.9	1.04
8	0.5	2.3	1.16
9	0.35	2.0	1.31

Setting the time constant of the first order lag filter


Sets the time constant of the first order lag filter for the target speed V_c square wave command in the following cases.

- When two-degree-of-freedom control mode is disabled
- When two-degree-of-freedom control mode is enabled and the set value for the ones place of Pr6.49, “Command response filter attenuation term setup”, is 0 to 4



*1 The actual filter time constant is (set value $\times 0.1$ ms) with a relative error of up to 0.2% above 20 ms, and the error increases to a maximum of 0.4 ms until 100 ms.

*2 Parameter switching when changing Pr2.22 "Positional command smoothing filter" settings




- If the positional command smoothing filter-related parameters (Pr2.22 "Positional command smoothing filter", Pr6.49 "Command response/tuning filter attenuation term") are changed during command input, parameter switching occurs at the rising up of the command (before position command filter) from 0 during positioning complete (in-position) output.
- When the positioning complete (in-position) range is set to a large value, a large accumulated pulse (the area obtained by integrating the difference between the position command before the filter and the position command after the filter over time) may remain in the filter during parameter switching. In particular, if the setting is changed to reduce the positional command smoothing filter value or disable the filter, the motor may temporarily run at a higher speed than the original command speed because the accumulated pulses are transferred rapidly when switching occurs. Take due care.
- After changing the parameter settings of the filter during velocity control or torque control, the setting will not change even if the control mode is changed to position control.

- *3 There is a delay between when the set value for Pr2.22 “Positional command smoothing filter” is changed and when it is applied to the internal calculation. Therefore, if the switching of “*2” occurs during that delay period, the change may be put on hold.

■ Details on Pr2.23 “Positional command FIR filter”


For square wave commands

Sets the time to reach V_c for the target speed V_c square wave command. (See figure below)



For trapezoidal wave commands

If the position command is a trapezoidal wave, the waveform after passing through the filter will be an S-curve.



- *1 The actual average movement time has an absolute error of up to 0.2 ms for time periods of less than 10 ms and a relative error of up to 1.6% for time periods of 10 ms or more, with respect to (set value × 0.1 ms).
- *2 If the setting for Pr2.23 “Positional command FIR filter” is changed during command input, parameter switching will take place when the amount time remaining until the next command pulse is received exceeds the filter switch waiting time. The filter switching waiting time is (set value × 0.1 ms + 0.25 ms) for a set value of 10 ms or less and (set value × 0.1 ms × 1.05) for 10 ms or more.
- *3 There is a delay between when the set value for Pr2.23 “Positional command FIR filter” is changed and when it is applied to the internal calculation. Therefore, if the switching of “2” occurs during that delay period, the change may be put on hold.

5.7.4.1 For Manual Setting

<< Procedure >>

1. Tuning “FIR filter”

Tune Pr2.23 “Positional command FIR filter” to suppress vibration and velocity change caused by infrequent command updating cycles.

Tune the value of Pr2.23 “Positional command FIR filter” to a value greater than or equal to the command updating cycle.

2. Tuning “Smoothing filter”

Increase the set value of Pr2.22 “Positional command smoothing filter” to suppress vibration and velocity changes caused by command resolution. The set value should be changed by increasing by 10% at a time.

- If the beginning of the movement is vibratory, increasing the Pr2.22 “Positional command smoothing filter” set value results in a smoother movement, but with a longer command time. Tune to the optimal value.
- The ones place of Pr6.49 “Command response/tuning filter attenuation term” “Command response filter attenuation term setup” does not require tuning.
- When two-degree-of-freedom control mode is enabled, this functions as the command response filter. The smaller the set value, the smaller the delay caused by the filter, and thus the higher the command responsiveness.

— Precautions —


- Pr2.22 “Positional command smoothing filter” cannot be changed manually because it is automatically set based on the Pr0.28 “Selection of feed forward stiffness at real-time auto-gain tuning” set value when the auto tuning function is enabled in the two-degree-of-freedom control mode for standard type settings. If you want to change the parameters manually, set Pr0.02 “Real-time auto-gain tuning setup” to 0 (disabled) before changing. For details of the relationship between Pr0.28 “Selection of feed forward stiffness at real-time auto-gain tuning” and Pr2.22 “Positional command smoothing filter”, see [“4.1.1.6 Basic Gain Parameter Setup Table”](#).

5.7.4.2 When Set-up Support Software (PANATERM ver.7) Is Used


For manual setting, see “Step 5” onward.

<< Procedure >>

1. Activate Set-up Support Software (PANATERM ver.7).
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.




3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.

4. Click on the [Damping settings] button or “Damping settings” in blue text.



The advanced damping settings screen is displayed.

5. Tune the Pr2.23 Positional command FIR filter and the Pr2.22 Positional command smoothing filter.

Manual TUNING

Selected driver: Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

Vibration monitor Not detected

Vibration frequency [Hz] 0.0

① "0.0" is displayed until vibration is detected

Damping filter setup

Pr2.13 Damping filter switching 0: Use up to two simultaneo... ▾

Automatic frequency setting ① 1st damping frequency ▾

① When vibrations are detected, the vibration frequency value is automatically applied to the damping frequency of the target filter.

IN

■ FIR filter Automatic setting

Pr2.23 Positional command FIR filter [0.1 ms] 10

■ Smoothing filter

Pr2.22 Positional command smoothing filter... 37

Pr6.49 Command response filter attenuation... 5: 1 ▾

■ Damping filter 1

Pr2.14 1st damping frequency [0.1 Hz] 0

Pr2.15 1st damping filter setup [0.1 Hz] 0

Pr2.27 1st damping width setting 0

Pr6.41 1st damping depth 0

■ Damping filter 2

Pr2.16 2nd damping frequency [0.1 Hz] 0

Pr2.17 2nd damping filter setup [0.1 Hz] 0

Pr2.28 2nd damping width setting 0

Pr6.60 2nd damping depth 0

OUT

■ Tuning filter

Filter function switching A7 mode ▾

Tuning filter time constant [0.01 ms] 4

Pr6.49 Tuning filter attenuation term setup 1: No attenuation term ▾

- Tuning “FIR filter”

Tune Pr2.23 “Positional command FIR filter” to suppress vibration and velocity change caused by infrequent command updating cycles.

- To set automatically

Click the [Auto tuning] button. The Pr2.23 “Positional command FIR filter” value is automatically set based on the command updating cycle setting and communication cycle setting.

- To set manually

See “5.7.4.1 For Manual Setting”.

- Tuning “Smoothing filter”

Tune Pr2.22 “Positional command smoothing filter” to suppress vibration and velocity change caused by command resolution.

- See “5.7.4.1 For Manual Setting”.

5.7.4.3 Error Troubleshooting

- When Err24.0.0 “Position deviation excess protection” occurs

Tuning related parameters may cause the position deviation excess setup value to deviate from the appropriate value.

Review the set value using the formula for calculating the position deviation excess setup value shown in Operating Instructions (Overall) “7.2.9 Before Gain Tuning Protection Function Setup”.

5.8 Speed Command Acceleration/Deceleration Setting Function

5.8.1 Function Overview

This function performs speed control by applying a speed command for which acceleration and deceleration have been tuned inside the servo driver with respect to the speed command input from the host device. Smooth acceleration and deceleration is possible when stepwise speed commands are input.

To reduce shock caused by acceleration changes, the S-curve acceleration/deceleration function can be used to suppress vibration by reducing the change in acceleration at the start and end of acceleration.

5.8.2 Operational Conditions

Item	Operational Conditions
Control mode	<ul style="list-style-type: none"> Speed control

5.8.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
3	12	B	Acceleration time setup	0 to 10000	ms/ (1000 r/min)	Sets the acceleration time for acceleration processing with respect to speed command input.
3	13	B	Deceleration time setup	0 to 10000	ms/ (1000 r/min)	Sets the deceleration time for deceleration processing with respect to speed command input.
3	14	B	Sigmoid acceleration / deceleration time setup	0 to 1000	ms	Sets the S-curve time for acceleration/deceleration processing with respect to speed command input.

*1 For attributes, see [“7.1 List of Parameters”](#).

— Precautions —

- Do not use Pr3.12 “Acceleration time setup” and Pr3.13 “Deceleration time setup” if a position loop is configured outside the servo driver. Use all of the above settings with the value set to 0.


5.8.4 How to Use

■ Pr3.12 “Acceleration time setup” , Pr3.13 “Deceleration time setup”

When a stepwise speed command is input, these parameters set the time it takes for the speed command to reach 1000 r/min in Pr3.12 “Acceleration time setup”. They also set the time it takes for the speed command to reach 0 r/min from 1000 r/min in Pr3.13 “Deceleration time setup”. The time required for acceleration and deceleration can be calculated by the following formula, assuming the target value of the speed command is V_c [r/min].


$$\text{Acceleration time (ta) [ms]} = V_c/1000 \times \text{Pr3.12} \times 1 \text{ ms}$$

$$\text{Deceleration time (td) [ms]} = V_c/1000 \times \text{Pr3.13} \times 1 \text{ ms}$$



■ Pr3.14 “Sigmoid acceleration / deceleration time setup”


Sets the time of the S-curve part in the time width with the inflection point during acceleration and deceleration at the center and with respect to the acceleration and deceleration time set by Pr3.12 “Acceleration time setup” and Pr3.13 “Deceleration time setup”.



5.9 Hybrid Vibration Suppression Function

5.9.1 Function Overview

This function suppresses vibration caused by the amount of torsion between the motor and the load in full-closed control mode.



5.9.2 Operational Conditions

Item	Operational conditions
Control mode	<ul style="list-style-type: none"> Full-closed control

Under the following conditions, the effects of the hybrid vibration suppression function may not be seen.

Item	Conditions that obstruct operation of the hybrid vibration suppression function
Load conditions	<ul style="list-style-type: none"> Looseness, backlash, etc. are present and the load non-linearity is strong

5.9.3 Related Parameters

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	34	B	Hybrid vibration suppression gain	0 to 30000	0.1 s ⁻¹	Sets hybrid vibration suppression gain. Normally set to the same value as the position loop gain, and then fine-tune as necessary.
6	35	B	Hybrid vibration suppression filter	0 to 32000	0.01 ms	Sets the hybrid vibration suppression filter. Disabled when the set value is 0 to 3.

*1 For attributes, see [“7.1 List of Parameters”](#).

5.9.4 How to Use

5.9.4.1 For Manual Setting

<< Procedure >>


- Set Pr6.34 “Hybrid vibration suppression gain” to the same setting as the position loop gain (Pr1.00 “1st gain of position loop” or Pr1.05 “2nd gain of position loop”).

2. Set the Pr6.35 “Hybrid vibration suppression filter” [ms] value using the vibration cycle confirmed when this function is unused. This can be obtained with the following equation:
Pr6.35 “Hybrid vibration suppression filter” [Ms] value = vibration cycle/(2 π)
3. While driving in full-closed control, gradually increase the Pr6.35 “Hybrid vibration suppression filter” set value to check the change in response. The set value should be changed by increasing by 10% at a time. If the response seems to improve, tune Pr6.34 “Hybrid vibration suppression gain” and Pr6.35 “Hybrid vibration suppression filter” to find the combination that provides the best response.


5.9.4.2 When Set-up Support Software (PANATERM ver.7) Is Used

<< Procedure >>


1. Activate Set-up Support Software (PANATERM ver.7) .
2. Select one device that you want to tune in the device tree and click the “Tuning” tab.



3. In the “Tuning” tab screen, select “Manual TUNING”, and click the [Go to the Tuning screen] button.



The “Manual TUNING” settings screen is displayed.



4. Click the [Application] button.

<

Manual TUNING

Selected driver:Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

>

 Feedforward function

>

 Load fluctuation control function

>

 High response current control function

>

 Gain switching function

>

 Quadrant glitch suppression function

>

 Hybrid vibration suppression function

5. Click on “>” of “> Hybrid vibration suppression function” to expand “Hybrid vibration suppression function”.

<

Manual TUNING

Selected driver:Axis0_No name set

Basic	Load characteristic settings	Notch settings
Damping settings	Application	Manual

>

 Feedforward function

>

 Load fluctuation control function

>

 High response current control function

>

 Gain switching function

>

 Quadrant glitch suppression function

>

 Hybrid vibration suppression function

Enabling this suppresses oscillation.

Hybrid vibration suppression gain [0.1/s]

Hybrid vibration suppression filter [0.01 ms]

6. For details on tuning each parameter, see “5.9.4.1 For Manual Setting”.

6 Functions to Assist Tuning

- 6.1 Waveform Measurement 237
 - 6.1.1 Function Overview 237
 - 6.1.2 Purpose of Use 237
 - 6.1.3 Measurement Procedure..... 237
 - 6.1.4 Method of Use 239
- 6.2 Frequency Response Measurement 240
 - 6.2.1 Function Overview 240
 - 6.2.2 Types of Measurement Modes 240
 - 6.2.3 Changes from measurements using A6 Series drivers 241
 - 6.2.4 Restrictions 241
 - 6.2.5 Measurement Procedure..... 242
 - 6.2.6 Method of Use 248

6.1 Waveform Measurement

6.1.1 Function Overview

This function uses Set-up Support Software (PANATERM ver.7) .

This function draws up data stored inside drivers and motors into Set-up Support Software (PANATERM ver.7) as time-series data and displays it as waveform graphs.

Waveform graphs can also be displayed within the tuning function screens, such as One Minute TUNING, precAIse TUNING, and Manual TUNING, and can be used to check response during tuning.

6.1.2 Purpose of Use


An example of waveform measurement usage is shown below.

- Checking responsiveness with One Minute TUNING and precAIse TUNING
- Checking the amplitude and frequency of residual vibration for the settling waveform during damping control tuning
- Checking the overshoot amount for the settling waveform when tuning the feedforward function, etc.

6.1.3 Measurement Procedure

<< Procedure >>

1. Select **Logging>Wave graphic** in Set-up Support Software (PANATERM ver.7) to open the main screen.



2. In “Measurement condition” of “Graph display settings”, set the measurement items, measurement conditions, sampling cycle, and trigger.

Graph display settings

Measurement Condition Edit displayed data Cursor

Acquire from driver Acquire from file Load condition presets Save condition presets

Measurement item Edit


Actual speed[r/min]
Position command speed[r/min]
Torque command[%]
Command position deviation[Command unit]

Sampling cycle [ms] 0.7500 Measurement time [ms] 1.535.25


Trigger condition 1 or 2 Trigger position 1/8 Data average ON

	Target	Level	Slope	Filter
Trigger 1	Position command speed[r/min]	50	Rising up	No use
Trigger 2	Position command speed[r/min]	-50	Falling down	No use

3. Click the [Start measurement] button.



The measurement results are displayed.



6.1.4 Method of Use


■ Checking settling time

See Set-up Support Software (PANATERM ver.7) Operating Manual “10.1.14 Measure the Fixed Time from the Measurement Data” .

■ Checking vibration frequency

- 1 Check the “Cursor” check box in “Graph display settings” to display the cursor.
- 2 Drag Cursor 1 (green dotted line) or Cursor 2 (red dotted line) on the graph with the mouse to move it to the desired position. You can also enter a numerical value in the numeric field at the bottom of the screen to move the cursor to that position. Set Cursor 1 to match the peak position of the vibration waveform, and set Cursor 2 to match the peak one cycle after Cursor 1.
- 3 The time (in seconds) can be calculated from the difference between the times displayed in Cursors 1-2 for the item “Time”, and the frequency can be found from the inverse.

For example, if the difference in time between Cursor 1 and Cursor 2 is 20 ms (0.02 sec), the frequency can be calculated as 1/0.02 sec = 50 Hz.



6.2 Frequency Response Measurement

6.2.1 Function Overview

This function uses Set-up Support Software (PANATERM ver.7) .

Operate the motor to measure the frequency response including the load and display the Bode diagram.

From the measurement results, the resonance point can be identified, benchmarks for filter setting values decided, and the stability of the feedback control system determined.

The measurement results can also be saved to a file.

— Precautions —

- The speed of the motor changes rapidly during measurement. Take necessary safety precautions.
- Perform the measurement with the servo ready to be turned off immediately in case of unexpected operation of the motor or other hazards.
- Do not use this function if there is a possibility that the device could be damaged by violent movement of the motor.
- Setting a large offset may cause movement limits to be exceeded. Take due care.
- Initially, start measurement with the gain as low as possible.
- Frequency response measurement results may vary greatly or show incorrect values due to device characteristics or measurement conditions. Use the measurement results of this function as a reference for gain adjustment.
- Servo parameters during measurement are fixed to 1st gain.
- In measurement modes other than torque speed (normal), the measurement results include the effects of various torque filters and various notch filters.

6.2.2 Types of Measurement Modes

Measurement mode	Function overview	Application
Speed closed loop characteristics	Measures the characteristics of the speed feedback control system, including mechanical characteristics. Measures in speed control mode.	Checks the stability of the speed feedback control system when parameter tuning is in progress or has finished.
Torque speed (normal)	Measures mechanical characteristics. Takes measurements without applying a control to prevent the falling of moving parts due to gravity.	Used to determine the resonance frequency and resonance strength of a device where gravity is not applied to moving parts, and to obtain a guide for set values of various filters.
Torque speed (vertical)	Measures mechanical characteristics. Measurements are taken while applying a control to prevent the falling of moving parts due to gravity.	Used to determine the resonance frequency and resonance strength of a device where gravity is applied to moving parts, and to obtain a guide for set values of various filters.
Position loop characteristics	Measures the characteristics of the position feedback control system, including mechanical characteristics. Measures in position control mode.	Used to check the disturbance suppression of the position feedback control system when parameter tuning is in progress or has finished.

6.2.3 Changes from measurements using A6 Series drivers

Measurement mode	Change
Speed closed loop characteristics	<ul style="list-style-type: none"> • Since the operation mode corresponds to "Pr6.47:bit 0 "Two-degree-of-freedom control mode" = 0 (disabled)" during measurement operation, "Pr6.47:bit 0" does not require switching before measurement in Set-up Support Software (PANATERM ver.7) . • Measurement results unaffected by the feedforward system can be obtained regardless of the set value of the parameter "Pr6.47:bit 0 "Two-degree-of-freedom control mode" " (0 = disabled, 1 = enabled) at the time of measurement.
Torque speed (normal)	<ul style="list-style-type: none"> • Because torque commands are applied as noise signals after various filters, mechanical characteristics unaffected by various filters can be obtained. This means that the various torque filters and various notch filters do not need to be disabled during measurement in Set-up Support Software (PANATERM ver.7) . • Although the Set-up Support Software (PANATERM ver.6) formerly displayed gain with the same scaling as speed closed loop characteristics by offsetting the gain, this function has been deleted.
Torque speed (vertical)	<ul style="list-style-type: none"> • The load fluctuation control function is disabled during measurement. • Torque commands are applied as noise signals after the various filters. • Although the Set-up Support Software (PANATERM ver.6) formerly displayed gain with the same scaling as speed closed loop characteristics by offsetting the gain, this function has been deleted.
Position loop characteristics	<ul style="list-style-type: none"> • Torque commands are applied as noise signals after the various filters. • Although the Set-up Support Software (PANATERM ver.6) formerly displayed gain with the same scaling as speed closed loop characteristics by offsetting the gain, this function has been deleted.


6.2.4 Restrictions

The waveform graphic function cannot be used at the same time.

6.2.5 Measurement Procedure

<< Procedure >>

1. Select **Logging>Frequency response** in Set-up Support Software (PANATERM ver.7) to open the main screen.



2. Select the desired measurement mode from the “Measurement mode” drop-down list.

Frequency characteristic setup/analysis

Measurement ConditionList of displayed dataResonance/antiresonance frequency display

Measurement modeSpeed closed loop characteristics

Some parameters are temporarily changed when measuring.

Sampling rate0:5000Hz

Input signal 1 amplitude [r/...50

Input signal 1 offset [r/min]50

Setting a large offset may cause operating limits to be exceeded.

Check the precautions for the selected measurement mode.

Measurement mode	Precautions
Speed closed loop characteristics	When an offset speed is entered, the load moves. (See details in “Step 5”) Therefore, if the movable range of the device is narrow, the moving part may collide with the mechanical end.
Torque speed (normal)	Do not use in devices with a Z axis that may cause the mechanism to fall when in servo-on. For such devices, use torque speed (vertical).
Torque speed (vertical)	Before measurement, change Pr1.01 “1st velocity loop gain” to a value lower than the frequency bandwidth you wish to check. Furthermore, Pr1.02 “1st velocity loop integration time constant” should also be tuned by referencing “4.1.1.6 Basic Gain Parameter Setup Table” of “4.1 Real-time Auto Tuning Function” . Technically, the measurement results include the effects of various torque filters and various notch filters. Disabling the aforementioned filters can remove their effects, but there is a risk of oscillation if the various filters are disabled when the Pr1.01 “1st velocity loop gain” value is large.

3. Select “Sampling rate” from the drop-down list.

The respective upper limits of the frequency range that can be checked are displayed.

- When the upper limit of the frequency range that can be checked is high
Although measuring accuracy in the low frequency band is reduced, a wide range of frequency response can be checked. Measurement time is reduced.
- When the upper limit of the frequency range that can be checked is low
The frequency range that can be checked is narrower, but measuring accuracy in the low frequency band is improved. Measurement time is longer.

Select the sampling rate to include the frequency range you want to view with high accuracy.

If you are unsure of which frequency range you want to view with high accuracy, first measure the frequency response with “0:5000 Hz”, which can measure the widest range of frequency response, and then select the optimal sampling rate based on those measurement results.

When the sampling rate is other than “0:5000 Hz”, folding due to aliasing may occur.

Frequency characteristic setup/analysis

Measurement ConditionList of displayed dataResonance/antiresonance frequency display

Measurement modeSpeed closed loop characteristics

Some parameters are temporarily changed when measuring.

Sampling rate0:5000Hz

Input signal 1 amplitude [r/...50

Input signal 1 offset [r/min]50

Setting a large offset may cause operating limits to be exceeded.

4. Set the amplitude of the noise waveform to be applied to the speed or torque command in “Input signal 1 amplitude”.

See table *“Amplitude and offset setting ranges”* below for the range that can be set for amplitude.

Increasing the amplitude improves measuring accuracy, but too large an amplitude results in torque saturation and reduced accuracy. Start from a small value and gradually increase it as you observe the measurement results.

The torque command units [%] set for torque speed (normal), torque speed (vertical), and position loop characteristics are ratios of the motor rated torque at 100%.

We recommend confirming that amplitude is 50% for torque speed (normal), torque speed (vertical), and position loop characteristics, and that amplitude is 50 r/min for speed closed loop characteristics.

Frequency characteristic setup/analysis

Measurement ConditionList of displayed dataResonance/antiresonance frequency display

Measurement modeSpeed closed loop characteristics

Some parameters are temporarily changed when measuring.

Sampling rate0:5000Hz

Input signal 1 amplitude [r/...50

Input signal 1 offset [r/min]50

Setting a large offset may cause operating limits to be exceeded.

5. Set the offset value of the noise waveform to be applied to the speed command to “Input signal 1 offset”.

See table “*Amplitude and offset setting ranges*” below for the range that can be set for offset.

During speed closed loop characteristics measurement, the motor operates with the set offset as the average speed command. Polarity is + for positive directions and - for negative directions. Good measurement results are obtained when the offset is greater than the set value for amplitude and the motor always rotates in one direction. (For example, if input signal 1 amplitude is 50 r/min, set input signal 1 offset [r/min] to 50 r/min.)

However, note that if the working range of the device mechanism is narrow, the movement limits may be exceeded.

The approximate amount of motor rotation during measuring operation can be determined by the following equation. Before starting a measurement, always make sure that the movement limits of the device mechanism are not exceeded.

Approximate amount of rotation [r] = offset [r/min] × 0.017 × (sampling rate + 1)

Amplitude and offset setting ranges

—: N/A

Measurement mode	Amplitude setting range	Offset setting range
Speed closed loop characteristics	1 r/min to rated speed [r/min]	- rated speed [r/min] to rated speed [r/min]
Torque speed (normal)	1 to 100%	—
Torque speed (vertical)	1 to 100%	—
Position loop characteristics	1 to 100%	—

Frequency characteristic setup/analysis

Measurement Condition
 List of displayed data
 Resonance/antiresonance frequency display

Measurement mode: Speed closed loop characteristics
 Some parameters are temporarily changed when measuring.

Sampling rate: 0:5000Hz

Input signal 1 amplitude [r/...]: 50

Input signal 1 offset [r/min]: 50

⚠ Setting a large offset may cause operating limits to be exceeded.


6. Check the “Automatic servo-on/off” check box to automatically servo-on at the start of measurement.

- Do not check the box when measuring in servo-on state by external input.

After servo-on by external input, go to “Step 7”.

- Uncheck the box if the brake release operation is performed by a host device in a network.

After servo-on, release the brake from the host device and go to “Step 7”.




7. Click the [Start measurement] button to execute measurement.

A “buzzing” noise may be heard during operation. This noise is caused by the operation of motor excitation by the noise signal and does not indicate a problem.

To stop in an emergency, click the [Stop] button.

Depending on the parameter values for the safety function or protection function systems, a measurement error may occur. If an error occurs, see the table below.




Measurement error troubleshooting

Error	Solution
After the measurement, a "Torque saturated. Lower the amplitude and measure again" pop-up dialog appeared. An alarm is not triggered.	Set the amplitude to a smaller value and measure again. If possible, the torque limit determined by Pr5.21 "Selection of torque limit" should be set to a value large enough for the amplitude of the measurement condition. If there are no special constraints, the initial values are recommended for the relevant torque limit-related parameters.
An "Alarm triggered during measurement" pop-up dialog appeared. An Err16.0 alarm was triggered.	After clearing the alarm, set the amplitude to a smaller value and measure again. Also, if possible, change Pr5.12 "Motor overload level setup" to a larger value. If there are no special constraints, the initial values are recommended.
An "Alarm triggered during measurement" pop-up dialog appeared. An Err26.0 alarm was triggered.	After clearing the alarm, set the amplitude to a smaller value and measure again. This error always occurs when the speed closed loop characteristics are measured and the speed set for offset in the measurement conditions is greater than the speed set by Pr5.13 "Over-speed level setup". Make sure the offset speed is set smaller. Also, if possible, change Pr5.13 "Over-speed level setup" to a larger value. If there are no special constraints, the initial values are recommended.
An "Alarm triggered during measurement" pop-up dialog appeared. An Err26.1 alarm was triggered.	After clearing the alarm, set the amplitude to a smaller value and measure again. This error always occurs when the speed closed loop characteristics are measured and the speed set for offset in the measurement conditions is greater than the speed set by Pr6.15 "2nd overspeed level setting". Make sure the offset speed is set smaller. Also, if possible, change Pr6.15 "2nd overspeed level setting" to a larger value. If there are no special constraints, the initial values are recommended.

Error	Solution
An “Alarm triggered during measurement” pop-up dialog appeared. Alarms other than the above alarms were triggered.	Take the specified measures for handling each alarm. Measure again after clearing the alarm.

8. After measurement is completed, the gain and phase are displayed on the main screen.
- For detailed instructions on how to operate the graph area of the main screen, see Set-up Support Software (PANATERM ver.7) Operating Manual.
- Also, if parameters were changed manually prior to measurement, such as torque speed (vertical), do not forget to restore the relevant parameters once the measurement of frequency response is complete.
- If the servo-on is performed manually with “Step 6”, the waveform is displayed on the main screen after servo-off.
- If the brake is operated by a host device, apply the brake before servo-off.




6.2.6 Method of Use

- **Understanding mechanical resonance and using it as reference for the set values of various filters**
- 1 Measure “Torque speed (normal)” or “Torque speed (vertical)” according to “6.2.5 Measurement Procedure”.
 - 2 Select the “Resonance/antiresonance frequency display” tab on the screen to view the resonance frequency and antiresonance frequency.

The figure below is an example of “Torque speed (normal)”.


For an example of filter settings using these, see “5.6 Model-type Damping Filter Function”.




■ **Checking the stability of the feedback control system when parameter tuning is in progress or has finished**

- 1 Measure “Speed closed loop characteristics” according to “6.2.5 Measurement Procedure” .
- 2 Check if the peak gain exceeds 0 dB. If this value is exceeded, oscillation may occur. Basically, the lower the stiffness value of the feedback control system, the lower the peak gain. If a device has high friction, oscillation may not occur even though the value is above 0 dB.

For details on how to tune parameters, see “3.2.1 Manual TUNING” .



Resonance peaks from mechanical resonance may also be measured. When doing so, it may be possible to increase the stiffness by setting a notch filter to suppress the resonance peak. For information on how to set notch filters, see [“5.3 Notch Filter Function”](#).



7 References

7.1 List of Parameters	252
7.1.1 Sample Description	252
7.1.2 Class 0: Basic Settings	255
7.1.3 Class 1: Gain Adjustment.....	256
7.1.4 Class 2: Vibration Suppression	258
7.1.5 Class 3: Velocity/Torque Control/Full-closed Control	261
7.1.6 Class 4: I/O Monitor Settings	262
7.1.7 Class 5: Enhancing Settings	264
7.1.8 Class 6: Special Settings	266
7.1.9 Class 7: Special Settings 2	270
7.1.10 Class 8: Special Settings 3	273
7.1.11 Class 11: Manufacturer Use	274
7.2 Control Mode Block Diagram.....	275
7.2.1 Position Control Mode Block Diagram	275
7.2.2 Speed Control Mode Block Diagram	277
7.2.3 Torque Control Mode Block Diagram	279
7.2.4 Full-closed Control Mode Block Diagram	280
7.3 Parameters Related To TUNINGLESS.....	282
7.4 Parameters Related To One Minute TUNING	284
7.5 Other Parameters Related To Tuning	288
7.6 List of Errors Related to One Minute TUNING	292
7.7 Glossary	295

7.1 List of Parameters

Information on the parameters used for this product, such as parameter numbers, names, setting ranges and initial values, are shown in a list for each parameter class (whole number).

For this product, parameters are classified into the 11 classes below.

Parameter No.		Class name	Description	Reference
Class	No. (*1)			
0	00 to 28	Basic setting	Parameters relating to basic settings	“7.1.2 Class 0: Basic Settings”
1	00 to 115	Gain adjustment	Parameters relating to gain adjustment	“7.1.3 Class 1: Gain Adjustment”
2	00 to 80	Vibration suppression	Parameters relating to vibration suppression	“7.1.4 Class 2: Vibration Suppression”
3	04 to 42	Velocity, torque control	Parameters relating to velocity and torque control	“7.1.5 Class 3: Velocity/Torque Control/ Full-closed Control”
4	00 to 67	I/O monitor setting	Parameters relating to the interface monitor	“7.1.6 Class 4: I/O Monitor Settings”
5	03 to 112	Enhancing setting	Parameters relating to enhancing setting	“7.1.7 Class 5: Enhancing Settings”
6	02 to 127	Special setting	Parameters relating to special setting	“7.1.8 Class 6: Special Settings”
7	00 to 127	Special setting 2		“7.1.9 Class 7: Special Settings 2”
8	00 to 19	Special setting 3		“7.1.10 Class 8: Special Settings 3”
11	00 to 26	Manufacturer use	Parameters for manufacturer use	“7.1.11 Class 11: Manufacturer Use”

*1 No. is a 2- or 3-digit number.

7.1.1 Sample Description

The following is an example of entries for a List of Parameters.

Class 0: Basic Settings

○: Enabled X: Disabled —: N/A

Parameter No.		Parameter names (*3)	Setting range	Factory default values	Unit	Attribute (*4)	Related control modes (*5)				References (*6)
Class	No. (*2)						P	S	T	F	
**	**	*****	—	*****	—	—	X	X	X	X	—
**	**	*****	*****	*****	—	B	○	○	○	○	*****

*1 Shows the classification of the parameter (large number). Shows the X section of PrX.YY.

*2 Shows the parameter No. (small number). Shows the Y section of PrX.YY.

*3 Shows the parameter name. Do not change the setup value from the factory default value for the “Manufacturer use” parameter.

*4 For parameter attributes, see [“Parameter Attributes”](#).

*5 Shows the relationships between parameters and control modes. Shows whether a parameter is enabled or disabled for each control mode.

Control modes are indicated using the symbols below.

Symbol	Control mode
P	Position control

Symbol	Control mode
S	Velocity control
T	Torque control
F	Full-closed control

*6 Parameter references. The references provide details on parameters and describe their related functions.

For details on abbreviations used for document names, see [“1.2”](#).

■ Parameter Attributes

There are attributes for the parameters.

The attribute indicates the timing under which the parameter change description is enabled.

Symbol	When the changed parameter details are enabled
A	Always enabled
B	Always enabled Changes are prohibited while the motor is running and during command transfer. If parameters are changed while the motor is running and during position command transfer, the time it takes for the changes to be reflected will be uncertain, which may transiently lead to unstable operation.
C	Enabled after executing the RTEX communication reset command attribute C parameter enabling mode or by the same operation as attribute R below
R	Enabled by turning the control power back on after EEPROM writing or after executing the RTEX communication reset command software reset mode
RO	In read-only, changes cannot be made using the normal procedure for changing parameters

For the details on the RTEX communication reset command, see Technical Reference Communication Specification - .

For details on bit allocation of parameter attributes that can be read by parameter attribute reading, see Technical Reference Communication Specification - .

— Precautions —

- If, after changing a parameter, the power is turned off or the reset command software reset mode is executed, the changed value is lost.

To save the changed value, ensure that it is written to EEPROM.

Use the parameter command or Set-up Support Software (PANATERM ver.7) to write values to EEPROM.

Refer to the operating instructions for the host device or the operating instructions for the Set-up Support Software (PANATERM ver.7) .

■ Attribute C Parameter Enabling Mode

This is executed using the RTEX communication reset command from the host device. Refer to the operating instructions for the host device for the reset command for the host device.

Use this mode to enable the attribute C parameter change value when communication with the host device is established without turning the servo driver control power on again or performing a software reset.

It is not necessary to write the parameter to EEPROM before executing this mode. (It is not an issue if it is written to EEPROM).

Execute the reset command in a servo-off state and maintain servo-off state during reset command processing. If this command is received in servo-on state, this leads to command error (0045h). Also, if servo-on is executed (Servo_On = 1) while this command is processed, Err27.7.0 “Position information initialization error protection” is generated.

After the command is executed, position information is initialized, including actual position and position deviation, and is the same as when reset. Also, homing is not completed (excluding when in absolute mode) and latch is not completed. After the command is completed successfully, execute homing again.

The status during command execution and the output signals are as follows.

Status/output signal	Before execution	While executing	After execution
Position information	Current position information	Initialization	Information on current position with reference to the position at which command was executed (*1)
Homing state	Current state	Indeterminate	<ul style="list-style-type: none"> • Not complete in incremental mode • Complete in absolute mode
Latch state	Current state	Indeterminate	Not complete
Busy (non-cyclic status)	0	1	0
Other status	Current state	Indeterminate	Current state
Output signal	Current state	Indeterminate	Current state

*1 Position information after command execution (initialization)

- Incremental mode

All position information = 0

- Absolute mode

All position information = Value of absolute encoder (scale)/ electronic gear ratio + Pr7.13 "Absolute home position offset"

— Precautions —

- While executing the command, do not run operations from Set-up Support Software (PANATERM ver.7) .

7.1.2 Class 0: Basic Settings

○: Enabled ✕: Disabled —: N/A

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
0	00	Rotational direction setup	0 to 1	1	—	C	○	○	○	○	OI_O
0	01	Control mode setup	0 to 6	0	—	R	○	○	○	○	OI_O
0	02	Real-time auto-gain tuning setup	0 to 7	1	—	B	○	○	○	○	“4.1.1.4”
0	03	Real-time auto-tuning machine stiffness setup	0 to 31	Sizes A, B: 13 Sizes C, D: 11 (13) (*3)	—	B	○	○	○	○	“4.1.2.4” “4.1.3.4”
0	04	Inertia ratio	0 to 100000	250	%	B	○	○	○	○	“7.5”
0	08	Number of command pulses per one motor revolution	0 to 134217728	8388608	pulse	C	○	○	○	○	OI_O TR_CS
0	09	Numerator of electronic gear	0 to 2 ³⁰	1	—	C	○	○	○	○	
0	10	Denominator of electronic gear	1 to 2 ³⁰	1	—	C	○	○	○	○	
0	11	Number of output pulses per motor revolution	1 to 33554432	2500	pulse	R	○	○	○	○	OI_O
0	12	Reversal of pulse output logic	0 to 3	0	—	R	○	○	○	○	
0	13	1st torque limit	0 to 500	500 (*2)	%	B	○	○	○	○	OI_O
0	14	Position deviation excess setup	0 to 2 ³⁰	83886080	Command unit	A	○	✕	✕	○	OI_O
0	15	Absolute encoder setup	0 to 4	1	—	C	○	○	○	✕	OI_O TR_CS
0	16	External regenerative resistor setup	0 to 3	Sizes A, B: 3 Sizes C, D: 0	—	C	○	○	○	○	OI_O
0	17	Selection of load factor for external regenerative resistor	0 to 4	0	—	C	○	○	○	○	
0	18	Manufacturer use	—	0	—	—	—	—	—	—	—
0	22	Sensor feedback control mode setup (*1)	0 to 1	0	—	R	○	✕	✕	✕	OI_O TR_CS
0	27	Selection of machine stiffness at real-time auto-gain tuning 2	0 to 44	Sizes A, B: 16 Sizes C, D: 12 (16) (*3)	—	B	○	○	○	○	“4.1.1.4” “4.1.2.4” “4.1.3.4”
0	28	Selection of feed forward stiffness at real-time auto-gain tuning	0 to 44	Sizes A, B: 16 Sizes C, D: 12 (16) (*3)	—	B	○	○	○	○	

*1 Cannot be used with the standard type or multi-function type. Do not change the factory default value.

*2 Factory default values vary depending on the servo driver and motor combination.

For details, see Operating Instructions (Overall) “8.1 Torque Limit Switching Function”.

*3 Values in parentheses are initial values for models with an instantaneous maximum current (peak value) of less than 24 A.

7.1.3 Class 1: Gain Adjustment

○: Enabled X: Disabled —: N/A

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
1	00	1st gain of position loop	0 to 30000	Sizes A, B : 480 Sizes C, D: 320 (480) (*1)	0.1 s ⁻¹	B	○	X	X	○	“4.1.1.4” “4.1.2.4” “4.1.3.4”
1	01	1st velocity loop gain	1 to 32767	Sizes A, B: 270 Sizes C, D: 180 (270) (*1)	0.1 Hz	B	○	○	○	○	
1	02	1st velocity loop integration time constant	1 to 10000	Sizes A, B: 210 Sizes C, D: 310 (210) (*1)	0.1 ms	B	○	○	○	○	
1	03	1st filter of velocity detection	0 to 5	0	—	B	○	○	○	○	
1	04	1st torque filter time constant	0 to 2500	Sizes A, B: 84 Sizes C, D: 126 (84) (*1)	0.01 ms	B	○	○	○	○	“5.1.3”
1	05	2nd gain of position loop	0 to 30000	Sizes A, B: 480 Sizes C, D: 320 (480) (*1)	0.1 s ⁻¹	B	○	X	X	○	“7.5”
1	06	2nd velocity loop gain	1 to 32767	Sizes A, B: 270 Sizes C, D: 180 (270) (*1)	0.1 Hz	B	○	○	○	○	
1	07	2nd velocity loop integration time constant	1 to 10000	Sizes A, B: 210 Sizes C, D: 310 (210) (*1)	0.1 ms	B	○	○	○	○	
1	08	2nd filter of velocity detection	0 to 5	0	—	B	○	○	○	○	
1	09	2nd torque filter time constant	0 to 2500	Sizes A, B: 84 Sizes C, D: 126 (84) (*1)	0.01 ms	B	○	○	○	○	“5.1.3”
1	10	Velocity feed forward gain	0 to 4000	1000	0.1 %	B	○	X	X	○	“4.4.3”
1	11	Velocity feed forward filter	0 to 6400	0	0.01 ms	B	○	X	X	○	
1	12	Torque feed forward gain	0 to 2000	1000	0.1 %	B	○	○	○	○	
1	13	Torque feed forward filter	0 to 6400	0	0.01 ms	B	○	○	○	○	
1	14	2nd gain setup	0 to 1	1	—	B	○	○	○	○	“4.2.3” “4.3.3” OI_O
1	15	Mode of position control switching	0 to 10	0	—	B	○	X	X	○	“4.3.3”
1	16	Delay time of position control switching	0 to 10000	10	0.1 ms	B	○	X	X	○	
1	17	Level of position control switching	0 to 20000	0	—	B	○	X	X	○	“4.2.3”
1	18	Hysteresis at position control switching	0 to 20000	0	—	B	○	X	X	○	
1	19	Position gain switching time	0 to 10000	10	0.1 ms	B	○	X	X	○	
1	20	Mode of velocity control switching	0 to 5	0	—	B	X	○	X	X	
1	21	Delay time of velocity control switching	0 to 10000	0	0.1 ms	B	X	○	X	X	
1	22	Level of velocity control switching	0 to 20000	0	—	B	X	○	X	X	
1	23	Hysteresis at velocity control switching	0 to 20000	0	—	B	X	○	X	X	
1	24	Mode of torque control switching	0 to 3	0	—	B	X	X	○	X	
1	25	Delay time of torque control switching	0 to 10000	0	0.1 ms	B	X	X	○	X	
1	26	Level of torque control switching	0 to 20000	0	—	B	X	X	○	X	
1	27	Hysteresis at torque control switching	0 to 20000	0	—	B	X	X	○	X	

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
1	28	Manufacturer use	—	0	—	—	—	—	—	—	—
1	78	Manufacturer use	—	0	—	—	—	—	—	—	“7.5”
1	106	1st position loop gain change ratio	0 to 300	100	%	B	○	×	×	○	
1	107	1st velocity integration change ratio	0 to 300	100	%	B	○	○	○	○	
1	108	1st torque filter change ratio	0 to 300	100	%	B	○	○	○	○	
1	109	2nd position loop gain change ratio	0 to 300	100	%	B	○	×	×	○	
1	110	2nd velocity loop gain change ratio	0 to 300	100	%	B	○	○	○	○	
1	111	2nd velocity integration change ratio	0 to 300	100	%	B	○	○	○	○	
1	112	2nd torque filter change ratio	0 to 300	100	%	B	○	○	○	○	
1	113	Load fluctuation compensation filter change ratio	0 to 300	100	%	B	○	○	○	○	
1	114	Smoothing filter change ratio	0 to 300	100	%	B	○	○	○	○	
1	115	Tuning filter change ratio	0 to 300	100	%	B	○	○	○	○	

*1 Values in parentheses are initial values for models with an instantaneous maximum current (peak value) of less than 24 A.

7.1.4 Class 2: Vibration Suppression

○: Enabled X: Disabled —: N/A

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference	
Class	No.						P	S	T	F		
2	00	Adaptive filter mode setup	0 to 6	0	—	B	○	○	×	○	“5.4.3”	
2	01	1st notch frequency	10 to 5000	5000	Hz	B	○	○	○	○		“5.3.3”
2	02	1st notch width selection	0 to 20	2	—	B	○	○	○	○		
2	03	1st notch depth selection	0 to 99	0	—	B	○	○	○	○		
2	04	2nd notch frequency	10 to 5000	5000	Hz	B	○	○	○	○		
2	05	2nd notch width selection	0 to 20	2	—	B	○	○	○	○		
2	06	2nd notch depth selection	0 to 99	0	—	B	○	○	○	○	“5.3.3” “5.4.3”	
2	07	3rd notch frequency	10 to 5000	5000	Hz	B	○	○	○	○		
2	08	3rd notch width selection	0 to 20	2	—	B	○	○	○	○		
2	09	3rd notch depth selection	0 to 99	0	—	B	○	○	○	○		
2	10	4th notch frequency	10 to 5000	5000	Hz	B	○	○	○	○		
2	11	4th notch width selection	0 to 20	2	—	B	○	○	○	○		
2	12	4th notch depth selection	0 to 99	0	—	B	○	○	○	○	“5.5.3” “5.6.3”	
2	13	Selection of damping filter switching	0 to 7	0	—	B	○	×	×	○		
2	14	1st damping frequency	0 to 3000	0	0.1 Hz	B	○	×	×	○	“5.5.3”	
2	15	1st damping filter setup	0 to 1500	0	0.1 Hz	B	○	×	×	○		
2	16	2nd damping frequency	0 to 3000	0	0.1 Hz	B	○	×	×	○		
2	17	2nd damping filter setup	0 to 1500	0	0.1 Hz	B	○	×	×	○		
2	18	3rd damping frequency	0 to 3000	0	0.1 Hz	B	○	×	×	○		
2	19	3rd damping filter setup	0 to 1500	0	0.1 Hz	B	○	×	×	○		
2	20	4th damping frequency	0 to 3000	0	0.1 Hz	B	○	×	×	○		
2	21	4th damping filter setup	0 to 1500	0	0.1 Hz	B	○	×	×	○		
2	22	Positional command smoothing filter	0 to 10000	Sizes A, B: 92 Sizes C, D: 139 (92) (*1)	0.1 ms	B	○	○	×	○	“5.7.3” OI_O	
2	23	Positional command FIR filter	0 to 10000	10	0.1 ms	B	○	×	×	○	“5.7.3”	
2	24	5th notch frequency	10 to 5000	5000	Hz	B	○	○	○	○	“5.3.3”	
2	25	5th notch width selection	0 to 20	2	—	B	○	○	○	○		
2	26	5th notch depth selection	0 to 99	0	—	B	○	○	○	○		
2	27	1st damping width setting	0 to 1000	0	—	B	○	×	×	○	“5.5.3”	
2	28	2nd damping width setting	0 to 1000	0	—	B	○	×	×	○		
2	29	3rd damping width setting	0 to 1000	0	—	B	○	×	×	○		
2	30	4th damping width setting	0 to 1000	0	—	B	○	×	×	○		
2	31	Manufacturer use	—	0	—	—	—	—	—	—	—	
⋮												
2	37	Manufacturer use	—	0	—	—	—	—	—	—		
2	38	Filter function switching	-32768 to 32767	3	—	B	○	○	○	○	—	
		● bit 0: Custom notch filter									OI_O	
		● bit 1: Tuning filter 2									“4.1.1.4” “4.1.2.4” “4.1.3.4” OI_O	

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
2	39	Custom notch compensation coefficient	0 to 1000	0	0.01	B	O	O	O	O	OI_O “5.3.3”
2	40	Custom notch compensation frequency 1	0 to 10000	0	0.1 Hz	B	O	O	O	O	
2	41	Custom notch compensation frequency 2	0 to 10000	0	0.1 Hz	B	O	O	O	O	
2	42	Custom notch frequency	10 to 5000	5000	Hz	B	O	O	O	O	
2	43	Custom notch width	0 to 20	2	—	B	O	O	O	O	
2	44	Custom notch depth	0 to 99	0	—	B	O	O	O	O	
2	45	Function expansion setup 10	-2147483648 to 2147483647	61	—	B	O	O	O	O	—
		<ul style="list-style-type: none"> bit 1 to 0: Two-degree-of-freedom control function setting 									“4.1.1.4” “4.1.2.4” “4.1.3.4” OI_O
		<ul style="list-style-type: none"> bit 2: Friction torque compensation parameter selection 									“7.5”
		<ul style="list-style-type: none"> bit 3: Load fluctuation suppression function automatic calculation 									“4.1.1.4” “4.1.2.4” “4.1.3.4” “4.6.3” “4.7.3”
		<ul style="list-style-type: none"> bit 5 to 4: Stiffness setting resolution, individual FB/FF setting switching 									“4.1.1.4” “4.1.2.4” “4.1.3.4”
2	46	Tuning filter 2	0 to 20000	Size A: 110 Size B: 120 Sizes C, D: 170 (120) (*1)	0.01 ms	B	O	X	X	O	OI_O
2	50	Detection start vibration count	0 to 100	3	—	B	O	X	X	X	“5.5.3”
2	51	Detected vibration amplitude	0 to 134217728	0	Command unit	B	O	X	X	X	
2	52	Torque command additional value 2	-1000 to 1000	0	0.1 %	B	O	O	X	O	“4.5.3”
2	53	Positive direction torque compensation value 2	-1000 to 1000	0	0.1 %	B	O	X	X	O	
2	54	Negative direction torque compensation value 2	-1000 to 1000	0	0.1 %	B	O	X	X	O	
2	61	Target settling time	0 to 32767	0	ms	A	O	O	O	O	“7.5”
2	62	Settling time count condition	0 to 1	0	—	A	O	O	O	O	
2	63	Allowable overshoot amount	0 to 500	100	%	A	O	O	O	O	
2	64	Tuning amount of movement	0 to 2147483647	0	Command unit	A	O	O	O	O	
2	65	Tuning max speed	0 to 20000	0	r/min	A	O	O	O	O	
2	66	Tuning acceleration and deceleration time	0 to 5000	0	ms	A	O	O	O	O	
2	67	Tuning wait time	0 to 10000	2000	ms	A	O	O	O	O	
2	68	Tuning operating range upper limit	0 to 1073741823	8388608	Command unit	A	O	O	O	O	
2	69	Tuning operating range lower limit	-1073741824 to 0	-8388608	Command unit	A	O	O	O	O	
2	70	Tuning overspeed level setting	0 to 20000	0	r/min	A	O	O	O	O	
2	71	Tuning torque limit	0 to 500	0	%	A	O	O	O	O	
2	72	Tuning start RTAT machine stiffness setting	0 to 44	8	—	A	O	O	O	O	
2	73	Tuning stability margin	0 to 100	80	%	A	O	O	O	O	

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
2	74	Tuning auto tuning application selection	-32768 to 32767	0	—	A	○	○	○	○	“4.1.1.4” “4.1.2.4” “4.1.3.4”
2	75	Tuning step selection	-32768 to 32767	3	—	A	○	○	○	○	—
		• bit 0: Advance operation									“7.5”
		• bit 1: Homing operation									—
2	76	Tuning target function selection	-32768 to 32767	1009	—	A	○	○	○	○	—
		• bit 0: Inertia ratio									“7.5”
		• bit 1: Unbalanced load compensation (default disabled)									
		• bit 2: Dynamic friction compensation (default disabled)									
		• bit 3: Viscous friction compensation (default disabled)									
		• bit 4: RTAT machine stiffness setting (position and speed gains, speed integration time constant, torque filter)									
		• bit 5: RTAT feedforward control section stiffness setting (smoothing filter time constant)									
		• bit 6: Notch filter									
		• bit 7: 1st damping filter									
		• bit 8: 2nd damping filter									
		• bit 9: Load fluctuation control function									
2	77	Tuning start position	-1073741824 to 1073741823	0	Command unit	A	○	○	○	○	“7.5”
2	78	Tuning vibration automatic suppression effective level	0 to 100	15	%	A	○	○	○	○	
2	79	Tuning JOG test run command speed	0 to 500	60	r/min	A	○	○	○	○	
2	80	Tuning JOG test run acceleration and deceleration time	0 to 5000	50	ms	A	○	○	○	○	

*1 Values in parentheses are initial values for models with an instantaneous maximum current (peak value) of less than 24 A.

7.1.5 Class 3: Velocity/Torque Control/Full-closed Control

○: Enabled ✕: Disabled —: N/A

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
3	04	Manufacturer use	—	0	—	—	—	—	—	—	—
		⋮									
3	07	Manufacturer use	—	0	—	—	—	—	—	—	“5.8.3”
3	12	Acceleration time setup	0 to 10000	0	ms/(1000 r/min)	B	✕	○	✕	✕	
3	13	Deceleration time setup	0 to 10000	0	ms/(1000 r/min)	B	✕	○	✕	✕	
3	14	Sigmoid acceleration / deceleration time setup	0 to 1000	0	ms	B	✕	○	✕	✕	
3	17	Selection of speed limit	0 to 1	0	—	B	✕	✕	○	✕	OI_O
3	21	Velocity limit value 1	0 to 20000	0	r/min	B	✕	✕	○	✕	
3	22	Velocity limit value 2	0 to 20000	0	r/min	B	✕	✕	○	✕	
3	23	External scale selection	0 to 2	0	—	R	○	○	○	○	OI_O
3	24	Numerator of external scale division	0 to 2 ²⁷	0	—	R	✕	✕	✕	○	OI_O
3	25	Denominator of external scale division	1 to 2 ²⁷	10000	—	R	✕	✕	✕	○	
3	26	Reversal of direction of external scale	0 to 3	0	—	R	○	○	○	○	OI_O
3	27	External scale Z phase disconnection detection disable	0 to 1	0	—	R	○	○	○	○	OI_O
3	28	Hybrid deviation excess setup	1 to 2 ²⁷	16000	Command unit	C	✕	✕	✕	○	OI_O
3	29	Hybrid deviation clear setup	0 to 100	0	Rotation	C	✕	✕	✕	○	
3	33	Analog input gain (*1)	0 to 30000	0	Command unit/mV	B	○	✕	✕	○	OI_O
3	34	Analog input polarity (*1)	0 to 1	0	—	B	○	✕	✕	○	
3	35	Analog input integration time constant (*1)	0 to 100000	0	0.01 ms	B	○	✕	✕	○	
3	36	Analog input integration limit (*1)	0 to 2147483647	0	Command unit	B	○	✕	✕	○	
3	42	Sensor feedback control function extended setup (*1)	-32768 to 32767	0	—	B	○	✕	✕	✕	—
		<ul style="list-style-type: none"> bit 0: Displacement control function position command latch switching 									OI_O TR_CS

*1 Cannot be used with the standard type or multi-function type. Do not change the factory default value.

7.1.6 Class 4: I/O Monitor Settings

○: Enabled X: Disabled —: N/A

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
4	00	SI1 input selection	0 to 00FFFFFFh	3289650	—	C	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OI_O
4	01	SI2 input selection	0 to 00FFFFFFh	8487297	—	C	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	02	SI3 input selection	0 to 00FFFFFFh	8553090	—	C	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	03	SI4 input selection	0 to 00FFFFFFh	3026478	—	C	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	04	SI5 input selection	0 to 00FFFFFFh	2236962	—	C	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	05	SI6 input selection	0 to 00FFFFFFh	2171169	—	C	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	06	SI7 input selection	0 to 00FFFFFFh	2829099	—	C	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	07	SI8 input selection	0 to 00FFFFFFh	3223857	—	C	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	10	SO1 output selection	0 to 00FFFFFFh	197379	—	C	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OI_O
4	11	SO2 output selection	0 to 00FFFFFFh	1052688	—	C	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	12	SO3 output selection	0 to 00FFFFFFh	65793	—	C	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	16	Type of analog monitor 1	0 to 35	0	—	A	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OI_O
4	17	Analog monitor 1 output gain	0 to 214748364	0	—	A	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	18	Type of analog monitor 2	0 to 35	0	—	A	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	19	Analog monitor 2 output gain	0 to 214748364	0	—	A	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	21	Analog monitor output setup	0 to 2	0	—	A	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	22	Analog input (AIN) offset setting (*1)	-26666 to 26666	0	0.375 mV	B	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OI_O TR_CS
4	23	Analog input (AIN) filter setting (*1)	0 to 6400	0	0.01 ms	B	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	24	Analog input (AIN) excessive setting (*1)	0 to 100	0	0.1 V	B	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	31	Positioning complete (In-position) range	0 to 2097152	8400	Command unit	A	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	“7.5” OI_O
4	32	Positioning complete (In-position) output setup	0 to 10	0	—	A	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	OI_O
4	33	INP hold time	0 to 30000	0	ms	A	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	
4	34	Zero-speed	10 to 20000	50	r/min	A	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OI_O
4	35	Speed coincidence range	10 to 20000	50	r/min	A	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	OI_O
4	36	At-speed (Speed arrival)	10 to 20000	1000	r/min	A	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	OI_O
4	37	Mechanical brake action at stalling setup	0 to 10000	0	ms	B	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OI_O
4	38	Mechanical brake action at running setup	0 to 32000	0	ms	B	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OI_O
4	39	Brake release speed setup	30 to 3000	30	r/min	B	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OI_O
4	40	Selection of alarm output 1	0 to 32767	0	—	A	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OI_O
4	41	Selection of alarm output 2	0 to 32767	0	—	A	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	42	Positioning complete (In-position) range 2	0 to 2097152	8400	Command unit	A	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	OI_O
4	44	Position comparison output pulse width setting	0 to 32767	0	0.1 ms	R	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OI_O
4	45	Position comparison output polarity selection	0 to 7	0	—	R	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—
		● bit 0: Polarity for SO1 (general-purpose output) or OCMP1 (encoder/position comparison output terminal)									OI_O
		● bit 1: Polarity for SO2 (general-purpose output) or OCMP2 (encoder/position comparison output terminal)									
		● bit 2: Polarity for SO3 (general-purpose output) or OCMP3 (encoder/position comparison output terminal)									
4	47	Pulse output selection	0 to 1	0	—	R	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OI_O
4	48	Position comparison value 1	-2147483648 to 2147483647	0	Command unit	A	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	OI_O

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference	
Class	No.						P	S	T	F		
4	49	Position comparison value 2	-2147483648 to 2147483647	0	Command unit	A	O	O	O	O	OI_O	
4	50	Position comparison value 3	-2147483648 to 2147483647	0	Command unit	A	O	O	O	O		
4	51	Position comparison value 4	-2147483648 to 2147483647	0	Command unit	A	O	O	O	O		
4	52	Position comparison value 5	-2147483648 to 2147483647	0	Command unit	A	O	O	O	O		
4	53	Position comparison value 6	-2147483648 to 2147483647	0	Command unit	A	O	O	O	O		
4	54	Position comparison value 7	-2147483648 to 2147483647	0	Command unit	A	O	O	O	O		
4	55	Position comparison value 8	-2147483648 to 2147483647	0	Command unit	A	O	O	O	O		
4	56	Position comparison output delay compensation amount	-32768 to 32767	0	0.1 μs	B	O	O	O	O		
4	57	Position comparison output assignment setting	-2147483648 to 2147483647	0	—	R	O	O	O	O	—	
		● bit 3 to 0: Position comparison 1										OI_O
		● bit 7 to 4: Position comparison 2										
		● bit 11 to 8: Position comparison 3										
		● bit 15 to 12: Position comparison 4										
		● bit 19 to 16: Position comparison 5										
		● bit 23 to 20: Position comparison 6										
		● bit 27 to 24: Position comparison 7										
● bit 31 to 28: Position comparison 8												
4	63	Manufacturer use	—	5242884	—	—	—	—	—	—	—	
4	64	Manufacturer use	—	64	—	—	—	—	—	—	—	
4	65	Analog input internal offset setting	-32768 to 32767	0	mV	A	O	O	O	O	OI_O TR_CS	
4	66	Analog input deviation limit setting	0 to 65535	0	mV	A	O	O	O	O		
4	67	Analog input voltage dead zone setting	0 to 65535	0	mV	B	O	O	O	O		

*1 Cannot be used with the standard type or multi-function type. Do not change the factory default value.

7.1.7 Class 5: Enhancing Settings

○: Enabled X: Disabled —: N/A

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
5	03	Denominator of pulse output division	0 to 134217728	0	—	R	○	○	○	○	OI_O
5	04	Over-travel inhibit input setup	0 to 2	1	—	C	○	○	○	○	OI_O TR_CS
5	05	Sequence at over-travel inhibit	0 to 2	0	—	C	○	○	○	○	OI_O
5	06	Sequence at servo-off	0 to 9	0	—	B	○	○	○	○	OI_O
5	07	Sequence upon main power off	0 to 9	0	—	B	○	○	○	○	OI_O
5	08	L/V trip selection upon main power off	0 to 3	1	—	B	○	○	○	○	—
		• bit 0: Operation selection with main power supply OFF									OI_O
		• bit 1: Main power off warning condition detection time									
5	09	Detection time of main power off	20 to 2000	70	ms	C	○	○	○	○	OI_O
5	10	Sequence at alarm	0 to 7	0	—	B	○	○	○	○	OI_O
5	11	Torque setup for emergency stop	0 to 500	0	%	B	○	○	○	○	OI_O
5	12	Motor overload level setup	0 to 500	0	%	A	○	○	○	○	OI_O
5	13	Over-speed level setup	0 to 20000	0	r/min	B	○	○	○	○	OI_O
5	14	Motor working range setup	0 to 1000	10	0.1 rotation	A	○	X	X	○	OI_O
5	15	Control input signal reading setup	0 to 3	0	—	C	○	○	○	○	OI_O
5	20	Position setup unit select	0 to 1	0	—	C	○	X	X	○	OI_O
5	21	Selection of torque limit	0 to 4	1	—	B	○	○	X	○	OI_O TR_CS
5	22	2nd torque limit	0 to 500	500 (*1)	%	B	○	○	X	○	OI_O
5	23	Torque limit switching setup 1	0 to 4000	0	ms/100 %	B	○	○	X	○	
5	24	Torque limit switching setup 2	0 to 4000	0	ms/100 %	B	○	○	X	○	
5	25	Positive direction torque limit	0 to 500	500 (*1)	%	B	○	○	X	○	
5	26	Negative direction torque limit	0 to 500	500 (*1)	%	B	○	○	X	○	
5	29	Manufacturer use	—	2	—	—	—	—	—	—	—
5	31	USB axis address	0 to 127	1	—	C	○	○	○	○	PT_OM
5	33	Pulse regenerative output limit setup	0 to 1	0	—	C	○	○	○	○	OI_O
5	34	Manufacturer use	—	4	—	—	—	—	—	—	—
5	36	Manufacturer use	—	0	—	—	—	—	—	—	—
5	45	Quadrant glitch positive-direction compensation value	-1000 to 1000	0	0.1 %	B	○	X	X	○	"4.9.3"
5	46	Quadrant glitch negative-direction compensation value	-1000 to 1000	0	0.1 %	B	○	X	X	○	
5	47	Quadrant glitch compensation delay time	0 to 1000	0	ms	B	○	X	X	○	
5	48	Quadrant glitch compensation filter setting L	0 to 6400	0	0.01 ms	B	○	X	X	○	
5	49	Quadrant glitch compensation filter setting H	0 to 10000	0	0.1 ms	B	○	X	X	○	

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
5	50	Manufacturer use	—	0	—	—	—	—	—	—	—
⋮											
5	55	Manufacturer use	—	0	—	—	—	—	—	—	
5	56	Slow stop deceleration time setting	0 to 10000	0	ms/(1000 r/min)	B	○	○	○	×	OI_O
5	57	Slow stop S-shape acceleration and deceleration setting	0 to 1000	0	ms	B	○	○	○	×	
5	66	Deterioration diagnosis convergence judgment time	0 to 10000	0	0.1 s	A	○	○	○	○	OI_O
5	67	Deterioration diagnosis inertia ratio upper limit	0 to 10000	0	%	A	○	○	○	○	
5	68	Deterioration diagnosis inertia ratio lower limit	0 to 10000	0	%	A	○	○	○	○	
5	69	Deterioration diagnosis unbalanced load upper limit	-1000 to 1000	0	0.1 %	A	○	○	○	○	
5	70	Deterioration diagnosis unbalanced load lower limit	-1000 to 1000	0	0.1 %	A	○	○	○	○	
5	71	Deterioration diagnosis dynamic friction upper limit	-1000 to 1000	0	0.1 %	A	○	○	○	○	
5	72	Deterioration diagnosis dynamic friction lower limit	-1000 to 1000	0	0.1 %	A	○	○	○	○	
5	73	Deterioration diagnosis viscous friction upper limit	0 to 10000	0	0.1%/(10000 r/min)	A	○	○	○	○	
5	74	Deterioration diagnosis viscous friction lower limit	0 to 10000	0	0.1%/(10000 r/min)	A	○	○	○	○	
5	75	Deterioration diagnosis velocity setting	-20000 to 20000	0	r/min	A	○	○	○	○	
5	76	Deterioration diagnosis torque average time	0 to 10000	0	ms	A	○	○	○	○	
5	77	Deterioration diagnosis torque upper limit	-1000 to 1000	0	0.1 %	A	○	○	○	○	
5	78	Deterioration diagnosis torque lower limit	-1000 to 1000	0	0.1 %	A	○	○	○	○	
5	95	Manufacturer use	—	0	0	—	—	—	—	—	—
5	110	Driver derating factor	0 to 100	100	%	A	○	○	○	○	OI_O
5	112	Manufacturer use	—	0	—	—	—	—	—	—	—

*1 Factory default values vary depending on the servo driver and motor combination.

For details, see Operating Instructions (Overall) “8.1 Torque Limit Switching Function” .

7.1.8 Class 6: Special Settings

○: Enabled X: Disabled —: N/A

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference	
Class	No.						P	S	T	F		
6	02	Speed deviation excess setup	0 to 20000	0	r/min	A	○	×	×	×	OI_O	
6	03	Manufacturer use	—	0	—	—	—	—	—	—		
6	05	Position 3rd gain valid time	0 to 10000	0	0.1 ms	B	○	×	×	○	“4.3.3”	
6	06	Position 3rd gain scale factor	50 to 1000	100	%	B	○	×	×	○		
6	07	Torque command additional value	-100 to 100	0	%	B	○	○	×	○	“4.5.3”	
6	08	Positive direction torque compensation value	-100 to 100	0	%	B	○	×	×	○		
6	09	Negative direction torque compensation value	-100 to 100	0	%	B	○	×	×	○		
6	10	Function expansion setup	-32768 to 32767	16	—	B	○	○	○	○	—	
		● bit 1: Load fluctuation control function										“4.6.3”
		● bit 2: Load fluctuation stabilization setting										“4.7.3”
		● bit 4: Current response improvement										“7.5”
		● bit 10: Fall prevention function during an alarm										OI_O
		● bit 11: Encoder overheat error protection detection										OI_O
		● bit 14: Load fluctuation suppression function automatic tuning										“4.1.1.4” “4.1.2.4” “4.1.3.4” “4.6.3” “4.7.3”
		● bit 15: Slow stop function										OI_O
6	11	Current loop gain response setup	10 to 300	100	%	B	○	○	○	○	“4.8.3”	
6	14	Emergency stop time at alarm	0 to 1000	200	ms	B	○	○	○	○	OI_O	
6	15	2nd overspeed level setting	0 to 20000	0	r/min	B	○	○	○	○	OI_O	
6	18	Power-up wait time	0 to 100	0	0.1 s	R	○	○	○	○	OI_O	
6	19	Manufacturer use	—	0	—	—	—	—	—	—	—	
⋮												
6	21	Manufacturer use	—	0	—	—	—	—	—	—		
6	22	AB phase external scale pulse outputting method selection	0 to 1	0	—	R	×	×	×	○	OI_O	
6	23	Load change compensation gain	-100 to 100	0	%	B	○	○	×	○	“4.6.3” “4.7.3”	
6	24	Load change compensation filter	10 to 2500	53	0.01 ms	B	○	○	×	○		
6	26	Manufacturer use	—	0	—	—	—	—	—	—	—	
6	27	Warning latch state setup	0 to 3	0	—	C	○	○	○	○	—	
		● bit 0: Expanded warnings										OI_O
		● bit 1: General warnings										
6	30	Manufacturer use	—	0	—	—	—	—	—	—	—	
6	31	Real time auto tuning estimation speed	0 to 3	1	—	B	○	○	○	○	“4.1.1.4”	
											“4.1.2.4”	
											“4.1.3.4”	

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
6	32	Real time auto tuning custom setup	-32768 to 32767	0	—	B	○	○	○	○	— “4.1.1.4” “4.1.2.4” “4.1.3.4”
		● bit 1 to 0: Load characteristics estimation									
		● bit 3 to 2: Inertia Ratio Update									
		● bit 6 to 4: Torque compensation									
		● bit 7: Stiffness Setup									
		● bit 8: Fixed Parameter Setup									
		● bit 10 to 9: Gain Switching Setup									
		● bit 11: Torque compensation setting switching									
		● bit 15 to 12: Individual torque compensation settings									
6	34	Hybrid vibration suppression gain	0 to 30000	0	0.1 s ⁻¹	B	×	×	×	○	“5.9.3”
6	35	Hybrid vibration suppression filter	0 to 32000	10	0.01 ms	B	×	×	×	○	
6	36	Dynamic brake operation input setup	0 to 1	0	—	R	○	○	○	○	OI_O
6	37	Oscillation detecting level	0 to 1000	0	0.1 %	B	○	○	○	○	OI_O
6	38	Warning mask setup	-32768 to 32767	4	—	C	○	○	○	○	
6	39	Warning mask setup 2	-32768 to 32767	0	—	C	○	○	○	○	
6	41	1st damping depth	0 to 1000	0	—	B	○	×	×	○	“5.5.3”
6	42	2-stage torque filter time constant	0 to 2500	0	0.01 ms	B	○	○	○	○	“5.2.3”
6	43	2-stage torque filter attenuation term	0 to 1000	0	—	B	○	○	○	○	
6	47	Function expansion setup 2	-32768 to 32767	1	—	R	○	○	○	○	—
		● bit 0: Two-degree-of-freedom control mode									“7.5” OI_O
		● bit 2: Encoder communication error/warning judgment setup									OI_O
		● bit 3: Two-degree-of-freedom control real-time auto tuning selection									“7.5” OI_O
		● bit 14: Quadrant glitch compensation function									“4.9.3”
6	48	Tuning filter	0 to 2000	Size A: 11 Size B: 12 Sizes C, D: 17 (12) (*1)	0.1 ms	B	○	○	×	○	OI_O
6	49	Command response/tuning filter attenuation term	0 to 99	15	—	B	○	×	×	○	“5.7.3” OI_O
6	50	Viscous friction compensating gain	0 to 10000	0	0.1 %/ (10000 r/min)	B	○	○	×	○	OI_O
6	51	Wait time for emergency stop	0 to 10000	0	ms	B	○	○	○	○	OI_O
6	52	Manufacturer use	—	0	—	—	—	—	—	—	—
⋮											
6	54	Manufacturer use	—	0	—	—	—	—	—	—	
6	57	Torque saturation error protection detection time	0 to 5000	0	ms	B	○	○	×	○	OI_O
6	58	Manufacturer use	—	0	—	—	—	—	—	—	—
6	59	Manufacturer use	—	0	—	—	—	—	—	—	—
6	60	2nd damping depth	0 to 1000	0	—	B	○	×	×	○	“5.5.3”
6	61	1st resonance frequency	0 to 3000	0	0.1 Hz	B	○	×	×	×	“5.6.3”
6	62	1st resonance attenuation ratio	0 to 1000	0	—	B	○	×	×	×	
6	63	1st anti-resonance frequency	0 to 3000	0	0.1 Hz	B	○	×	×	×	

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
6	64	1st anti-resonance attenuation ratio	0 to 1000	0	—	B	O	X	X	X	"5.6.3"
6	65	1st response frequency	0 to 3000	0	0.1 Hz	B	O	X	X	X	
6	66	2nd resonance frequency	0 to 3000	0	0.1 Hz	B	O	X	X	X	
6	67	2nd resonance attenuation ratio	0 to 1000	0	—	B	O	X	X	X	
6	68	2nd anti-resonance frequency	0 to 3000	0	0.1 Hz	B	O	X	X	X	
6	69	2nd anti-resonance attenuation ratio	0 to 1000	0	—	B	O	X	X	X	
6	70	2nd response frequency	0 to 3000	0	0.1 Hz	B	O	X	X	X	
6	71	3rd damping depth	0 to 1000	0	—	B	O	X	X	O	"5.5.3"
6	72	4th damping depth	0 to 1000	0	—	B	O	X	X	O	
6	73	Load estimation filter	0 to 2500	0	0.01 ms	B	O	O	X	O	"4.6.3" "4.7.3"
6	74	Torque compensation frequency 1	0 to 5000	0	0.1 Hz	B	O	O	X	O	
6	75	Torque compensation frequency 2	0 to 5000	0	0.1 Hz	B	O	O	X	O	
6	76	Load estimation count	0 to 8	0	—	B	O	O	X	O	
6	85	Retracting operation condition setting	-32768 to 32767	0	—	C	O	O	O	O	—
		<ul style="list-style-type: none"> bits 0 to 3: Retracting operation initialization conditions (I/O) bits 7 to 4: Retracting operation initialization conditions (communication) bits 9 to 8: Judgment condition for stopping retracting operation 									OI_O
6	86	Retracting operation alarm setting	-32768 to 32767	0	—	C	O	O	O	O	—
		<ul style="list-style-type: none"> bit 0: Err85.0.0 "Retracting operation completion (I/O)" /Err87.1.0 "Retracting operation completion (I/O)" bit 1: Err85.1.0 "Retracting operation completion (communication)" /Err87.2.0 "Retracting operation completion (communication)" bit 2: Err85.2.0 "Retracting operation error" /Err87.3.0 "Retracting operation error" bit 15: Retracting operation-related alarm switching 									OI_O
6	87	Manufacturer use	—	0	—	—	—	—	—	—	—
6	88	Absolute encoder multi-turn data upper-limit value	0 to 65534	0	—	C	O	O	O	O	OI_O TR_CS
6	95	Motor overload warning detection level	0 to 114	0	%	A	O	O	O	O	OI_O
6	96	Motor overload warning release level	0 to 114	0	%	A	O	O	O	O	
6	97	Function expansion setup 3	-2147483648 to 2147483647	1024	—	B	O	O	O	O	—
		<ul style="list-style-type: none"> bit 0: Quadrant glitch compensation HPF clear bit 1: Deterioration Diagnosis Warning Function bit 2: Motor movable range error protection expansion bit 6: Manufacturer use bit 10: Position comparison output function selection bit 27: Alarm display switch setting 									"4.9.3" OI_O OI_O — OI_O TR_FS
6	98	Function expansion setup 4	-2147483648 to 2147483647	0	—	R	O	O	O	O	—
		<ul style="list-style-type: none"> bit 3: Effective bit expansion for multi-turn data bit 9: Virtual full-closed control mode function 									TR_CS OI_O
6	104	Open-phase monitoring setup	0 to 3	0	—	B	O	O	O	O	OI_O
6	106	Manufacturer use	—	0	—	—	—	—	—	—	—
6	121	Current feed forward response setup	0 to 300	100	%	B	O	O	O	O	"4.8.3"

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
6	125	Manufacturer use	—	0	—	—	—	—	—	—	—
6	126	Warning 2 mask setup	-2147483648 to 2147483647	0	—	C	O	O	O	O	OI_O
6	127	Warning 3 mask setup	-2147483648 to 2147483647	0	—	C	O	O	O	O	

*1 Values in parentheses are initial values for models with an instantaneous maximum current (peak value) of less than 24 A.

7.1.9 Class 7: Special Settings 2

○: Enabled X: Disabled —: N/A

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
7	00	Display on LED	0 to 32767	0	—	A	O	O	O	O	OI_O
7	01	Address display time setup upon power-up	-1 to 1000	0	100 ms	R	O	O	O	O	
7	03	Output setup during torque limit	0 to 1	0	—	A	X	X	O	X	OI_O
7	04	Manufacturer use	—	0	—	—	—	—	—	—	—
⋮											
7	08	Manufacturer use	—	0	—	—	—	—	—	—	
7	09	Correction time of latch delay 1	-2000 to 2000	360	25 ns	B	O	O	O	O	TR_CS
7	10	Software limit function	0 to 3	0	—	A	O	X	X	O	TR_CS
7	11	Positive side software limit value	-1073741823 to 1073741823	500000	Command unit	A	O	X	X	O	
7	12	Negative side software limit value	-1073741823 to 1073741823	-500000	Command unit	A	O	X	X	O	
7	13	Absolute home position offset	-2147483648 to 2147483647	0	Command unit	C	O	O	O	O	OI_O TR_CS
7	14	Main power off warning detection time	0 to 2000	0	ms	C	O	O	O	O	OI_O
7	15	Positioning proximity range	0 to 1073741823	10	Command unit	A	O	X	X	O	TR_CS
7	16	Torque saturation error protection frequency	0 to 30000	0	Incidences	B	O	O	X	O	OI_O
7	20	RTEX communication cycle setup	-1 to 12	3	—	R	O	O	O	O	OI_O TR_CS
7	21	RTEX command updating cycle ratio setup	1 to 2	2	—	R	O	O	O	O	
7	22	RTEX function expansion setup 1	-32768 to 32767	0	—	R	O	O	O	O	—
		● bit 0: RTEX communication data size									OI_O TR_CS
		● bit 1: Interaxis full-synchronous mode using RTEX communication TMG_CNT									
		● bit 4: External scale position information monitoring function setting for semi-closed control									OI_O TR_CS
		● bit 5: Command position change saturation function selection									TR_CS
● bit 6: Homing return velocity limit enabled									TR_CS		
7	23	RTEX function expansion setup 2	-32768 to 32767	18	—	B	O	O	O	O	—
		● bit 0: Parameter writing via RTEX communication permitted									TR_CS
		● bit 1: Alarm No. sub-number setting									TR_CS
		● bit 2: RTEX status response condition setting with POT and NOT functions disabled									OI_O TR_CS
		● bit 3: POT and NOT RTEX status bit arrangement settings									OI_O TR_CS
		● bit 4: COM-LED compatibility (COM-LED is the phase status)									OI_O
		● bit 5: Non-cyclic Command Startup Mode Settings									TR_CS
		● bit 6: POT and NOT RTEX status logical settings									OI_O TR_CS
		● bit 7: RTEX status bit arrangement settings for PSL and NSL									TR_CS
		● bit 8: RTEX status selection of In_Progress/AC_OFF									OI_O TR_CS
		● bit 9: Command error return switching for commands received in the direction of over-travel inhibit input after over-travel inhibit deceleration to stop									OI_O TR_CS
		● bit 14: Position deviation [command unit] output setup									OI_O
		● bit 15: In_Progress/AC_OFF/Pr7.112 value									OI_O TR_CS

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
7	24	RTEX function expansion setup 3	-32768 to 32767	0	—	C	O	O	O	O	—
		● bit 0: EX-OUT1 output status setting at the time of communication interrupted after RTEX communication is established									TR_FS TR_CS
		● bit 1: EX-OUT2 output status setting at the time of communication interrupted after RTEX communication is established									
		● bit 3: RTEX communication In_Position judgment condition setting									OI_O
		● bit 4: Servo_Active ON timing switching									TR_CS
		● bit 5: Latch position detection delay compensation function switching									TR_CS
		● bit 7: Internal value status selection of TFF from RTEX communication (fall prevention when servo-on)									OI_O TR_CS
7	25	RTEX velocity unit setup	0 to 1	0	—	C	O	O	O	O	OI_O
7	26	RTEX continuous communication error warning setup	0 to 32767	0	Incidences	A	O	O	O	O	OI_O
7	27	RTEX accumulated communication error warning setup	0 to 32767	0	Incidences	A	O	O	O	O	
7	28	RTEX_Update_Counter error warning setup	0 to 32767	0	Incidences	A	O	O	O	O	
7	29	RTEX monitor select 1	0 to 32767	0	—	A	O	O	O	O	TR_CS
7	30	RTEX monitor select 2	0 to 32767	0	—	A	O	O	O	O	TR_CS
7	31	RTEX monitor select 3	0 to 32767	0	—	A	O	O	O	O	
7	32	RTEX monitor select 4	0 to 32767	0	—	A	O	O	O	O	TR_CS
7	33	RTEX monitor select 5	0 to 32767	0	—	A	O	O	O	O	TR_CS
7	34	RTEX monitor select 6	0 to 32767	0	—	A	O	O	O	O	
7	35	RTEX command setup 1	0 to 2	0	—	C	O	O	O	O	OI_O TR_CS
7	36	RTEX command setup 2	0 to 2	0	—	C	O	O	O	O	
7	37	RTEX command setup 3	0 to 2	0	—	C	O	O	O	O	
7	38	RTEX_Update_Counter error protection setup	0 to 32767	0	Incidences	A	O	O	O	O	OI_O
7	39	Manufacturer use	—	0	—	—	—	—	—	—	—
7	41	RTEX function expansion setup 5	-32768 to 32767	0	—	R	O	O	O	O	—
		● bit 7: Over-travel inhibit input detection setting during Z-phase homing return operation									TR_CS
7	44	Manufacturer use	—	16908546	—	—	—	—	—	—	—
7	78	Latch trigger signal reading setting with stop function	0 to 3	0	—	C	O	X	X	O	OI_O
7	80	Manufacturer use	—	0	—	—	—	—	—	—	—
7	87	Manufacturer use	—	0	—	—	—	—	—	—	—
⋮											
7	89	Manufacturer use	—	0	—	—	—	—	—	—	
7	91	RTEX communication cycle expansion setup	0 to 2000000	500000	ns	R	O	O	O	O	OI_O TR_CS
7	92	Correction time of latch delay 2	-2000 to 2000	0	25 ns	B	O	O	O	O	TR_CS
7	93	Homing return speed limit value	0 to 20000	0	r/min	C	O	O	O	O	TR_CS
7	95	RTEX continuous communication error protection 1 detection count	0 to 17	4	Incidences	R	O	O	O	O	TR_CS OI_O
7	96	RTEX continuous communication error protection 2 detection count	0 to 17	12	Incidences	R	O	O	O	O	TR_CS OI_O
7	97	RTEX communication timeout error protection detection count	0 to 17	4	Incidences	R	O	O	O	O	OI_O
7	98	RTEX cyclic data error protection 1/2 detection count	0 to 17	4	Incidences	R	O	O	O	O	OI_O

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
7	99	RTEX function expansion setup 6	-32768 to 32767	0	—	B	O	O	O	O	—
		● bit 0: Enable/disable FFT execution while RTEX communication is established									OI_O TR_CS
		● bit 3: Command pulse accumulated value [command unit] output setting									OI_O
		● bit 7: Monitor command regenerative load factor unit switching									TR_CS
7	100	Manufacturer use	—	0	—	—	—	—	—	—	—
⋮											
7	104	Manufacturer use	—	0	—	—	—	—	—	—	
7	108	RTEX communication synchronization setup	0 to 7	7	—	R	O	O	O	O	OI_O
7	109	Manufacturer use	—	1	—	—	—	—	—	—	—
7	110	RTEX function expansion setup 7	-2147483648 to 2147483647	0	—	B	×	×	×	O	—
		● bit 4: Profile position control mode startup condition expansion									TR_CS
		● bit 16: External scale position variation enabled during virtual full-closed control mode									OI_O
7	111	Trigger signal allocation setting of latch mode with stop function	0 to 64	0	—	C	O	×	×	O	OI_O TR_CS
7	112	Selection of RTEX communication status flag	0 to 2	0	—	B	O	O	O	O	OI_O
7	127	Manufacturer use	—	0	—	—	—	—	—	—	—

7.1.10 Class 8: Special Settings 3

○: Enabled ✕: Disabled —: N/A

Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
8	00	Manufacturer use	—	0	—	—	—	—	—	—	—
8	01	Profile linear acceleration constant	1 to 429496	100	10,000 command units/s ²	B	○	○	○	○	OI_O TR_CS
8	02	Manufacturer use	—	0	—	—	—	—	—	—	—
8	03	Manufacturer use	—	0	—	—	—	—	—	—	—
8	04	Profile linear deceleration constant	1 to 429496	100	10,000 command units/s ²	B	○	○	○	○	OI_O TR_CS
8	05	Manufacturer use	—	0	—	—	—	—	—	—	—
8	10	Amount of travel after profile position latch detection	-1073741823 to 1073741823	0	Command unit	B	○	✕	✕	○	TR_CS
8	12	Profile homing mode setting	0 to 1	0	—	B	○	✕	✕	○	
8	13	Profile homing speed 1	0 to 2147483647	50	Command unit/s or r/min	B	○	✕	✕	○	
8	14	Profile homing speed 2	0 to 2147483647	5	Command unit/s or r/min	B	○	✕	✕	○	OI_O
8	15	Manufacturer use	—	0	—	—	—	—	—	—	
8	17	Relative movement of retracting operation	-2147483647 to 2147483647	0	Command unit	B	○	○	○	○	
8	18	Retracting operation speed	0 to 2147483647	0	Command unit/s or r/min	B	○	○	○	○	—
8	19	Manufacturer use	—	0	—	—	—	—	—	—	

7.1.11 Class 11: Manufacturer Use

○: Enabled X: Disabled —: N/A


Parameter No.		Parameter name	Setting range	Factory default values	Unit	Attribute	Related control mode				Reference
Class	No.						P	S	T	F	
11	00	Manufacturer use	—	1	—	—	—	—	—	—	—
11	01	Manufacturer use	—	503578880	—	—	—	—	—	—	—
11	02	Manufacturer use	—	658185	—	—	—	—	—	—	—
11	03	Manufacturer use	—	-1	—	—	—	—	—	—	—
11	04	Manufacturer use	—	-1	—	—	—	—	—	—	—
11	05	Manufacturer use	—	-1	—	—	—	—	—	—	—
11	06	Manufacturer use	—	-1	—	—	—	—	—	—	—
11	07	Manufacturer use	—	16	—	—	—	—	—	—	—
11	08	Manufacturer use	—	6	—	—	—	—	—	—	—
11	09	Manufacturer use	—	1	—	—	—	—	—	—	—
11	10	Manufacturer use	—	129	—	—	—	—	—	—	—
11	11	Manufacturer use	—	0	—	—	—	—	—	—	—
11	12	Manufacturer use	—	0	—	—	—	—	—	—	—
11	13	Manufacturer use	—	0	—	—	—	—	—	—	—
11	14	Manufacturer use	—	0	—	—	—	—	—	—	—
11	15	Manufacturer use	—	0	—	—	—	—	—	—	—
11	16	Manufacturer use	—	255	—	—	—	—	—	—	—
11	17	Manufacturer use	—	0	—	—	—	—	—	—	—
11	18	Manufacturer use	—	0	—	—	—	—	—	—	—
11	19	Manufacturer use	—	0	—	—	—	—	—	—	—
11	20	Manufacturer use	—	0	—	—	—	—	—	—	—
11	21	Manufacturer use	—	0	—	—	—	—	—	—	—
11	22	Manufacturer use	—	15	—	—	—	—	—	—	—
11	23	Manufacturer use	—	0	—	—	—	—	—	—	—
11	24	Manufacturer use	—	0	—	—	—	—	—	—	—
11	25	Manufacturer use	—	0	—	—	—	—	—	—	—
11	26	Manufacturer use	—	0	—	—	—	—	—	—	—

7.2 Control Mode Block Diagram

Block diagrams of each control mode including the various control functions are shown below.

7.2.1 Position Control Mode Block Diagram


Control Block Diagram: Position Control (Two-degree-of-freedom Control Mode Enabled)



*1 Position deviation [command unit] operation criteria can be changed in Pr7.23 "Communication function extended setup 2" :bit 14.

*2 Position commands in Set-up Support Software (PANATERM ver.7) depend on Pr7.99 "Communication function extended setup 6" :bit 3 "Command pulse accumulated value [command unit] output setting" settings.

Control Block Diagram: Position Control (Two-degree-of-freedom Control Mode Disabled)




*1 Position deviation [command unit] operation criteria can be changed in Pr7.23 "Communication function extended setup 2" :bit 14.


*2 Position commands in Set-up Support Software (PANATERM ver.7) depend on Pr7.99 "Communication function extended setup 6" :bit 3 "Command pulse accumulated value [command unit] output setting" settings.

7.2.2 Speed Control Mode Block Diagram

Control Block Diagram: Velocity Control (Two-degree-of-freedom Control Mode Enabled)




Control Block Diagram: Velocity Control (Two-degree-of-freedom Control Mode Disabled)




7.2.3 Torque Control Mode Block Diagram

Control Block Diagram: Torque Control



7.2.4 Full-closed Control Mode Block Diagram

Control Block Diagram: Full-closed Control (Two-degree-of-freedom Control Mode Enabled)




*1 Position deviation [command unit] operation criteria can be changed in Pr7.23 "Communication function extended setup 2" :bit 14.

*2 Position commands in Set-up Support Software (PANATERM ver.7) depend on Pr7.99 "Communication function extended setup 6" :bit 3 "Command pulse accumulated value [command unit] output setting" settings.

*3 Velocity [r/min] unit calculated from encoder, not external scale.

Control Block Diagram: Full-closed Control (Two-degree-of-freedom Control Mode Disabled)



*1 Position deviation [command unit] operation criteria can be changed in Pr7.23 "Communication function extended setup 2" :bit 14.

*2 Position commands in Set-up Support Software (PANATERM ver.7) depend on Pr7.99 "Communication function extended setup 6" :bit 3 "Command pulse accumulated value [command unit] output setting" settings.

*3 Velocity [r/min] unit calculated from encoder, not external scale.

7.3 Parameters Related To TUNINGLESS

- Pr0.02 “Real-time auto-gain tuning setup”
- Pr0.03 “Real-time auto-tuning machine stiffness setup”
- Pr0.04 “Inertia ratio”
- Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2”
- Pr0.28 “Selection of feed forward stiffness at real-time auto-gain tuning”
- Pr1.00 “1st gain of position loop”
- Pr1.01 “1st velocity loop gain”
- Pr1.02 “1st velocity loop integration time constant”
- Pr1.03 “1st filter of velocity detection”
- Pr1.04 “1st torque filter time constant”
- Pr1.10 “Velocity feed forward gain”
- Pr1.11 “Velocity feed forward filter”
- Pr1.12 “Torque feed forward gain”
- Pr1.13 “Torque feed forward filter”
- Pr1.14 “2nd gain setup”
- Pr2.00 “Adaptive filter mode setup”
- Pr2.01 “1st notch frequency”
- Pr2.02 “1st notch width selection”
- Pr2.03 “1st notch depth selection”
- Pr2.04 “2nd notch frequency”
- Pr2.05 “2nd notch width selection”
- Pr2.06 “2nd notch depth selection”
- Pr2.07 “3rd notch frequency”
- Pr2.08 “3rd notch width selection”
- Pr2.09 “3rd notch depth selection”
- Pr2.10 “4th notch frequency”
- Pr2.11 “4th notch width selection”
- Pr2.12 “4th notch depth selection”
- Pr2.13 “Selection of damping filter switching”
- Pr2.14 “1st damping frequency”
- Pr2.15 “1st damping filter setup”
- Pr2.16 “2nd damping frequency”
- Pr2.17 “2nd damping filter setup”
- Pr2.18 “3rd damping frequency”
- Pr2.19 “3rd damping filter setup”
- Pr2.20 “4th damping frequency”
- Pr2.21 “4th damping filter setup”
- Pr2.22 “Positional command smoothing filter”
- Pr2.23 “Positional command FIR filter”
- Pr2.24 “5th notch frequency”
- Pr2.25 “5th notch width selection”

- Pr2.26 “5th notch depth selection”
- Pr2.27 “1st damping width setting”
- Pr2.28 “2nd damping width setting”
- Pr2.29 “3rd damping width setting”
- Pr2.30 “4th damping width setting”
- Pr2.38 “Filter function switching”
- Pr2.39 “Custom notch compensation coefficient”
- Pr2.40 “Custom notch compensation frequency 1”
- Pr2.41 “Custom notch compensation frequency 2”
- Pr2.42 “Custom notch frequency”
- Pr2.43 “Custom notch width”
- Pr2.44 “Custom notch depth”
- Pr2.45 “Function expansion setup 10”
- Pr2.46 “Tuning filter 2”
- Pr2.52 “Torque command additional value 2”
- Pr2.53 “Positive direction torque compensation value 2”
- Pr2.54 “Negative direction torque compensation value 2”
- Pr5.45 “Quadrant glitch positive-direction compensation value”
- Pr5.46 “Quadrant glitch negative-direction compensation value”
- Pr6.05 “Position 3rd gain valid time”
- Pr6.06 “Position 3rd gain scale factor”
- Pr6.07 “Torque command additional value”
- Pr6.08 “Positive direction torque compensation value”
- Pr6.09 “Negative direction torque compensation value”
- Pr6.10 “Function expansion setup”
- Pr6.11 “Current loop gain response setup”
- Pr6.23 “Load change compensation gain”
- Pr6.24 “Load change compensation filter”
- Pr6.32 “Real time auto tuning custom setup”
- Pr6.41 “1st damping depth”
- Pr6.42 “2-stage torque filter time constant”
- Pr6.43 “2-stage torque filter attenuation term”
- Pr6.47 “Function expansion setup 2”
- Pr6.50 “Viscous friction compensating gain”
- Pr6.60 “2nd damping depth”
- Pr6.71 “3rd damping depth”
- Pr6.72 “4th damping depth”
- Pr6.73 “Load estimation filter”
- Pr6.74 “Torque compensation frequency 1”
- Pr6.75 “Torque compensation frequency 2”
- Pr6.76 “Load estimation count”
- Pr6.121 “Current feed forward response setup”

7.4 Parameters Related To One Minute TUNING

- Pr0.02 “Real-time auto-gain tuning setup”
- Pr0.04 “Inertia ratio”
- Pr0.27 “Selection of machine stiffness at real-time auto-gain tuning 2”
- Pr0.28 “Selection of feed forward stiffness at real-time auto-gain tuning”
- Pr1.00 “1st gain of position loop”
- Pr1.01 “1st velocity loop gain”
- Pr1.02 “1st velocity loop integration time constant”
- Pr1.03 “1st filter of velocity detection”
- Pr1.04 “1st torque filter time constant”
- Pr1.05 “2nd gain of position loop”
- Pr1.06 “2nd velocity loop gain”
- Pr1.07 “2nd velocity loop integration time constant”
- Pr1.08 “2nd filter of velocity detection”
- Pr1.09 “2nd torque filter time constant”
- Pr1.10 “Velocity feed forward gain”
- Pr1.11 “Velocity feed forward filter”
- Pr1.12 “Torque feed forward gain”
- Pr1.13 “Torque feed forward filter”
- Pr1.14 “2nd gain setup”
- Pr1.15 “Mode of position control switching”
- Pr1.16 “Delay time of position control switching”
- Pr1.17 “Level of position control switching”
- Pr1.18 “Hysteresis at position control switching”
- Pr1.19 “Position gain switching time”
- Pr1.20 “Mode of velocity control switching”
- Pr1.21 “Delay time of velocity control switching”
- Pr1.22 “Level of velocity control switching”
- Pr1.23 “Hysteresis at velocity control switching”
- Pr1.24 “Mode of torque control switching”
- Pr1.25 “Delay time of torque control switching”
- Pr1.26 “Level of torque control switching”
- Pr1.27 “Hysteresis at torque control switching”
- Pr2.00 “Adaptive filter mode setup”
- Pr2.01 “1st notch frequency”
- Pr2.02 “1st notch width selection”
- Pr2.03 “1st notch depth selection”
- Pr2.04 “2nd notch frequency”
- Pr2.05 “2nd notch width selection”
- Pr2.06 “2nd notch depth selection”
- Pr2.07 “3rd notch frequency”
- Pr2.08 “3rd notch width selection”

- Pr2.09 “3rd notch depth selection”
- Pr2.10 “4th notch frequency”
- Pr2.11 “4th notch width selection”
- Pr2.12 “4th notch depth selection”
- Pr2.13 “Selection of damping filter switching”
- Pr2.14 “1st damping frequency”
- Pr2.15 “1st damping filter setup”
- Pr2.16 “2nd damping frequency”
- Pr2.17 “2nd damping filter setup”
- Pr2.18 “3rd damping frequency”
- Pr2.19 “3rd damping filter setup”
- Pr2.20 “4th damping frequency”
- Pr2.21 “4th damping filter setup”
- Pr2.22 “Positional command smoothing filter”
- Pr2.23 “Positional command FIR filter”
- Pr2.24 “5th notch frequency”
- Pr2.25 “5th notch width selection”
- Pr2.26 “5th notch depth selection”
- Pr2.27 “1st damping width setting”
- Pr2.28 “2nd damping width setting”
- Pr2.29 “3rd damping width setting”
- Pr2.30 “4th damping width setting”
- Pr2.38 “Filter function switching”
- Pr2.39 “Custom notch compensation coefficient”
- Pr2.40 “Custom notch compensation frequency 1”
- Pr2.41 “Custom notch compensation frequency 2”
- Pr2.42 “Custom notch frequency”
- Pr2.43 “Custom notch width”
- Pr2.44 “Custom notch depth”
- Pr2.45 “Function expansion setup 10”
- Pr2.46 “Tuning filter 2”
- Pr2.52 “Torque command additional value 2”
- Pr2.53 “Positive direction torque compensation value 2”
- Pr2.54 “Negative direction torque compensation value 2”
- Pr2.61 “Target settling time”
- Pr2.62 “Settling time count condition”
- Pr2.63 “Allowable overshoot amount”
- Pr2.64 “Tuning amount of movement”
- Pr2.65 “Tuning max speed”
- Pr2.66 “Tuning acceleration and deceleration time”
- Pr2.67 “Tuning wait time”
- Pr2.68 “Tuning operating range upper limit”
- Pr2.69 “Tuning operating range lower limit”

- Pr2.70 “Tuning overspeed level setting”
- Pr2.71 “Tuning torque limit”
- Pr2.72 “Tuning start RTAT machine stiffness setting”
- Pr2.73 “Tuning stability margin”
- Pr2.74 “Tuning auto tuning application selection”
- Pr2.75 “Tuning step selection”
- Pr2.76 “Tuning target function selection”
- Pr2.77 “Tuning start position”
- Pr2.78 “Tuning vibration automatic suppression effective level”
- Pr2.79 “Tuning JOG test run command speed”
- Pr2.80 “Tuning JOG test run acceleration and deceleration time”
- Pr5.45 “Quadrant glitch positive-direction compensation value”
- Pr5.46 “Quadrant glitch negative-direction compensation value”
- Pr5.47 “Quadrant glitch compensation delay time”
- Pr5.48 “Quadrant glitch compensation filter setting L”
- Pr5.49 “Quadrant glitch compensation filter setting H”
- Pr6.05 “Position 3rd gain valid time”
- Pr6.06 “Position 3rd gain scale factor”
- Pr6.07 “Torque command additional value”
- Pr6.08 “Positive direction torque compensation value”
- Pr6.09 “Negative direction torque compensation value”
- Pr6.10 “Function expansion setup”
- Pr6.11 “Current loop gain response setup”
- Pr6.23 “Load change compensation gain”
- Pr6.24 “Load change compensation filter”
- Pr6.32 “Real time auto tuning custom setup”
- Pr6.41 “1st damping depth”
- Pr6.42 “2-stage torque filter time constant”
- Pr6.43 “2-stage torque filter attenuation term”
- Pr6.47 “Function expansion setup 2”
- Pr6.48 “Tuning filter”
- Pr6.49 “Command response/tuning filter attenuation term”
- Pr6.50 “Viscous friction compensating gain”
- Pr6.60 “2nd damping depth”
- Pr6.61 “1st resonance frequency”
- Pr6.62 “1st resonance attenuation ratio”
- Pr6.63 “1st anti-resonance frequency”
- Pr6.64 “1st anti-resonance attenuation ratio”
- Pr6.65 “1st response frequency”
- Pr6.66 “2nd resonance frequency”
- Pr6.67 “2nd resonance attenuation ratio”
- Pr6.68 “2nd anti-resonance frequency”
- Pr6.69 “2nd anti-resonance attenuation ratio”

- Pr6.70 “2nd response frequency”
- Pr6.71 “3rd damping depth”
- Pr6.72 “4th damping depth”
- Pr6.73 “Load estimation filter”
- Pr6.74 “Torque compensation frequency 1”
- Pr6.75 “Torque compensation frequency 2”
- Pr6.76 “Load estimation count”
- Pr6.80 “3rd resonance frequency”
- Pr6.121 “Current feed forward response setup”

7.5 Other Parameters Related To Tuning

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
0	04	B	Inertia ratio	0 to 100000	%	Sets the ratio of load inertia to motor rotor inertia.
1	00	B	1st gain of position loop	0 to 30000	0.1 s ⁻¹	Sets the 1st position loop gain.
1	01	B	1st velocity loop gain	1 to 32767	0.1 Hz	Sets the 1st velocity loop gain.
1	02	B	1st velocity loop integration time constant	1 to 10000	0.1 ms	Sets the 1st velocity loop integration time constant. The integral is retained at the set value of 9999. Disabled when set value is 10000.
1	03	B	1st filter of velocity detection	0 to 5	—	Sets the 1st filter of velocity detection in 6 stages.
1	106	B	1st position loop gain change ratio	0 to 300	%	Sets the change ratio of Pr1.00 “1st gain of position loop” at the stiffness setting value when the gain change ratio is enabled . When this setup value is 0, this is set to 100 %.
1	107	B	1st velocity integration change ratio	0 to 300	%	Sets the change ratio of Pr1.02 “1st velocity loop integration time constant” at the stiffness setting value when the gain change ratio is enabled . When this setup value is 0, this is set to 100%.
1	108	B	1st torque filter change ratio	0 to 300	%	Sets the change ratio of Pr1.04 “1st torque filter time constant” at the stiffness setting value when the gain change ratio is enabled .
1	109	B	2nd position loop gain change ratio	0 to 300	%	Sets the change ratio of Pr1.05 “2nd gain of position loop” at the stiffness setting value when the gain change ratio is enabled . When this setup value is 0, this is set to 100%.
1	110	B	2nd velocity loop gain change ratio	0 to 300	%	Sets the change ratio of Pr1.06 “2nd velocity loop gain” at the stiffness setting value when the gain change ratio is enabled . When this setup value is 0, this is set to 100%.
1	111	B	2nd velocity integration change ratio	0 to 300	%	Sets the change ratio of Pr1.07 “2nd velocity loop integration time constant” at the stiffness setting value when the gain change ratio is enabled . When this setup value is 0, this is set to 100 %.
1	112	B	2nd torque filter change ratio	0 to 300	%	Sets the change ratio of Pr1.09 “2nd torque filter time constant” at the stiffness setting value when the gain change ratio is enabled .
1	113	B	Load fluctuation compensation filter change ratio	0 to 300	%	Sets the change ratio of Pr6.24 “Load change compensation filter” at the stiffness setting value when the gain change ratio is enabled . When this setup value is 0, this is set to 100%.
1	114	B	Smoothing filter change ratio	0 to 300	%	Sets the change ratio of Pr2.22 “Positional command smoothing filter” at the stiffness setting value when the gain change ratio is enabled .
1	115	B	Tuning filter change ratio	0 to 300	%	Sets the change ratio of Pr6.48 “Tuning filter” at the stiffness setting value when the gain change ratio is enabled .
2	61	A	Target settling time	0 to 32767	ms	Sets the target settling time during tuning. If the setup value is 0, the settling time is tuned to be shorter.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	62	A	Settling time count condition	0 to 1	—	Specifies the condition for counting the settling time during tuning. 0: Counted after completion of command transfer judgment. 1: Counted at start of command transfer judgment.
2	63	A	Allowable overshoot amount	0 to 500	%	Sets the allowable amount of overshoot during tuning as a percentage of Pr4.31 "Positioning complete (In-position) range". Set to 0 to tune without overshoot.
2	64	A	Tuning amount of movement	0 to 2147483647	Command unit	Sets the amount of movement when using operation commands during tuning. This can be set when tuning is performed using only operation commands from the servo driver. If the setup value is 0, the value automatically determined by the servo driver is used.
2	65	A	Tuning max speed	0 to 20000	r/min	Sets the maximum speed when using operation commands during tuning. This can be set when tuning is performed using only operation commands from the servo driver. If the setup value is 0, the value automatically determined by the servo driver is used.
2	66	A	Tuning acceleration and deceleration time	0 to 5000	ms	Sets the acceleration/deceleration time when using operation commands during tuning. This can be set when tuning is performed using only operation commands from the servo driver. If the setup value is 0, the value automatically determined by the servo driver is used.
2	67	A	Tuning wait time	0 to 10000	ms	Sets the waiting time when using operation commands during tuning. This can be set when tuning is performed using only operation commands from the servo driver.
2	68	A	Tuning operating range upper limit	0 to 1073741823	Command unit	Sets the amount of movement that the motor is allowed to move in the positive direction from the tuning start position during tuning.
2	69	A	Tuning operating range lower limit	-1073741824 to 0	Command unit	Sets the amount of movement that the motor is allowed to move in the negative direction from the tuning start position during tuning.
2	70	A	Tuning over-speed level setting	0 to 20000	r/min	Sets the upper limit for the allowable motor speed during tuning. Various speed protection settings are used when the setup value is 0.
2	71	A	Tuning torque limit	0 to 500	%	Sets the upper-limit value (absolute value) for the allowable torque command during tuning. Torque limit settings are used when the setup value is 0.
2	72	A	Tuning start RTAT machine stiffness setting	0 to 44	—	Specifies the RTAT machine stiffness setting at the start of the tuning.
2	73	A	Tuning stability margin	0 to 100	%	Specifies the stability margin during tuning in %.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
2	75	A	Tuning step selection	-32768 to 32767	—	Specifies the target step for performing tuning. If the bit is 0, it is excluded from the step to be adjusted. If the bit is 1, it is the step to be adjusted. bit 0: Advance operation bit 1: Homing operation bit 2 to 15: Manufacturer use
2	76	A	Tuning target function selection	-32768 to 32767	—	Specifies the function to be tuned. If the bit is 0, it is excluded from the parameters to be tuned. If the bit is 1, it is the parameter to be tuned. bit 0: Inertia ratio bit 1: Unbalanced load compensation (default disabled) bit 2: Dynamic friction compensation (default disabled) bit 3: Viscous friction compensation (default disabled) bit 4: RTAT machine stiffness setting (position and speed gains, speed integration time constant, torque filter) bit 5: RTAT feedforward control section stiffness setting (smoothing filter time constant) bit 6: Notch filter bit 7: 1st damping filter bit 8: 2nd damping filter bit 9: Load fluctuation control function bit 15 to 10: Manufacturer use
2	77	A	Tuning start position	-1073741824 to 1073741823	Command unit	Sets the initial position at the start of tuning.
2	78	A	Tuning vibration automatic suppression effective level	0 to 100	%	Sets the threshold for automatic vibration suppression during tuning.
2	79	A	Tuning JOG test run command speed	0 to 500	r/min	Sets the command speed for JOG trial runs at the time of tuning.
2	80	A	Tuning JOG test run acceleration and deceleration time	0 to 5000	ms	Sets the acceleration/deceleration time during JOG trial run at the time of tuning.
4	31	A	Positioning complete (In-position) range	0 to 2097152	Command unit	Sets the threshold value of position deviation that outputs the positioning complete signal (INP). The command unit is used as the default unit but can be replaced by the encoder unit or external scale unit by using Pr5.20 "Position setup unit select". However, in such cases, note that the unit of Pr0.14 "Position deviation excess setup" will also be changed. The position deviation value can switch the command before and after the position command filter using the Pr7.23 "Communication function extended setup 2" :bit 14 setting.

Class	No.	Attribute (*1)	Parameter name	Setting range	Unit	Function
6	10	B	Function expansion setup	-32768 to 32767	—	bit 4: Current response improvement 0: Disabled 1: Enabled Set to bit = 1 (enabled) when in synchronous mode, synchronous friction compensation mode, stiffness setting mode, or load fluctuation support mode (Pr0.02 = 1 to 3, or 6).
6	47	R	Function expansion setup 2	-32768 to 32767	—	Set the functions in bit units. bit 0: Two-degree-of-freedom control mode 0: Disabled 1: Enabled bit 3: Two-degree-of-freedom control real-time auto tuning selection 0: Standard type 1: Synchronization type Notes <ul style="list-style-type: none"> bit 3 can only be used when bit 0 is 1.

*1 For attributes, see [“7.1 List of Parameters”](#).

7.6 List of Errors Related to One Minute TUNING

—: N/A

Error No.	Error name	Primary Causes and Measures	Reference
257	Initial setting error 1	Command conditions are not set. Set Tuning amount of movement [command unit], Tuning max speed [r/min], and Tuning acceleration and deceleration time [ms/max speed] all to a value greater than 0.	“Advanced Settings Items” - “Command conditions” of “3.1.2.4.2 Initial Settings”
258	Initial setting error 2	Target settling time is set greater than the command (Tuning wait time - 500 ms). Set Target settling time [ms] to a value smaller than (Tuning wait time - 500 ms).	“Advanced Settings Items” - “Required performance” of “3.1.2.4.2 Initial Settings”
259	Initial setting error 3	Target settling time is set greater than the command (operation time + Tuning wait time - 500 ms) in [Command conditions]. Set Target settling time [ms] to a value smaller than (operating time + Tuning wait time - 500 ms). The value obtained by adding the operating time and tuning wait time [ms] is 10000 [ms] or more. Set the tuning amount of movement [command unit], tuning max speed [r/min], tuning acceleration and deceleration time [ms/JOG speed], and tuning wait time [ms] so that the sum of the operating time and tuning wait time [ms] is less than 10000 [ms]. Notes <ul style="list-style-type: none"> Operating time is the time from the start of command transfer to the completion of transfer. 	“Advanced Settings Items” - “Required performance” of “3.1.2.4.2 Initial Settings” “Advanced Settings Items” - “Command conditions”
260	Initial setting error 4	Positioning complete (In-position) range is set greater than the operating range. Set Positioning complete (In-position) range [command unit] to a value smaller than the operating range [command unit].	“Advanced Settings Items” - “Required performance” of “3.1.2.4.2 Initial Settings”
261	Initial setting error 5	Positioning complete (In-position) range is set greater than the command amount of movement. Set Positioning complete (In-position) range [command unit] to a value smaller than Tuning amount of movement [command unit].	“Advanced Settings Items” - “Required performance” of “3.1.2.4.2 Initial Settings”
263	Initial setting error 6	Allowable overshoot amount is set greater than the operating range. (Set Positioning complete (In-position) range [command unit] × Allowable overshoot amount[%]/100) to a value smaller than the operating range [command unit].	“Step 5” of “3.1.2.4.2 Initial Settings” “Advanced Settings Items” - “Required performance”
264	Initial setting error 7	The command amount of movement exceeds the operating range. Set Tuning amount of movement [command unit] to the operating range [command unit] or less.	“Advanced Settings Items” - “Command conditions” of “3.1.2.4.2 Initial Settings” “Step 5”
265 266	Initial setting error 8	The JOG trial run command speed or command maximum speed exceeds Over-speed level setup. Set Tuning JOG test run command speed [r/min] and Tuning max speed [r/min] to Over-speed level setup [r/min] or less.	“Advanced Settings Items” - “Detailed Protection Function” of “3.1.2.4.2 Initial Settings” “Step 3”

Error No.	Error name	Primary Causes and Measures	Reference
267 268	Initial setting error 9	The JOG trial run command speed or command maximum speed exceeds Tuning overspeed level setting. Set Tuning JOG test run command speed [r/min] and Tuning max speed [r/min] to Tuning overspeed level setting [r/min] or less.	“Advanced Settings Items” - “Command conditions” of “3.1.2.4.2 Initial Settings” “Advanced Settings Items” - “Detailed Protection Function”
275	Initial setting error 10	The set command acceleration is outside the allowable range for One Minute TUNING. Set the command acceleration to be in the range of 125001 to 4294967295 [command unit/s ²], referring to the formula below. $\text{Acceleration [command unit/s}^2\text{]} = \text{Tuning max speed [r/min]} / \text{Tuning acceleration and deceleration time [ms/max speed]} \times 1000/60 \times (\text{encoder resolution} / \text{electronic gear ratio})$ *For rotary type motor	“Advanced Settings Items” - “Command conditions” of “3.1.2.4.2 Initial Settings”
277	Initial setting error 11	A tuning target is not selected. Turn ON one of the tuning targets.	“Advanced Settings Items” - “Tuning conditions” of “3.1.2.4.2 Initial Settings”
278	Initial setting error 12	Tuning cannot be performed correctly because the set operating range is too small. Set a larger operating range. For One Minute TUNING, a setting of 0.5 rotations or more is recommended for the amount of motor rotations.	“Step 5” of “3.1.2.4.2 Initial Settings”
279	Initial setting error 13	Tuning cannot be performed correctly because the value set for Tuning amount of movement is too small. Increase the value set for Tuning amount of movement.	“Advanced Settings Items” - “Command conditions” of “3.1.2.4.2 Initial Settings”
513	Load characteristic measurement error	Load characteristic measurement failed. 1 Execute One Minute TUNING once more with a larger operating range. 2 If the inertia estimating conditions cannot be met due to the device mechanism, set the specification value to the inertia ratio and perform One Minute TUNING with the inertia ratio, unbalanced load compensation, dynamic friction compensation, and viscous friction compensation of Tuning target function selection all turned to OFF.	“Step 5” of “3.1.2.4.2 Initial Settings” “Advanced Settings Items” - “Tuning conditions”
769	Oscillation error	Oscillation detected during operation. Execute One Minute TUNING once more after lowering the speed loop gain value on the Parameter Settings screen.	PT_OM “8.11 All Parameters”
1025	Torque saturation error	Tuning torque limit exceeded during operation. Execute One Minute TUNING once more after revising command conditions to reduce acceleration.	“Advanced Settings Items” - “Command conditions” of “3.1.2.4.2 Initial Settings”
1281	Stiffness measurement error	RTAT machine stiffness setting, notch, and load fluctuation suppression could not be adjusted. Execute One Minute TUNING once more after lowering the speed loop gain value on the Parameter Settings screen.	PT_OM “8.11 All Parameters”
1537	Device characteristics measuring error 1	Device characteristics could not be measured correctly. Execute One Minute TUNING once more with a larger operating range.	“Step 5” of “3.1.2.4.2 Initial Settings”
1793	Device characteristics measuring error 2	Device characteristics could not be measured correctly. Execute One Minute TUNING once more with a smaller operating range.	“Step 5” of “3.1.2.4.2 Initial Settings”

Error No.	Error name	Primary Causes and Measures	Reference
2049	Control mode error 1	Not supported in full-closed control. (Supported in position control and speed control modes.)	—
2050	Control mode error 2	The control mode was changed to something other than position control mode during operation. Do not switch to a mode other than position control mode when executing One Minute TUNING.	—
2305	Control mode error 3	Two-degree-of-freedom control mode for synchronization type is not supported. (Two-degree-of-freedom control mode for standard type and two-degree-of-freedom control mode disabled type are supported.)	—
2306	Auto tuning application selection error	Customize is not supported with Tuning auto tuning application selection. (Positioning/general-purpose are supported.)	—
2817	Command input error	A command was input that exceeds the movable range during operation. Contact the manufacturer.	—

7.7 Glossary

Abbreviations used in this document and their official names are shown below.

Abbreviation	Official Name
CCW	Counterclockwise Rotation
CP	Cyclic Position Mode
CP	Continuous Path
CT	Cyclic Torque Mode
CV	Cyclic Velocity Mode
CW	Clockwise Rotation
DB	Dynamic Brake
EDM	External Device Monitoring
EXPOS	External scale position
FB	Feedback
FF	Feed Forward
FFT	Fast Fourier Transform
FIR	Finite Impulse Response
HPF	High Pass Filter
LSD	Least Significant Digit
LV	Low Voltage
MSD	Most Significant Digit
OSS	Open Source Software
PP	Profile Position Mode
Recv	Receive
RTAT	Real-Time Auto Tuning
SRV	Servo
SSU	STO Signal Unmatch
STO	Safe Torque Off
TFF	Torque Feed Forward

REVISIONS

Date	Rev.	Page	Description
Sep. 13, 2024	0.0	—	NEWLY ISSUED
Dec. 20, 2024	0.1	2.1.3, 3.1.3.2, 3.1.3.4.2	Revised the precAIseTUNING specifications and added their associated Precautions
Feb. 5, 2025	0.2	3.1.3.4.3	Added a note about precAIseTUNING Removed the precAIse TUNING temporary stop function
Apr. 1, 2025	0.3	1.3.4	Changed Function (Add to Unsupported Features) ● Monitor Signal Output
Apr. 11, 2025	1.0	1.3.2, 1.3.5	Software version upgrade ● CPU1: Ver1.04→Ver1.05
		1.3.4	Remove from the list of Unsupported Features ● Monitor Signal Output
		7.6	Corrected typographical errors (Err275, Err277)
May 28, 2025	1.1	4.4.3, 4.6.3, 4.7.3, 4.9.3 , 5.1.3, 5.2.3, 5.9.3, 7.2.4	Added Description

Repairs, Inquiries and Technical Information

Repairs

Contact your dealer regarding repairs.

If installed in a machine or device, consult with the machine or device manufacturer first.

Contact us

If you have any questions, please contact the seller of the product (Sales office or Distributor).

Technical information

- Operating instructions, technical reference, CAD data downloads, and Web-based inquiries are available online.

["industry.panasonic.com/global/en/"](http://industry.panasonic.com/global/en/)

Industrial Device Business Division, Panasonic Industry Co., Ltd.

7-1-1 Morofuku, Daito City, Osaka, 574-0044, Japan

(c) Panasonic Industry Co., Ltd. 2024-2025