

IO-Link Configuration Tool

SC-LG-CEF

Configuration Tool

User's Manual

(MEMO)

Thank you for using **SC-LG-CEF Configuration Tool**.

SC-LG-CEF Configuration Tool is an application that can collect measurement data from Panasonic IO-Link master **SC-LG2-CEF-P** and IO-Link devices connected to the IO-Link master, set up various parameters, and load data.

Notes

- 1) No part of this manual may be reproduced or reprinted in any form or by any means without prior written permission from Panasonic.
- 2) The contents of this manual are subject to change without notice for future improvement.
- 3) This manual has undergone strict quality control; but should you discover any dubious information, mistakes, misplaced pages, or missing pages, please contact your local dealer.
- 4) CC-Link IE Field is a registered trademark of Mitsubishi Electric Corporation and a trademark managed by CC-Link Partner Association.
- 5) GX Works3 is a registered trademark or trademark of Mitsubishi Electric Corporation.
- 6) Windows is a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.
- 7) Ethernet is a registered trademark of FUJIFILM Business Innovation Corp..
- 8) IO-Link is a registered trademark of PROFIBUS User Organization.
- 9) The ownerships of all other trademarks belong to their respective owners.

Manual Configuration

1 Before Using This Product	This chapter explains the terminology and the functions of this software tool.
2 Preparation	This chapter explains the system environment, system overview, and connections.
3 Name and Function of Each Window	This chapter explains the name and function of each configuration window.
4 Other Functions	This chapter explains the master addition, removal, and assignment functions, project creation and saving functions, network number setting function, and other functions.
5 Messages	This chapter explains confirmation dialog boxes.

Contents

Manual Configuration	4
1 Before Using This Product	1-1
1.1 Handling Precautions	1-2
1.2 Terminology	1-2
1.3 Overview	1-3
2 Preparation	2-1
2.1 System requirements	2-2
2.2 System Overview	2-3
2.2.1 System Connection Diagram	2-3
2.3 Setup on the Programmable Controller (GX Works3) Side	2-4
3 Name and Function of Each Window	3-1
3.1 Operating Procedure	3-2
3.2 Login Window	3-3
3.3 Start Window	3-4
3.4 Master Port Configuration Window	3-5
3.4.1 Master Port Configuration	3-5
3.4.2 Select Device Window	3-8
3.5 Master Information Window	3-10
3.6 Device Monitoring Window	3-11
3.7 Device Setup Window	3-12
3.8 Device Diagnosis Window	3-13
3.9 Device Information Window	3-14
3.10 Option Window	3-15
3.11 Version Information Window	3-16
4 Other Functions	4-1
4.1 Master Addition Function	4-2
4.2 Master Removal Function	4-3
4.3 Master Assignment Function	4-3
4.4 Device Settings Copy / Paste Function	4-4
4.5 Project Creation Function	4-4
4.6 Project Saving Function	4-5
4.7 IODD Management Function	4-5
4.8 Network Number Setting Function	4-6
4.9 Language Switching Function	4-7
4.10 Exit Function	4-7
5 Messages	5-1
5.1 Messages	5-2

(MEMO)







1 Before Using This Product

1.1 Handling Precautions	1-2
1.2 Terminology	1-2
1.3 Overview	1-3

1.1 Handling Precautions

1.1 Handling Precautions

■The following symbols are used to indicate safety information that must be observed.

	Indicates an action that is prohibited.
	Indicates an action that must be taken.
	Indicates a matter that requires caution.
 Information	Indicates supplemental information.
 Reference	Indicates reference to details about the subject in question.
 Caution	Indicates points to be noted when the product is operated.

1.2 Terminology

	Term	Description
CC-Link IE Field related	Master station	A station that controls the entire network. This station can perform cyclic transmission and transient transmission to all stations.
	Slave station	A generic name of all stations other than master stations (local stations, remote I/O stations, remote device stations, and intelligent device stations)
	SC-LG2-CEF-P	An IO-Link master compliant with CC-Link IE Field. This master connects IO-Link devices using e-CON connectors. PNP connection is based on the I/O interface specifications of IO-Link devices.
	CC-Link IE Field network	A high-speed and large-capacity open field network using Ethernet (1000BASE-T)
	Cyclic transmission	A function that periodically exchanges data between stations on the same network in the data link layer
	Transient transmission	A function that uses the read/write instructions of the program at the local station to read and write data from / to remote stations and communicate with remote stations via peripheral devices in the data link layer
	Memory map	A memory map where the functions of the communication unit are allocated to link devices. The master station can use the functions of the communication unit by accessing the link devices allocated on the memory map.
	Link device	Internal devices held by the unit (RX, RY, RWr, and RWw)
	Network number	A unique number that is assigned to identify each network when multiple networks are created. Duplicate numbers cannot be set among all networks.
	Station number	A unique number that is assigned to identify each network unit that is connected to a network. Duplicate numbers cannot be set among all network units within a network.
Intelligent device station	A station that cyclically transmits bit-based I/O signals and word-based I/O data to the master station. This station returns responses to transient transmission requests from other stations.	

	Term	Description
IO-Link re- lated	Process data (PD)	Cycle data. Process data is automatically transmitted during normal operation.
	IEC 61131-9	One of the international certifications handling PLC standards that specifies an I/O connection technology standardized for communication with sensors or actuators
	IODD	Describes the device's own information and settings
	IO-Link	A digital communications protocol that connects sensors or actuators to remote I/O, PLC, etc.
	IO-Link device	Performs one-to-one and point-to-point IO-Link communications with the IO-Link master
	IO-Link master	Plays a role as a gateway to transfer data between each IO-Link device and each of the systems connected to high-level buses
	Port	An IO-Link communication channel port

1.3 Overview

SC-LG-CEF Configuration Tool has the following functions.

- IO-Link master detection function
This function detects IO-Link master **SC-LG2-CEF-P** on the CC-Link IE Field network via a programmable controller (PLC).
- IO-Link master port configuration function
This function configure a port for IO-Link master **SC-LG2-CEF-P** that is detected.
- Function for communicating with IO-Link devices via IO-Link master
The following processing can be performed on IO-Link devices connected to IO-Link master **SC-LG2-CEF-P** that is detected.
 - Reading process data from IO-Link devices and setting some data
 - Monitoring the IO-Link device detection status
 - Checking diagnosis information for IO-Link devices
- Other functions
Project saving function, language switching function, and other functions

(MEMO)

2 Preparation

2.1 System requirements	2-2
2.2 System Overview	2-3
2.2.1 System Connection Diagram	2-3
2.3 Setup on the Programmable Controller (GX Works3) Side	2-4

2.1 System requirements

2.1 System requirements

SC-LG-CEF Configuration Tool operates in the following system environment.

Compatible OS	Windows®11 (64 bit) Windows®10 (32 bit,64 bit)
CPU	2 GHz or faster processor
RAM	4 GB or more (Windows®11 64 bit) 2 GB or more (Windows®10 32 bit) 4 GB or more (Windows®10 64 bit)
Hard disk	Maximum 2 GB free space required
Interface	1 Gbps

- CD or DVD drive: Not required
- .NET Framework 4.6.2 onwards
Download and install .NET Framework from Microsoft® download center if it is not already installed.
- Microsoft Visual C++ 2019
Redistributable Package (x86) must be installed separately.
- Adobe Reader
To display the Manual from the **Help** menu, Adobe Reader must be installed separately.
- Programmable controller (PLC) and CC-Link IE Field master unit
- GXWorks3
GXWorks3 must be installed separately because SC-LG-CEF Configuration Tool controls SC-LG2-CEF via sequencer manufactured by Mitsubishi Electric Corporation.

Reference

For information about compatible PLCs and CC-Link IE Field master units, refer to the website of CC-Link Partner Association (<https://www.cc-link.org/en/>).

The following models have been tested and confirmed to connect properly as of December 2021.

- QJ71GF11-T2
- LJ71GF11-T2
- RJ71EN71
- RJ71GF11-T2


2.2 System Overview

This system enables **SC-LG-CEF Configuration Tool** to transfer measured values and other data from IO-Link devices (such as sensors) via a programmable controller (PLC) and CC-Link IE Field network.

The main functions of the system are the IO-Link master setup function and the IO-Link device data monitoring / setting function.

2.2.1 System Connection Diagram

This system is explained as below.



The PC and PLC are connected with an Ethernet or USB cable.

The **SC-LG2-CEF-P** is used as IO-Link masters.

IO-Link devices including other manufacturers' products are used as IO-Link devices. The IODD file associated with each IO-Link device must be imported into **SC-LG-CEF Configuration Tool**.

Caution

- Download the IODD files from the website of the IO-Link device manufacturer or the IODDfinder website (<https://ioddfinder.io-link.com/>).
- The IODD files of Panasonic IO-Link devices can be downloaded from our website (<https://industry.panasonic.com/global/en/downloads/?tab=software>).

2.3 Setup on the Programmable Controller (GX Works3) Side

2.3 Setup on the Programmable Controller (GX Works3) Side

This section explains how to set up parameters for IO-Link master **SC-LG2-CEF-P**.
The parameter setting method differs according to the master station unit.
The parameter setting method is explained below, using Mitsubishi Electric Corporation's RJ71EN71 as an example.

▼ Reference

For details, refer to the instruction manual of the master station unit that you use.

- **Example of RJ71EN71(CCIEF) unit parameter settings**

Station type: Master station

Network No.: 1

<Network configuration settings>

Station number: 1

RX / RY settings (starting / ending): 1000 / 106F

RWw / RWr settings (starting / ending): 1000 / 1083

<Refresh settings>


Link side				CPU side	
Device name	Starting address	Ending address		Device name	Starting address
SB	00000	001FF	⇔	SB	00000
SW	00000	001FF	⇔	SW	00000
RX	01000	0106F	⇔	X	01000
RY	01000	0106F	⇔	Y	01000
RWr	01000	01083	⇔	W	01400
RWw	01000	01083	⇔	W	00400

2.3 Setup on the Programmable Controller (GX Works3) Side

- **Setting up RJ71EN71(CCIEF) unit parameters**

Set up parameters in the engineering software (GX Works3) at the master station.


1. In the **Navigation** window, select **Module Information** and then **RJ71EN71(CCIEF)**.



▼ Reference


For details on how to set up the master station, refer to the instruction manual of the master station unit that you use.

2. Set up the contents of **Required Settings** for module parameters as shown below.





2.3 Setup on the Programmable Controller (GX Works3) Side

3. Double-click <Detailed Setting> in Network Configuration Settings.



4. The CC IE Field Configuration dialog box will be displayed. In the **Module List**, select **SC-LG2-CEF-P** under **CC IE Field Module (Panasonic Industry)** and drag and drop it into the station list or network configuration diagram. **SC-LG2-CEF-P** will be added.




 If CSP+ for SC-LG2-CEF-P has not been registered, "SC-LG2-CEF-P" will not be displayed in the **Module List**. Register CSP+ in advance.
 If CSP+ for SC-LG2-CEF-P cannot be registered, use and set CSP+ for general intelligent device stations.

Reference


For information about how to download CSP+, refer to the **SC-LG2-CEF-P User's Manual** (our website: <https://industry.panasonic.com/>).

2.3 Setup on the Programmable Controller (GX Works3) Side

5. Set up a CC IE Field configuration as shown below.




6. After setting up the configuration, click the **Close with Reflecting the Setting** menu to close the **CC IE Field Configuration** dialog box.



2.3 Setup on the Programmable Controller (GX Works3) Side

7. Double-click <Detailed Setting> in Refresh Settings.



8. A refresh parameter setting window will be displayed. Specify settings as below.

No.	Link Side					CPU Side				
	Device Name	Points	Start	End		Target	Device Name	Points	Start	End
-	SB	512	00000	001FF	↔	Specify Devic	SB	512	00000	001FF
-	SW	512	00000	001FF	↔	Specify Devic	SW	512	00000	001FF
1	RX	112	01000	0106F	↔	Specify Devic	X	112	01000	0106F
2	RY	112	01000	0106F	↔	Specify Devic	Y	112	01000	0106F
3	RW _r	132	01000	01083	↔	Specify Devic	W	132	01400	01483
4	RW _w	132	01000	01083	↔	Specify Devic	W	132	00400	00483
5					↔					
6					↔					

3 Name and Function of Each Window


3.1 Operating Procedure	3-2
3.2 Login Window	3-3
3.3 Start Window	3-4
3.4 Master Port Configuration Window	3-5
3.4.1 Master Port Configuration	3-5
3.4.2 Select Device Window	3-8
3.5 Master Information Window	3-10
3.6 Device Monitoring Window	3-11
3.7 Device Setup Window	3-12
3.8 Device Diagnosis Window	3-13
3.9 Device Information Window	3-14
3.10 Option Window	3-15
3.11 Version Information Window	3-16

3.1 Operating Procedure

3.1 Operating Procedure

The procedure for operating **SC-LG-CEF Configuration Tool** is shown below.

Reference section




- Notes: 1) If the **Auto Login** check box in the **Option** window is selected, the **Login** window will not be displayed.
2) When starting **SC-LG-CEF Configuration Tool** for the first time, set a network number to add an IO-Link master for which no network number has been set.

3.2 Login Window

In the Login window, log in to the tool by entering the password corresponding to the user authority of **SC-LG-CEF Configuration Tool**.

When **SC-LG-CEF Configuration Tool** starts, the Login window is displayed only if the Auto Login check box in the Option window is not selected.



	Name	Description
1	User Administration	Select an appropriate user authority from Operator, Maintenance, and Specialist. After login is completed, information in the IOOD file corresponding to the selected user authority will be displayed.
2	Password	You can enter the password corresponding to each user authority. A password that you enter is displayed as black dots (●). The default password is unset. You can change a password in the Option window.
3	Login	Clicking this button displays the main window if the user authority and the password match. If they do not match, you cannot proceed to the next window even if you click the Login button.
4	Exit	Clicking this button closes SC-LG-CEF Configuration Tool .


▼ Reference

For details on how to set a password, refer to “**3.10 Option Window**”.

3.3 Start Window

3.3 Start Window

This window is used to select appropriate start options and start **SC-LG-CEF Configuration Tool**.



	Name	Description
1	New	Select this option to set up a new IO-Link master or IO-Link device offline.
2	Open	Select this option to open the file of a project that has been set up before.
3	Load from Master	Select this option to load data from an IO-Link master that is connected to the PC via a PLC. When this option is selected, the "Connecting IO-Link Master" area can be manipulated.
4	Connecting IO-Link Master	A list of IO-Link masters that are connected to the PC via a PLC is displayed. You can select a desired IO-Link master by selecting the check box on the top left of the frame of the device. The product name and connecting information [NNo. (network No.), SNo. (station number)] are displayed. Select the check box on the top left of the frame of the master that you want to set up. By clicking the Select All check box, you can select or cancel all the IO-Link masters that are displayed.
5	Start	After selecting New, Open, or Load from Master, click this button to start SC-LG-CEF Configuration Tool . <ul style="list-style-type: none"> • If you select New and then click the Start button, you will be prompted to select the IO-Link master to be added. • If you select Open and then click the Start button, the previously set conditions will be displayed. • If you select Load from Master and then click the Start button, the data of the selected IO-Link master(s) will be loaded. If none of the connected IO-Link masters is selected, the Start button will be grayed out.

Reference

For information about how to add IO-Link masters offline, refer to **"4.1 Master Addition Function"**.

3.4 Master Port Configuration Window

3.4 Master Port Configuration Window

3.4.1 Master Port Configuration

This window is used to display and set up each port of the IO-Link master selected in the tree on the left side of the window.

If you select an IO-Link master in the tree, a master port subwindow will be displayed in the Port Setting tab.

The screenshot shows the 'Port Setting' window with a table of port configurations. A red box highlights the table, and red lines with numbers 1-5 point to specific elements:

- 1: Detect Devices button
- 2: Write button
- 3: Read button
- 4: Add button
- 5: Delete button



No.	Mode	Device	Vendor	Validation & Backup	PD Size IN	PD Size OUT
1	IO-Link	DP-101ZL3-M-P	Panasonic Industry Co., Ltd.	No Check	32	32
2	Inactive			No Check	32	32
3	Inactive			No Check	32	32
4	Inactive			No Check	32	32
5	Inactive			No Check	32	32
6	Inactive			No Check	32	32
7	Inactive			No Check	32	32
8	Inactive			No Check	32	32

The screenshot shows the 'Port Setting' window with a table of port configurations. A red box highlights the table, and red lines with numbers 6-9 point to specific elements:

- 6: Validation & Backup column
- 7: PD Size IN and PD Size OUT columns
- 8: Add button
- 9: Delete button

Mode	Device	Vendor	Validation & Backup	PD Size IN	PD Size OUT
IO-Link	DP-101ZL3-M-P	Panasonic Industry Co., Ltd.	No Check	32	32
active			No Check	32	32
active			No Check	32	32
active			No Check	32	32
active			No Check	32	32
active			No Check	32	32
active			No Check	32	32
active			No Check	32	32

3.4 Master Port Configuration Window

	Name	Description
1	Detect Devices	Clicking this button changes the settings of all the ports to IO-Link mode and detects the IO-Link devices connected to the selected IO-Link master. If the selected IO-Link master is unconnected the Detect Devices button will be grayed out.
2	Write	Clicking this button writes the current port configuration to the selected IO-Link master. If the selected IO-Link master is unconnected, the Write button will be grayed out.
3	Read	Clicking this button reads the port configuration from the selected IO-Link master. If the selected IO-Link master is unconnected, the Read button will be grayed out.
4	Mode	<p>You can change the port mode for each port of the selected IO-Link master.</p>  <ul style="list-style-type: none"> ● Inactive: Select this option when you use no port. ● DI: Select this option when you use the port in DI mode. ● DO: Select this option when you use the port in DO mode. ● IO-Link: Select this option when you use the port in IO-Link mode. <p>If you select IO-Link, in the Select Device window, you must select the IO-Link device to be connected. The IO-Link device list is configured using the IODD files that are imported.</p>
5	Device / Vendor	The Device and Vendor columns display product names and vendor names, respectively, for IO-Link devices that are connected. To change the IO-Link device, click the  button.

3.4 Master Port Configuration Window

	Name	Description
6	Validation & Backup	<p>If you select IO-Link in the Mode column, you can select the validation level and data storage mode as below.</p> <div data-bbox="546 324 1094 595" style="border: 1px solid gray; padding: 5px; margin: 10px 0;"> <p>No Check</p> <p>Compatible V1.0 device, No Data Storage</p> <p>Compatible V1.1 device, Backup & Restore</p> <p>Compatible V1.1 device, No Data Storage</p> <p>Compatible V1.1 device, Restore</p> </div> <ul style="list-style-type: none"> ● No Check: No IO-Link device validation or data storage is performed. ● Compatible V1.0 device, No Data Storage: Vendor ID and device ID are validated for V1.0 IO-Link devices. No data storage is performed. ● Compatible V1.1 device, No Data Storage: Vendor ID and device ID are validated for V1.1 IO-Link devices. No data storage is performed. ● Compatible V1.1 device, Backup & Restore: Vendor ID and device ID are validated for V1.1 IO-Link devices. For data storage, both backup and restoration are performed. ● Compatible V1.1 device, Restore: Vendor ID and device ID are validated for V1.1 IO-Link devices. For data storage, only restoration is performed.
7	PD Size IN / PD Size OUT (Process data size IN / OUT)	<p>If you select IO-Link in the Mode column, you can select process data size (IN / OUT). (Input range: 1 to 32)</p> <ul style="list-style-type: none"> ● If the values of PD Size IN and PD Size OUT are different, the size will be set to the larger value. (For example, if the value of PD Size IN is 4 and the value of PD Size OUT is 1, both values will be set to 4.)
8	Add	Clicking this button adds a new IO-Link master to the tree.
9	Delete	Clicking this button deletes the selected IO-Link master from the tree.

Information


By right-clicking with a port selected, you can copy and paste all the settings of the port.


Reference


For details on how to change devices, refer to “**3.4.2 Select Device Window**”.
 For details on how to add IO-Link masters, refer to “**4.1 Master Addition Function**”.
 For details on how to delete IO-Link masters, refer to “**4.2 Master Removal Function**”.

3.4 Master Port Configuration Window




3.4.2 Select Device Window

This window allows you to select the IO-Link device to be connected to the IO-Link master. Clicking the  button in the master port configuration window displays the Select Device window.



	Name	Description
1	Vendor	IO-Link devices in the device list can be narrowed down to the IO-Link devices of the vendor that you select. <ul style="list-style-type: none"> ● All: Displays the IO-Link devices of all vendors ● Favorite: Displays only the IO-Link devices specified as favorites ● Latest: Displays only the IO-Link devices that have been used lately
2	IO-Link Revision	IO-Link devices in the device list can be narrowed down according to the version of IO-Link devices. <div style="border: 1px solid gray; padding: 5px; margin-top: 10px;"> <p>IO-Link Revision</p> <p>All </p> <hr/> <p>All</p> <p>V1.1</p> <p>V1.0</p> </div>
3	Search	IO-Link devices in the device list can be narrowed down to only the products whose product names match the string that you enter.
4	Device Family	IO-Link devices in the device list can be narrowed down to the IO-Link devices of the product family that you select.

3.4 Master Port Configuration Window


	Name	Description
5	Display method switching function	<p>The device list display method can be changed.</p>  <p>● Details: Displays IO-Link devices in detail</p>  <p>● List: Displays only IO-Link device names and vendor names</p> 
6	Device list	This area displays IO-Link devices that match the search criteria specified in Vendor, IO-Link Revision, Search, or Device Family.
7	Delete	Clicking this button deletes the IODD file included in the IO-Link device selected in the device list. A confirmation dialog box is displayed before the IODD file is deleted. If "Yes" is selected, the IODD file will be deleted.
8	Assign	Clicking this button determines the IO-Link device selected in the device list and returns the display to the master port configuration window.
9	Cancel	Clicking this button returns the display to the master port configuration window without determining the IO-Link device.

3.5 Master Information Window

3.5 Master Information Window

This window displays device information for the IO-Link master selected in the tree on the left side of the window.

If you select an IO-Link master in the tree, a master information subwindow will be displayed in the **Information** tab.



	Name	Description
1	Label	You can assign a name to the device selected in the tree. The assigned name will be reflected in the tree.
2	Network No. Setting	Clicking this button displays the window for changing the network number of the IO-Link master.


Reference


For details on how to change network numbers, refer to “4.8 Network Number Setting Function”.

3.6 Device Monitoring Window

This window is used to monitor process data for the IO-Link device selected in the tree on the left side of the window.

If you select an IO-Link device in the tree, a device monitoring subwindow will be displayed in the **Monitor** tab.




	Name	Description
1	Update cycle	You can set an update cycle at which a graph is drawn. (Unit: ms) 
2	Operation	You can replay, pause, or stop graph drawing.
3	Analog - Item	You can select analog items for which graphs are to be drawn. Items that you can select are analog items of process data for IO-Link devices.
4	Analog - Upper / Lower	You can set the upper and lower limit values for analog items for which graphs are to be drawn.
5	Analog - Custom	You can set up a bar of custom values on the graph.
6	Digital - Item	You can select digital items for which graphs are to be drawn. Items that you can select are digital items of process data for IO-Link devices.
7	Graph drawing area	Graphs are displayed by reflecting the settings in "Update cycle", "Operation", "Analog - Item", "Analog - Upper / Lower", "Analog - Custom", or "Digital - Item".

3.7 Device Setup Window

3.7 Device Setup Window

This window is used to set up parameters for the IO-Link device selected in the tree on the left side of the window.

If you select an IO-Link device in the tree, a device setup subwindow will be displayed in the **Set** tab.




	Name	Description
1	Process data display area	Process data items are displayed according to the information in the IODD file of the IO-Link device selected in the tree. The values obtained from the selected device are displayed as the values of the process data items.
2	Parameter display area	Parameters are displayed according to the information in the IODD file of the IO-Link device selected in the tree. <input type="button" value="↔"/> buttons are arranged for each item, so that individual items can be loaded. If the user changes the value of an item, a red asterisk (*) will be displayed at the beginning of the item.
3	Write	Clicking this button writes the parameter value(s) changed in the parameter display area to the IO-Link device.
4	Read	Clicking this button reads all the parameter values in the parameter display area from the IO-Link device.
5	Write Auto	If this check box is selected, when the value of any parameter displayed in the parameter display area is changed, the value will be immediately reflected in the IO-Link device. If this check box is not selected, when the value of any parameter displayed in the parameter display area is changed, the value will not be reflected in the IO-Link device until the Write button is clicked.

3.8 Device Diagnosis Window

This window displays diagnosis information for the IO-Link device selected in the tree on the left side of the window.

If you select an IO-Link device in the tree, a device diagnosis subwindow will be displayed in the Diagnosis tab.



	Name	Description
1	Status	The status of the current IO-Link device is displayed. The status is Normal, Notification, Caution or Abnormal.
2	Status details	Details are displayed when the status is Notification, Caution, or Abnormal. <ul style="list-style-type: none"> ● Notification: Measurement error, reduced amount of entering light, unstable entering light, or applied voltage during zero-point adjustment ● Caution: Operating time limit exceeded or nonvolatile memory saving count limit exceeded ● Abnormal: DC output short-circuit, nonvolatile memory error, or damaged LED circuit
3	Operating Time	The amount of IO-Link device operating time is displayed.
4	Stored Count	The number of write operations to the IO-Link device is displayed.


Information

The Diagnosis tab is displayed only when a Panasonic IO-Link device is selected.

3.9 Device Information Window

3.9 Device Information Window


This window displays device information for the IO-Link device selected in the tree on the left side of the window. If you select an IO-Link device in the tree, a device information subwindow will be displayed in the Information tab.



	Name	Description
1	Label	You can assign a name to the device selected in the tree. The assigned name will be reflected in the tree.

3.10 Option Window

This window allows you to set options for **SC-LG-CEF Configuration Tool**.
 Selecting Option from the File menu displays the Option window as a pop-up window.



	Name	Description
1	Login Setting	You can set up auto login and specify a user authority and password that are required for auto login. <ul style="list-style-type: none"> You can specify a user authority and password only when you select the Auto Login check box. If you select the Auto Login check box, you must specify a user authority and password. In this case, the Login window will be omitted when the tool starts.
2	Password of User Administration	You can specify a password for each user authority.
3	OK	Clicking this button saves the setting changes and closes the window.
4	Cancel	Clicking this button closes the window without saving the setting changes.

3.11 Version Information Window

3.11 Version Information Window

This window displays version information for **SC-LG-CEF Configuration Tool**. Selecting **Version** from the Help menu displays a pop-up window that shows the version information.



4 Other Functions


4.1 Master Addition Function	4-2
4.2 Master Removal Function	4-3
4.3 Master Assignment Function	4-3
4.4 Device Settings Copy / Paste Function	4-4
4.5 Project Creation Function	4-4
4.6 Project Saving Function	4-5
4.7 IODD Management Function	4-5
4.8 Network Number Setting Function	4-6
4.9 Language Switching Function	4-7
4.10 Exit Function	4-7

4.1 Master Addition Function

4.1 Master Addition Function

This function adds a new IO-Link master to the tree.

Clicking the Add button under the tree displays the Adding a Master window.



	Name	Description
1	Create a new Master	A list of IO-Link masters is displayed. By selecting an IO-Link master in the Create a new Master tab and then clicking the Add button, you can add the IO-Link master in an offline state to the tree.
2	Connecting IO-Link Master	A list of IO-Link masters connected to the PC is displayed. You can select a desired IO-Link master by selecting the check box on the top left of the frame of the device. By selecting the Select All check box, you can select all the IO-Link masters.
3	Add	Clicking this button adds an IO-Link master to the tree.
4	Cancel	Clicking this button closes the Adding a Master window.

4.2 Master Removal Function

This function removes the selected IO-Link master from the tree.

Clicking the Delete button under the tree displays a confirmation dialog box and clicking the OK button removes the selected IO-Link master from the tree.

Information

If an IO-Link device is selected in the tree, the Delete button will be grayed out.

4.3 Master Assignment Function


This function assigns the selected IO-Link master (in an offline state) to the actual IO-Link master.

Clicking the connection icon of an IO-Link master in an offline state in the tree displays a dialog box.



The dialog box displays IO-Link masters that are connected. Select an IO-Link master that you want to assign.

By clicking the Assign button with the IO-Link master selected, you can reflect the settings of the IO-Link master (that you set up offline) into the actual IO-Link master.



Information

The settings of IO-Link devices that you set up offline cannot be reflected by assignment processing.


4.4 Device Settings Copy / Paste Function

4.4 Device Settings Copy / Paste Function

This function enables you to copy and paste the settings of the IO-Link device that you select. By selecting and right-clicking an IO-Link device in the tree, you can copy and paste the settings of the IO-Link device.




Executing the Copy function causes the frame of the target IO-Link device to blink.



After copying, if you select the same device and execute the Paste function, the settings of the selected IO-Link device will be replaced with the settings of the copy source. You cannot paste the settings to any IO-Link device that differs from the copy source.

The copy / paste function can be executed by selecting Copy and Paste from the Edit menu or using the shortcut keys.



4.5 Project Creation Function

This function creates new projects.

Selecting New from the File menu displays a confirmation dialog box asking whether to save the project that you are currently working on. Then, you can create the project as a new project.

4.6 Project Saving Function

This function saves the project that you have worked on.

You can save the current project by selecting **Save** or **Save As** from the File menu. (The extension of saved files is ".iol".)

By selecting **Open** from the File menu, you can open any project that has been saved.

4.7 IODD Management Function


This function enables you to import or delete IODD files.

Selecting **Import IODD** from the File menu displays a file selection window. Selecting a valid IODD file imports the file into **SC-LG-CEF Configuration Tool**.

The IO-Link device specified in the imported IODD file will be added to the Select Device window.

Selecting **Delete IODD** from the File menu displays the Select Device window.

Selecting an IO-Link device and then clicking the **Delete** button deletes the IODD file that contains the selected IO-Link device.



Caution


- IODD files that have been imported can be used until they are deleted.
- Download the IODD files from the website of the IO-Link device manufacturer or the IODDfinder website (<https://ioddfinder.io-link.com/>).
- The IODD files of Panasonic IO-Link devices can be downloaded from our website (<https://industry.panasonic.com/global/en/downloads/?tab=software>).

4.8 Network Number Setting Function

4.8 Network Number Setting Function

This function sets a network number for each IO-Link master.

The Network number window is displayed when you add an IO-Link master without a network number or click the **Network No. Setting** button in the Information tab of the IO-Link master information window.



Network number

Network number 1

Set Cancel

Information

In the Network number field, enter the network number that is set for the IO-Link master.



Unless the correct network number is set, the IO-Link master and IO-Link devices cannot be set up normally.

4.9 Language Switching Function

This function allows you to switch the language for **SC-LG-CEF Configuration Tool**.
Selecting Language from the File menu enables you to switch the language between Japanese and English.



Information

When you have switched the language, restart **SC-LG-CEF Configuration Tool**.

4.10 Exit Function

This function closes **SC-LG-CEF Configuration Tool**.
Selecting Exit from the File menu enables you to close **SC-LG-CEF Configuration Tool**.

(MEMO)

5 Messages

5.1 Messages 5-2

5.1 Messages

Various confirmation dialog boxes are displayed when the user is asked for confirmation during operation or the device enters in an inoperable state. If any message is displayed, carefully read the following information and check an appropriate action method.

5.1 Messages

Message	Action method
Invalid IODD file!	The IODD file that you attempted to import is invalid and so you cannot import it. Contact the organization from which you obtained the IODD file.
The file can't be deleted because XXX is using	The IODD file that you want to delete is currently in use, so it cannot be deleted. Close the project first and then delete the file.
It failed to write the device's parameter.	An attempt to write the parameter to the IO-Link device has failed. Check the connections. If any error message is displayed, take action according to the message.
Loading the setting file is failed	The file required to start SC-LG-CEF Configuration Tool was not found. The tool will be started using the default settings.
The password you entered is incorrect	Enter the same password in both password fields.
The real device and configured device are different	The IO-Link device set up with SC-LG-CEF Configuration Tool differs from the IO-Link device that is actually connected. Check the tool settings or actual connections.
The data format is wrong.	The format of the entered data is incorrect. Enter data in the correct format.
The real device and configured device are different	The IO-Link device set up with SC-LG-CEF Configuration Tool differs from the IO-Link device that is actually connected. Check the tool settings or actual connections.
It's a same port number.	For the paste target port, specify any port other than the copy source port.
It failed to read the port configuration.	An attempt to read port settings from the IO-Link master has failed. Check the connections.
The password you entered is incorrect.	Enter the correct password.
It failed to write the port configuration.	An attempt to write port settings to the IO-Link master has failed. Check the connections.

Revision history	Revision date	Revision item
First edition	February 2019	—
2nd edition	December 2021	<ul style="list-style-type: none"> • Revision due to software version upgrade (Ver. 1.3) • Revision due to addition of compatible CC-Link IE Field master unit
3rd edition	January 2023	<ul style="list-style-type: none"> • Revised “ 1.4 Software License Agreement “ • Revised “ 2.1 System Environment “ • Added notes • Corrected errors
4th edition	April 2024	<ul style="list-style-type: none"> • Change in Corporate name

Panasonic Industry Co., Ltd.

1006, Oaza Kadoma, Kadoma-shi, Osaka 571-8506, Japan
<https://industry.panasonic.com/>

Please visit our website for inquiries and about our sales network.

© Panasonic Industry Co., Ltd. 2019-2024

April, 2024

WUME-SCLGCT-4