


High-performance Digital Display Pressure Sensor DP-100 Series

MJE-DP100 No.0102-86V Thank you very much for purchasing Panasonic products. Read this Instruction Manual carefully and thoroughly for the correct and optimum use of this product. Kindly keep this manual in a convenient place for quick reference.

- WARNING
1. Never use this product as a sensing device for personnel protection.
2. In case of using sensing devices for personnel protection, use products which meet laws and standards, such as OSHA, ANSI or IEC etc., for personnel protection applicable in each region or country.
3. This product is used for noncorrosive gas. The product shall not be used for liquid or corrosive gas. Never use fluids having inflammability, toxicity, etc., that affect the human body, either.
4. A product intended for use in Japan conform ms to the Japanese Measurement Act. Do not use a product intended for use overseas in Japan.

1 PART DESCRIPTION




- When connecting a commercial coupler to the pressure port, attach a 12 mm spanner (14 mm for DP-100-E type) to the pressure port's hexagon section to fix the port, and then tighten with a tightening torque of 9.8 N·m or less (M5 female: 1 N·m or less). The commercial coupler or pressure port section will be damaged if the tightening torque is excessive. Wrap sealing tape around the coupler when connecting to prevent leaks.

2 MOUNTING

- The sensor mounting bracket MS-DP1-1 is available as an option. When mounting the sensor onto the sensor mounting bracket, etc., the tightening torque should be 0.5 N·m or less.
The panel mounting bracket MS-DP1-2 (optional) and MS-DP1-4 (optional), as well as the front cover MS-DP1-3 (optional) and DPX-04 (optional) are also available.
Use MS-DP1-3 for MS-DP1-2, and DPX-04 for MS-DP1-4.
For mounting of the panel mounting bracket, refer to the Instruction Manual enclosed with MS-DP1-2 or MS-DP1-4.

3 WIRING




Note: Do not pull by holding the cable without pressing the release lever, as this can cause cable break or connector break.

<Connection connector pin arrangement>


Table with 3 columns: Connector pin No., Terminal name, and Standard type. Rows 1-4 describe output modes.

3 I/O CIRCUIT DIAGRAMS




4 OUTPUT MODE AND OUTPUT OPERATION

- The EASY mode, hysteresis mode or window comparator mode can be selected as the output mode for comparative output 1 and comparative output 2. Refer to <Comparative output 1 / 2 output mode setting> in MENU SETTING MODE for details.
ON / OFF of the comparative output is controlled in this mode.
Hysteresis mode
The comparative output ON / OFF state can be controlled with randomly set hysteresis in this mode.




5 Window comparator mode



6 RUN MODE

- Setting the threshold value
Refer to <Comparative output 1 / 2 output mode setting>, <Analogue voltage / current output / external input selection> in MENU SETTING MODE for setting conditions.
The sub display conducts the threshold value. Main display does not change.
Display is changed by pressing down.
Press: Increase threshold value to high pressure side.
Press: Decrease threshold value to low pressure side.



7 Key lock function

- The key lock function prevents key operations so that the conditions set in each setting mode are not inadvertently changed.
Key lock set
Key lock released
Peak / bottom hold function
The peak / bottom hold functions display the peak value and bottom value of the fluctuating pressure.
The peak value is displayed on the main display and the bottom value is displayed on the sub-display.
The higher vacuum side indicates the peak value, while the lower vacuum side indicates the bottom value.

8 MENU SETTING MODE




Table with 3 columns: Setting item, Factory setting, and Description. Lists settings such as Sub-display selection, Display speed selection, Hysteresis fixed value selection, etc.

9 PRO MODE




Table with 3 columns: Setting item, Factory setting, and Description. Lists settings like Eco mode setting, Setting check code, Response time setting, etc.


10 Code table

Table with 5 columns: Color, 1st digit, 2nd digit, 3rd digit, 4th digit. Describes the meaning of each digit in the display code.

Table with 4 columns: 5th digit, 6th digit, 7th digit, 8th digit. Describes the meaning of each digit in the display code.

11 SETTING COPY FUNCTION

- This can copy the settings of the master side sensor to the slave side sensor.
Be sure to use the setting copy function between the identical models. This function cannot be used between different models.
Only one sensor can be connected on slave side with a master side sensor for the setting copy function.



- How to cancel the setting copy mode of master side sensor
1. Whilst the slave side sensor is disconnected, turn on the power of the master side sensor.
2. Press the mode selection key for approx. 2 seconds.
Turn ON the master side sensor and the slave side sensor at the same time.
Set contents (16-bit coded) are shown in orange on the main display of the master side sensor and the copying starts.
The same code explained above is shown in green on the main display of the slave side sensor, and "OK" is shown on the sub-display (When copying is complete).

12 AUTO-REFERENCE FUNCTION (ONLY HIGH-FUNCTION TYPE)

- The auto-reference function corrects the set value using the detected pressure value during auto-reference input as the reference pressure.
Using the detected pressure value at auto-reference input P(a) as a reference, the set value \*f is automatically corrected to \*f set value f + P(a).
Settingtable range and set pressure range after correction
The set pressure range is wider than the rating pressure range so that the auto-reference function can be handled.
Operation chart
During normal operation (each comparative output set to N.O.)
During auto-reference input (each comparative output set to N.O.)

13 REMOTE ZERO-ADJUSTMENT FUNCTION (HIGH-FUNCTION TYPE)

- The remote zero-adjustment function forcibly sets the pressure value to "zero" when the external signal is inputted.
Setting procedure
1. Set the setting copy function of the master side sensor to "Copy sending ON" or "Copy sending OFF", and then press the mode selection key so that the sensor is in copy ready state. For details, refer to <Setting copy mode> in PRO MODE.
2. Turn OFF the master side sensor.
3. Connect the master side sensor with the slave side sensor as shown below.
4. Turn ON the master side sensor and the slave side sensor at the same time.
5. Set contents (16-bit coded) are shown in orange on the main display of the master side sensor and the copying starts.
6. The same code explained above is shown in green on the main display of the slave side sensor, and "OK" is shown on the sub-display (When copying is complete).

14 ERROR INDICATION

Table with 3 columns: Error message, Cause, and Corrective action. Lists error codes E-1 to E-7 and their corresponding causes and solutions.

15 SPECIFICATIONS

- Model
DP-100: 1: Low-pressure type, 2: High-pressure type
None: For outside of Japan, Z: For inside of Japan
None: Standard type, A: High-function type
None: R: 1/8" + M5 female screw, E: G: 1/8" + M5 female screw, M: M5 female screw, N: NPT 1/8" + M5 female screw, P: PNP output type
None: NPN output type, J: No cable with connector
None: Cable with connector enclosed, J: No cable with connector

16 CAUTIONS

- This product has been developed / produced for industrial use only.
This product is suitable for indoor use only.
The operating altitude of this product is 2,000 m or less.
Use within the rated pressure range.
Do not apply pressure exceeding the pressure withstanding ability value. The diaphragm will get damaged and correct operation shall not be maintained.
Make sure that the power supply is off while wiring.
Take care that wrong wiring will damage the sensor.
Verify that the supply voltage variation is within the rating.
If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
In case noise generating equipment (switching regulator, inverter motor, etc.) is used in the vicinity of this sensor, connect the frame ground (F.G.) terminal of the equipment to an actual ground.
Do not use during the initial transient time (0.5 sec.) after the power supply is switched on.
Extension up to total 100 m or less, is possible with more than 0.3 mm<sup>2</sup> of electric conductor cross-sectional area as a CE Marking / UKCA Marking conformity product, the wire connected to this product must be within 30 m.
Do not run the wires together with high-voltage lines or power lines or put them in the same raceway. This can cause malfunction due to induction.
The specification may not be satisfied in a strong magnetic field.
Avoid dust, dirt, and steam.
Take care that the sensor does not come in direct contact with water, oil, grease, or organic solvents, such as, thinner, etc.
Do not insert wires, etc. into the pressure port. The diaphragm will get damaged and correct operation shall not be maintained.
Do not operate the keys with pointed or sharp objects.
Make sure that stress by forcible bend or pulling is not applied directly to the sensor cable joint.
Do not drop the product or otherwise subject to strong shock. Otherwise, the product may be damaged.
Do not apply an excessive load to the front surface or corners of the product. Otherwise, the product may be damaged.