

Panasonic INSTRUCTION MANUAL

Digital Laser Sensor Amplifier LS-400 Series


Thank you very much for purchasing Panasonic products. Please read this Instruction Manual carefully and thoroughly for the correct and optimum use of this product. Kindly keep this manual in a convenient place for quick reference.

WARNING

- Never use this product as a sensing device for personnel protection.
- In case of using sensing devices for personnel protection, use products which meet laws or standards, such as OSHA, ANSI or IEC etc., for personnel protection applicable in each region or country.
- Use of control or adjustment or performance of procedures other than those specified in this instruction manual may result in hazardous radiation exposure.

For details of the setting contents or setting procedure, refer to 'LS Series PRO mode operation guide' in 'Panasonic Industry Co., Ltd. website (https://industry.panasonic.com/)'.
 Select 1 indicator (Yellow) Select 2 indicator (Yellow) MODE indicator / TIMER (Yellow)
 Output 1 operation indicator (Orange) Output 2 operation indicator (Orange) MODE indicator / PRO (Yellow)
 Laser emission indicator (Green) MODE indicator / TEACH (Yellow) MODE indicator / L/D ON (Yellow)
 MODE indicator / PRO (Yellow) MODE indicator / TEACH (Yellow) MODE indicator / L/D ON (Yellow)
 Digital display (Green, Red) Jog switch Turn: Code selecting Pressdown: Confirmed

1 PART DESCRIPTION



2 MOUNTING

- ### How to mount the amplifier
- Fit the rear part of the mounting section of the amplifier on a DIN rail.
 - Press down the rear part of the mounting section of the unit on the DIN rail and fit the front part of the mounting section to the DIN rail.
-
- ### How to remove the amplifier
- Push the amplifier forward. (Note)
 - Lift up the front part of the amplifier to remove it.
-


- ### How to mount the sensor head
- Insert the sensor head connector into the inlet until it clicks.
 - Fit the cover to the connector.
-

- ### CASCADING CONNECTOR TYPE LS-401(P)
- For mounting and removing the amplifier, refer to '2 MOUNTING'.
 - Up to maximum 15 amplifiers can be added. (total 16 amplifiers connected in cascade.)
 - When this product is used with the digital fiber amplifier, be sure to place this product to the left most position. (When viewed from the connector side) In case this product is not placed to the leftmost position, this product may not operate properly.


- ### Cascading method
- Mount the amplifiers, one by one, on the 35mm width DIN rail.
 - Slide the amplifiers next to each other, and connect the quick-connection cables.
 - Mount the optional end plates (MS-DIN-E) at both ends to hold the amplifiers between their flat sides.
 - Tighten the screws to fix the end plates.
-

- ### Dismantling method
- Loosen the screws of the end plates
 - Remove the end plates.
 - Slide the amplifiers and remove them one by one.
-











4 I/O CIRCUIT DIAGRAM



- ### EXTERNAL INPUT [only for LS-401(P)-C2]
- When 'emission halt', 'limit teaching' or 'full-auto teaching' is set, the time chart is as follows.
-















- ### OPERATION PROCEDURE
- Be sure to set each item after selecting the output 1 or the output 2.
 - The items that can be set in the output 1 and the output 2 respectively are only 1. Threshold value, 2. Output operation, 3. Timer operation and Timer period, and 4. Detection mode. The items other than those are common. (However, in case of setting with the direct code, a combination of the output 1/2 can be set only for output operation. The items other than output operation are valid only for the output 1.)
 - System of basic operation
The amplifier LS-400 series features and settings are generally classified into two main modes; the 'NAVI' mode for items and settings that are frequently re-configured, and the 'PRO' mode that contains more detailed settings.















10 TEACHING MODE

When teaching in Window comparator mode or Hysteresis mode, a setting has to be made in PRO6 beforehand. In case of 1-level teaching, a shift value (the initial value is 100 digit or 15%) has to be set as well. teaching.








11 PRO MODE











This is the method to set the shift value to the desired value and set the threshold range by using the single-point teaching.



PRO2 mode setting



PRO6 mode setting



15 SPECIFICATIONS

Type	Connector type	Cable type
Model No.	NPN Output LS-401	LS-401-C2
	PNP Output LS-401P	LS-401P-C2
Supply voltage	12 to 24V DC±10% Ripple P-P 10% or less	
Power consumption	Normal operation: 500mW or less (Current consumption 40mA or less at 24V supply voltage) ECO mode: 700mW or less (Current consumption 50mA or less at 24V supply voltage)	
Output (Output 1, Output 2)	<NPN output type> NPN open-collector transistor • Maximum sink current: 100mA (Note 1) • Applied voltage: 30V DC or less (between output and +V) • Residual voltage: 1.5V or less (at 100mA (Note 1) sink current)	<PNP output type> PNP open-collector transistor • Maximum source current: 100mA (Note 1) • Applied voltage: 30V DC or less (between output and +V) • Residual voltage: 1.5V or less (at 100mA (Note 1) source current)
Output operation	Light-ON or Dark-ON, selectable with jog switch	
Short-circuit protection	Incorporated	
External input (Note 2)	<NPN output type> NPN non-contact input • Signal condition High: +5 to +V DC or open Low: 0 to 2V DC (source current 0.5mA) • Input impedance: 10kΩ approx.	<PNP output type> PNP non-contact input • Signal condition High: +4 to +V DC or open Low: 0 to 0.6V DC, or open • Input impedance: 10kΩ approx.
Response time	H-SP: 80µs or less, FAST: 150µs or less, STD: 500µs or less, U-LG: 4ms or less, selectable with jog switch	
Digital display	4 digit (green) + 4 digit (red) LED display	
Normal mode	2-level teaching / Limit teaching / Full-auto teaching / Manual adjustment	
Window comparator mode	Teaching (1, 2, 3 level) / Manual adjustment	
Hysteresis mode	Teaching (1, 2, 3 level) / Manual adjustment	
Differential mode	Teaching (1, 2, 3 level) / Manual adjustment	
Fine sensitivity adjustment function	Incorporated	
Timer function	Incorporated with variable ON-delay/OFF-delay/ONE-SHOT setting, switchable either effective or ineffective (Timer period: 1 to 999.99ms approx.)	
Interference prevention function	Incorporated (Up to four sensor heads can be mounted adjacently (however, in H-SP mode, the interference prevention function cannot be operated.) (Note 3)	
Ambient temperature	-10 to +55°C (if 4 to 7 units are mounted closely, -10 to +50°C; no dew condensation or icing allowed), Storage: -20 to +70°C	
Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH	
Material	Enclosure: Heat-resistant ABS, Transparent cover: Polycarbonate, Mode key switch: Avic, Jog switch: ABS	
Weight	Approx. 155g	Approx. 65g

- Notes: 1) 50mA max. if 5 to 8 units are connected in cascade, and 25mA max. if 16 units are connected in cascade.
 2) External input is not incorporated with the connector type LS-401(P).
 3) After H-SP mode was changed to other mode, when the interference prevention function, the collective data bank load/save function or the copy function is used, turn the power supply on again.
 4) The cable is not supplied as an accessory for connector type LS-401(P). Be sure to use the optional quick-connection cables given below.
 Main cable (4-core) CN-74-C1 (cable length 1m), CN-74-C2 (cable length 2m), CN-74-C5 (cable length 5m)
 Sub cable (2-core) CN-72-C1 (cable length 1m), CN-72-C2 (cable length 2m), CN-72-C5 (cable length 2m)

16 CAUTIONS

- This product has been developed / produced for industrial use only.
- Make sure that the power supply is off while wiring.
- Verify that the supply voltage variation is within the rating.
- Take care that if a voltage exceeding the rated range is applied, or if an AC power supply is directly connected, the sensor may get burnt or damaged.
- In case noise generating equipment (switching regulator, inverter motor, etc.) is used in the vicinity of this product, connect the frame ground (F.G.) terminal of the equipment to an actual ground.
- The ultra long distance (U-LG) mode is more likely to be affected by extraneous noise since the sensitivity of that is higher than the other modes. Make sure to check the environment before use.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- Do not use during the initial transient time (0.5 sec.) after the power supply is switched on.
- Take care that short-circuit of the load or wrong wiring may burn or damage the sensor.
- Do not run the wires together with high-voltage lines or power lines or put them in the same raceway. This can cause malfunction due to induction.
- Make sure to use the optional quick-connection cable for the connector type LS-401(P).
- Extension up to total 100m is possible with 0.3mm² or more, cable. However, in order to reduce noise, make the wiring as short as possible.
- This sensor is suitable for indoor use only.
- Avoid dust, dirt, and steam.
- Take care that the product does not come in contact with water, oil, grease, or organic solvents, such as, thinner, etc.
- This sensor cannot be used in an environment containing inflammable or explosive gases.
- Never disassemble or modify the sensor.

18 ERROR DISPLAY

Display	Description of error	Action
E-1	Overcurrent has been applied due to short-circuited load.	Turn off the power supply and check the load.
E-4	Disconnection error of sensor head	Check the connection of sensor head.
E-5	Transmission error during connection.	Verify that there is no loose or clearance between amplifiers.

14 OPTICAL COMMUNICATION

